

Crane Safety

MACDOW

May 2010

M^cCONNELL
DOWELL
CREATIVE CONSTRUCTION™

Learning's


MACDOW

- Site Setup
- Chain & Sling condition and checking
- Lifting and Slinging
- Crane movement
- Accidents
- Signalling
- MCD Requirements

- Crane Operators and Signaller should thoroughly inspect the working site prior to setting up.
 - Things to look for:
 - Overhead power lines
 - Even stable ground
 - Vehicle movements
 - No excavations close by
 - Outriggers on even packing / plates
 - Loads should not be lifted over:
 - Pedestrians and mobile equipment;
 - Office buildings, or structures where persons are likely to be present;
 - Dangerous materials such as chemical storage areas; or
 - Obstructions where the load could become caught.
 - Powerlines

Power Lines

MACDOW







Look at Ground Conditions

MACDOW



Outriggers need to be on even packing

MACDOW



Poor Ground Conditions

MACDOW



Chain and Wire Rope Condition

MACDOW

- Before use chains they must be checked for the following:
- Safe Working Load (SWL)
- Tagged with test date
- Chains:
 - Stretched or cracked links, unauthorised welding
- Shackles:
 - Worn / damaged, must be marked with SWL and test date, bent pin or distorted bow

Steel Wire Rope

MACDOW

- Steel Wire Rope is constructed of wires and strands laid around a central core. In the illustration below there are 19 wires to the strand and 6 strands around the core making up the rope.



INSPECTION

- It is important to check all wire ropes for wear and damage before use. Wire rope can deteriorate due to several factors:
 - Abrasion
 - Fatigue
 - Corrosion
 - Stretching (from overloading and shock loading)
 - mechanical damage.
- When inspecting:
 - Observe the construction and lay of the rope. Check for signs of stretching
 - Check the whole rope for broken wires - The total number of broken wires must not exceed 10% of the total wires.
 - Bird-caging, kinking, core collapse, corrosion or excessive number of broken wires

Steel Wire Rope


MACDOW

Discard SWR rope if there is:

- A single broken wire below a metal socket, end fitting or a machine splice.
- Abrasion and core collapse.
- Corrosion. Red oxide powder and loose and springy wires can indicate serious corrosion.
- Kinks, knots or fractures from bending or kinking.
- Crushed or jammed strands.
- Bird-caging. It can be caused by rotation of the end of a rope or a shock from a sudden release from loading.

Steel Wire Rope


MACDOW



Birdcaging




Mechanical wear



Kinking

Sheave wear- This can damage wire rope.



SAFE USE AND MAINTENANCE

- A chain sling is only as strong as its weakest link
- When using chains or slings, always check the SWL and that they are in a good condition.
- Do not lift a load heavier than the SWL of the chain.
- Do not use a chain in which the links are stretched, frozen or do not move freely.
- Do not twist, kink or knot chain.
- Do not drop a chain from a height.
- Do not roll loads over a chain.
- Do not use a chain with a link that is cracked, or that has been spot welded other than by the manufacturer.
- Use protective padding when using chain around sharp corners.
- Do not tow anything with lifting equipment

Chains

MACDOW



INSPECTION

- Inspect your chains and slings regularly.
- Ensure the monthly colour coding is correct.
- Links that are frozen together show that the chain has been stretched.
- Inspect connection points, pins, latches and hooks for signs for any signs of distortion.
- If any damage or wear the chain must be tagged and taken out of service.

Shackles

MACDOW



Bow Shackle

Shackles

MACDOW



D Shackle

Hook and Latch

MACDOW



Hook and Latch

Shackles

MACDOW

- Do not use a shackle that does not have the SWL marked.
- Do not use a bolt and nut in place of the proper shackle pin.
- Do not use a shackle that is bent, deformed or damaged.
- Secure the shackle. Prevent jamming by tightening the shackle pin finger tight and then release it by a quarter turn.
- Do not throw shackles on the ground as this causes damage and the dirt seizes the thread

Synthetic Slings

MACDOW



▲ Safe work load is clearly marked.

Synthetic Slings

MACDOW

LOOK FOR:

- Any external wear such as rips, cuts and tears.
- Internal damage is indicated by a thickening of the sling or the presence of grit and dirt
- Damage to protective coating of the sling.
- Damage caused by high temperatures, sunlight or chemicals , oils (which is indicated by discolouration).
- Damage to the label or stitching.
- Damage to the eyes.
- Annual test date.

Synthetic Slings



DISCARD A SYNTHETIC SLING IF:

- The label has been removed or destroyed.
- There is any damage to the sleeve or protective coating.
- A sling comes into contact with acid.
- A polypropylene sling comes into contact with an organic solvent such as, paint, coal tar or paint stripper.
- There are any visible cuts on the sling.

Storage and care of lifting equipment

MACDOW

Lifting equipment must be stored:

- In a clean, dry, well ventilated place
- Off the ground or floor
- Away from direct sunlight
- Away from extreme heat.
- Away from people welding cutting
- Not stored in same location as chemicals such as paint and solvents

NEVER

- Wrap a tagline around your hand or body
- Leave a suspended load unattended
- Pass loads over people
- Use lifting accessories for towing or pulling
- Ride or climb on machines or suspended loads
- Lift near power lines
- Stand or walk underneath a suspended load – Golden Rule # 2

The Rigger / Signaller is responsible for :


- Attaching and detaching the load to and from the crane
- The use of correct lifting accessories
- Directing the safe movement of the crane and load
- Must be easily identifiable by all personnel – Red Helmet and vest with Rigger / Signaller on back
- Ensure lifting zone is established and maintained and barricaded where needed

Crane Movement

MACDOW



**Keep clear of the swing radius of the crane –
Make sure there are barriers to prevent persons entering the
swing radius**



Don't stand under a suspended load
Golden Rule # 2

Things that can go wrong

MACDOW



Things that can go wrong

MACDOW



Inadequate maintenance or inspection

MACDOW



Never Ride the Hook

MACDOW



Crane signals

MACDOW



STOP


Crane signals

MACDOW

Wire up

Or

Up on the hook



Crane signals

MACDOW



Down hook

Crane signals

MACDOW


Jib up



Crane signals


MACDOW

Jib down



Crane signals

MACDOW



Boom out

Crane signals


MACDOW

Boom in



Crane signals


MACDOW



Use main hook

Crane signals

MACDOW




**Use auxiliary
hook**

Crane signals

MACDOW


Jib up

Hook down



Crane signals

MACDOW



Jib down

Hook up

MCD Requirements



- Lifting and Slinging K012-020[SIN].
- Operating Cranes K015-020[SIN].
- Lift Plans are required for all lifts over 75% of crane capacity or when a 2 crane lift is required or when working near high voltage equipment.
- Approved Lifting Permit – (valid for one shift only).
- Lifting crew must be appointed to position and certified competent, hold the relevant Singapore qualification (ticket).
- Must be easily recognised by coloured helmet, fluoro vest with position name on the back of the vest i.e. Lifting Supervisor, Rigger / Signaller or Banksman.