WATER QUALITY

CONTINUING EDUCATION PROFESSIONAL DEVELOPMENT COURSE

16 PDHs, 16 Training Hours or 1.5 CEU upon completion





Printing and Saving Instructions

The best thing to do is to download this pdf document to your computer desktop and open it with Adobe Acrobat reader.

Abode Acrobat reader is a free computer software program and you can find it at Abode Acrobat's website.

You can complete the course by viewing the course materials on your computer or you can print it out. We give you permission to print this document.

Printing Instructions: If you are going to print this document, this document is designed to be printed double-sided or duplexed but can be single-sided.

This course booklet does not have the assignment. Please visit our website and download the assignment also.

Internet Link to Assignment... http://www.abctlc.com/PDF/WATER%20QUALITY%20ASSIGNMENT.pdf

State Approval Listing Link, check to see if your State accepts or has preapproved this course. Not all States are listed. Not all courses are listed. If the course is not accepted for CEU credit, we will give you the course free if you ask your State to accept it for credit.

Professional Engineers; Most states will accept our courses for credit but we do not officially list the States or Agencies acceptance or approvals.

State Approval Listing URL... http://www.tlch2o.com/PDF/CEU%20State%20Approvals.pdf

You can obtain a printed version from TLC for an additional \$79.95 plus shipping charges.

Copyright Notice

©2006 Technical Learning College (TLC). No part of this work may be reproduced or distributed in any form or by any means without TLC's prior written approval. Permission has been sought for all images and text where we believe copyright exists and where the copyright holder is traceable and contactable. All material not credited or acknowledged is the copyright of TLC. The information in this manual is intended for educational purposes only. Most unaccredited photographs have been taken by TLC instructors or TLC students. We would be pleased to hear from any copyright holder and will make good on your work if any unintentional copyright infringements were made upon these issues being brought to our attention.

Every possible effort is made to ensure all information provided in this course is accurate. All written, graphic, photographic or other material is provided for information only. Therefore, TLC accepts no responsibility or liability whatsoever for the application or misuse of any information included herein. Requests for permission to make copies should be made to the following address:

TLC P.O. Box 420

Payson, AZ 85547-0420

Information in this document is subject to change without notice. TLC is not liable for errors or omissions appearing in this document.

Library of Congress Card Number 6582264 ISBN 978-0-9799559-3-8

Contributing Editors

Joseph Camerata has a BS in Management with honors (magna cum laude). He retired as a Chemist in 2006 having worked in the field of chemical, environmental, and industrial hygiene sampling and analysis for 40 years.

Eric Pearce S.M.E., chemistry and biological review.

Pete Greer S.M.E., retired biology instructor.

Jack White, Environmental, Health, Safety expert, City of Phoenix. Art Credits.



Jerry Durbin, Course Proctor, known affectionately to many as Little Jerry.

CEU Course Description

WATER QUALITY CEU TRAINING COURSE

This CEU course is a review of Environmental Protection Agency's Rules and Regulation related to water quality and water sampling. This course will cover water quality fundamentals and basic requirements of the federal rule which concerning water sampling and general laboratory operations. This course will also cover water sampling techniques, waterborne disease identification, general water quality operations and definitions; disease symptoms, disease diagnosis, history, susceptibility, and disease sources of contamination. This course will apply to all categories of water treatment/distribution. As water professionals, it is your responsibility to identify, stop and control all waterborne diseases, and provide drinking water that meets minimum drinking water standards.

Attention Water Distribution, Well Drillers, Pump Installers, and Water Treatment Operators. The target audience for this course is the person interested in working in a water treatment or distribution facility and wishing to maintain CEUs for certification license, meet education needs for promotion, or to learn how to do the job more safely and effectively.

Water systems monitor for a wide variety of contaminants to verify that the water they provide to the public meets all federal and state standards. Currently, the nation's community water systems (CWSs) and nontransient non-community water systems (NTNCWSs) must monitor for more than 83 contaminants. The major classes of contaminants include volatile organic compounds (VOCs), synthetic organic compounds (SOCs), inorganic compounds (IOCs), radionuclides, and microbial organisms (including bacteria). Testing for these contaminants takes place on varying schedules and at different locations throughout the water system.



Transient non-community water systems may monitor less frequently and for fewer contaminants than CWSs. Because these types of systems serve an ever-changing population, it is most important for them to monitor for contaminants such as microbiologicals and nitrate that can cause an immediate, acute public health effect. Water systems also monitor for a number of contaminants that are currently not regulated. This monitoring data provides the basis for identifying contaminants to be regulated in the future.

Prerequisites: None

Final Examination for Credit

Opportunity to pass the final comprehensive examination is limited to three attempts per course enrollment.

Course Procedures for Registration and Support

All of Technical Learning College's (TLC) correspondence courses have complete registration and support services offered. Delivery of services will include, e-mail, web site, telephone, fax and mail support. TLC will attempt immediate and prompt service. When students register for a distance or correspondence course, they'll be assigned a start date and an ending date.

It is the student's responsibility to note dates for assignments and keep up with the course work. If a student falls behind, he/she must contact TLC and request an ending date extension in order to complete the course. It is the prerogative of TLC to decide whether to grant the request. All students will be tracked by their social security number or a unique number.

Instructions for Written Assignments

The Water Quality CEU training course uses a multiple-choice answer key.

Feedback Mechanism (examination procedures)

Each student will receive a feedback form as part of his or her study packet. You will be able to find this form in the rear of the course or lesson.

Security and Integrity

All students are required to do their own work. All lesson sheets and final exams are not returned to the student to discourage sharing of answers. Any fraud or deceit will result in forfeiture of all fees, and the appropriate agency will be notified.

Grading Criteria

TLC will offer the student either pass/fail or a standard letter grading assignment. If TLC is not notified, you will only receive a pass/fail notice.

Required Texts

The Water Quality CEU training course comes complete with a short summary of the EPA's Rules and Regulations and drinking water standards. If you need more information or a complete set of Rules, you can download them off the EPA's web page, www.epa.gov or contact your local state environmental agency. You may need to contact a laboratory or state agency for certain sampling information.

Recordkeeping and Reporting Practices

TLC will keep all student records for a minimum of seven years. It is the student's responsibility to give the completion certificate to the appropriate agencies. TLC will not release any records to any party, except to the student self or the state agency. We will send the required information to Texas, Indiana, New York and Pennsylvania for your certificate renewals.

ADA Compliance

TLC will make reasonable accommodations for persons with documented disabilities. Students should notify TLC and their instructors of any special needs. Course content may vary from this outline to meet the needs of this particular group.

Mission Statement

Our only product is educational service. Our goal is to provide you with the best possible education service possible. TLC will attempt to make your learning experience an enjoyable opportunity.

Educational Mission The educational mission of TLC is:


To provide TLC students with comprehensive and ongoing training in the theory and skills needed for the environmental education field.

To provide TLC students with opportunities to apply and understand the theory and skills needed for operator certification,

To provide opportunities for TLC students to learn and practice environmental educational skills with members of the community for the purpose of sharing diverse perspectives and experience,

To provide a forum in which students can exchange experiences and ideas related to environmental education,

To provide a forum for the collection and dissemination of current information related to environmental education, and to maintain an environment that nurtures academic and personal growth.





LOUIS PASTEUR


During the last half of the 19th century, several key discoveries were made that set the stage for the discovery of viruses. Pasteur is usually credited for dispelling the notion of spontaneous generation and proving that organisms reproduce new organisms. The German scientist Robert Koch, a student of Jacob Henle and the British surgeon Joseph Lister developed techniques for growing cultures of single organisms that allowed the assignment of specific bacteria to specific diseases.


Table of Contents


Introduction	11
Key Words	15
New EPA Rules	19
Microbes	22
Radionuclides	23
Inorganic Contaminants	24
Volatile Organic Contaminants	24

Primary Drinking Water Requirements 27 Secondary Drinking Water Regulations 33

occommany brinking water	ivege
Waterborne Diseases	59
Bacteria	65
Eukaryotes	73
Viruses	77
Protozoa	83
Giardia	101
Cryptosporidiosis	111
Cholera	123
Legionella	135
E. Coli	145
Groundwater	165
Source Water Quality	169
Jar Test	189
Chlorine	205
Alternate Disinfectants	235
Water Storage	265
Hard Water	269
Membrane Filtration	275
Common Chemical	291
Math Camuanalana	207







Common Disinfectant Information

Contaminant	MRDL ¹ (mg/L) ²	MRDL ¹ (mg/L) ²	Potential Health Effects from Ingestion of Water	Sources of Contaminant in Drinking Water
Chloramines (as Cl ₂)	MRDLG=4 ¹	MRDL=4.0 ¹	Eye/nose irritation; stomach discomfort, anemia	Water additive used to control microbes
Chlorine (as Cl ₂)	MRDLG=4 ¹	MRDL=4.0 ¹	Eye/nose irritation; stomach discomfort	Water additive used to control microbes
Chlorine dioxide (as CIO ₂)	MRDLG=0.8 ¹	MRDL=0.8 ¹	Anemia; infants & young children: nervous system effects	Water additive used to control microbes

Water Quality Introduction

Water is basic to life and health. Over 1 billion people worldwide have no access to safe drinking water. The United States is fortunate to have one of the best supplies of drinking water in the world. Although tap water that meets federal and state standards is generally safe to drink, threats to drinking water quality in the United States still exist. Outbreaks of drinking water-associated illness and water restrictions during droughts demonstrate that we cannot take our drinking water for granted.

We are blessed to have plentiful supplies of good drinking water sources. Water-related illnesses – typhoid fever, cholera, dysentery – are almost unknown in this country today. Waste and wastewater treatment, the development and enforcement of drinking water guidelines, public health practices and education – all have resulted in a decrease in water related illnesses. Developing nations are less fortunate: 80% of their diseases are water-related.

The price we must pay to prevent water-borne disease is constant vigilance against bacterial contamination. Periodic beach closures and local epidemics are evidence that the battle is never won. These problems underscore the need for maintaining strict control over water quality and for improving water and wastewater treatment.

A major concern today is toxic chemicals that enter our waters from many different sources, including industry, agriculture and the home. Little is known about the effects of these toxic substances on human health; often the effects do not become noticeable for long periods of time, and it is difficult to distinguish them from the effects of other factors that impact on our day-to-day life (e.g., nutrition, stress, air quality). Much more remains to be done to control toxic chemical pollution. Meanwhile, we can all contribute to the prevention of water pollution by not abusing the water or the land.

Municipalities throughout the US - from the largest cities to the smallest towns - sometimes fail to meet EPA standards. The EPA may fine the jurisdiction responsible for the violation, but this does not always motivate the municipality to take corrective action. In such cases, non-compliance with SEPA may continue for many months or years after the initial violation. This could result from the fact that the city simply doesn't have the financial resources necessary to replace aging water pipes or upgrade their purification equipment.

In rare cases, the source water used by the municipality could be so polluted that water purification processes can't do an adequate job. This can occur when a town is downstream from a large sewage treatment plant or large-scale agricultural operations. Citizens who live in such places - especially young children, the elderly, or people of any age with autoimmune deficiencies - may suffer serious health complications as a long-term result of drinking water from their own taps.



Common Water Quality Definitions

Units of Measurement

mg/l = Milligrams per liter. One milligram per liter equals one packet of artificial sweetener sprinkled into 250 gallons of iced tea.

 $\mu g/I$ = Micrograms per liter. One microgram per liter is equal to one packet of artificial sweetener sprinkled into an Olympic-size swimming pool.

NTU = Nephelometric Turbidity Units. A measurement on the cloudiness of the water.

pCi/I = Picocuries per liter. A measure of radioactivity.

Acronyms

Maximum Contaminant Level (MCL) - The highest level of a contaminant that is allowed in drinking water.

Maximum Contaminant Level Goal (MCLG) - The level of a contaminant in drinking water below which there is no known or expected risk to health.

Treatment Technique (TT) - A required process intended to reduce the level of a contaminant in drinking water.

Action Level (AL) - The concentration of a contaminant that, if exceeded, triggers treatment or other requirements which a water system must follow.

Timeline of Existing Federal Water and State Drinking Water Quality Regulations



National Interim Primary Drinking Water Regulations (NIPDWR) Promulgated 1975-1981 Contained 7 contaminants Targeted: Trihalomethanes, Arsenic, and Radionuclides Established 22 drinking water standards.

Phase 1 Standards Promulgated 1987 Contained 8 contaminants Targeted: VOCs.

Phase 2 Standards Promulgated 1991 Contained 36 contaminants Targeted: VOCs, SOCs, and IOCs.

Phase 5 Standards Promulgated 1992 Contained 23 contaminants Targeted: VOCs, SOCs, and IOCs.

Surface Water Treatment Rule (SWTR) Promulgated 1989 Contained 5 contaminants Targeted: Microbiological and Turbidity.

Stage 1 Disinfectant/Disinfection By-product (D/DBP) Rule Promulgated 1998 Contained 14 contaminants Targeted: DBPs and precursors.

Interim Enhanced Surface Water Treatment Rule (IESWTR) Promulgated 1998 Contained 2 contaminants Targeted: Microbiological and Turbidity.

Radionuclide Rule Promulgated 2000 Contained 4 contaminants Targeted: Radionuclides.

Arsenic Rule Promulgated 2001 Contained 1 contaminant Targeted: Arsenic.

Filter Backwash Recycling Rule Promulgated 2001 Contained - Targeted: Microbiological and Turbidity.



News

Studies have shown that pharmaceuticals are present in some of our nation's waterbodies. Further research suggests that there may be some ecological harm when certain drugs are present. To date, no evidence has been found of human health effects from pharmaceutical and personal care products in the environment. This includes drinking water sources.

Chapter Key Words

2,4-D: A chlorinated phenoxy compound, functions as a systemic herbicide and is used to control many types of broadleaf weeds. There are many forms or derivatives (esters, amines, salts) of 2,4-D and these vary in solubility and volatility. Unless otherwise specified, this document will refer to the acid form of 2,4-D. This compound is used in cultivated agriculture and in pasture and rangeland applications, forest management, home and garden situations and for the control of aquatic vegetation. 2,4-D was a major component (about 50%) of the product Agent Orange used extensively throughout Vietnam. However most of the problems associated with the use of Agent Orange were associated with a contaminant (dioxin) in the 2,4,5-T component of the defoliant. The association of 2,4-D with Agent Orange has prompted a vast amount of study on the herbicide

ANTIMONY: A chemical element with the symbol Sb (Latin: stibium, meaning "mark") and atomic number 51. A metalloid, antimony has four allotropic forms. The stable form of antimony is a blue-white metalloid. Yellow and black antimony are unstable non-metals. Antimony is used in flame-proofing, paints, ceramics, enamels, a wide variety of alloys, electronics, and rubber.

ASBESTOS: A mineral fiber that has been used commonly in a variety of building construction materials for insulation and as a fire-retardant. EPA and CPSC have banned several asbestos products. Manufacturers have also voluntarily limited uses of asbestos. Today, asbestos is most commonly found in older homes, in pipe and furnace insulation materials, asbestos shingles, millboard, textured paints and other coating materials, and floor tiles.

BARIUM: A chemical element. It has the symbol Ba, and atomic number 56. Barium is a soft silvery metallic alkaline earth metal. It is never found in nature in its pure form due to its reactivity with air. Its oxide is historically known as baryta but it reacts with water and carbon dioxide and is not found as a mineral. The most common naturally occurring minerals are the very insoluble barium sulfate, BaSO4 (barite), and barium carbonate, BaCO₃ (witherite). Benitoite is a rare gem containing barium.

BERYLLIUM: A chemical element with the symbol Be and atomic number 4. A bivalent element, beryllium is a steel grey, strong, light-weight yet brittle alkaline earth metal. It is primarily used as a hardening agent in alloys, most notably beryllium copper. Commercial use of beryllium metal presents technical challenges due to the toxicity (especially by inhalation) of beryllium-containing dusts.

BROMATE: An inorganic anion, bromate is tasteless and colourless, with a low volatility. As a moderately strong oxidant, bromate is reactive. BrO₃- is a bromine-based oxoanion. A bromate is a chemical compound that contains this ion. Examples of bromates include sodium bromate, (NaBrO₃), and potassium bromate, (KBrO₃).

CADMIUM: A chemical element with the symbol Cd and atomic number 48. A relatively abundant, soft, bluish-white, transition metal, cadmium is known to cause cancer and occurs with zinc ores. Cadmium is used largely in batteries and pigments, for example in plastic products.

CHLORITE: The chlorite ion is CIO_2 -. A chlorite (compound) is a compound that contains this group, with chlorine in oxidation state +3. Chlorites are also known as salts of chlorous acid.

CHROMIUM: A chemical element which has the symbol Cr and atomic number 24. It is a steel-gray, lustrous, hard metal that takes a high polish and has a high melting point. It is also odorless, tasteless, and malleable.

CONFINED AQUIFER: A water-bearing stratum that is confined or overlain by a rock layer that does not transmit water in any appreciable amount or that is impermeable.

CONTACT TIME (CT): To inactivate viruses and bacteria, the minimum disinfection contact time measured before the first customer should be six milligrams per minute per liter (6 mg-min/L). This value is called "Chlorine Contact Time" or CT. To calculate CT, multiply the free chlorine residual concentration (C) times the contact time (T). To get the required CT value of 6, adjust the free chlorine residual concentration or the contact time.

DISINFECTION BYPRODUCTS: Disinfection byproducts are chemical, organic and inorganic substances that can form during a reaction of a disinfectant with naturally present organic matter in the water.

DPD METHOD: Presence of free chlorine in the distribution network is indication of correct disinfection. Chlorine in water is determined according to ISO 7393-2 by colorimetric HACH method on the basis of DPD (N, N-diethyl - p – phenylendiamine). The photometric detection uses the wave lengths of 490 - 555 nm. Hach elected, for most of his DPD colorimetric systems, the wave length of 530 nm.

FORMAZIN TURBIDITY UNIT (FTU): A unit used to measure the clarity of water. The ISO refers to the units as FNU (Formazin Nephelometric Units). The technique is the same as that for the NTU, but the calibration uses microspheres of the polymer formazin.

HALOACETIC ACIDS: Haloacetic acids are carboxylic acids in which a halogen atom takes the place of a hydrogen atom in acetic acid. Thus, in a monohaloacetic acid, a single halogen would replace a hydrogen atom. For example, chloroacetic acid would have the structural formula CH₂CICO₂H. In the same manner, in dichloroacetic acid two chlorine atoms would take the place of two hydrogen atoms (CHCl₂CO₂H).

HIGH-TEST HYPOCHLORITE: A composition composed mainly of calcium hypochlorite is commonly called high test hypochlorite. High-Test Hypochlorite contains not less than 60.0% of available chlorine.

HYDROCHLORIC ACID: It is the aqueous solution of hydrogen chloride gas (**HCI**). It is a strong acid, and the major component of gastric acid, and of wide industrial use. Hydrochloric acid must be handled with appropriate safety precautions because it is a highly corrosive liquid.

INFORMATION COLLECTION RULE (ICR): EPA collected data required by the Information Collection Rule (May 14, 1996) to support future regulation of microbial contaminants, disinfectants, and disinfection byproducts. The rule was intended to provide EPA with information on chemical byproducts that form when disinfectants used for microbial control react with chemicals already present in source water (disinfection byproducts (**DBPs**)); disease-causing microorganisms (pathogens), including Cryptosporidium; and engineering data to control these contaminants.

IRON BACTERIA: In the management of water-supply wells, iron bacteria are bacteria that derive the energy they need to live and multiply by oxidizing dissolved ferrous iron (or the less frequently available manganese and aluminium). The resulting ferric oxide is insoluble, and appears as brown gelatinous slime that will stain plumbing fixtures, and clothing or utensils washed with the water carrying it, and may contribute to internal corrosion of the pipes and fixtures the water flows through. They are known to grow and proliferate in waters containing as low as 0.1mg/l of iron. However, at least 0.3 ppm of dissolved oxygen is needed to carry out oxidation. The proliferation of iron bacteria, in some way, increases the chance of sulfur bacteria infestation.

LETHAL CONCENTRATION 50: Also referred to as LC50, a concentration of a pollutant or effluent at which 50 percent of the test organisms die; a common measure of acute toxicity.

MANGANESE (IV) OXIDE: The chemical compound MnO2, commonly called manganese dioxide. This blackish or brown solid occurs naturally as the mineral pyrolusite, which is the main ore of manganese. It is also present in manganese nodules. The principal use for MnO2 is for dry-cell batteries, such as the alkaline battery and the zinc-carbon battery. In 1976 this application accounted for 500,000 tonnes of pyrolusite.[1] MnO2 is also used for production of MnO4—. It is used extensively as an oxidising agent in organic synthesis, for example, for the oxidation of allylic alcohols.

MAXIMUM CONTAMINANT LEVEL (MCL): The maximum concentration of a chemical that is allowed in public drinking water systems.

MAXIMUM CONTAMINANT LEVEL GOAL (MCLG): The maximum level at which a contaminant can exist in drinking water without having an adverse effect on human health.

NEPHELOMETRIC TURBIDITY UNIT (NTU): The unit used to describe turbidity. Nephelometric refers to the way the instrument, a nephelometer, measures how much light is scattered by suspended particles in the water. The greater the scattering, the higher the turbidity. Therefore, low NTU values indicate high water clarity, while high NTU values indicate low water clarity.

PERMISSIBLE EXPOSURE LIMIT (PEL or OSHA PEL): A legal limit in the United States for exposure of an employee to a substance or physical agent. For substances it is usually expressed in parts per million (ppm), or sometimes in milligrams per cubic meter (mg/m³). Units of measure for physical agents such as noise are specific to the agent. Permissible Exposure Limits are established by the Occupational Safety and Health Administration (OSHA).

POWDERED ACTIVATED CARDON TREATMENT (PACT): A wastewater technology in which powdered activated carbon is added to an anaerobic or aerobic treatment system. The carbon in the biological treatment process acts as a "buffer" against the effects of toxic organics in the wastewater.

PPM: Abbreviation for parts per million.

QUICKLIME: A calcium oxide material produced by calcining limestone to liberate carbon dioxide, also called "calcined lime" or "pebble lime", commonly used for pH adjustment. Chemical formula is CaO.

RECOMMENDED EXPOSURE LIMIT (REL): An occupational exposure limit that has been recommended by the U.S. National Institute for Occupational Safety and Health to OSHA for adoption as a Permissible Exposure Limit. The REL is a level that NIOSH believes would be protective of worker safety and health over a working lifetime if used in combination with engineering and work practice controls, exposure and medical monitoring, posting and labeling of hazards, worker training and personal protective equipment. No REL has ever been adopted by OSHA, but they have been used as guides by some industry and advocacy organizations.

SCADA: A remote method of monitoring pumps and equipment. 130 degrees F is the maximum temperature that transmitting equipment is able to with stand. If the level controller may be set with too close a tolerance 45 could be the cause of a control system that is frequently turning a pump on and off.

TRANSIENT, NON-COMMUNITY WATER SYSTEM: TNCWS A water system which provides water in a place such as a gas station or campground where people do not remain for long periods of time. These systems do not have to test or treat their water for contaminants which pose long-term health risks because fewer than 25 people drink the water over a long period. They still must test their water for microbes and several chemicals. A Transient Non-community Water System: Is not required to sample for VOC's.

U.S. ENVIRONMENTAL PROTECTION AGENCY: In the United States, this agency responsible for setting drinking water standards and for ensuring their enforcement. This agency sets federal regulations which all state and local agencies must enforce.

VOLATILE ORGANIC COMPOUNDS (VOCs): Solvents used as degreasers or cleaning agents. Improper disposal of VOCs can lead to contamination of natural waters. VOCs tend to evaporate very easily. This characteristic gives VOCs very distinct chemical odors like gasoline, kerosene, lighter fluid, or dry cleaning fluid. Some VOCs are suspected cancer-causing agents. Volatile organic compounds (VOCs) are organic chemical compounds that have high enough vapor pressures under normal conditions to significantly vaporize and enter the atmosphere. A wide range of carbon-based molecules, such as aldehydes, ketones, and other light hydrocarbons are VOCs. The term often is used in a legal or regulatory context and in such cases the precise definition is a matter of law. These definitions can be contradictory and may contain "loopholes"; e.g. exceptions, exemptions, and exclusions. The United States Environmental Protection Agency defines a VOC as any organic compound that participates in a photoreaction; others believe this definition is very broad and vague as organics that are not volatile in the sense that they vaporize under normal conditions can be considered volatile by this EPA definition. The term may refer both to well characterized organic compounds and to mixtures of variable composition.

WATER HAMMER: A surge in a pipeline resulting from the rapid increase or decrease in water flow. Water hammer exerts tremendous force on a system and can be highly destructive.

WATERBORNE DISEASE: A disease, caused by a virus, bacterium, protozoan, or other microorganism, capable of being transmitted by water (e.g., typhoid fever, cholera, amoebic dysentery, gastroenteritis).

WHOLE EFFLUENT TOXICITY: The total toxic effect of an effluent measured directly with a toxicity test.

New EPA Water Rules

Arsenic

Arsenic is a chemical that occurs naturally in the earth's crust. When rocks, minerals and soil erode, they release arsenic into water supplies. When people either drink this water or eat animals and plants that drink it, they are exposed to arsenic. In the U.S., eating and drinking are the most common ways that people are exposed to arsenic, although it can also come from industrial sources. Studies have linked long-term exposure of arsenic in drinking water to a variety of cancers in humans.

To protect human health, an EPA standard limits the amount of arsenic in drinking water. In January 2001, the EPA revised the standard from 50 parts per billion (**ppb**), ordering that it fall to 10 ppb by 2006. After adopting ppb 10 as the new standard for arsenic in drinking water, the EPA decided to review the decision to ensure the final standard was based on sound science and accurate estimates of costs and benefits. In October 2001, the EPA decided to move forward with implementing the ppb 10 standard for arsenic in drinking water.

More information on the rulemaking process and the costs and benefits of setting the arsenic limit in drinking water at 10ppb can be found at www.epa.gov/safewater/arsenic.html.

ICR

The EPA has collected data required by the Information Collection Rule (ICR) to support future regulation of microbial contaminants, disinfectants and disinfection byproducts. The rule is intended to provide the EPA with information on chemical byproducts that form when disinfectants used for microbial control react with chemicals already present in source water (disinfection byproducts (DBPs)); disease-causing microorganisms (pathogens), including Cryptosporidium; and engineering data to control these contaminants. Drinking water microbial and disinfection byproduct information collected for the ICR is now available in the EPA's Envirofacts Warehouse.



Disinfection Byproduct Regulations

In December 1998, the EPA established the Stage 1 Disinfectants/Disinfection Byproducts Rule requiring public water systems to use treatment measures to reduce the formation of disinfection byproducts and to meet the following specific standards:

Total trihalomethanes (TTHM)80 ppbHaloacetic acids (HAA5)60 ppbBromate10 ppb

Chlorite 1.0 parts per million

(ppm)

Currently trihalomethanes are regulated at a maximum allowable annual average level of 100 ppb for water systems serving more than 10,000 people under the Total Trihalomethane Rule finalized by the EPA in 1979. The Stage 1 Disinfectant/Disinfection Byproduct Rule standards became effective for trihalomethanes and other disinfection byproducts listed above in December 2001 for large surface water public water systems. Those standards became effective in December 2003 for small surface water and all ground water public water systems.

Disinfection byproducts are formed when disinfectants used in water treatment plants react with bromide and/or natural organic matter (i.e., decaying vegetation) present in the source water. Different disinfectants produce different types or amounts of disinfection byproducts. Disinfection byproducts for which regulations have been established have been identified in drinking water, including trihalomethanes, haloacetic acids, bromate and chlorite.

Trihalomethanes (**THM**) are a group of four chemicals that are formed along with other disinfection byproducts when chlorine or other disinfectants used to control microbial contaminants in drinking water react with naturally occurring organic and inorganic matter in water. The trihalomethanes are chloroform, bromodichloromethane, dibromochloromethane, and bromoform. The EPA has published the **Stage 1 Disinfectants/Disinfection Byproducts Rule** to regulate total trihalomethanes (TTHM) at a maximum allowable annual average level of **80 ppb**. This standard replaced the older standard of a maximum allowable annual average level of 100 ppb back in December 2001 for large surface water **public water systems**. The new standard became effective for the first time in December 2003 for small surface water and all ground water systems.

Haloacetic Acids (HAA5) are a group of chemicals that are formed along with other disinfection byproducts when chlorine or other disinfectants used to control microbial contaminants in drinking water react with naturally occurring organic and inorganic matter in water. The regulated haloacetic acids, known as HAA5, are monochloroacetic acid, dichloroacetic acid, trichloroacetic acid, monobromoacetic acid and dibromoacetic acid. The EPA has published the Stage 1 Disinfectants/Disinfection Byproducts Rule to regulate HAA5 at 60 ppb annual average.

This new standard became effective for large surface water **public water systems** in December 2001 and for small surface water and all ground water public water systems back in December 2003.

Bromate is a chemical that is formed when ozone used to disinfect drinking water, reacts with naturally occurring bromide found in source water. The EPA has established the **Stage 1 Disinfectants/Disinfection Byproducts Rule** to regulate bromate at an annual average of **10 ppb** in drinking water.

This standard became effective for large **public water systems** by December 2001 and for small surface water and all ground public water systems in December 2003.

Chlorite is a byproduct formed when chlorine dioxide is used to disinfect water. The EPA has published the **Stage 1 Disinfectants/Disinfection Byproducts Rule** to regulate chlorite at a monthly average level of **1 ppm** in drinking water. This standard became effective for large surface water public water systems in December 2001 and for small surface water and all ground water public water systems in December 2003.

Microbial Regulations

One of the key regulations developed and implemented by the United States Environmental Protection Agency (USEPA) to counter pathogens in drinking water is the **Surface Water Treatment Rule**. Among its provisions, the rule requires that a public water system, using surface water (or ground water under the direct influence of surface water) as its source, have sufficient treatment to reduce the source water concentration of *Giardia* and viruses by at least 99.9% and 99.99%, respectively. The Surface Water Treatment Rule specifies treatment criteria to assure that these performance requirements are met; they include turbidity limits, disinfectant residual and disinfectant contact time conditions.

The Interim Enhanced Surface Water Treatment Rule was established in December 1998 to control *Cryptosporidium*, and to maintain control of pathogens while systems lower disinfection byproduct levels to comply with the **Stage 1 Disinfectants/Disinfection Byproducts Rule**. The EPA established a Maximum Contaminant Level Goal (MCLG) of zero for all public water systems and a 99 percent removal requirement for Cryptosporidium in filtered public water systems that serve at least 10,000 people. The new rule had tightened turbidity standards by December 2001. Turbidity is an indicator of the physical removal of particulates, including pathogens.

The EPA is also planning to develop other rules to further control pathogens. The EPA has promulgated a Long Term 1 Enhanced Surface Water Treatment Rule for systems serving fewer than 10,000 people. This is to improve physical removal of *Cryptosporidium* and to maintain control of pathogens while systems comply with **Stage 1 Disinfectants/Disinfection Byproducts Rule**.



Microbes

Coliform bacteria are common in the environment and are generally not harmful. However, the presence of these bacteria in drinking water are usually a result of a problem with the treatment system or the pipes which distribute water and indicates the water may be contaminated with germs which can cause disease.

Fecal Coliform and E coli are bacteria whose presence indicates that water may be contaminated with human or animal wastes. Microbes in these wastes can cause short-term effects such as diarrhea, cramps, nausea, headaches or other symptoms.

Cryptosporidium is a parasite which enters lakes and rivers through sewage and animal waste. It causes cryptosporidiosis, a mild gastrointestinal disease. However, the disease can be severe or fatal for people with severely weakened immune systems. The EPA and CDC have prepared advice for those with severely compromised immune systems who are concerned about *Cryptosporidium*.

Giardia lamblia is a parasite which enters lakes and rivers through sewage and animal waste. It causes gastrointestinal illness (i.e. diarrhea, vomiting and cramps).



Heterotrophic Plate Count Bacteria (HPC): A broad group of bacteria including nonpathogens, pathogens, and opportunistic pathogens; they may be an indicator of poor general biological quality of drinking water. Often referred to as HPC. The above photo is of a SimPlate for HPC multi-dose used for the quantification of HPC in water.

Radionuclides

Alpha emitters. Certain minerals are radioactive and may emit a form of radiation known as alpha radiation. Some people who drink water containing alpha emitters in excess of the EPA standards for many years may have an increased risk of developing cancer.

Beta/photon emitters. Certain minerals are radioactive and may emit forms of radiation known as photons and beta radiation. Some people who drink water containing beta and photon emitters in excess of the EPA standards for many years may have an increased risk of developing cancer.

Combined Radium 226/228. Some people who drink water containing radium 226 or 228 in excess of the EPA standards for many years may have an increased risk of developing cancer.

Radon gas can dissolve and accumulate in underground water sources such as wells or in the air in your home. Breathing radon can cause lung cancer. Drinking water containing radon presents a risk of developing cancer. Radon in air is more dangerous than radon in water.



Gas Chromatograph (GC)
Separates vaporized sample into individual components.

Operation

A sample is placed into a heated injection port. As the organics are driven off by heating, a carrier gas transports them through a separation column and into a Flame Ionization Detector (**FID**) where individual components are identified.

Inorganic Contaminants (IOC)

Antimony Cadmium Cyanide Nitrite
Asbestos Chromium Mercury Selenium
Barium Copper Nitrate Thallium

Beryllium

Inorganic Contaminants

Arsenic. Some people who drink water containing arsenic in excess of the EPA's standard for many years could experience skin damage or problems with their circulatory system, and may have an increased risk of developing cancer.

Fluoride. Many communities add fluoride to their drinking water to promote dental health. Each community makes its own decision about whether or not to add fluoride. The EPA has set an enforceable drinking water standard for fluoride of 4 mg/L (some people who drink water containing fluoride in excess of this level over many years could develop bone disease, including pain and tenderness of the bones). The EPA has also set a secondary fluoride standard of 2 mg/L to protect against dental fluorosis.



Dental fluorosis, in its moderate or severe forms, may result in a brown staining and/or pitting of the permanent teeth. This problem occurs only in developing teeth, before they erupt from the gums. Children under the age of nine should not drink water that has more than 2 mg/L of fluoride.

Lead typically leaches into water from plumbing in older buildings. Lead pipes and plumbing fittings have been banned since August 1998. Children and pregnant women are most susceptible to lead health risks. For advice on avoiding lead poisoning, see the EPA's lead in vour drinking water fact sheet.

Synthetic Organic Contaminants, including pesticides & herbicides

2,4-D Dibromochloropropane Hexachlorobenzene

2,4,5-TP (Silvex) Dinoseb Hexachlorocyclopentadiene

Acrylamide Dioxin (2,3,7,8-TCDD) Lindane Alachlor Diquat Methoxychlor Atrazine Endothall Oxamyl [Vydate]

Benzoapyrene Endrin PCBs [Polychlorinated biphenyls]

Carbofuran Epichlorohydrin Pentachlorophenol

Chlordane Ethylene dibromide Picloram
Dalapon Glyphosate Simazine
Di 2-ethylhexyl adipate Heptachlor Toxaphene

Di 2-ethylhexyl phthalate Heptachlor epoxide

Volatile Organic Contaminants (VOC)


Benzene
Carbon Tetrachloride
Chlorobenzene
o-Dichlorobenzene
p-Dichlorobenzene
1,1-Dichloroethylene

trans-1,2-Dicholoroethylene Dichloromethane 1,2-Dichloroethane 1,2-Dichloropropane Ethylbenzene Styrene Tetrachloroethylene 1,2,4-Trichlorobenzene
1,1,1,-Trichloroethane
1,1,2-Trichloroethane
Trichloroethylene
Toluene
Vinyl Chloride
Xylenes




Common water sampling bottles.

VOC bottles are the smaller, thin bottles with the septum tops. Be careful not to get any air bubbles in the VOC bottles and this may take a few weeks to learn to collect a proper sample.



Giardia




Cryptosporidium

National Primary Drinking Water Regulations

Inorganic Chemicals	MCLG 1 (mg/L)	MCL ² or TT ³ (mg/L)	Potential Health Effects from Ingestion of Water	Sources of Contaminant in Drinking Water
Antimony	0.006	0.006	Increase in blood cholesterol; decrease in blood glucose	Discharge from petroleum refineries; fire retardants; ceramics; electronics; solder
Arsenic	none ⁵	0.010	Skin damage; circulatory system problems; increased risk of cancer	Discharge from semiconductor manufacturing; petroleum refining; wood preservatives; animal feed additives; herbicides; erosion of natural deposits
Asbestos (fiber >10 micrometers)	7 million fibers per Liter	7 MFL	Increased risk of developing benign intestinal polyps	Decay of asbestos cement in water mains; erosion of natural deposits
Barium	2	2	Increase in blood pressure	Discharge of drilling wastes; discharge from metal refineries; erosion of natural deposits
Beryllium	0.004	0.004	Intestinal lesions	Discharge from metal refineries and coal-burning factories; discharge from electrical, aerospace, and defense industries
Cadmium	0.005	0.005	Kidney damage	Corrosion of galvanized pipes; erosion of natural deposits; discharge from metal refineries; runoff from waste batteries and paints
Chromium (total)	0.1	0.1	Some people who use water containing chromium well in excess of the MCL over many years could experience allergic dermatitis	Discharge from steel and pulp mills; erosion of natural deposits
Copper	1.3	Action Level=1. 3; TT ⁶	Short term exposure: Gastrointestinal distress. Long term exposure: Liver or kidney damage. Those with Wilson's Disease should consult their personal doctor if their water systems exceed the copper action level.	Corrosion of household plumbing systems; erosion of natural deposits; leaching from wood preservatives
Cyanide (as free cyanide)	0.2	0.2	Nerve damage or thyroid problems	Discharge from steel/metal factories; discharge from plastic and fertilizer factories
Fluoride	4.0	4.0	Bone disease (pain and tenderness of the bones); Children may get mottled teeth.	Water additive which promotes strong teeth; erosion of natural deposits; discharge from fertilizer and aluminum factories
Lead	zero	Action Level=0. 015; TT ⁶	Infants and children: Delays in physical or mental development. Adults: Kidney problems; high blood pressure	Corrosion of household plumbing systems; erosion of natural deposits

Inorganic Mercury	0.002	0.002	Kidney damage	Erosion of natural deposits; discharge from refineries and factories; runoff from landfills and cropland
Nitrate (measured as Nitrogen)	10	10	"Blue baby syndrome" in infants under six months - life threatening without immediate medical attention. Symptoms: Infant looks blue and has shortness of breath.	Runoff from fertilizer use; leaching from septic tanks, sewage; erosion of natural deposits
Nitrite (measured as Nitrogen)	1	1	"Blue baby syndrome" in infants under six months - life threatening without immediate medical attention. Symptoms: Infant looks blue and has shortness of breath.	Runoff from fertilizer use; leaching from septic tanks, sewage; erosion of natural deposits
Selenium	0.05	0.05	Hair or fingernail loss; numbness in fingers or toes; circulatory problems	Discharge from petroleum refineries; erosion of natural deposits; discharge from mines
Thallium	0.0005	0.002	Hair loss; changes in blood; kidney, intestine, or liver problems	Leaching from ore-processing sites; discharge from electronics, glass, and pharmaceutical companies

EUGLENA




	MCLG	MCL ²		
Organic	MCLG 1	or TT ³	Potential Health	Sources of
Chemicals	(mg/L)	(mg/L)	Effects from	Contaminant in
Officialicals	(IIIg/L)	(III <u>4</u> /L)	Ingestion of Water	Drinking Water
Acrylamide	zero	TT <u>′</u>	Nervous system or blood problems; increased risk of cancer	Added to water during sewage/wastewater treatment
Alachlor	zero	0.002	Eye, liver, kidney or spleen problems; anemia; increased risk of cancer	Runoff from herbicide used on row crops
Atrazine	0.003	0.003	Cardiovascular system problems; reproductive difficulties	Runoff from herbicide used on row crops
Benzene	zero	0.005	Anemia; decrease in blood platelets; increased risk of cancer	Discharge from factories; leaching from gas storage tanks and landfills
Benzo(a)pyrene	zero	0.0002	Reproductive difficulties; increased risk of cancer	Leaching from linings of water storage tanks and distribution lines
Carbofuran	0.04	0.04	Problems with blood or nervous system; reproductive difficulties.	Leaching of soil fumigant used on rice and alfalfa
Carbon tetrachloride	zero	.005	Liver problems; increased risk of cancer	Discharge from chemical plants and other industrial activities
Chlordane	zero	0.002	Liver or nervous system problems; increased risk of cancer	Residue of banned termiticide
Chlorobenzene	0.1	0.1	Liver or kidney problems	Discharger from chemical and agricultural chemical factories
2,4-D	0.07	0.07	Kidney, liver, or adrenal gland problems	Runoff from herbicide used on row crops
Dalapon	0.2	0.2	Minor kidney changes	Runoff from herbicide used on rights of way
1,2-Dibromo-3- chloropropane (DBCP)	zero	0.0002	Reproductive difficulties; increased risk of cancer	Runoff/leaching from soil fumigant used on soybeans, cotton, pineapples, and orchards
o-Dichlorobenzene	0.6	0.6	Liver, kidney, or circulatory system problems	Discharge from industrial chemical factories
p-Dichlorobenzene	0.075	0.075	Anemia; liver, kidney or spleen damage; changes in blood	Discharge from industrial chemical factories
1,2-Dichloroethane	zero	0.005	Increased risk of cancer	Discharge from industrial chemical factories
1-1- Dichloroethylene	0.007	0.007	Liver problems	Discharge from industrial chemical factories
cis-1, 2- Dichloroethylene	0.07	0.07	Liver problems	Discharge from industrial chemical factories
trans-1,2- Dichloroethylene	0.1	0.1	Liver problems	Discharge from industrial chemical factories
Dichloromethane	zero	0.005	Liver problems; increased risk of cancer	Discharge from pharmaceutical and chemical factories
1-2- Dichloropropane	zero	0.005	Increased risk of cancer	Discharge from industrial chemical factories
Di(2- ethylhexyl)adipate	0.4	0.4	General toxic effects or reproductive difficulties	Leaching from PVC plumbing systems; discharge from chemical factories
Di(2- ethylhexyl)phthalate	zero	0.006	Reproductive difficulties; liver problems; increased risk of cancer	Discharge from rubber and chemical factories
Dinoseb	0.007	0.007	Reproductive difficulties	Runoff from herbicide used on soybeans and vegetables

Dioxin (2,3,7,8- TCDD)	zero	0.000000 03	Reproductive difficulties; increased risk of cancer	Emissions from waste incineration and other combustion; discharge from chemical factories
Diquat Endothall	0.02 0.1	0.02 0.1	Cataracts Stomach and intestinal problems	Runoff from herbicide use Runoff from herbicide use
Endrin Epichlorohydrin	0.002 zero	0.002 TT ⁷	Nervous system effects Stomach problems; reproductive difficulties; increased risk of cancer	Residue of banned insecticide Discharge from industrial chemical factories; added to water during treatment process
Ethylbenzene	0.7	0.7	Liver or kidney problems	Discharge from petroleum refineries
Ethelyne dibromide	zero	0.00005	Stomach problems; reproductive difficulties; increased risk of cancer	Discharge from petroleum refineries
Glyphosate	0.7	0.7	Kidney problems; reproductive difficulties	Runoff from herbicide use
Heptachlor	zero	0.0004	Liver damage; increased risk of cancer	Residue of banned termiticide
Heptachlor epoxide	zero	0.0002	Liver damage; increased risk of cancer	Breakdown of hepatachlor
Hexachlorobenzene	zero	0.001	Liver or kidney problems; reproductive difficulties; increased risk of cancer	Discharge from metal refineries and agricultural chemical factories
Hexachlorocyclopen tadiene	0.05	0.05	Kidney or stomach problems	Discharge from chemical factories
Lindane	0.0002	0.0002	Liver or kidney problems	Runoff/leaching from insecticide used on cattle, lumber, gardens
Methoxychlor	0.04	0.04	Reproductive difficulties	Runoff/leaching from insecticide used on fruits, vegetables, alfalfa, livestock
Oxamyl (Vydate)	0.2	0.2	Slight nervous system effects	Runoff/leaching from insecticide used on apples, potatoes, and tomatoes
Polychlorinated biphenyls (PCBs)	zero	0.0005	Skin changes; thymus gland problems; immune deficiencies; reproductive or nervous system difficulties; increased risk of cancer	Runoff from landfills; discharge of waste chemicals
Pentachlorophenol	zero	0.001	Liver or kidney problems; increased risk of cancer	Discharge from wood preserving factories
Picloram Simazine	0.5 0.004	0.5 0.004	Liver problems Problems with blood	Herbicide runoff Herbicide runoff
Styrene	0.1	0.1	Liver, kidney, and circulatory problems	Discharge from rubber and plastic factories; leaching from landfills
Tetrachloroethylene	zero	0.005	Liver problems; increased risk of cancer	Discharge from factories and dry cleaners
Toluene	1	1	Nervous system, kidney, or liver problems	Discharge from petroleum factories
Total Trihalomethanes (TTHMs)	none ⁵	0.10	Liver, kidney or central nervous system problems; increased risk of cancer	Byproduct of drinking water disinfection
Toxaphene	zero	0.003	Kidney, liver, or thyroid problems; increased risk of cancer	Runoff/leaching from insecticide used on cotton and cattle
2,4,5-TP (Silvex)	0.05	0.05	Liver problems	Residue of banned herbicide

1,2,4- Trichlorobenzene	0.07	0.07	Changes in adrenal glands	Discharge from textile finishing factories
1,1,1- Trichloroethane	0.20	0.2	Liver, nervous system, or circulatory problems	Discharge from metal degreasing sites and other factories
1,1,2- Trichloroethane	0.003	0.005	Liver, kidney, or immune system problems	Discharge from industrial chemical factories
Trichloroethylene	zero	0.005	Liver problems; increased risk of cancer	Discharge from petroleum refineries
Vinyl chloride	zero	0.002	Increased risk of cancer	Leaching from PVC pipes; discharge from plastic factories
Xylenes (total)	10	10	Nervous system damage	Discharge from petroleum factories; discharge from chemical factories

Radionuclides Beta particles and photon emitters Gross alpha particle activity	MCLG 1 (mg/L) none ⁵ none ⁵	MCL ² or TT ³ (mg/L) 4 millirems per year 15 picocurie s per Liter	Potential Health Effects from Ingestion of Water Increased risk of cancer Increased risk of cancer	Sources of Contaminant in Drinking Water Decay of natural and man- made deposits Erosion of natural deposits
Radium 226 and Radium 228 (combined)	none ⁵	(pCi/L) 5 pCi/L	Increased risk of cancer	Erosion of natural deposits
Microorganisms	MCLG (mg/L)	or TT ³ (mg/L)	Potential Health Effects from Ingestion of Water	Sources of Contaminant in Drinking Water
Giardia lamblia	zero	TT <u>8</u>	Giardiasis, a gastroenteric	Human and animal fecal waste
Heterotrophic plate count	N/A	TT <u>8</u>	disease HPC has no health effects, but can indicate how effective treatment is at controlling microorganisms.	n/a
Legionella	zero	TT ⁸	Legionnaire's Disease, commonly known as	Found naturally in water; multiplies in heating systems
Total Coliforms (including fecal	zero	5.0% ⁹	potentially harmful bacteria	Human and animal fecal waste
coliform and <i>E. Coli</i>) Turbidity	N/A	TT ⁸	may be present ¹⁰ Turbidity has no health effects but can interfere with disinfection and provide a medium for microbial growth. It may indicate the presence of microbes.	Soil runoff
Viruses (enteric)	zero	TT ⁸	Gastroenteric disease	Human and animal fecal waste



Cholera



Legionella

National Secondary Drinking Water Regulations

National Secondary Drinking Water Regulations (NSDWRs) or secondary standards are non-enforceable guidelines regulating contaminants which may cause cosmetic effects (such as skin or tooth discoloration) or aesthetic effects (such as taste, odor or color) in drinking water. The EPA recommends secondary standards to water systems but does not require systems to comply. However, states may choose to adopt them as enforceable standards.

Contaminant	Secondary Standard
Aluminum	0.05 to 0.2 mg/L
Chloride	250 mg/L
Color	15 (color units)
Copper	1.0 mg/L
Corrosivity	noncorrosive
Fluoride	2.0 mg/L
Foaming Agents	0.5 mg/L
Iron	0.3 mg/L
Manganese	0.05 mg/L
Odor	3 threshold odor number
рН	6.5-8.5
Silver	0.10 mg/L
Sulfate	250 mg/L
Total Dissolved Solids	500 mg/L
Zinc	5 mg/L

Notes

- ¹ Maximum Contaminant Level Goal (MCLG) The maximum level of a contaminant in drinking water at which no known or anticipated adverse effect on the health effect of persons would occur and which allows for a proper margin of safety. MCLGs are non-enforceable public health goals.
- ² Maximum Contaminant Level (MCL) The maximum permissible level of a contaminant in water which is delivered to any user of a public water system. MCLs are enforceable standards. The margins of safety in MCLGs ensure that exceeding the MCL slightly does not pose significant risk to public health.
- ³ Treatment Technique An enforceable procedure or level of technical performance which public water systems must follow to ensure control of a contaminant.
- ⁴ Units are in milligrams per liter (mg/L) unless otherwise noted.
- ⁵ MCLGs were not established before the 1986 Amendments to the Safe Drinking Water Act. Therefore, there is no MCLG for this contaminant.
- ⁶ Lead and copper are regulated in a Treatment Technique which requires systems to take tap water samples at sites with lead pipes or copper pipes that have lead solder and/or are served by lead service lines. The action level, which triggers water systems into taking treatment steps if exceeded in more than 10% of tap water samples, for copper is 1.3 mg/L, and for lead is 0.015mg/L.
- ⁷ Each water system must certify, in writing, to the state (using third-party or manufacturer's certification) that when acrylamide and epichlorohydrin are used in drinking water systems, the combination (or product) of dose and monomer level does not exceed the levels specified, as follows:
 - Acrylamide = 0.05% dosed at 1 mg/L (or equivalent)
 - **Epichlorohydrin** = 0.01% dosed at 20 mg/L (or equivalent)
- ⁸ The Surface Water Treatment Rule requires systems using surface water or ground water under the direct influence of surface water to disinfect water, and filter water or meet criteria for avoiding filtration so that the following contaminants are controlled at the following levels:
 - *Giardia lamblia*: 99.9% killed/inactivated Viruses: 99.99% killed/inactivated
 - **Legionella**: No limit, but EPA believes if **Giardia** and viruses are inactivated, **Legionella** will also be controlled.
 - **Turbidity**: At no time can turbidity (cloudiness of water) go above 5 nephelolometric turbidity units (NTU); systems that filter must ensure that the turbidity go no higher than 1 NTU (0.5 NTU for conventional or direct filtration) in at least 95% of the daily samples in any month.
 - **HPC**: NO more than 500 bacterial colonies per milliliter.
- ⁹ No more than 5.0% samples total coliform-positive in a month. (For water systems that collect fewer than 40 routine samples per month, no more than one sample can be total coliform-positive). Every sample that has total coliforms must be analyzed for fecal coliforms. There cannot be any fecal coliforms.
- ¹⁰ Fecal coliform and *E. coli* are bacteria whose presence indicates water may be contaminated with human animal wastes. Microbes in these wastes can cause diarrhea, cramps, nausea, headaches or other symptoms.

Drinking Water Rule Section Review Answers at end of practice exam.

1. The first list was called the drinking water CCL of contaminants/contaminant groups, included 10 pathogens, and was public Federal Register on March 2, 1998. A decision concerning whether to contaminants from CCL was required by August 2001. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Safe Drinking Water Act (SDWA) of 1974 D. Contaminant Candidate List (CCL) E. Surface Water Treatment Rule (SWTR)	ished in the
 Public water systems are regulated under the subsequent 1986 and 1996 amendments. Under it, the EPA is authorized to standards to protect drinking water and its sources against naturally occur made contaminants. Total Coliform Rule (TCR) 1996 SDWA amendments Safe Drinking Water Act (SDWA) of 1974 Contaminant Candidate List (CCL) Surface Water Treatment Rule (SWTR) 	
3. The require the EPA to publish a list every contaminants that are known or anticipated to occur in public water systemight need to be regulated. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Safe Drinking Water Act (SDWA) of 1974 D. Contaminant Candidate List (CCL) E. Surface Water Treatment Rule (SWTR)	5 years of ms and that
 4. Microbial contamination is regulated under the Total Coliform Rule (TCR) the of 1989. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Safe Drinking Water Act (SDWA) of 1974 D. Contaminant Candidate List (CCL) E. Surface Water Treatment Rule (SWTR) 	of 1989 and
5 covers all water systems that use surface groundwater under the direct influence of surface water. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Safe Drinking Water Act (SDWA) of 1974 D. Contaminant Candidate List (CCL) E. Surface Water Treatment Rule (SWTR)	e water or

 6 is intended to protect against exposure to Giardia intestinalist viruses, and Legionella, as well as selected other pathogens. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Safe Drinking Water Act (SDWA) of 1974 D. Contaminant Candidate List (CCL) E. Surface Water Treatment Rule (SWTR) 	3,
7. In 1998, the EPA promulgated the, which provides additional protection against Cryptosporidium and other waterborne pathogens for systems the serve ≥10,000 persons. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Long Term 1 Enhanced SWTR (LT1ESWTR) E. Surface Water Treatment Rule (SWTR)	al at
 8. In 2002, the EPA finalized the for public water systems that use surface water or groundwater under the direct influence of surface water and served 10,000 persons. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Long Term 1 Enhanced SWTR (LT1ESWTR) E. Surface Water Treatment Rule (SWTR) 	at e
9 was proposed in combination with the Filter Backwas Recycling Rule (FBRR), which was finalized in 2001. A. Total Coliform Rule (TCR) B. Filter Backwash Recycling Rule (FBRR) C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Long Term 1 Enhanced SWTR (LT1ESWTR) E. Surface Water Treatment Rule (SWTR)	h
10. The require the EPA to develop regulations that require disinfection of groundwater systems as necessary to protect the public health; EPA has proposed the Ground Water Rule (GWR) to meet this mandate. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Long Term 1 Enhanced SWTR (LT1ESWTR) E. Surface Water Treatment Rule (SWTR)	e s
11 specifies the appropriate use of disinfection in groundwater and addresses other components of groundwater systems to ensure public healt protection. GWR applies to public groundwater systems (systems that have ≥15 service connections or regularly serve ≥25 persons/day for ≥60 days/year). A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Ground Water Rule (GWR)	h

12. This rule also applies to any system that mixes surface and groundwater if the groundwater is added directly to the distribution system and provided to consumers without treatment does not apply to privately owned wells. A. Total Coliform Rule (TCR) B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Ground Water Rule (GWR) E. Surface Water Treatment Rule (SWTR)
13. To fill gaps in existing data regarding occurrence of microbial pathogens and other indicators of microbial contamination, occurrence of disinfection byproducts, and characterization of treatment processes, the EPA promulgated thein 1996, which required systems serving ≥100,000 persons to provide treatment data and monitor disinfection byproducts and source-waterquality parameters. A. Information Collection Rule B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Ground Water Rule (GWR) E. Surface Water Treatment Rule (SWTR)
14 are also required to monitor for the presence of Cryptosporidium, Giardia, total culturable viruses, and total* and fecal coliforms or Escherichia coli ≥1 time/month for 18 months. The required monitoring ended in December 1998, and data were analyzed. A. Information Collection Rule B. 1996 SDWA amendments C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Ground Water Rule (GWR) E. None of the above
15. The EPA also made minor changes in 2000 to the to streamline requirements, promote consistent national implementation, and in certain cases, reduce the burden for water systems. The action levels of 0.015 mg/L for lead and 1.3 mg/L for copper remain the same. A. Information Collection Rule B. Lead and Copper Rule C. Interim Enhanced Surface Water Treatment Rule (IESWTR) D. Ground Water Rule (GWR) E. None of the above
1.D, 2.C, 3.B, 4.E, 5.E, 6.E, 7.C, 8.D, 9.C, 10.B, 11.D, 12.D, 13.A, 14.E, 15.B



Transient, Non-Community Water System: A water system which provides water in a place such as a gas station or campground where people do not remain for long periods of time. These systems do not have to test or treat their water for contaminants which pose long-term health risks because fewer than 25 people drink the water over a long period. They still must test their water for microbes and several chemicals.

Treatment Technique: A required process intended to reduce the level of a contaminant in drinking water.

Turbidity: The cloudy appearance of water caused by the presence of tiny particles. High levels of turbidity may interfere with proper water treatment and monitoring.

Variance: State or EPA permission not to meet a certain drinking water standard. The water system must prove that: (1) it cannot meet a MCL, even while using the best available treatment method, because of the characteristics of the raw water, and (2) the variance will not create an unreasonable risk to public health. The State or EPA must review, and allow public comment on, a variance every three years. States can also grant variances to water systems that serve small populations and which prove that they are unable to afford the required treatment, an alternative water source, or otherwise comply with the standard.

Violation: A failure to meet any state or federal drinking water regulation.



This lab equipment is used for testing parameters in water such as Metals, Pesticides and Hydrocarbons. Often geotechnical water testing that is performed to support characterization regarding the fate and transport of contaminants in soils and sediments. Information such as the grain size distribution provides insight into the absorption, accumulation and movement of contaminants as it may relate to various particle sizes.






Top Photo: Extraction is a process used to concentrate trace levels of materials, in this case metals. Some metals are able to be complexed with an organic chelating agent. The organic chelating agent, Ammonium pyrrolidine dithiocarbamate (APDC), chemically binds the metals in the water. APDC is easily dissolved in the nonpolar organic solvent, methyl isobutyl ketone (MIBK). Because MIBK is nonpolar, it will not dissolve in water and will separate from the water like oil and water.


Bottom Photo: Atomic absorption requires the presence of ground state metal atoms (Me°). The initial process which takes place in an atomic absorption spectrophotometer is to create a population of ground state atoms. This is accomplished in a variety of ways, usually classified as flame and non-flame. The simplest and most common method uses a flame to produce these atoms.





Vapor atomic fluorescence spectroscopy (CVAFS) analytical techniques were designed by the EPA for the analysis of Mercury at low and sub parts per trillion (ppt) concentrations. Low detection limits were developed to support risk assessment, Mercury bioaccumulation in fish is a heightened concern. Thirty-nine states have issued fish consumption advisories due to mercury contamination. Mercury is a toxic pollutant across most regulatory programs (air, water, hazardous waste & pollution prevention). It is persistent and harmful to human health and the environment at relatively low levels.






This lab's Quality Assurance Quality Control (QAQC) methods includes spikes, performance samples, replicates, detection limits and blanks.





Prepared samples stored for metal analysis.






Top Photo: This form shows a typical ion chromatography run will have a standard curve consisting of 4 or 5 points for each ion of interest. A combined ion stock standard is used. The correlation coefficient of the standard curve for each ion should be >.998. The coefficient is calculated by plotting the peak area against the standard concentration using a linear fit.


Bottom Photo: Some labs have the luxury of automatic filling dilution water for BOD bottles. If the BOD bottle is filled too rapidly, excessive agitation and bubbling may result in supersaturated water. This device also has the capability of measuring the oxygen level.





Top Photo: Running a BOD analysis on a sample consists of placing a portion of a sample (along with prepared dilution water) into an air-tight bottle (300 ml volume) and incubating the bottle at 20 +/- 1 deg C for (usually) 5 days.

Bottom Photo: Dissolved oxygen is often measured to determine the oxygen level in receiving streams, in the aeration basin, and in the BOD test. The DO meter and electrode work in similar fashion to other electronic meters but unlike the others, this meter must be continually "on" to remain polarized.





Top Photo: Collecting the seed in a 500 ml bottle and let settle at least 1 hour and up to 36 hours. This will allow settleable solids to settle and help assure the seed is homogeneous.

Bottom Photo: In order to validate the BOD test conditions, reagents, and procedure, it is necessary to measure a solution with a known amount of organics. A solution that has a known value is called a standard.






Top Photo: This area is used for Fecal coliform which the most common dilution is prepared by transferring 11 ml of sample to 99 ml of sterile phosphate dilution water using a sterile serological pipet.

Bottom Photo: Some labs perform a variation of coliform testing this technician is making sure his area follows QAQC standards.





IDEXX bottles are clear plastic disposable containers that are supplied by the manufacturer with the colilert testing kits. Many labs that use the colilert method also issue the IDEXX bottles. Positive identification of total coliform is indicated by fluorescent under the UV light. E-coli are indicated by fluorescent blue colonies.





Top Photo: This technician is using Colilert which is a commercially available enzyme-substrate liquid-broth medium (IDEXX Laboratories, Inc.) that allows the simultaneous detection of total coliforms and *Escherichia coli* (*E. coli*). It is available in the most-probable number (MPN) or the presence/absence (PA) format. The MPN method is facilitated by use of a specially designed disposable incubation tray called the Quanti-Tray®.

Bottom Photo: Another method is using a petri dish with a filter membrane. The broth and membrane used vary depending on the sample type for water or wastewater.





The MPN method (also called Multiple Tube Fermentation Technique) for fecal coliform detection is often used when the sample has excessive turbidity. Excessive turbidity in the sample will plug the membrane filter, causing poor bacteria recovery and slow filtration times.

The MPN method involves adding the wastewater sample to a series of 5 sets of tubes, each of which contains either lactose broth or lauryl tryptose broth and an inverted tube. The tubes are then incubated at 35 + 0.5oC for 24 to 48 hours.





Top Photo: Analytical funnels are 100 ml filtration units that allow the membrane to be removed.

Bottom Photo: The heterotrophic plate count (HPC) is a procedure for estimating the number of live heterotrophic bacteria (requiring organic compounds of carbon and nitrogen for nourishment) in water. The technician will count the colored holes for the results.



Water Quality & River Sampling Photos



Top Photo: Technicians use several different devices to sample wells depending on the depth of the water table. Some use hand bailers or small gas powered submersible pumps.

Bottom Photo: Technicians are always concerned with Quality Assurance; here the containers have DI water for rinsing in the field. The containers that look like milk bottles are used for the equal width depth integrated sampler.





Top Photo: This multi probe device measures dissolved oxygen (DO), pH, conductivity and total dissolved solids (TDS), the device requires calibration for each parameter.

Bottom Photo: Collection of isokinetic, depth-integrated samples is done using either an equal-width-increment (EWI) or equal-discharge-increment (EDI) sampling method. The methods typically result in a composite sample that represents the streamflow-weighted concentrations of the stream cross section being sampled. That sample is poured into the bottles that resemble old fashion milk bottles.





The churn splitter was designed to facilitate the withdrawal of a representative subsample from a large composite sample of a water-sediment mixture. For example, samples from several verticals in a stream cross section, differing slightly from each other in chemical quality and sediment concentration, can be placed in the churn and be mixed into a relatively homogenous suspension, any subsample withdrawn from the churn should be equal in chemical quality and sediment concentration to any other subsample from the churn.





Ampullariidae, common name the apple snails, is a family of large freshwater snails, aquatic gastropod mollusks with a gill and an operculum. This family is in the superfamily Ampullarioidea and is the type family of that superfamily. The Ampullariidae are unusual because they have both a gill and a lung, the mantle cavity being divided in order to separate the two types of respiratory structures. This adaptation allows these snails to be amphibious. Bottom photo, snail eggs clusters on rocks.





Top Photo: When sampling in the river it is suggested that a minimum of two people participate. One person is holding the collection net while the other carefully disturbs the sediment for collection.

Bottom Photo: This river contained larvae of mayfly and stone flies along with leaches.





Sieving invertebrate samples reduces the volume of sediment that must be sorted through in the lab. A #60 sieve is recommended because the smaller invertebrates will be retained by the #60 sieve and should yield more complete invertebrate community data for a site. Any large debris should be cleaned (remove invertebrates and add them to the sample) and removed from the sample. The sample is then washed through the sieve over the side of the boat or in a tub with site water until no more fine sediment washes through the mesh.



Waterborne Disease Section

Bacteria, viruses and protozoans that cause disease are known as pathogens. Most pathogens are generally associated with diseases that cause intestinal illness and affect people in a relatively short amount of time, generally a few days to two weeks. They can cause illness through exposure to small quantities of contaminated water or food or from direct contact with infected people or animals. Pathogens that may cause waterborne outbreaks through drinking water have one thing in common: they are spread by the fecal-oral, or feces-to-mouth, route.

Pathogens may get into water and spread when infected humans or animals pass the bacteria, viruses and protozoa in their stool. For another person to become infected, he or she must take that pathogen in through the mouth.

Waterborne pathogens are different from other types of pathogens such as the viruses that cause influenza (the flu) or the bacteria that cause tuberculosis. Influenza virus and tuberculosis bacteria are spread by secretions that are coughed or sneezed into the air by an infected person.

Human or animal wastes in watersheds, failing septic systems, failing sewage treatment plants or cross-connections of water lines with sewage lines provide the potential for contaminating water with pathogens. The water may not appear to be contaminated because the feces has been broken up, dispersed and diluted into microscopic particles. These particles, containing pathogens, may remain in the water and be passed to humans or animals unless adequately treated.

Only proper treatment will ensure eliminating the spread of disease. In addition to water, other methods exist for spreading pathogens by the fecal-oral route. The foodborne route is one of the more common methods. A frequent source is a food handler who does not wash his hands after a bowel movement and then handles food with "unclean" hands. The individual who eats feces-contaminated food may become infected and ill. It is interesting to note the majority of foodborne diseases occur in the home, not restaurants.

Day care centers are another common source for spreading pathogens by the fecal-oral route. Here, infected children in diapers may get feces on their fingers, then put their fingers in a friend's mouth or handle toys that other children put into their mouths. You will usually be asked to sample at these facilities for Giardia.

The general public and some of the medical community usually refer to diarrhea symptoms as "stomach flu." Technically, influenza is an upper respiratory illness and rarely has diarrhea associated with it; therefore, stomach flu is a misleading description for foodborne or waterborne illnesses, yet is accepted by the general public. So the next time you get the stomach flu, you may want to think twice about what you've digested within the past few days.

Chain of Transmission

When water is contaminated with feces, this contamination may be of human or animal origin. If the human or animal source is not infected with a pathogen (disease-causing bacteria, viruses or protozoa), no disease will result.

The pathogens must survive in the water. This depends on the temperature of the water and the length of time the pathogens are in the water. Some pathogens will survive for only a short time in water, others, such as Giardia or Cryptosporidium, may survive for months. The pathogens in the water must enter the water system's intake and in numbers sufficient to infect people. The water is either not treated or inadequately treated for the pathogens present. A susceptible person must drink the water that contains the pathogen in order for illness (**disease**) to occur. This chain lists the events that must occur for the transmission of disease via drinking water. By breaking the chain at any point, the transmission of disease will be prevented.


Bacterial Diseases (More detailed information in the next chapters)

Campylobacteriosis is the most common diarrheal illness caused by bacteria. Symptoms include abdominal pain, malaise, fever, nausea and vomiting, and usually begin three to five days after exposure. The illness is frequently over within two to five days and usually lasts no more than 10 days. Campylobacteriosis outbreaks have most often been associated with food, especially chicken and unpasteurized milk as well as unchlorinated water. These organisms are also an important cause of "*travelers' diarrhea.*" Medical treatment generally is not prescribed for campylobacteriosis because recovery is usually rapid.

Cholera, Legionellosis, salmonellosis, shigellosis, yersiniosis, are other bacterial diseases that can be transmitted through water. All bacteria in water are readily killed or inactivated with chlorine or other disinfectants.

Viral Diseases or Viruses

Hepatitis A is a common example of a viral disease that may be transmitted through water. The onset is usually abrupt with fever, malaise, loss of appetite, nausea and abdominal discomfort, followed within a few days by jaundice. The disease varies in severity from a mild illness lasting one to two weeks, to a severely disabling disease lasting several months (rare). The incubation period is 15-50 days and averages 28-30 days. Hepatitis A



outbreaks have been related to fecally contaminated water, food contaminated by infected food handlers, including sandwiches and salads that are not cooked or are handled after cooking; and raw or undercooked mollusks harvested from contaminated waters. Aseptic meningitis, polio and viral gastroenteritis (Norwalk agent) are other viral diseases that can be transmitted through water. Most viruses in drinking water can be inactivated by chlorine or other disinfectants.

Terrorism

Recent investigations have shown proof the terrorist organizations have been able to reproduce most of these pathogens and have the technology and funding to attack our public water supply system. You will need to know these diseases and how to deal with these issues. Even diseases that we have not seen in years are easily and readily available for a terrorist to backflow into our distribution system, or pour into a wellhead or clearwell.

The Main Players- History and Biology

Before we define the major waterborne diseases, let's first examine the germs and other creatures that cause the diseases. Most of the following information may be simple or instruction that you already know. But to be safe, let's review the basics.

History of Research

By the last half of the 19th century, the microbial world was known to consist of protozoa, fungi, and bacteria, all visible with a light microscope. In the 1840s, the German scientist Jacob Henle suggested that there were infectious agents too small to be seen with a light microscope, but for the lack of direct proof, his hypothesis was not accepted. Although the French scientist Louis Pasteur was working to develop a vaccine for rabies in the 1880s, he did not understand the concept of a virus.



Louis Pasteur

During the last half of the 19th century, several key discoveries were made that set the stage for the discovery of viruses. Pasteur is usually credited for dispelling the notion of spontaneous generation and proving that organisms reproduce new organisms. The German scientist Robert Koch, a student of Jacob Henle, and the British surgeon Joseph Lister developed techniques for growing cultures of single organisms that allowed the assignment of specific bacteria to specific diseases.

First Experiment

The first experimental transmission of a viral infection was accomplished in about 1880 by the German scientist Adolf Mayer, when he demonstrated that extracts from infected tobacco leaves could transfer tobacco mosaic disease to a new plant, causing spots on the leaves. Because Mayer was unable to isolate a bacterium or fungus from the tobacco leaf extracts, he considered the idea that tobacco mosaic disease might be caused by a soluble agent, but he concluded incorrectly that a new type of bacteria was likely to be the cause. The Russian scientist Dmitri Ivanofsky extended Mayer's observation and reported in 1892 that the tobacco mosaic agent was small enough to pass through a porcelain filter known to block the passage of bacteria. He too failed to isolate bacteria or fungi from the filtered material. But Ivanofsky, like Mayer, was bound by the dogma of his times and concluded in 1903 that the filter might be defective or that the disease agent was a toxin rather than a reproducing organism.

Unaware of Ivanofsky's results, the Dutch scientist Martinus Beijerinck, who collaborated with Mayer, repeated the filter experiment but extended this finding by demonstrating that the filtered material was not a toxin because it could grow and reproduce in the cells of the plant tissues. In his 1898 publication, Beijerinck referred to this new disease agent as a contagious living liquid—contagium vivum fluid—initiating a 20-year controversy over whether viruses were liquids or particles.

The conclusion that viruses are particles came from several important observations. In 1917 the French-Canadian scientist Félix H. d'Hérelle discovered that viruses of bacteria, which he named bacteriophage, could make holes in a culture of bacteria. Because each hole, or plaque, developed from a single bacteriophage, this experiment provided the first method for counting infectious viruses (the plaque assay). In 1935 the American biochemist Wendell Meredith Stanley crystallized tobacco mosaic virus to demonstrate that viruses had regular shapes, and in 1939 tobacco mosaic virus was first visualized using the electron microscope.

In 1898 the German bacteriologists Friedrich August Johannes Löffler and Paul F. Frosch (both trained by Robert Koch) described foot-and-mouth disease virus as the first filterable agent of animals, and in 1900, the American bacteriologist Walter Reed and colleagues recognized yellow fever virus as the first human filterable agent. For several decades viruses were referred to as filterable agents, and gradually the term virus (Latin for "slimy liquid" or "poison") was employed strictly for this new class of infectious agents. Through the 1940s and 1950s many critical discoveries were made about viruses through the study of bacteriophages because of the ease with which the bacteria they infect could be grown in the laboratory. Between 1948 and 1955, scientists at the National Institutes of Health (NIH) and at Johns Hopkins Medical Institutions revolutionized the study of animal viruses by developing cell culture systems that permitted the growth and study of many animal viruses in laboratory dishes.

Germ Theory of Disease History

Louis Pasteur along with Robert Koch developed the germ theory of disease which states that "a specific disease is caused by a specific type of microorganism."

In 1876, Robert Koch established an experimental procedure to prove the germ theory of disease. This scientific procedure is known as Koch's postulates.

Koch's Postulates

- the causative agent must be present in every case of the disease and must not be present in healthy animals.
- the pathogen must be isolated from the diseased host animal and must be grown in pure culture.
- the same disease must be produced when microbes from the pure culture are inoculated into healthy susceptible animals.
- the same pathogen must be recoverable once again from this artificially infected animal and it must be able to be grown in pure culture.

Koch's postulates not only proved the germ theory but also gave a tremendous boost to the development of microbiology by stressing a laboratory culture and identification of microorganisms.

Circumstances under which Koch's postulates do not easily apply

- Many healthy people carry pathogens but do not exhibit the symptoms of disease. These "carriers" may transmit the pathogens to others who then may become diseased. Example: epidemics of certain hospital acquired (nosocomial) infections, gonorrhea, typhoid, pneumonia, and AIDS.
- Some microbes are very difficult to grow under in-vitro (in the laboratory) conditions. Example: viruses, chlamydia, rickettsias, and bacteria that cause leprosy and syphilis. Some of the fastidious organisms can now be grown in cultures of human or animal cells or in small animals.
- Not all laboratory animals are susceptible to all pathogens. Many pathogens are species specific. Ethical considerations limit the use of laboratory animals and human volunteers.
- Certain diseases develop only when an opportunistic pathogen invades a susceptible host. These secondary invaders or opportunists cause disease only when a person is ill or recovering from another disease. For example, in the case of pneumonia and ear infections following influenza, isolation of bacteria causing pneumonia may mislead the isolation of influenza virus.
- Not all diseases are caused by microorganisms. Many diseases are caused by dietary deficiencies (scurvy, rickets). Some of the diseases are inherited or are caused by abnormality in chromosomes. Still others, such as cancer of the lungs and skin, are influenced by environmental factors.

Cells

Robert Hooke observed small empty chambers in the structure of cork with the help of his crude microscope. He called them cells. With the help of advanced microscopes it is now known that a cell is composed of many different substances and contains tiny particles called organelles that have important functions. Two German biologists Matthias Schleiden and Thedore Schwann proposed the "Cell theory' in 1838. According to this theory, all living things are composed of cells.

Rudolph Virchow completed the cell theory with the idea that all cells must arise from preexisting cells.

In biology, a <u>cell</u> is defined as the fundamental living unit of any organism and exhibits the basic characteristics of life. A cell obtains food from the environment to produce energy and nutrients for metabolism.

Metabolism


Metabolism is a term that describes all the chemical reactions by which food is transformed for use by the cells.

Through its metabolism, a cell can grow, reproduce and it can respond to changes in its environment. As a result of accidental changes in its environment, a cell can undergo changes in its genetic material. This is called mutation.



Bacteria

Bacteria consist of only a single cell, but don't let their small size and seeming simplicity fool you. They're an amazingly complex and fascinating group of creatures. Bacteria have been found that can live in temperatures above the boiling point and in cold that would freeze your blood. They "eat" everything from sugar and starch to sunlight, sulfur and iron. There's even a species of bacteria—*Deinococcus radiodurans*—that can withstand blasts of radiation 1,000 times greater than would kill a human being.




BACTERIA

Schematic of a typical rod-type bacteria.

"Bacteria" is a plural word. The singular for this word is "bacterium" (**bacter** = rod, staff). Bacteria are prokaryotes (Kingdom Monera), which means that they have no true nucleus. They do have one chromosome of double-stranded DNA in a ring. They reproduce by binary fission. Most bacteria lack or have very few internal membranes, which means that they don't have some kinds of organelles (like mitochondria or chloroplasts). Most bacteria are **benign** (**benign** = good, friendly, kind) or beneficial, and only a few are "bad guys" or **pathogens**.

Kingdom Monera is a very diverse group. There are some bacteria relatives that can do photosynthesis--they don't have chloroplasts, but their chlorophyll and other needed chemicals are built into their cell membranes.



These organisms are called **Cyanobacteria** (**cyano** = blue, dark blue) or bluegreen algae, although they're not really algae (real algae are in Kingdom Protista). Like us, some kinds of bacteria need and do best in O_2 , while others are poisoned or killed by it.

Prokaryotes

Bacteria and archaea are the only prokaryotes. All other life forms are Eukaryotes (you-carry-oats), creatures whose cells have nuclei. (Note: viruses are not considered true cells, so they don't fit into either of these categories; this will be covered in the next few pages.)

Early Origins

Bacteria are among the earliest forms of life that appeared on Earth thousands of years ago. Scientists think that bacteria helped shape and change the young planet's environment, eventually creating atmospheric oxygen that enabled other, more complex life forms to develop. Many believe that more complex cells developed as once free-living bacteria took up residence in other cells, eventually becoming the organelles in modern complex cells. The mitochondria (mite-oh-con-dree-uh) that make energy for your body cells is one example of such an organelle. There are thousands of species of bacteria, but all of them are basically one of three different shapes. Some are rod - or stick-shaped and called bacilli (buh-sill-eye). Others are shaped like little balls and called cocci (cox-eye). Others still are helical or spiral in shape. Some bacterial cells exist as individuals while others cluster together to form pairs, chains, squares or other groupings. Bacteria live on or in just about every material and environment on Earth from soil to water to air, and from your house to arctic ice to volcanic vents. Each square centimeter of your skin averages about 100,000 bacteria. A single teaspoon of topsoil contains more than a billion (1,000,000,000) bacteria.

Peptidoglycan


Most bacteria secrete a covering for themselves which we call a **cell wall**.

However, bacterial cell walls are a totally different thing than the cell walls we talk about plants having. Bacterial cell walls do **NOT** contain cellulose like plant cell walls do. Bacterial cell walls are made mostly of a chemical called **peptidoglycan** (made of polypeptides bonded to modified sugars), but the amount and location of the peptidoglycan are different in the two possible types of cell walls, depending on the species of bacterium.

Some antibiotics, like penicillin, inhibit the formation of the chemical cross linkages needed to make peptidoglycan.

These antibiotics don't kill the bacteria outright; just stop them from being able to make more cell wall so they can grow.

That's why antibiotics must typically be taken for ten days until the bacteria, unable to grow, die of "old age". If a person stops taking the antibiotic sooner, any living bacteria could start making peptidoglycan, grow, and reproduce.



Gram⁺



Lactobacillus acidophilus



Streptococcus thermophilus

Gram-




Escherichia coli

Gram Stain

However, because one of the two possible types of bacterial cell walls has more peptidoglycan than the other, antibiotics like penicillin are more effective against bacteria with that type of cell wall and less effective against bacteria with less peptidoglycan in their cell walls. Thus it is important, before beginning antibiotic treatment, to determine with which of the two types of bacteria one is dealing. Dr. Hans Christian Gram, a Danish physician, invented a staining process to tell these two types of bacteria apart, and in his honor, this process is called Gram stain. In this process, the amount of peptidoglycan in the cell walls of the bacteria under study will determine how those bacteria absorb the dyes with which they are stained; thus, bacterial cells can be Gram⁺ or Gram . Gram bacteria have simpler cell walls with lots of peptidoglycan, and stain a dark purple color. Gram bacteria have more complex cell walls with less peptidoglycan. thus absorb less of the purple dye used and stain a pinkish color instead. Also, Gram bacteria often incorporate toxic chemicals into their cell walls, and thus tend to cause worse reactions in our bodies. Because Gram bacteria have less peptidoglycan. antibiotics like penicillin are less effective against them. As we have discussed before, taking antibiotics that don't work can be bad for you, thus a good doctor should always have a culture done before prescribing antibiotics to make sure the person is getting something that will help.

Pseudomonas aeruginosa is a strictly aerobic, oxidase positive, gram-negative nonfermentative bacterium. The Gram-stain appearance is not particularly characteristic although rods are somewhat thinner than those seen for the enteric-like bacteria. Mucoid strains that produce an extracellular polysaccharide are frequently isolated from patients with cystic fibrosis and this capsular material can be seen in the photo.



Two types of cells- Procaryotes and Eucaryotes

A Procaryotic cell exhibits all the characteristics of life but it lacks the complex system of membranes and organelles. *Example*: Bacterial cells and cyanobacteria.

A Eukaryotic cell has a complex structure. It contains a true nucleus and many membrane bound organelles. *Example*: Protozoa, fungi, algae, all plants and animal cells.

Structure of a Eukaryotic Cell

Cell Membrane: The cell is enclosed and held intact by the cell membrane/plasma membrane/cytoplasmic membrane. It is composed of large molecules of proteins and phospholipids. These large molecules permit the passage of nutrients, waste products and secretions across the cellular membrane. The cell membrane is selectively permeable.

Nucleus

The Nucleus unifies, controls and integrates the function of the entire cell. The nucleus is enclosed in the nuclear membrane and contains chromosomes; the number and composition of chromosomes and the number of genes on each chromosome are characteristic of each species. Human cells have 46 (23 pairs) chromosomes.

Each chromosome consists of many genes. A gene is a coiled unit made up of DNA and proteins that code for or determine a particular characteristic of an individual organism.

Cytoplasm

Cytoplasm is the cellular material outside the nucleus. It is composed of a semifluid gelatinous nutrient matrix and cytoplasmic organelles including endoplasmic reticulum, ribosomes, Golgi complex, mitochondria, centrioles, microtubules, lysosomes and vacoules.

Cell Wall

A cell wall is found as an external structure of plant cells, algae, and fungi. It consists of cellulose, pectin, chitin, and some mineral salts. A rigid exterior cell wall defines the shape of bacterial cells. It is different from the simple cell wall of plant cells and is made up of macromolecular polymer-peptidoglycan (protein and polysaccharide chain). The thickness and its exact composition varies with the species of bacteria.

Cilia and Flagella

Some eukaryotic cells possess relatively long and thin structures called flagella. These are organs of locomotion. Cilia are also organs of locomotion but are shorter and more numerous

Structure of a Procaryotic Cell

All bacteria are procaryotes and are simple cells. They divide by binary fission.

Chromosome

The chromosome of a prokaryotic cell is not surrounded by a nuclear membrane, it has no definite shape and no protein material associated with it. It usually consists of a single circular DNA molecule and serves as the control center of the bacterial cell. A typical bacterial chromosome contains approximately 10,000 genes.

Cytoplasm

Cytoplasm is a semi-liquid that surrounds the chromosome and is contained within the plasma membrane. Located within the cytoplasm are several ribosomes, which are the sites of protein synthesis. Cytoplasmic granules occur in certain species of bacteria which can be specifically stained and used to identify the bacteria.

Cell Membrane

The Cell Membrane is similar to that of the eukaryotic cell membrane. It is selectively permeable and controls the substances entering or leaving the cell. It is very thin and can be seen by electron microscopes only.

Capsules

Some bacteria have a layer of material outside the cell wall. When highly organized and firmly attached to the cell wall, this layer is called a capsule or if it is not highly organized and not firmly attached, a slime layer. Capsules consist of complex sugars or polysaccharides combined with lipids and proteins. The composition of the capsule is useful in differentiating between different types of bacteria. Capsules are usually detected by negative staining, where the bacterial cell and the background become stained but the capsule remains unstained.

Encapsulated bacteria produce colonies on nutrient agar that are smooth, mucoid and glistening, whereas the noncapsulated bacteria produce rough and dry colonies. Capsules enable the bacterial species to attach to mucus membranes and protect the bacteria from phagocytosis.

Flagella

Flagella are thread-like proteins that enable the bacteria to move. Flagellated bacteria are said to be motile while non-flagellated bacteria are generally non-motile. The number and arrangement of flagella are species specific and can be used to classify bacteria.

Peritrichous bacteria- possess flagella over the entire surface.

Lophotrichous bacteria-possess a tuft of flagella at one or both ends.

Amphitrichous bacteria-bacteria with one flagellum at each end.

Monotrichous bacteria-bacteria with a single polar flagellum.

Pili or Fimbriae

Pili or Fimbriae are thin hair-like structures observed on gram negative bacteria. They are not associated with motility. They enable the bacteria to attach to other bacteria or to membrane surfaces such as intestinal linings or RBC. They are also used to transfer genetic material from one bacteria cell to another.

Spores

Some bacteria are capable of forming spores (also called endospore) as a means of survival under adverse conditions. During sporulation the genetic material is enclosed in several protein coats that are resistant to heat, drying and most chemicals. Spores have been shown to survive in soil or dust. When the dried spore lands on a nutrient rich surface, it forms a new vegetative cell. Spore formation is related to the survival of bacterial cells, not reproduction.

Bacterial Nutrition

All life has the same basic nutritional requirements which include:

Energy. This may be light (the sun or lamps) or inorganic substances like sulfur, carbon monoxide or ammonia, or preformed organic matter like sugar, protein, fats etc. Without energy life cannot exist and quickly dies or becomes inactive.

Nitrogen. This may be nitrogen gas, ammonia, nitrate/nitrite, or a nitrogenous organic compound like protein or nucleic acid.

Carbon. This can be carbon dioxide, methane, carbon monoxide, or a complex organic material.

Oxygen. All cells use oxygen in a bound form and many require gaseous oxygen (air), but oxygen is lethal to many microbes.

Phosphorous, Sulfur, Magnesium, Potassium, and Sodium.

Calcium. Most cells require calcium in significant quantities, but some seem to only need it in trace amounts.

Water. All life requires liquid water in order to grow and reproduce; which is why the Mars Mission is so interested in water on Mars. Some resting stages of cells, like bacterial spores, can exist for long periods without free water, but they do not grow or metabolize.

Iron, Zinc, Cobalt. These are called trace metals that are required by some enzymes to function.

The sources of these various requirements define an organism, so a description of every organism should include this information.

Fastidious

Many bacteria can synthesize every complex molecule they need from the basic minerals, but others, said to be fastidious, require preformed organic molecules like vitamins, amino acids, nucleic acids, carbohydrates; humans are *fastidious*. In general bacterial pathogens need more preformed organic molecules than do nonpathogens, but that is not always true. For example, some bacteria that are found in milk hardly make any of their own basic organic molecules; that is, they let the cow (or more to the point the number of microbes that live in the cow's gut) make these things for them. A simple rule of thumb is "*if humans can use something for food, many microbes will also love it*". The reverse is not always true, as microbes can "digest" some very strange substances including cellulose, sulfur, some plastics, turkey feathers and asphalt, just to name a few.

Table of differences between Archaea, Bacteria and Eukaryotes				
Characteristic	Archaea	Bacteria	Eukaryotes	
Predominantly multicellular	No	No	Yes	
Cell contains a nucleus and other membrane bound organelles	No	No	Yes	
DNA occurs in a circular form*	Yes	Yes	No	
Ribosome size	70s	70s	80s	
Membrane lipids ester-linked**	No	Yes	Yes	
Photosynthesis with chlorophyll	No	Yes	Yes	
Capable of growth at temperatures greater than 80 C	Yes	Yes	No	
Histone proteins present in cell	Yes	No	Yes	
Methionine used as tRNA Initiator***	Yes	No	Yes	
Operons present in DNA	Yes	Yes	No	
Interon present in most genes	No	No	Yes	
Capping and poly-A tailing of mRNA	No	No	Yes	
Gas vesicles present	Yes	Yes	No	
Capable of Methanogenesis	Yes	No	No	
Sensitive to chloramphenicol, kanamycin and streptomycin	No	Yes	No	
Transcription factors required	No	Yes	Yes	
Capable of Nitrification	No	Yes	No	
Capable of Denitrification	Yes	Yes	No	
Capable of Nitrogen Fixation	Yes	Yes	No	
Capable of Chemolithotrophy	Yes	Yes	No	
* Eukaryote DNA is linear				
** Archaea membrane lipids are ether-linked				
*** Bacteria use Formylmethionine				

What in the World is an Eukaryote?

Eukaryotes are organisms with complex cells, in which the genetic material is organized into membrane-bound nuclei. They include the animals, plants, and fungi, which are mostly multicellular, as well as various other groups called protists, many of which are unicellular. In contrast, other organisms such as bacteria lack nuclei and other complex cell structures, and are called prokaryotes. The eukaryotes share a common origin, and are often treated formally as a superkingdom, empire, or domain. The name comes from the Greek *eus* or true and *karyon* or nut, referring to the nucleus.

What are Protists?

- They are **eukaryotes** because they all have a **nucleus**.
- Most have mitochondria although some have later lost theirs. Mitochondria
 were derived from aerobic alpha-proteobacteria (prokaryotes) that once lived
 within their cells.
- Many have chloroplasts with which they carry on photosynthesis. Chloroplasts
 were derived from photosynthetic cyanobacteria (also prokaryotes) living within
 their cells.

Eukaryotic Cells

Eukaryotic cells are generally much larger than prokaryotes, typically with a thousand times their volumes. They have a variety of internal membranes and structures, called organelles, and a cytoskeleton composed of microtubules and microfilaments, which plays an important role in defining the cell's organization. Eukaryotic DNA is divided into several bundles called chromosomes, which are separated by a microtubular spindle during nuclear division. In addition to asexual cell division, most eukaryotes have some process of sexual reproduction via cell fusion, which is not found among prokaryotes.

Eukaryotic cells include a variety of membrane-bound structures, collectively referred to as the endomembrane system. Simple compartments, called vesicles or vacuoles, can form by budding off of other membranes. Many cells ingest food and other materials through a process of endocytosis, where the outer membrane invaginates and then pinches off to form a vesicle. It is probable that most other membrane-bound organelles are ultimately derived from such vesicles.

The nucleus is surrounded by a double membrane, with pores that allow material to move in and out. Various tube- and sheet-like extensions of the nuclear membrane form what is called the endoplasmic reticulum or ER, which is involved in protein transport. It includes rough sections where ribosomes are attached, and the proteins they synthesize enter the interior space or lumen. Subsequently, they generally enter vesicles, which bud off from the smooth section. In most eukaryotes, the proteins may be further modified in stacks of flattened vesicles, called Golgi bodies or dictyosomes.

Vesicles may be specialized for various purposes. For instance, lysosomes contain enzymes that break down the contents of food vacuoles, and peroxisomes are used to break down peroxide which is toxic otherwise.

Contractile Vacuoles

Many protozoa have contractile vacuoles, which collect and expel excess water, and extrusomes, which expel material used to deflect predators or capture prey. In multicellular organisms, hormones are often produced in vesicles. In higher plants, most of a cell's volume is taken up by a central vacuole or tonoplast, which maintains its osmotic pressure.

Many eukaryotes have slender motile projections, usually called flagella when long and cilia when short. These are variously involved in movement, feeding, and sensation. These are entirely distinct from prokaryotic flagella. They are supported by a bundle of microtu-bules arising from a basal body, also called a kinetosome or centriole, characteristically arranged as nine doublets surrounding two singlets. Flagella also may have hairs or mastigonemes, scales, connecting membranes, and internal rods. Their interior is continuous with the cell's cytoplasm.

Centrioles

Centrioles are often present even in cells and groups that do not have flagella. They generally occur in groups of one or two, called kinetids that give rise to various microtubular roots. These form a primary component of the cytoskeletal structure, and are often assembled over the course of several cell divisions, with one flagellum retained from the parent and the other derived from it. Centrioles may also be associated in the formation of a spindle during nuclear division.

Some protists have various other microtubule-supported organelles. These include the radiolaria and heliozoa, which produce axopodia used in flotation or to capture prey, and the haptophytes, which have a peculiar flagellum-like organelle called the haptonema.





Figure 1. A diagram of *Paramecium* sp. with major organelles indicated.




Contractile Vacuoles


Figure 2. The contractile vacuole when full (top) and after contraction (bottom).

Paramecium

Members of the genus *Paramecium* are single-celled, freshwater organisms in the kingdom Protista. They exist in an environment in which the osmotic concentration in their external environment is much lower than that in their cytoplasm. More specifically, the habitat in which they live is **hypotonic** to their cytoplasm. As a result of this, *Paramecium* is subjected to a continuous influx of water, as water diffuses inward to a region of higher osmotic concentration.

If *Paramecium* is to maintain homeostasis, water must be continually pumped out of the cell (against the osmotic gradient) at the same rate at which it moves in. This process, known as **osmoregulation**, is carried out by two organelles in *Paramecium* known as **contractile vacuoles** (Figures 1 and 2).






BACTERIA TYPES

Viruses

Viruses are acellular microorganisms. They are made up of only genetic material and a protein coat. Viruses depend on the energy and metabolic machinery of the host cell to reproduce. A virus is an infectious agent found in virtually all life forms, including humans, animals, plants, fungi, and bacteria. Viruses consist of genetic material—either deoxyribonucleic acid (DNA) or ribonucleic acid (RNA)—surrounded by a protective coating of protein, called a capsid, with or without an outer lipid envelope. Viruses are between 20 and 100 times smaller than bacteria and hence are too small to be seen by light microscopy.



CROSS SECTIONAL VIEW

Viruses vary in size from the largest poxviruses of about 450 nanometers (about 0.000014 in) in length to the smallest polioviruses of about 30 nanometers (about 0.000001 in). Viruses are not considered free-living, since they cannot reproduce outside of a living cell; they have evolved to transmit their genetic information from one cell to another for the purpose of replication. Viruses often damage or kill the cells that they infect, causing disease in infected organisms. A few viruses stimulate cells to grow uncontrollably and produce cancers. Although many infectious diseases, such as the common cold, are caused by viruses, there are no cures for these illnesses. The difficulty in developing antiviral therapies stems from the large number of variant viruses that can cause the same disease, as well as the inability of drugs to disable a virus without disabling healthy cells. However, the development of antiviral agents is a major focus of current research, and the study of viruses has led to many discoveries important to human health.

Virions

Individual viruses, or virus particles, also called virions, contain genetic material, or genomes, in one of several forms. Unlike cellular organisms, in which the genes always are made up of DNA, viral genes may consist of either DNA or RNA. Like cell DNA, almost all viral DNA is double-stranded, and it can have either a circular or a linear arrangement. Almost all viral RNA is single-stranded; it is usually linear, and it may be either segmented (with different genes on different RNA molecules) or nonsegmented (with all genes on a single piece of RNA).

Capsids

The viral protective shell, or capsid, can be either helical (spiral-shaped) or icosahedral (having 20 triangular sides). Capsids are composed of repeating units of one or a few different proteins. These units are called protomers or capsomers. The proteins that make up the virus particle are called structural proteins. Viruses also carry genes for making proteins that are never incorporated into the virus particle and are found only in infected cells. These viral proteins are called nonstructural proteins; they include factors required for the replication of the viral genome and the production of the virus particle.

Capsids and the genetic material (DNA or RNA) they contain are together referred to as nucleocapsids. Some virus particles consist only of nucleocapsids, while others contain additional structures.

Some icosahedral and helical animal viruses are enclosed in a lipid envelope acquired when the virus buds through host-cell membranes. Inserted into this envelope are glycoproteins that the viral genome directs the cell to make; these molecules bind virus particles to susceptible host cells.

Bacteriophages

The most elaborate viruses are the bacteriophages, which use bacteria as their hosts. Some bacteriophages resemble an insect with an icosahedral head attached to a tubular sheath. From the base of the sheath extend several long tail fibers that help the virus attach to the bacterium and inject its DNA to be replicated, direct capsid production, and virus particle assembly inside the cell.

Viroids and Prions

Viroids and prions are smaller than viruses, but they are similarly associated with disease. Viroids are plant pathogens that consist only of a circular, independently replicating RNA molecule. The single-stranded RNA circle collapses on itself to form a rodlike structure. The only known mammalian pathogen that resembles plant viroids is the deltavirus (hepatitis D), which requires hepatitis B virus proteins to package its RNA into virus particles. Co-infection with hepatitis B and D can produce more severe disease than can infection with hepatitis B alone. Prions are mutated forms of a normal protein found on the surface of certain animal cells.


Virus Classification

Viruses are classified according to their type of genetic material, their strategy of replication, and their structure. The International Committee on Nomenclature of Viruses (ICNV), established in 1966, devised a scheme to group viruses into families, subfamilies, genera, and species. The ICNV report published in 1995 assigned more than 4000 viruses into 71 virus families. Hundreds of other viruses remain unclassified because of the lack of sufficient information.

Replication

The first contact between a virus particle and its host cell occurs when an outer viral structure docks with a specific molecule on the cell surface. For example, a glycoprotein called gp120 on the surface of the human immunodeficiency virus (HIV, the cause of acquired immunodeficiency syndrome, or AIDS) virion specifically binds to the CD4 molecule found on certain human T lymphocytes (a type of white blood cell). Most cells that do not have surface CD4 molecules generally cannot be infected by HIV.

After binding to an appropriate cell, a virus must cross the cell membrane. Some viruses accomplish this goal by fusing their lipid envelope to the cell membrane, thus releasing the nucleocapsid into the cytoplasm of the cell.



Other viruses must first be endocytosed (enveloped by a small section of the cell's plasma membrane that pokes into the cell and pinches off to form a bubble-like vesicle called an endosome) before they can cross the cell membrane. Conditions in the endosome allow many viruses to change the shape of one or more of their proteins.

These changes permit the virus either to fuse with the endosomal membrane or to lyse the endosome (cause it to break apart), allowing the nucleocapsid to enter the cell cytoplasm.

Once inside the cell, the virus replicates itself through a series of events. Viral genes direct the production of proteins by the host cellular machinery. The first viral proteins synthesized by some viruses are the enzymes required to copy the viral genome. Using a combination of viral and cellular components, the viral genome can be replicated thousands of times. Late in the replication cycle for many viruses, proteins that make up the capsid are synthesized. These proteins package the viral genetic material to make newly formed nucleocapsids.

To complete the virus replication cycle, viruses must exit the cell. Some viruses bud out of the cell's plasma membrane by a process resembling reverse endocytosis. Other viruses cause the cell to lyse, thereby releasing newly formed virus particles ready to infect other cells. Still other viruses pass directly from one cell into an adjacent cell without being exposed to the extracellular environment. The virus replication cycle can be as short as a couple of hours for certain small viruses or as long as several days for some large viruses.

Virus Battle

Some viruses kill cells by inflicting severe damage resulting in cell lysis; other viruses cause the cell to kill itself in response to virus infection. This programmed cell suicide is thought to be a host defense mechanism to eliminate infected cells before the virus can complete its replication cycle and spread to other cells. Alternatively, cells may survive virus infection, and the virus can persist for the life of its host. Virtually all people harbor harmless viruses.

Retroviruses

Retroviruses, such as HIV, have RNA that is transcribed into DNA by the viral enzyme reverse transcriptase upon entry into the cell. (The ability of retroviruses to copy RNA into DNA earned them their name because this process is the reverse of the usual transfer of genetic information, from DNA to RNA.) The DNA form of the retrovirus genome is then integrated into the cellular DNA and is referred to as the provirus. The viral genome is replicated every time the host cell replicates its DNA and is thus passed on to daughter cells.

Hepatitis B Virus

Hepatitis B virus can also transcribe RNA to DNA, but this virus packages the DNA version of its genome into virus particles. Unlike retroviruses, hepatitis B virus does not integrate into the host cell DNA.

Viral Infections

Most viral infections cause no symptoms and do not result in disease. For example, only a small percentage of individuals who become infected with Epstein-Barr virus or western equine encephalomyelitis virus ever develop disease symptoms. In contrast, most people who are infected with measles, rabies, or influenza viruses develop the disease.

A wide variety of viral and host factors determine the outcome of virus infections. A small genetic variation can produce a virus with increased capacity to cause disease. Such a virus is said to have increased virulence.

Infection

Viruses can enter the body by several routes. Herpes simplex virus and poxviruses enter through the skin by direct contact with virus-containing skin lesions on infected individuals. Ebola, hepatitis B, and HIV can be contracted from infected blood products. Hypodermic needles and animal and insect bites can transmit a variety of viruses through the skin. Viruses that infect through the respiratory tract are usually transmitted by airborne droplets of mucus or saliva from infected individuals who cough or sneeze.

Viruses that enter through the respiratory tract include orthomyxovirus (influenza), rhinovirus and adenovirus (common cold), and varicella-zoster virus (chicken pox).

Viruses such as rotavirus, coronavirus, poliovirus, hepatitis A, and some adenoviruses enter the host through the gastrointestinal tract. Sexually transmitted viruses, such as herpes simplex, HIV, and human papilloma viruses (HPV), gain entry through the genitourinary route. Other viruses, including some adenoviruses, echoviruses, Coxsackie viruses, and herpes viruses, can infect through the eye.

Localized or Systemic Infections

Virus infections can be either localized or systemic. The path of virus spread through the body in systemic infections differs among different viruses. Following replication at the initial site of entry, many viruses are spread to their target organs by the bloodstream or the nervous system.

The particular cell type can influence the outcome of virus infection. For example, herpes simplex virus undergoes lytic replication in skin cells around the lips but can establish a latent or dormant state in neuron cell bodies (located in ganglia) for extended periods of time. During latency, the viral genome is largely dormant in the cell nucleus until a stimulus such as a sunburn causes the reactivation of latent herpes virus, leading to the lytic replication cycle. Once reactivated, the virus travels from the ganglia back down the nerve to cause a cold sore on the lip near the original site of infection. The herpesvirus genome does not integrate into the host cell genome.

Virus-induced Illnesses

Virus-induced illnesses can be either acute, in which the patient recovers promptly, or chronic, in which the virus remains with the host or the damage caused by the virus is irreparable. For most acute viruses, the time between infection and the onset of disease can vary from three days to three weeks. In contrast, onset of AIDS following infection with HIV takes an average of 7 to 11 years.

Several human viruses are likely to be agents of cancer, which can take decades to develop. The precise role of these viruses in human cancers is not well understood, and genetic and environmental factors are likely to contribute to these diseases. But because a number of viruses have been shown to cause tumors in animal models, it is probable that many viruses have a key role in human cancers.

Alphaviruses and Flaviviruses

Some viruses—alphaviruses and flaviviruses, for example—must be able to infect more than one species to complete their life cycles. Eastern equine encephalomyelitis virus, an alphavirus, replicates in mosquitoes and is transmitted to wild birds when the mosquitoes feed. Thus, wild birds and perhaps mammals and reptiles serve as the virus reservoir, and mosquitoes serve as vectors essential to the virus life cycle by ensuring transmission of the virus from one host to another. Horses and people are accidental hosts when they are bitten by an infected mosquito, and they do not play an important role in virus transmission.

Defense

Although viruses cannot be treated with antibiotics, which are effective only against bacteria, the body's immune system has many natural defenses against virus infections. Infected cells produce interferons and other cytokines (soluble components that are largely responsible for regulating the immune response), which can signal adjacent uninfected cells to mount their defenses, enabling uninfected cells to impair virus replication.

Cytokines

Some cytokines can cause a fever in response to viral infection; elevated body temperature retards the growth of some types of viruses. B lymphocytes produce specific antibodies that can bind and inactivate viruses. Cytotoxic T cells recognize virus-infected cells and target them for destruction. However, many viruses have evolved ways to circumvent some of these host defense mechanisms.

The development of antiviral therapies has been thwarted by the difficulty of generating drugs that can distinguish viral processes from cellular processes. Therefore, most treatments for viral diseases simply alleviate symptoms, such as fever, dehydration, and achiness. Nevertheless, antiviral drugs for influenza virus, herpesviruses, and HIV are available, and many others are in the experimental and developmental stages.

Prevention has been a more effective method of controlling virus infections. Viruses that are transmitted by insects or rodent excretions can be controlled with pesticides. Successful vaccines are currently available for poliovirus, influenza, rabies, adenovirus, rubella, yellow fever, measles, mumps, and chicken pox.

Vaccines are prepared from killed (inactivated) virus, live (attenuated or weakened) virus, or isolated viral proteins (subunits). Each of these types of vaccines elicits an immune response while causing little or no disease, and there are advantages and disadvantages to each. (For a more complete discussion of vaccines, see the Immunization article.)

Vaccination

The principle of vaccination was discovered by British physician Edward Jenner. In 1796 Jenner observed that milkmaids in England who contracted the mild cowpox virus infection from their cows were protected from smallpox, a frequently fatal disease. In 1798 Jenner formally demonstrated that prior infection with cowpox virus protected those that he inoculated with smallpox virus (an experiment that would not meet today's protocol standards because of its use of human subjects).

Mutation

Viruses undergo very high rates of mutation (genetic alteration) largely because they lack the repair systems that cells have to safeguard against mutations. A high mutation rate enables the virus to continually adapt to new intracellular environments and to escape from the host immune response.

Co-infection of the same cell with different related viruses allows for genetic reassortment (exchange of genome segments) and intramolecular recombination. Genetic alterations can alter virulence or allow viruses to gain access to new cell types or new animal hosts.


Many scientists believe that HIV is derived from a closely related monkey virus, SIV (simian immunodeficiency virus), that acquired the ability to infect humans. Many of today's emerging viruses may have similar histories.

Protozoa Section

The diverse assemblage of organisms that carry out all of their life functions within the confines of a single, complex eukaryotic cell are called protozoa.

Paramecium, Euglena, and Amoeba are well-known examples of these major groups of organisms. Some protozoa are more closely related to animals, others to plants, and still others are relatively unique. Although it is not appropriate to group them together into a single taxonomic category, the research tools used to study any unicellular organism are usually the same, and the field of protozoology has been created to carry out this research. The unicellular photosynthetic protozoa are sometimes also called algae and are addressed elsewhere. This report considers the status of our knowledge of heterotrophic protozoa (protozoa that cannot produce their own food).


EUGLENA




Free-living Protozoa

Protozoans are found in all moist habitats within the United States, but we know little about their specific geographic distribution. Because of their small size, production of resistant cysts, and ease of distribution from one place to another, many species appear to be cosmopolitan and may be collected in similar microhabitats worldwide (Cairns and Ruthven 1972). Other species may have relatively narrow limits to their distribution.

Marine ciliates inhabit interstices of sediment and beach sands, surfaces, deep sea and cold Antarctic environments, planktonic habitats, and the algal mats and detritus of estuaries and wetlands.



AMOEBA Amoeba



Amoeba proteus, pseudopods slowly engulf the small desmid Staurastrum.

Amoebas

Amoebas (Phylum Rhizopoda) are unicellular protists that are able to change their shape constantly. Each species has its own distinct repertoire of shapes.

How does an amoeba locomote?

Amoebas locomote by way of cytoplasmic movement. (cytoplasm is the cell content around the nucleus of the cell) The amoeba forms pseudopods (false feet) with which they 'flow' over a surface. The cytoplasma not only flows, it also changes from a fluid into a solid state.

These pseudopods are also used to capture prey, they simply engulf the food. They can detect the kind of prey and use different 'engulfing tactics'.

The image from the last page shows several cell organelles. Left from the center we can see aspherical water expelling vesicle and just right of it, the single nucleus of this species can be seen. Other species may have many nuclei. The cell is full of brown food vacuoles and also contains small crystals.

Protozoa Information

Our actual knowledge of salinity, temperature, and oxygen requirements of marine protozoa is poor (although some groups, such as the foraminifera, are better studied than others), and even the broadest outlines of their biogeographic ranges are usually a mystery. In general, freshwater protozoan communities are similar to marine communities except the specialized interstitial fauna of the sand is largely missing. In freshwater habitats, the foraminifera and radiolaria common in marine environments are absent or low in numbers while testate amoebae exist in greater numbers. Relative abundance of species in the marine versus freshwater habitat is unknown.

Soil-dwelling protozoa have been documented from almost every type of soil and in every kind of environment, from the peat-rich soil of bogs to the dry sands of deserts. In general, protozoa are found in greatest abundance near the soil surface, especially in the upper 15 cm (6 in), but occasional isolates can be obtained at depths of a meter (yard) or more.

Protozoa do not constitute a major part of soil biomass, but in some highly productive regions such as forest litter, the protozoa are a significant food source for the microinvertebrates, with a biomass that may reach 20 g/m2 of soil surface area there.

Environmental Quality Indicators

Polluted waters often have a rich and characteristic protozoan fauna. The relative abundance and diversity of protozoa are used as indicators of organic and toxic pollution (Cairns et al. 1972; Foissner 1987; Niederlehner et al. 1990; Curds 1992). Bick (1972), for example, provided a guide to ciliates that are useful as indicators of environmental quality of European freshwater systems, along with their ecological distribution with respect to parameters such as amount of organic material and oxygen levels.

Foissner (1988) clarified the taxonomy of European ciliates as part of a system for classifying the state of aquatic habitats according to their faunas.

Symbiotic Protozoa

Parasites

Protozoa are infamous for their role in causing disease, and parasitic species are among the best-known protozoa. Nevertheless, our knowledge has large gaps, especially of normally free-living protozoa that may become pathogenic in immunocompromised individuals. For example, microsporidia comprise a unique group of obligate, intracellular parasitic protozoa. Microsporidia are amazingly diverse organisms with more than 700 species and 80 genera that are capable of infecting a variety of plant, animal, and even other protist hosts.

They are found worldwide and have the ability to thrive in many ecological conditions. Until the past few years, their ubiquity did not cause a threat to human health, and few systematists worked to describe and classify the species. Since 1985, however, physicians have documented an unusual rise in worldwide infections in AIDS patients caused by four different genera of microsporidia (Encephalitozoon, Nosema, Pleistophora, and Enterocytozoon). According to the Centers for Disease Control in the United States, difficulties in identifying microsporidian species are impeding diagnosis and effective treatment of AIDS patients.

Protozoan Reservoirs of Disease

The presence of bacteria in the cytoplasm of protozoa is well known, whereas that of viruses is less frequently reported. Most of these reports simply record the presence of bacteria or viruses and assume some sort of symbiotic relationship between them and the protozoa. Recently, however, certain human pathogens were shown to not only survive but also to multiply in the cytoplasm of free-living, nonpathogenic protozoa. Indeed, it is now believed that protozoa are the natural habitat for certain pathogenic bacteria. To date, the main focus of attention has been on the bacterium Legionella pneumophila, the causative organism of Legionnaires' disease; these bacteria live and reproduce in the cytoplasm of some free-living amoebae (Curds 1992). More on this subject in the following chapters.

Symbionts

Some protozoa are harmless or even beneficial symbionts. A bewildering array of ciliates, for example, inhabit the rumen and reticulum of ruminates and the cecum and colon of equids. Little is known about the relationship of the ciliates to their host, but a few may aid the animal in digesting cellulose.

Data on Protozoa

While our knowledge of recent and fossil foraminifera in the U.S. coastal waterways is systematically growing, other free-living protozoa are poorly known. There are some regional guides and, while some are excellent, many are limited in scope, vague on specifics, or difficult to use. Largely because of these problems, most ecologists who include protozoa in their studies of aquatic habitats do not identify them, even if they do count and measure them for biomass estimates (Taylor and Sanders 1991).

Parasitic protozoa of humans, domestic animals, and wildlife are better known although no attempt has been made to compile this information into a single source. Large gaps in our knowledge exist, especially for haemogregarines, microsporidians, and myxosporidians (see Kreier and Baker 1987).

Museum Specimens

For many plant and animal taxa, museums represent a massive information resource. This is not true for protozoa. In the United States, only the National Natural History Museum (Smithsonian Institution) has a reference collection preserved on microscope slides, but it does not have a protozoologist curator and cannot provide species' identification or verification services. The American Type Culture Collection has some protozoa in culture, but its collection includes relatively few kinds of protozoa.

Ecological Role of Protozoa

Although protozoa are frequently overlooked, they play an important role in many communities where they occupy a range of trophic levels. As predators upon unicellular or filamentous algae, bacteria, and microfungi, protozoa play a role both as herbivores and as consumers in the decomposer link of the food chain. As components of the micro- and meiofauna, protozoa are an important food source for microinvertebrates. Thus, the ecological role of protozoa in the transfer of bacterial and algal production to successive trophic levels is important.

Factors Affecting Growth and Distribution

Most free-living protozoa reproduce by cell division (exchange of genetic material is a separate process and is not involved in reproduction in protozoa). The relative importance for population growth of biotic versus chemical-physical components of the environment is difficult to ascertain from the existing survey data. Protozoa are found living actively in nutrient-poor to organically rich waters and in fresh water varying between 0°C (32°F) and 50°C (122°F). Nonetheless, it appears that rates of population growth increase when food is not constrained and temperature is increased (Lee and Fenchel 1972; Fenchel 1974; Montagnes et al. 1988).

Comparisons of oxygen consumption in various taxonomic groups show wide variation (Laybourn and Finlay 1976), with some aerobic forms able to function at extremely low oxygen tensions and to thereby avoid competition and predation.

Many parasitic and a few free-living species are obligatory anaerobes (grow without atmospheric oxygen). Of the free-living forms, the best known are the plagiopylid ciliates that live in the anaerobic sulfide-rich sediments of marine wetlands (Fenchel et al. 1977). The importance of plagiopylids in recycling nutrients to aerobic zones of wetlands is potentially great.

Because of the small size of protozoa, their short generation time, and (for some species) ease of maintaining them in the laboratory, ecologists have used protozoan populations and communities to investigate competition and predation.

The result has been an extensive literature on a few species studied primarily under laboratory conditions. Few studies have been extended to natural habitats with the result that we know relatively little about most protozoa and their roles in natural communities. Intraspecific competition for common resources often results in cannibalism, sometimes with dramatic changes in morphology of the cannibals (Giese 1973). Field studies of interspecific competition are few and most evidence for such species interactions is indirect (Cairns and Yongue 1977).

Protozoan Diseases

Protozoan pathogens are larger than bacteria and viruses but still microscopic. They invade and inhabit the gastrointestinal tract. Some parasites enter the environment in a dormant form, with a protective cell wall called a "*cyst*." The cyst can survive in the environment for long periods of time and be extremely resistant to conventional disinfectants such as chlorine. Effective filtration treatment is therefore critical to removing these organisms from water sources.

Giardiasis

Giardiasis is a commonly reported protozoan-caused disease. It has also been referred to as "backpacker's disease" and "beaver fever" because of the many cases reported among hikers and others who consume untreated surface water. Symptoms include chronic diarrhea, abdominal cramps, bloating, frequent loose and pale greasy stools, fatigue and weight loss. The incubation period is 5-25 days or longer, with an average of 7-10 days.

Many infections are asymptomatic (no symptoms). Giardiasis occurs worldwide. Waterborne outbreaks in the United States occur most often in communities receiving their drinking water from streams or rivers without adequate disinfection or a filtration system. The organism, *Giardia lamblia*, has been responsible for more community-wide outbreaks of disease in the U.S. than any other pathogen. Drugs are available for treatment but are not 100% effective.

Cryptosporidiosis

Cryptosporidiosis is an example of a protozoan disease that is common worldwide, but was only recently recognized as causing human disease. The major symptom in humans is diarrhea, which may be profuse and watery. The diarrhea is associated with cramping abdominal pain. General malaise, fever, anorexia, nausea, and vomiting occur less often. Symptoms usually come and go, and end in fewer than 30 days in most cases. The incubation period is 1-12 days, with an average of about seven days. *Cryptosporidium* organisms have been identified in human fecal specimens from more than 50 countries on six continents. The mode of transmission is fecal-oral, either by person-to-person or animal-to-person. There is no specific treatment for *Cryptosporidium* infections.

All of these diseases, with the exception of hepatitis A, have one symptom in common: diarrhea. They also have the same mode of transmission, fecal-oral, whether through person-to-person or animal-to-person contact, and the same routes of transmission, being either foodborne or waterborne. Although most pathogens cause mild, self-limiting disease, on occasion, they can cause serious, even life threatening illness. Particularly vulnerable are persons with weak immune systems, such as those with HIV infections or cancer. By understanding the nature of waterborne diseases, the importance of properly constructed, operated and maintained public water systems becomes obvious. While water treatment cannot achieve sterile water (no microorganisms), the goal of treatment must clearly be to produce drinking water that is as pathogen-free as possible at all times. For those who operate water systems with inadequate source protection or treatment facilities, the potential risk of a waterborne disease outbreak is real. For those operating systems that currently provide adequate source protection and treatment, operating and maintaining the system at a high level on a continuing basis is critical to prevent disease.

Section References

Bick, H. 1972. Ciliated protozoa. An illustrated guide to the species used as biological indicators in freshwater biology. World Health Organization, Geneva. 198 pp.

Cairns, J., G.R. Lanza, and B.C. Parker. 1972. Pollution related structural and functional changes in aquatic communities with emphasis on freshwater algae and protozoa. Proceedings of the National Academy of Sciences 124:79-127.

Cairns, J., and J.A. Ruthven. 1972. A test of the cosmopolitan distribution of fresh-water protozoans. Hydrobiologia 39:405-427.

Cairns, J., and W.H. Yongue. 1977. Factors affecting the number of species of freshwater protozoan communities. Pages 257-303 in J. Cairns, ed. Aquatic microbial communities. Garland, New York.

Curds, C.R. 1992. Protozoa and the water industry. Cambridge University Press, MA. 122 pp.

Fenchel, T. 1974. Intrinsic rate increase: the relationship with body size. Oecologia 14:317-326.

Fenchel, T., T. Perry, and A. Thane. 1977. Anaerobiosis and symbiosis with bacteria in free-living ciliates. Journal of Protozoology 24:154-163.

Foissner, W. 1987. Soil protozoa: fundamental problems, ecological significance, adaptations in ciliates and testaceans, bioindicators, and guide to the literature. Progress in Protistology 2:69-212.

Foissner, W. 1988. Taxonomic and nomenclatural revision of Stádecek's list of ciliates (Protozoa: Ciliophora) as indicators of water quality. Hydrobiologia 166:1-64.

Giese, A.C. 1973. Blepharisma. Stanford University Press, CA. 366 pp.

Kreier, J.P., and J.R. Baker. 1987. Parasitic protozoa. Allen and Unwin, Boston, MA. 241 pp.

Laybourn, J., and B.J. Finlay. 1976. Respiratory energy losses related to cell weight and temperature in ciliated protozoa. Oecologia 44:165-174.

Lee, C.C., and T. Fenchel. 1972. Studies on ciliates associated with sea ice from Antarctica. II. Temperature responses and tolerances in ciliates from Antarctica, temperate and tropical habitats. Archive für Protistenkunde 114:237-244.

Montagnes, D.J.S., D.H. Lynn, J.C. Roff, and W.D. Taylor. 1988. The annual cycle of heterotrophic planktonic ciliates in the waters surrounding the Isles of Shoals, Gulf of Maine: an assessment of their trophic role. Marine Biology 99:21-30.

Niederlehner, B.R., K.W. Pontasch, J.R. Pratt, and J. Cairns. 1990. Field evaluation of predictions of environmental effects from multispecies microcosm toxicity test. Archives of Environmental Contamination and Toxicology 19:62-71.

Taylor, W., and R. Sanders. 1991. Protozoa. Pages 37-93 in J.H. Thorp and A.P. Covich, eds. Ecology and classification of North American freshwater invertebrates. Academic Press, New York.

Waterborne Diseases

Name	Causative organism	Source of organism	Disease
Viral gastroenteritis	Rotavirus (mostly in young children)	Human feces	Diarrhea or vomiting
Norwalk Agent	Noroviruses (genus Norovirus, family Caliciviridae) *1	Human feces; also, shellfish; lives in polluted waters	Diarrhea and vomiting
Salmonellosis	Salmonella (bacterium)	Animal or human feces	Diarrhea or vomiting
Gastroenteritis Escherichia <i>coli</i>	E. coli O1 57:H7 (bacterium): Other E. coli organisms:	Human feces	Symptoms vary with type caused
Typhoid	Salmonella typhi (bacterium)	Human feces, urine	Inflamed intestine, enlarged spleen, high temperature- sometimes fatal
Shigellosis	Shigella (bacterium)	Human feces	Diarrhea
Cholera	Vibrio choleras (bacterium)	Human feces; also, shellfish; lives in many coastal waters	Vomiting, severe diarrhea, rapid dehydration, mineral loss-high mortality
Hepatitis A	Hepatitis A virus	Human feces; shellfish grown in polluted waters	Yellowed skin, enlarged liver, fever, vomiting, weight loss, abdominal pain- low mortality, lasts up to four months
Amebiasis	Entamoeba histolytica (protozoan)	Human feces	Mild diarrhea, dysentery, extra intestinal infection
Giardiasis	Giardia lamblia (protozoan)	Animal or human feces	Diarrhea, cramps, nausea, and general weakness — lasts one week to months
Cryptosporidiosis	Cryptosporidium parvum	Animal or human feces	Diarrhea, stomach pain — lasts (protozoan) days to weeks

Notes:

^{*1} http://www.cdc.gov/

Waterborne Disease Section Review Assignment

Example Question, fill-in-the blank with one correct answer. is usually credited for dispelling the notion of spontaneous
generation and proving that organisms reproduce new organisms. A. Louis Pasteur B. Martinus Beijerinck C. Dimitri Ivanofsky D. Adolf Mayer E. Robert Koch
Review, you can check your answers at the end of this section. 1. The German scientist, a student of Jacob Henle, and the British surgeon Joseph Lister developed techniques for growing cultures of single organisms that allowed the assignment of specific bacteria to specific diseases. A. Louis Pasteur B. Martinus Beijerinck C. Dimitri Ivanofsky D. Adolf Mayer E. Robert Koch
 The first experimental transmission of a viral infection was accomplished in about 1880 by the German scientist, when he demonstrated that extracts from infected tobacco leaves could transfer tobacco mosaic disease to a new plant, causing spots on the leaves. Louis Pasteur Martinus Beijerinck Dimitri Ivanofsky Adolf Mayer Robert Koch
3. Because was unable to isolate a bacterium or fungus from the tobacco leaf extracts, he considered the idea that tobacco mosaic disease might be caused by a soluble agent, but he concluded incorrectly that a new type of bacteria was likely to be the cause. A. Louis Pasteur B. Martinus Beijerinck C. Dimitri Ivanofsky D. Adolf Mayer E. Robert Koch
4. The Russian scientist extended Mayer's observation and reported in 1892 that the tobacco mosaic agent was small enough to pass through a porcelain filter known to block the passage of bacteria. A. Louis Pasteur B. Martinus Beijerinck C. Dimitri Ivanofsky D. Adolf Mayer E. Robert Koch Answers in rear of assignment.

 5. In 1917 the French-Canadian scientist discovered that viruses of bacteria, which he named bacteriophage, could make holes in a culture of bacteria. A. Louis Pasteur B. Robert Koch C. Félix H. d'Hérelle D. Wendell Meredith Stanley E. Walter Reed
6. In 1935 the American biochemist crystallized tobacco mosaic virus to demonstrate that viruses had regular shapes, and in 1939 tobacco mosaic virus was first visualized using the electron microscope. A. Louis Pasteur B. Robert Koch C. Félix H. d'Hérelle D. Wendell Meredith Stanley E. Walter Reed
 7. In 1898 the German bacteriologists Friedrich August Johannes Löffler and Paul F. Frosch (both trained by) described foot-and-mouth disease virus as the first filterable agent of animals. A. Louis Pasteur B. Robert Koch C. Félix H. d'Hérelle D. Wendell Meredith Stanley E. Walter Reed
8. In 1900, the American bacteriologist and colleagues recognized yellow fever virus as the first human filterable agent. A. Louis Pasteur B. Robert Koch C. Félix H. d'Hérelle D. Wendell Meredith Stanley E. Walter Reed
9. For several decades viruses were referred to as filterable agents, and gradually the term virus (Latin for "" or "poison") was employed strictly for this new class of infectious agents. A. Slimy liquid B. Bacteriophages C. Cell culture systems D. Microorganism E. Germ theory
10. Through the 1940s and 1950s many critical discoveries were made about viruses through the study of

11. Between 1948 and 1955, scientists at the National Institutes of Health (NIH) and at Johns Hopkins Medical Institutions revolutionized the study of animal viruses by developing that permitted the growth and study of many animal viruses in laboratory dishes. A. Slimy liquid B. Bacteriophages C. Cell culture systems D. Microorganism E. Germ theory
12. Louis Pasteur along with developed the germ theory of disease which states that "a specific disease is caused by a specific type of microorganism." A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke
13. In 1876, established an experimental procedure to prove the germ theory of disease. This scientific procedure is known as Koch's postulates. A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke
14 postulates not only proved the germ theory but also gave a tremendous boost to the development of microbiology by stressing a laboratory culture and identification of microorganisms. A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke
15 observed small empty chambers in the structure of cork with the help of his crude microscope. He called them cells. A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke
16. Two German biologists and Thedore Schwann proposed the "Cell theory' in 1838. According to this theory, all living things are composed of cells. A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke

17 completed the cell theory with the idea that all cells must arise from preexisting cells. A. Robert Koch B. Matthias Schleiden C. Rudolph Virchow D. Thedore Schwann E. Robert Hooke
18. There's even a species of
19. "Bacteria" is a singular word. The plural for this word is "bacterium" (bacter = rod, staff).A. TrueB. False
20. Bacteria are prokaryotes (Kingdom Monera), which means that they have a large nucleus.A. TrueB. False
21. Bacteria do have one chromosome of single-stranded DNA in a ring. They reproduce by binary fission.A. TrueB. False
22. Most bacteria lack or have very few internal membranes, which means that they don't have some kinds of organelles (like mitochondria or chloroplasts). Most bacteria are benign (benign = good, friendly, kind) or beneficial, and only a few are "bad guys" or pathogens . A. True B. False
23. Kingdom Monera is a very diverse group. All bacteria relatives can do photosynthesis—because they have chloroplasts, because chlorophyll and other needed chemicals are built into their cell membranes. A. True B. False

24. These organisms are called **Cyanobacteria** (**cyano** = blue, dark blue) or bluegreen algae, although they're not really algae (real algae are in Kingdom Protista). Like us, some kinds of bacteria need and do best in O_3 , while others are poisoned/killed by it.

A. True

B. False

25. Bacteria fall into a category of life called the Prokaryotes (pro-carry-oats). Prokaryotes' genetic material, or DNA, is not enclosed in a cellular compartment called the nucleus. A. True B. False
26. Bacteria and archaea are the only prokaryotes. All other life forms are Eukaryotes (you-carry-oats), creatures whose cells have nuclei. A. True B. False
27. The mitochondria (mite-oh-con-dree-uh) that make energy for your body cells is one example of such an organelle.A. TrueB. False
28. There are less than 200 hundred of species of bacteria, but all of them are basically one of five different shapes.A. TrueB. False
29. Some bacteria are rod - or stick-shaped and are called A. Borrelia B. Bacilli C. Cocci D. Peptidoglycan E. None of the above
30. Some bacterial cells exist as individuals while others cluster together to form pairs, chains, squares or other A. Borrelia B. Bacilli C. Cocci D. Peptidoglycan E. None of the above
31. Most bacteria secrete a covering for themselves which we call a cell wall.A. TrueB. False
32. Bacterial cell walls do contain cellulose like plant cell walls do. A. True B. False
33. Bacterial cell walls are made mostly of a chemical called peptidoglycan (made of polypeptides bonded to modified sugars), but the amount and location of the peptidoglycan are different in the two possible types of cell walls, depending on the species of bacterium. A. True

B. False

needed to make peptidoglycan. A. True B. False
35. That's why antibiotics must typically be taken for ten days until the bacteria, unable to grow, die of "old age". If a person stops taking the antibiotic sooner, any living bacteria could start making peptidoglycan, grow, and reproduce. A. True B. False
36. However, because one of the two possible types of bacterial cell walls has more peptidoglycan than the other, antibiotics like penicillin are more effective against bacteria with that type of cell wall and less effective against bacteria with less peptidoglycan in their cell walls. A. True B. False
37. Thus it is important, before beginning antibiotic treatment, to determine with which of the two types of bacteria one is dealing. Dr. Hans Christian Gram, a Danish physician, invented a staining process to tell these two types of bacteria apart, and in his honor, this process is called Hetertropic Gram Count . A. True B. False
38. In this process, the amount of cellulose in the cell walls of the bacteria under study will determine how those bacteria absorb the dyes with which they are stained, thus bacterial cells can be Gram ⁺ or Gram ⁻ . A. True B. False
39. Gram⁺ bacteria have simpler cell walls with lots of peptidoglycan, and stain a dark purple color. A. True B. False
40. Human cells have 46 (23 pairs) chromosomes. Each consists of many genes. A. Golgi complex B. Nucleus C. Chromosome D. DNA E. Genes
41. A gene is a coiled unit made up of and proteins that codes for, or determines, a particular characteristic of an individual organism. A. Golgi complex B. Nucleus C. Chromosome D. DNA E. Genes

34. All antibiotics, like penicillin, prohibit the formation of the chemical cross linkages

gela ribo vac A. B. C. D.	The cellular material atinous nutrient matrix psomes, Golgi complesoules. Golgi complex Nucleus Chromosome DNA Genes	and cytoplasmic of	organelles in	cluding endo		ulum,
A. B. C. D.	Some eukaryotic o The Flagella Cilia Prokaryotes Cytoplasm Chromosome	ells possess re ese are organs of l		gand thin	structures	called
A. B. C. D.	nerous. Flagella Cilia Prokaryotes Cytoplasm Chromosome	_ are also organ	s of locomoti	on but are	shorter and	more
A. B. C. D.	All bacteria are Flagella Cilia Prokaryotes Cytoplasm Chromosome	·				
mer con bac A. B. C. D.	The	ite shape and no p	orotein mater	ial associate	d with it. It u	sually
A. B. C. D.	A typical bacterial Flagella Cilia Prokaryotes Cytoplasm Chromosome		contains ap	oroximately 1	10,000 genes	s.

48. Semi-liquid, surrounds the chromosome and is contained within the plasma membrane. Within the are located several ribosomes-which are the sites of protein synthesis. A. Flagella B. Cilia C. Prokaryotes D. Cytoplasm E. Chromosome
49. Eukaryotes are organisms with complex cells, in which the genetic material is organized into membrane-bound nuclei. A. True B. False
50. The eukaryotes share a common origin, and are often treated formally as a superkingdom, empire, or domain. A. True B. False
51. The name "eukaryotes" comes from the Greek eus or true and karyon or nut, referring to the nucleus.A. TrueB. False
52. Protists are eukaryotes because they all have a nucleus.A. TrueB. False
53. Protists have mitochondria, although some have later lost theirs were derived from aerobic alpha-proteobacteria (prokaryotes) that once lived within their cells. A. Vacuoles B. Mitochondria C. Prokaryotes D. Microtubules E. Chloroplasts
54. Many Protists have chloroplasts with which they carry on photosynthesis. ——————————————————————————————————

55. Eukaryotic cells are generally much larger than, typically a thousand times their volumes. A. Vacuoles B. Mitochondria C. Prokaryotes D. Microtubules E. Chloroplasts	with
56. Eukaryotic cells have a variety of internal membranes and structures, ca organelles, and a cytoskeleton composed of and microfilame which plays an important role in defining the cell's organization. A. Vacuoles B. Mitochondria C. Prokaryotes D. Microtubules E. Chloroplasts	
57. Eukaryotic DNA is divided into several bundles called chromosomes, which separated by a microtubular spindle during nuclear division. In addition to asexual division, most eukaryotes have some process of sexual reproduction via cell fus which is not found among A. Vacuoles B. Mitochondria C. Prokaryotes D. Microtubules E. Chloroplasts	cell
58. Eukaryotic cells include a variety of membrane-bound structures, collective referred to as the endomembrane system. Simple compartments, called vesicles, can form by budding off of other membranes. A. Vacuoles B. Mitochondria C. Prokaryotes D. Microtubules E. Chloroplasts	
1.E, 2.D, 3.D, 4.C, 5.C, 6.D, 7.B, 8.E, 9.A, 10.B, 11.C, 12.A, 13.A, 14.A, 15.E, 16.B, 17.C, 18.D, 19.B, 20.B, 21.B, 22.A, 23.B, 24.B, 25.A, 26.A, 27.A, 28.B, 29.B, 30. E, 31.A, 32.B, 33.A,34.B, 35.A, 36.A, 37.B, 38.B, 39.A, 40.C, 41.D, 42.B, 43.A, 44.B, 45.C, 46.E, 47.E, 48.D, 49.A, 50.A, 51.A, 52.A, 53.B, 54.E, 55.C, 56.D, 57.C, 58.A	

Microorganisms

Microorganish	ns			
Contaminant	MCLG ¹ (mg/L) ²	MCL or TT ¹ (mg/L) ²	Potential Health Effects from Ingestion of Water	Sources of Contaminant in Drinking Water
Cryptosporidium	zero	TT ³	Gastrointestinal illness (e.g., diarrhea, vomiting, cramps)	Human and animal fecal waste
Giardia lamblia	zero	TT ³	Gastrointestinal illness (e.g., diarrhea, vomiting, cramps)	Human and animal fecal waste
Heterotrophic plate count	n/a	TT ³	HPC has no health effects; it is an analytic method used to measure the variety of bacteria that are common in water. The lower the concentration of bacteria in drinking water, the better maintained the water system is.	HPC measures a range of bacteria that are naturally present in the environment
Legionella	zero	TT ³	Legionnaire's Disease, a type of pneumonia	Found naturally in water; multiplies in heating systems
Total Coliforms (including fecal coliform and <i>E. Coli</i>)	zero	5.0% ⁴	Not a health threat in itself; it is used to indicate whether other potentially harmful bacteria may be present ⁵	Coliforms are naturally present in the environment; as well as feces; fecal coliforms and <i>E. coli</i> only come from human and animal fecal waste.
Turbidity	n/a	TT ³	Turbidity is a measure of the cloudiness of water. It is used to indicate water quality and filtration effectiveness (e.g., whether disease-causing organisms are present). Higher turbidity levels are often associated with higher levels of disease-causing microorganisms such as viruses, parasites and some bacteria. These organisms can cause symptoms such as nausea, cramps, diarrhea, and associated headaches.	Soil runoff
Viruses (enteric)	zero	TT ³	Gastrointestinal illness (e.g., diarrhea, vomiting, cramps)	Human and animal fecal waste

Giardiasis Giardia lamblia Section

Giardia lamblia (intestinalis) is a single celled animal, i.e., a protozoa, that moves with the aid of five flagella. In Europe, it is sometimes referred to as Lamblia intestinalis.

Giardiasis is the most frequent cause of non-bacterial diarrhea in North America. *Giardia duodenalis*, cause of giardiasis (GEE-are-DYE-uh-sis), is a one-celled, microscopic

parasite that can live in the intestines of animals and people. It is found in every region throughout the world and has become recognized as one of the most common causes of waterborne (and occasionally foodborne) illness often referred to as "Beaver Fever." It is commonly known as "traveler's diarrhea", and referred to as "Montezuma's Revenge" by those who travel to third world countries in the Western Hemisphere.


Approximately one week after ingestion of the *Giardia* cysts, prolonged, greasy diarrhea, gas, stomach cramps, fatigue, and weight loss begin.



It is possible to experience some, not all, of the symptoms, yet still shed cysts and pass the parasite onto others. Typically, the disease runs its course in a week or two, although in some cases, the disease may linger for months, causing severe illness and weight loss. Nonetheless, the basic biology of this parasite--including how it ravages the digestive tract--is poorly understood.

The organism exists in two different forms--a hardy, dormant cyst that contaminates water or food and an active, disease-causing form that emerges after the parasite is ingested. National Institute of General Medical Sciences grantee Dr. Frances Gillin of the University of California, San Diego and her colleagues cultivated the entire life cycle of this parasite in the lab and identified biochemical cues in the host's digestive system that trigger Giardia's life cycle transformations. They also uncovered several tricks the parasite uses to evade the defenses of the infected organism. One of Giardia's techniques is to alter the proteins on its surface, which confounds the ability of the infected animal's immune system to detect and combat the parasite. This work reveals why Giardia infections are extremely persistent and prone to recur. In addition, these insights into Giardia's biology and survival techniques may enable scientists to develop better strategies to understand, prevent, and treat Giardia infections.

Recently, Giardia has been found to possess mitochondrial remnants known as 'mitosomes', one assumption is that the condition of amitochondrialism is not primitive to eukaryotes but instead is a result of reductive evolution.



The microaerophilic Giardia uses these mitosomes in the maturation of iron-sulfur proteins rather than in ATP synthesis as is the case in mitochondria-possessing eukaryotes.

Nature of Disease

Organisms that appear identical to those that cause human illness have been isolated from domestic animals (dogs and cats) and wild animals (beavers and bears). A related but morphologically distinct organism infects rodents, although rodents may be infected with human isolates in the laboratory. Human giardiasis may involve diarrhea within 1 week of ingestion of the cyst, which is the environmental survival form and infective stage of the organism.

Normally illness lasts for 1 to 2 weeks, but there are cases of chronic infections lasting months to years. Chronic cases, both those with defined immune deficiencies and those without, are difficult to treat.

The disease mechanism is unknown, with some investigators reporting that the organism produces a toxin while others are unable to confirm its existence. The organism has been demonstrated inside host cells in the duodenum, but most investigators think this is such an infrequent occurrence that it is not responsible for disease symptoms. Mechanical obstruction of the absorptive surface of the intestine has been proposed as a possible pathogenic mechanism, as has a synergistic relationship with some of the intestinal flora.

Giardia can be excysted, cultured and encysted in vitro; new isolates have bacterial, fungal, and viral symbionts. Classically, the disease was diagnosed by demonstration of the organism in stained fecal smears.

Several strains of *G. lamblia* have been isolated and described through analysis of their proteins and DNA; type of strain, however, is not consistently associated with disease severity. Different individuals show various degrees of symptoms when infected with the same strain, and the symptoms of an individual may vary during the course of the disease.

Diagnosis of Human Illness


Giardia lamblia is frequently diagnosed by visualizing the organism, either the trophozoite (active reproducing form) or the cyst (the resting stage that is resistant to adverse environmental conditions) in stained preparations or unstained wet mounts with the aid of a microscope. A commercial fluorescent antibody kit is available to stain the organism. Organisms may be concentrated by sedimentation or flotation; however, these procedures reduce the number of recognizable organisms in the sample. An enzyme linked immunosorbant assay (ELISA) that detects excretory secretory products of the organism is also available. So far, the increased sensitivity of indirect serological detection has not been consistently demonstrated.

Giardiasis is most frequently associated with the consumption of contaminated water. Five outbreaks have been traced to food contamination by infected or infested food handlers, and the possibility of infections from contaminated vegetables that are eaten raw cannot be excluded. Cool moist conditions favor the survival of the organism.

Relative Frequency of Disease

Giardiasis is more prevalent in children than in adults, possibly because many individuals seem to have a lasting immunity after infection. This organism is implicated in 25% of the cases of gastrointestinal disease and may be present asymptomatically. The overall incidence of infection in the United States is estimated at 2% of the population. This disease afflicts many homosexual men, both HIV-positive and HIV-negative individuals. This is presumed to be due to sexual transmission. The disease is also common in child day care centers, especially those in which diapering is done.

Acute outbreaks appear to be common with infants and is not usually associated with water but is related to child care and diaper changing hygiene procedures. When I worked for a major water provider, I would receive 2-3 calls a week about infants diagnosed with Giardiasis. The problem lies with the water provider in that we are obligated to investigate and analyze all water customer complaints and make sure that our water is safe.



This is an example of infectious diarrhea due to Giardia lamblia infection of the small intestine. The small pear-shaped trophozoites live in the duodenum and become infective cysts that are excreted. They produce a watery diarrhea. A useful test for diagnosis of infectious diarrheas is stool examination for ova and parasites.

Course of Disease and Complications

About 40% of those who are diagnosed with giardiasis demonstrate disaccharide intolerance during detectable infection and up to 6 months after the infection can no longer be detected. Lactose (i.e., milk sugar) intolerance is most frequently observed. Some individuals (less than 4%) remain symptomatic more than 2 weeks; chronic infections lead to a malabsorption syndrome and severe weight loss.

Chronic cases of giardiasis in immunodeficient and normal individuals are frequently refractile to drug treatment. Flagyl is normally quite effective in terminating infections. In some immune deficient individuals, giardiasis may contribute to a shortening of the life span.

Target Populations

Giardiasis occurs throughout the population, although the prevalence is higher in children than adults. Chronic symptomatic giardiasis is more common in adults than children.

Major Outbreaks

Major outbreaks are associated with contaminated water systems that do not use sand filtration or have a defect in the filtration system.

In April 1988, the Albuquerque Environmental Health Department and the New Mexico Health and Environment Department investigated reports of giardiasis among members of a church youth group in Albuquerque. The first two members to be affected had onset of diarrhea on March 3 and 4, respectively; stool specimens from both were positive for Giardia lamblia cysts. These two persons had only church youth group activities in common.

On August 8, 1983, the Utah Department of Health was notified by the Tooele County Health Department (TCHD) of an outbreak of diarrheal illness in Tooele, Utah, possibly associated with a contaminated public water supply that resulted from flooding during Utah's spring thaw.

References

- Hetsko ML, McCaffery JM, Svard SG, Meng TC, Que X, Gillin FD. Cellular and transcriptional changes during excystation of Giardia lamblia in vitro. Exp. Parasitol. 1998;88(3):172-83.
- Svard SG, Meng TC, Hetsko ML, McCaffery JM, Gillin FD. Differentiationdriven surface antigen variation in the ancient eukaryote. Molec. Microbiol. 1998;30:979-89.
- Tovar J, Levila G, Shez LB, Sutak R, Tachezy J, Van Der Giezen Mitochondrial remnant organelles of Giardia function in iron-sulphur protein maturation. Nature 2003;426:172-176

Giardia Images




Photo Credit: H.D.A Lindquist, U.S. EPA

Above: Differential interference contrast (DIC) image of *Giardia lamblia* cysts, purified from Mongolian gerbil fecal material. Cysts are ovoidal or elipsoidal objects, usually 11-14 microns in length. Cysts may contain as many as 4 nuclei, and residual structures from their trophozoite or vegetative form. These residua include central axonemes, remnants of the striated disk, and remnant median bodies. In some cysts these structures will be indistinct. Scale bar is 10 microns.




Photo Credit: H.D.A Lindquist, U.S. EPA

Above: Immunofluorescence image of *Giardia lamblia* cysts, purified from Mongolian gerbil fecal material. (Same field of view) Cysts were stained with commercially available immunofluorescent antibodies. Cysts should have an intense apple green fluorescence on the periphery of their cyst wall, and measure 11-14 microns in length. Scale bar is 10 microns.




Photo Credit: H.D.A Lindquist, U.S. EPA

Above: Fluorescence image of Giardia lamblia cysts, purified from Mongolian gerbil fecal material. (Same field of view) Cysts were stained with 4,6-diamidino 2-phenyl-indole dihydrochloride (DAPI). DAPI interacts with nucleic acids and stains the nuclei within the cyst. There should be 4 nuclei in each cyst. Cysts that appear to have fewer than 4 stained nuclei may have 4 nuclei with the others not visible in this plane of focus.

Cysts with no nuclei visible, may be dead, may be resistant to DAPI staining, or may be organisms other than *G. lamblia*.

Giardiasis Giardia lamblia Section Review

- 1. Giardia duodenalis, cause of giardiasis, is a one-celled, microscopic parasite that can live in the intestines of animals and people. It is found in every region throughout the world and has become recognized as one of the most common causes of waterborne (and occasionally foodborne) illness often referred to as "Beaver Fever." It is commonly known as "traveler's diarrhea", and referred to as "Montezuma's Revenge" by those who travel to third world countries in the Western Hemisphere.
- A. True
- B. False
- 2. Giardia lamblia (intestinalis) is a single celled animal, i.e., a protozoa, that moves with the aid of five flagella.
- A. True
- B. False
- 3. In Europe, Giardia lamblia is sometimes referred to as Lamblia intestinalis.
- A. True
- B. False
- 4. Giardiasis is the least frequent cause of non-bacterial diarrhea in North America.
- A. True
- B. False
- 5. Approximately one week after ingestion of the Giardia ______ prolonged, greasy diarrhea, gas, stomach cramps, fatigue, and weight loss begin.
- A. Cysts
- B. Immune system
- C. Parasite
- D. Amitochondrialism
- E. None of the above
- 6. It is possible to experience some, not all, of the symptoms, yet still shed _____ and pass the parasite onto others. Typically, the disease runs its course in a week or two, although in some cases, the disease may linger for months, causing severe illness and weight loss. Nonetheless, the basic biology of this parasite--including how it ravages the digestive tract--is poorly understood.
- A. Cvsts
- B. Immune system
- C. Parasite
- D. Amitochondrialism
- E. None of the above

7. The organism exists in two different formsa hardy, dormant
8. One of Giardia's techniques is to alter the proteins on its surface, which confounds the ability of the infected animal's immune system to detect and combat the This work reveals why Giardia infections are extremely persistent and prone to recur. In addition, these insights into Giardia's biology and survival techniques may enable scientists to develop better strategies to understand, prevent, and treat Giardia infections. A. Cysts B. Immune system C. Parasite D. Amitochondrialism E. None of the above
9. Recently, Giardia has been found to possess mitochondrial remnants known as 'mitosomes', which suggest that the condition of is not primitive to eukaryotes but instead is a result of reductive evolution. A. Cysts B. Immune system C. Parasite D. Amitochondrialism E. None of the above
10. The microaerophilic Giardia uses these in the maturation of iron-sulfur proteins rather than in ATP synthesis as is the case in mitochondria-possessing eukaryotes. A. Cysts B. Immune system C. Parasite D. Amitochondrialism E. None of the above

11. Several strains of G. lamblia have been isolated and described through analysis of their and DNA; type of strain, however, is not consistently associated with disease severity. Different individuals show various degrees of symptoms when infected with the same strain, and the symptoms of an individual may vary during the course of the disease. A. Survival B. Trophozoite C. Excysted D. Proteins E. Enzyme
12. Giardia lamblia is frequently diagnosed by visualizing the organism, either the (active reproducing form) or the cyst (the resting stage that is resistant to adverse environmental conditions) in stained preparations or unstained wet mounts with the aid of a microscope. A commercial fluorescent antibody kit is available to stain the organism. A. Survival B. Trophozoite C. Excysted D. Proteins E. Enzyme
13. Organisms may be concentrated by sedimentation or flotation; however, these procedures reduce the number of recognizable organisms in the sample. Anlinked immunosorbant assay (ELISA) that detects excretory secretory products of the organism is also available. So far, the increased sensitivity of indirect serological detection has not been consistently demonstrated. A. Survival B. Trophozoite C. Excysted D. Proteins E. Enzyme
14. Giardiasis is most frequently associated with the consumption of contaminated water. Five outbreaks have been traced to food contamination by infected or infested food handlers, and the possibility of infections from contaminated vegetables that are eaten raw cannot be excluded. Cool moist conditions favor the of the organism. A. Survival B. Trophozoite C. Excysted D. Proteins E. Enzyme
15. Giardiasis is more prevalent in children than in adults, possibly because many individuals seem to have a lasting immunity after infection. This organism is implicated in 25% of the cases of gastrointestinal disease and may be present asymptomatically. A. True

B. False

- 16. The disease is also common in child day care centers, especially those in which diapering is done.
- A. True
- B. False
- 17. Acute outbreaks appear to be common with infants and are not usually associated with water but are related to child care and diaper changing hygiene procedures.
- A. True
- B. False
- 18. About 40% of those who are diagnosed with giardiasis demonstrate disaccharide intolerance during detectable infection and up to 6 months after the infection can no longer be detected. Lactose (i.e., milk sugar) intolerance is most frequently observed. Some individuals (less than 4%) remain symptomatic more than 2 weeks; chronic infections lead to a malabsorption syndrome and severe weight loss.
- A. True
- B. False
- 19. Chronic cases of giardiasis in immunodeficient and normal individuals are frequently refractile to drug treatment.
- A. True
- B. False
- 20. Flagyl is normally quite effective in terminating infections. In some immune deficient individuals, giardiasis may contribute to a shortening of the life span.
- A. True
- B. False
- 21. Giardiasis occurs throughout the population, although the prevalence is higher in children than adults. Chronic symptomatic giardiasis is more common in adults than children.
- A. True
- B. False
- 1.B, 2.A, 3.A, 4.B,5.A, 6.A, 7.A, 8.C, 9.D, 10.E, 11.D,12.B, 13.E, 14.A, 15.A, 16.A, 17.A, 18.A, 19.A, 20.A, 21.A

Cryptosporidiosis Cryptosporidium Section

Introduction

Until 1993, when over 400,000 people in Milwaukee became ill with diarrhea after drinking water contaminated with the parasite, few people had heard of *Cryptosporidium parvum*, or the disease it causes, cryptosporidiosis. Today, however, public health and water utility officials are increasingly called on to provide information and make decisions about the control of this protozoan found in public water supplies, recreational water and other areas.

Cryptosporidiosis is most particularly a danger for the immunocompromised, especially HIV-positive persons and persons with AIDS. Individuals with CD4 cell counts below 200 are more likely to experience severe complications, including prolonged diarrhea, dehydration, and possible death. Those with CD4 counts above 200 may recover from the symptoms of cryptosporidiosis yet maintain the infection asymptomatically, with symptoms potentially returning if their CD4 count later drops.

Other diseases besides AIDS can cause immunosuppression severe enough to lead to chronic cryptosporidiosis. Persons with these diseases should also be concerned about becoming infected. These diseases include congenital agammaglobulinemia, congenital IgA deficiency and cancer. Persons taking corticosteroids, for cancer and bone marrow or organ transplants, also need to be concerned about becoming infected. Even though persons who are taking immunosuppressive drugs may develop chronic and/or severe cryptosporidiosis, the infection usually resolves when these drugs are decreased or stopped. Persons taking immunosuppressive drugs need to consult with their healthcare provider if they believe they have cryptosporidiosis.

Persons at increased risk for contracting cryptosporidiosis include child care workers; diaper-aged children who attend child care centers; persons exposed to human feces by sexual contact; and caregivers who might come in direct contact with feces while caring for a person infected with cryptosporidiosis.

Transmission is by an oral-fecal route, including hand contact with the stool of infected humans or animals or with objects contaminated with stool. Transmission is also common from ingestion of food or water contaminated with stool, including water in the recreational water park and swimming pool settings.

Symptoms of cryptosporidiosis include, most commonly, watery diarrhea and cramps, sometimes severe. Weight loss, nausea, vomiting, and fever are also possible. The severity of symptoms varies with the degree of underlying immunosuppression, with immunocompetent patients commonly experiencing watery diarrhea for a few days to 4 or more weeks and occasionally having a recurrence of diarrhea after a brief period of recovery.

AIDS

Patients with AIDS can have a large number of stools per day for months or even years. There is currently no cure for cryptosporidiosis, though drug research is continuing. Patients who suspect they may have cryptosporidiosis should drink extra fluids and may wish to drink oral rehydration therapy liquid, to avoid dehydration.

HIV-positive Individuals

HIV-positive individuals who suspect they have cryptosporidiosis should contact their healthcare provider. Infected individuals should be advised to wash their hands frequently, especially before preparing food and after going to the toilet.


They should also avoid close contact with anyone who has a weakened immune system. Individuals with diarrhea should not swim in public bathing areas while they have diarrhea and for at least 2 weeks after each attack of diarrhea.

Prevention

Washing hands is the most effective means of preventing cryptosporidiosis transmission.

For the immunocompromised, sex, including oral sex, that involves possible contact with stool should be avoided. Immunocompromised individuals should also avoid the stool of all animals and wash their hands thoroughly after any contact with animals or the living areas of animals. Immunocompromised persons may also wish to wash, peel, or cook all vegetables and to take extra measures, such as boiling or filtering their drinking water, to ensure its safety.





Life cycle of Cryptosporidium parvum and C. hominis.

Life cycle of Cryptosporidium parvum and C. hominis.

Cryptosporidium stages were reproduced from Juranek DD. Cryptosporidiosis. In: Strickland GT, editor. Hunter's Tropical Medicine and Emerging Infectious Diseases, 8th ed. Philadelphia: WB Saunders; 2000. Originally adapted from the life cycle that appears in Current WL, Garcia LS. Cryptosporidiosis. Clinc Microbiol Rev 1991;4:325-58.

Sporulated oocysts, containing 4 sporozoites, are excreted by the infected host through feces and possibly other routes such as respiratory secretions ••.

Transmission of *Cryptosporidium parvum* and *C. hominis* occurs mainly through contact with contaminated water (e.g., drinking or recreational water).

Occasionally food sources, such as chicken salad, may serve as vehicles for transmission. Many outbreaks in the United States have occurred in waterparks, community swimming pools, and day care centers. Zoonotic and anthroponotic transmission of *C. parvum* and anthroponotic transmission of *C. hominis* occur through exposure to infected animals or exposure to water contaminated by feces of infected animals **2**.

Following ingestion (and possibly inhalation) by a suitable host ③, excystation ② occurs. The sporozoites are released and parasitize epithelial cells (⑤, ⓒ) of the gastrointestinal tract or other tissues such as the respiratory tract. In these cells, the parasites undergo asexual multiplication (schizogony or merogony) (⑥, ⑥, ⑥) and then sexual multiplic-ation (gametogony) producing microgamonts (male) ⑤ and macrogamonts (female) ⑥.

Upon fertilization of the macrogamonts by the microgametes $(\mathbf{0})$, oocysts $(\mathbf{0}, \mathbf{0})$ develop that sporulate in the infected host. Two different types of oocysts are produced, the thick-walled, which is commonly excreted from the host $\mathbf{0}$, and the thin-walled oocyst $\mathbf{0}$, which is primarily involved in autoinfection.

Oocysts are infective upon excretion, thus permitting direct and immediate fecal-oral transmission.

Note that oocysts of *Cyclospora cayetanensis*, another important coccidian parasite, are unsporulated at the time of excretion and do not become infective until sporulation is completed.

Refer to the life cycle of *Cyclospora cayentanensis* for further details.

Cryptosporidiosis Oocysts




Cryptosporidium oocysts

Genus Cryptosporidium


Members of the genus *Cryptosporidium* are parasites of the intestinal tracts of fishes, reptiles, birds, and mammals. It seems that members of this genus do not display a high degree of host specificity, so the number of species in this genus remains a matter of some discussion. *Cryptosporidium* isolated from humans is now referred to as *C. parvum. Cryptosporidium* infections have been reported from a variety of wild and domesticated animals, and in the last six or seven years literally hundreds of human infections have been reported, including epidemics in several major urban areas in the United States. Cryptosporidiosis is now recognized as an important opportunistic infection, especially in immunocompromised hosts.

Cryptosporidium is a small parasite, measuring about 3-5 µm. It lives on (or just under) the surface of the cells lining the small intestine, reproduces asexually, and oocysts are passed in the feces. Transmission of the infection occurs via the oocysts. Many human infections have been traced to the contamination of drinking water with oocysts from agricultural "run-off" (i.e., drainage from pastures), so it is considered a zoonosis.


In most patients infected with cryptosporidiosis the infection causes a short term, mild diarrhea. Since such symptoms are associated with a number of ailments, infected individuals may not seek medical treatment, and the infection may subside on its own. Thus, it is difficult to say how many people are infected. On the other hand, in persons with compromised immune systems, this parasite can cause a pronounced, chronic diarrhea; in severe cases the infected individual may produce up to 15 liters/day of stools, and this may go on for weeks or months. Needless to say, such an infection, if not fatal unto itself, can exacerbate other opportunistic infections common in immunocompromised hosts.



A scanning electron micrograph of a broken meront of *Cryptosporidium* showing the merozoites within. (From: Gardiner *et al.*, 1988, An Atlas of Protozoan Parasites in Animal Tissues, USDA Agriculture Handbook No. 651.)



An electron micrograph showing several stages of *Cryptosporidium* (two are marked with asterisks) on the intestinal epithelium of a sheep. (From: Gardiner *et al.*, 1988, An Atlas of Protozoan Parasites in Animal Tissues, USDA Agriculture Handbook No. 651.)



A scanning electron micrograph of *Cryptosporidium* lining the intestinal tract. (From: Gardiner *et al.*, 1988, An Atlas of Protozoan Parasites in Animal Tissues, USDA Agriculture Handbook No. 651.)

How is cryptosporidiosis spread?

Cryptosporidium lives in the intestine of infected humans or animals. Millions of crypto germs can be released in a bowel movement from an infected human or animal.

Consequently, *Cryptosporidium* is found in soil, food, water, or surfaces that have been contaminated with infected human or animal feces. If a person swallows the parasite they become infected. You **cannot** become infected through contact with blood. The parasite can be spread by:

- Accidentally putting something into your mouth or swallowing something that has come into contact with feces of a person or animal infected with *Cryptosporidium*.
- Swallowing recreational water contaminated with *Cryptosporidium* (Recreational water includes water in swimming pools, hot tubs, jacuzzis, fountains, lakes, rivers, springs, ponds, or streams that can be contaminated with sewage or feces from humans or animals.) **Note:** *Cryptosporidium* can survive for days in swimming pools with adequate chlorine levels.
- Eating uncooked food contaminated with *Cryptosporidium*. Thoroughly wash with clean, safe water all vegetables and fruits you plan to eat raw.
- Accidentally swallowing *Cryptosporidium* picked up from surfaces (such as bathroom fixtures, changing tables, diaper pails, or toys) contaminated with feces from an infected person.

What are the Symptoms of Cryptosporidiosis?

The most common symptom of cryptosporidiosis is watery diarrhea. Other symptoms include:

- Dehydration
- Weight loss
- Stomach cramps or pain
- Fever
- Nausea
- Vomiting

Some people with crypto will have no symptoms at all. While the small intestine is the site most commonly affected, *Cryptosporidium* infections could possibly affect other areas of the digestive or the respiratory tract.

How long after infection do symptoms appear?

Symptoms of cryptosporidiosis generally begin 2 to 10 days (average 7 days) after becoming infected with the parasite.

How long will symptoms last?

In persons with healthy immune systems, symptoms usually last about 1 to 2 weeks. The symptoms may go in cycles in which you may seem to get better for a few days, then feel worse again before the illness ends.

If I have been diagnosed with *Cryptosporidium*, should I worry about spreading the infection to others?

Yes, *Cryptosporidium* can be very contagious. Follow these guidelines to avoid spreading the disease to others:

- 1. Wash your hands with soap and water after using the toilet, changing diapers, and before eating or preparing food.
- 2. Do not swim in recreational water (pools, hot tubs, lakes or rivers, the ocean, etc.) if you have cryptosporidiosis and for at least 2 weeks after diarrhea stops. You can pass *Cryptosporidium* in your stool and contaminate water for several weeks after your symptoms have ended. This has resulted in outbreaks of cryptosporidiosis among recreational water users.
 - **Note:** Cryptosporidium can be spread in a chlorinated pool because it is resistant to chlorine and, therefore, can live for days in chlorine-treated swimming pools.
- 3. Avoid fecal exposure during sexual activity.

Who is most at risk for cryptosporidiosis?

People who are most likely to become infected with *Cryptosporidium* include:

- Children who attend day care centers, including diaper-aged children
- Child care workers
- Parents of infected children
- International travelers
- Backpackers, hikers, and campers who drink unfiltered, untreated water
- Swimmers who swallow water while swimming in swimming pools, lakes, rivers, ponds, and streams
- People who drink from shallow, unprotected wells
- People who swallow water from contaminated sources

Contaminated water includes water that has not been boiled or filtered. Several community-wide outbreaks of cryptosporidiosis have been linked to drinking municipal water or recreational water contaminated with *Cryptosporidium*.

Who is most at risk for getting seriously ill with cryptosporidiosis?

Although Crypto can infect all people, some groups are more likely to develop more serious illness.

- Young children and pregnant women may be more susceptible to the dehydration resulting from diarrhea and should drink plenty of fluids while ill.
- If you have a severely weakened immune system, you are at risk for more serious disease. Your symptoms may be more severe and could lead to serious or life-threatening illness. Examples of persons with weakened immune systems include those with HIV/AIDS; cancer and transplant patients who are taking certain immunosuppressive drugs; and those with inherited diseases that affect the immune system.

If you have a severely weakened immune system, talk to your health care provider for additional quidance. You can also call the CDC AIDS HOTLINE tollfree at 1-800-342-2437. Ask for more information on cryptosporidiosis, or go to the CDC fact sheet Preventing Cryptosporidiosis: A Guide for People with Compromised *Immune Systems* available by visitina http://www.cdc.gov/ncidod/dpd/ parasites/cryptosporidiosis/

factsht crypto prevent ci.htm

What should I do if I think I may have cryptosporidiosis?

If you suspect that you have cryptosporidiosis, see your health care provider.

How is cryptosporidiosis diagnosed?

Your health care provider will ask you to submit stool samples to see if you are infected. Because testing for Crypto can be difficult, you may be asked to submit several stool specimens over several days. Tests for Crypto are not routinely done in most laboratories; therefore, your health care provider should specifically request testing for the parasite.

What is the treatment for cryptosporidiosis?

Although there is no standard treatment for cryptosporidiosis, the symptoms can be treated. Most people who have a healthy immune system will recover without treatment. If you have diarrhea, drink plenty of fluids to prevent dehydration. Rapid loss of fluids from diarrhea may be especially life threatening to babies; therefore, parents should talk to their health care provider about fluid replacement therapy options for infants. Antidiarrheal medicine may help slow down diarrhea, but talk to your health care provider before taking it. A new drug, nitazoxanide, has been approved for treatment of diarrhea caused by *Cryptosporidium* in healthy children less than 12 years old. Consult with your health care provider for more information. People who are in poor health or who have a weakened immune system are at higher risk for more severe and more prolonged illness. For persons with AIDS, anti-retroviral therapy that improves immune status will also decrease or eliminate symptoms of Crypto. However, even if symptoms disappear, cryptosporidiosis is usually not curable and the symptoms may return if the immune status worsens. See your health care provider to discuss anti-retroviral therapy used to improve your immune status.

How Can I Prevent Cryptosporidiosis?

Practice good hygiene.

- 1. Wash hands thoroughly with soap and water.
 - a. Wash hands after using the toilet and before handling or eating food (especially for persons with diarrhea).
 - b. Wash hands after every diaper change, especially if you work with diaperaged children, even if you are wearing gloves.
- 2. Protect others by not swimming if you are experiencing diarrhea (essential for children in diapers).

Avoid water that might be contaminated.

- 1. Do not swallow recreational water
- 2. Do not drink untreated water from shallow wells, lakes, rivers, springs, ponds, and streams.
- 3. Do not drink untreated water during community-wide outbreaks of disease caused by contaminated drinking water.

 http://www.cdc.gov/healthyswimming.
- 4. Do not use untreated ice or drinking water when traveling in countries where the water supply might be unsafe.

In the United States, nationally distributed brands of bottled or canned carbonated soft drinks are safe to drink. Commercially packaged non-carbonated soft drinks and fruit juices that do not require refrigeration until after they are opened (those that are stored un-refrigerated on grocery shelves) also are safe.

If you are unable to avoid using or drinking water that might be contaminated, then you can make the water safe to drink by doing one of the following:

- Heat the water to a rolling boil for at least 1 minute.
 OR
- Use a filter that has an absolute pore size of at least 1 micron or one that has been NSF rated for "cyst removal."

Do not rely on chemicals to disinfect water and kill *Cryptosporidium*. Because it has a thick outer shell, this particular parasite is highly resistant to disinfectants such as chlorine and iodine.

For information on choosing safe bottled water, see the CDC fact sheet entitled "Preventing Cryptosporidiosis: A Guide to Water Filters and Bottled Water," available by visiting http://www.cdc.gov/ncidod/dpd/parasites/cryptosporidiosis/factsht_crypto_prevent_water.htm.

For information on recreational

Healthy Swimming website at

water-related illnesses, visit CDC's

For information on choosing a water filter, see the CDC fact sheet entitled "Preventing Cryptosporidiosis: A Guide to Water Filters and Bottled Water," available by visiting http://www.cdc.gov/ncidod/dpd/parasites/cryptosporidiosis/factsht_crypto_prevent_water.htm.


Avoid food that might be contaminated.

- 1. Wash and/or peel all raw vegetables and fruits before eating.
- 2. Use safe, uncontaminated water to wash all food that is to be eaten raw.
- 3. Avoid eating uncooked foods when traveling in countries with minimal water treatment and sanitation systems.

Take extra care when traveling.

If you travel to developing nations, you may be at a greater risk for *Cryptosporidium* infection because of poorer water treatment and food sanitation. Warnings about food, drinks, and swimming are even more important when visiting developing countries. Avoid foods and drinks, in particular raw fruits and vegetables, tap water, or ice made from tap water, unpasteurized milk or dairy products, and items purchased from street vendors. These items may be contaminated with *Cryptosporidium*. Steaming-hot foods, fruits you peel yourself, bottled and canned processed drinks, and hot coffee or hot tea are probably safe. Talk with your health care provider about other guidelines for travel abroad.

Avoid fecal exposure during sexual activity.




This is another infectious agent that is becoming more frequent in immunocompromised patients, particularly those with AIDS. The small round blue organisms at the lumenal border are cryptosporidia. Cryptosporidiosis produces a copious watery diarrhea.





Vortecella Ciliate



Rotifer

Cholera Vibrio cholerae Section

Cholera has been very rare in industrialized nations for the last 100 years; however, the disease is still common today in other parts of the world, including the Indian subcontinent and sub-Saharan Africa. Although cholera can be life-threatening, it is easily prevented and treated. In the United States, because of advanced water and sanitation systems, cholera is not a major threat; however, everyone, especially travelers, should be aware of how the disease is transmitted and what can be done to prevent it.



Vibrio cholerae

Cholera, which is derived from a Greek term meaning "flow of bile," is caused by *Vibrio cholerae* and is the most feared epidemic diarrheal disease because of its severity. Dehydration and death can occur within a matter of hours of infection.

In 1883, Robert Koch discovered *V cholerae* during a cholera outbreak in Egypt. The organism is a comma-shaped, gram-negative aerobic bacillus whose size varies from 1-3 mm in length by 0.5-0.8 mm in diameter. Its antigenic structure consists of a flagellar H antigen and a somatic O antigen. The differentiation of the latter allows for separation into pathogenic and nonpathogenic strains. *V cholerae* O1 or O139 are associated with epidemic cholera. *V cholerae* O1 has 2 major biotypes: classic and El Tor.

Currently, El Tor is the predominant cholera pathogen. Organisms in both biotypes are subdivided into serotypes according to the structure of the O antigen, as follows:

- Serotype Inaba O antigens A and C
- Serotype Ogawa O antigens A and B
- Serotype Hikojima O antigens A, B, and C

How does a person get cholera?

A person may get cholera by drinking water or eating food contaminated with the cholera bacterium. In an epidemic, the source of the contamination is usually the feces of an infected person. The disease can spread rapidly in areas with inadequate treatment of sewage and drinking water. The cholera bacterium may also live in the environment in brackish rivers and coastal waters. Shellfish eaten raw have been a source of cholera, and a few persons in the United States have contracted cholera after eating raw or undercooked shellfish from the Gulf of Mexico. The disease is not likely to spread directly from one person to another; therefore, casual contact with an infected person is not a risk for becoming ill.

Vibrio Cholerae Bacterium

Cholera (also called Asiatic cholera) is a disease of the gastrointestinal tract caused by the Vibrio cholerae bacterium. These bacteria are typically ingested by drinking water contaminated by improper sanitation or by eating improperly cooked fish, especially shellfish. Symptoms include diarrhea, abdominal cramps, nausea, vomiting, and dehydration. Death is generally due to the dehydration caused by the illness. When left untreated, Cholera generally has a high mortality rate. Treatment is typically an aggressive rehydration regimen usually delivered intravenously, which continues until the diarrhea ceases.

- * About one million Vibrio cholerae bacteria must be ingested to cause cholera in normally healthy adults, although increased susceptibility may be observed in those with a weakened immune system, individuals with decreased gastric acidity (as from the use of antacids), or those who are malnourished.
- * 1,099,882 cases and 10,453 deaths were reported in the Western Hemisphere between January 1991 and July 1995.
- * On average, one case of cholera is reported in the United States every week. Vibrio cholerae causes disease by producing a toxin that disables the GTPase function of G proteins which are part of G protein-coupled receptors in intestinal cells. This has the effect that the G proteins are locked in the "on position" binding GTP (normally, the G proteins quickly return to "off" by hydrolyzing GTP to GDP). The G proteins then cause adenylate cyclases to produce large amounts of cyclic AMP (cAMP) which results in the loss of fluid and salts across the lining of the gut.

The resulting diarrhea allows the bacterium to spread to other people under unsanitary conditions.

What is the risk for cholera in the United States?

In the United States, cholera was prevalent in the 1800s but has been virtually eliminated by modern sewage and water treatment systems. However, as a result of improved transportation, more persons from the United States travel to parts of Latin America, Africa, or Asia where epidemic cholera is occurring. U.S. travelers to areas with epidemic cholera may be exposed to the cholera bacterium. In addition, travelers may bring contaminated seafood back to the United States; foodborne outbreaks have been caused by contaminated seafood brought into this country by travelers.

Although cholera can be life-threatening, it is easily prevented and treated. In the United States, because of advanced water and sanitation systems, cholera is not a major threat. The last major outbreak of cholera in the United States was in 1911. However, everyone, especially travelers, should be aware of how the disease is transmitted and what can be done to prevent it.

What should travelers do to avoid getting cholera?

The risk for cholera is very low for U.S. travelers visiting areas with epidemic cholera. When simple precautions are observed, contracting the disease is unlikely.

All travelers to areas where cholera has occurred should observe the following recommendations:

- Drink only water that you have boiled or treated with chlorine or iodine. Other safe beverages include tea and coffee made with boiled water and carbonated, bottled beverages with no ice.
- Eat only foods that have been thoroughly cooked and are still hot, or fruit that you have peeled yourself.
- Avoid undercooked or raw fish or shellfish, including ceviche.
- Make sure all vegetables are cooked, avoid salads.
- Avoid foods and beverages from street vendors.
- Do not bring perishable seafood back to the United States.

A simple rule of thumb is "Boil it, cook it, peel it, or forget it."

Treatment

The objective of treatment is to replace fluid and electrolytes lost through diarrhea. Depending on the condition of the person, oral or intravenous fluid will be given. Tetracycline and other antibiotics may shorten the duration of the symptoms.

Note: Tetracycline is usually not prescribed for children until after all the permanent teeth have come in, because it can permanently discolor teeth that are still forming.

The World Health Organization (WHO) has developed an oral rehydration solution that is cheaper and easier to use than the typical intravenous fluid. This solution of sugar and electrolytes is now being used internationally.

Expectations (prognosis)

Severe dehydration can cause death. Given adequate fluids, most people will make a full recovery.

Complications

· Severe dehydration.

Calling your health care provider

Call your health care provider if profuse watery diarrhea develops.

Call your health care provider if signs of dehydration occur, including rapid pulse (heart rate), dry skin, dry mouth, thirst, "glassy" eyes, lethargy, sunken eyes, no tears, reduced or no urine, and unusual sleepiness or tiredness.

Susceptibility

Recent genetic research has determined that a person's susceptibility to cholera and other diarrheas) is affected by their blood type. Those with type O blood are the most susceptible. Those with type AB are the most resistant, virtually immune. Between these two extremes are the A and B blood types, with type A being more resistant than type B.

Carriers of the cystic fibrosis gene are protected from the severe effects of cholera because they don't lose water as quickly. This explains the high incidence of cystic fibrosis among populations which were formerly exposed to cholera.

Epidemic control and preventive measures

When cholera appears in a community it is essential to ensure three things: hygienic disposal of human feces, an adequate supply of safe drinking water, and good food hygiene. Effective food hygiene measures include cooking food thoroughly and eating it while still hot; preventing cooked foods from being contaminated by contact with raw foods, including water and ice, contaminated surfaces or flies; and avoiding raw fruits or vegetables unless they are first peeled. Washing hands after defecation, and particularly before contact with food or drinking water, is equally important.

Routine treatment of a community with antibiotics, or "mass chemoprophylaxis", has no effect on the spread of cholera, nor does restricting travel and trade between countries or between different regions of a country. Setting up a *cordon sanitaire* at frontiers uses personnel and resources that should be devoted to effective control measures, and hampers collaboration between institutions and countries that should unite their efforts to combat cholera.

Limited stocks of two oral cholera vaccines that provide high-level protection for several months against cholera caused by *V. cholerae* O1 have recently become available in a few countries. Both are suitable for use by travelers but they have not yet been used on a large scale for public health purposes. Use of this vaccine to prevent or control cholera outbreaks is not recommended because it may give a false sense of security to vaccinated subjects and to health authorities, who may then neglect more effective measures.

Is a vaccine available to prevent cholera?

At the present time, the manufacture and sale of the only licensed cholera vaccine in the United States (Wyeth-Ayerst) has been discontinued. It has not been recommended for travelers because of the brief and incomplete immunity it offers. No cholera vaccination requirements exist for entry or exit in any country.

Two recently developed vaccines for cholera are licensed and available in other countries (Dukoral®, Biotec AB and Mutacol®, Berna). Both vaccines appear to provide a somewhat better immunity and fewer side-effects than the previously available vaccine. However, neither of these two vaccines are recommended for travelers nor are they available in the United States.

History and spread of epidemic cholera

Cholera has smoldered in an endemic fashion on the Indian subcontinent for centuries. There are references to deaths due to dehydrating diarrhea dating back to Hippocrates and Sanskrit writings. Epidemic cholera was described in 1563 by Garcia del Huerto, a Portuguese physician at Goa, India. The mode of transmission of cholera by water was proven in 1849 by John Snow, a London physician. In 1883, Robert Koch successfully isolated the cholera vibrio from the intestinal discharges of cholera patients and proved conclusively that it was the agent of the disease.

The first long-distance spread of cholera to Europe and the Americas began in 1817 and by the early 20th century, six waves of cholera had spread across the world in devastating epidemic fashion. Since then, until the 1960s, the disease contracted, remaining present only in southern Asia.

El Tor

In 1961, the **"El Tor"** biotype (distinguished from classic biotypes by the production of hemolysins) reemerged to produce a major epidemic in the Philippines and to initiate a seventh global pandemic. Since then this biotype has spread across Asia, the Middle East, Africa, and more recently, parts of Europe.

There are several characteristics of the EI Tor strain that confer upon it a high degree of "epidemic virulence," allowing it to spread across the world as previous strains have done. First, the ratio of cases to carriers is much less than in cholera due to classic biotypes (1: 30-100 for EI Tor vs. 1: 2 - 4 for "classic" biotypes). Second, the duration of carriage after infection is longer for the EI Tor strain than the classic strains. Third, the EI Tor strain survives for longer periods in the extraintestinal environment. Between 1969 and 1974, EI Tor replaced the classic strains in the heartland of endemic cholera, the Ganges River Delta of India.

El Tor broke out explosively in Peru in 1991 (after an absence of cholera there for 100 years), and spread rapidly in Central and South America, with recurrent epidemics in 1992 and 1993. From the onset of the epidemic in January 1991 through September 1, 1994, a total of 1,041,422 cases and 9,642 deaths (overall case-fatality rate: 0.9%) were reported from countries in the Western Hemisphere to the Pan American Health Organization. In 1993, the numbers of reported cases and deaths were 204,543 and 2362, respectively.

So far, the United States has been spared except for imported cases, or clusters of infections from imported food. In the United States during 1993 and 1994, 22 and 47 cholera cases were reported to CDC, respectively. Of these, 65 (94%) were associated with foreign travel. In 1982, in Bangladesh, a classic biotype resurfaced with a new capacity to produce more severe illness, and it rapidly replaced the El Tor strain which was thought to be well-entrenched. This classic strain has not yet produced a major outbreak in any other country.

In December, 1992, a large epidemic of cholera began in Bangladesh, and large numbers of people have been involved. The organism has been characterized as *V. cholerae* **O139** "Bengal". It is derived genetically from the EI Tor pandemic strain but it has changed its antigenic structure such that there is no existing immunity and all ages, even in endemic areas, are susceptible. The epidemic has continued to spread. and *V. cholerae* **O139** has affected at least 11 countries in southern Asia. Specific totals for numbers of *V. cholerae* **O139** cases are unknown because affected countries do not report infections caused by O1 and O139 separately.

Antigenic Variation and LPS Structure in Vibrio cholerae

Antigenic variation plays an important role in the epidemiology and virulence of cholera. The emergence of the Bengal strain, mentioned above, is an example. The flagellar antigens of *V. cholerae* are shared with many water vibrios and therefore are of no use in distinguishing strains causing epidemic cholera. O antigens, however, do distinguish strains of *V. cholerae* into 139 known serotypes. Almost all of these strains of *V. cholerae* are nonvirulent. Until the emergence of the Bengal strain (which is "non-O1") a single serotype, designated O1, has been responsible for epidemic cholera.

However, there are three distinct **O1 biotypes**, named Ogawa, Inaba and Hikojima, and each biotype may display the "classical" or El Tor phenotype. The Bengal strain is a new serological strain with a unique O-antigen which partly explains the lack of residual immunity.

Antigenic Determinants of Vibrio cholerae

Serotype	O Antigens
Ogawa	A, B
Inaba	A, C
Hikojima	A, B, C

Endotoxin is present in *Vibrio cholerae* as in other Gram-negative bacteria. Fewer details of the chemical structure of *Vibrio cholerae* LPS are known than in the case of *E. coli* and *Salmonella typhimurium*, but some unique properties have been described. Most importantly, variations in LPS occur in vivo and in vitro, which may be correlated with reversion in nature of nonepidemic strains to classic epidemic strains and vice versa.


Cholera Toxin

Cholera toxin activates the adenylate cyclase enzyme in cells of the intestinal mucosa leading to increased levels of intracellular cAMP, and the secretion of H_2O , Na^+ , K^+ , Cl^- , and HCO_3^- into the lumen of the small intestine. The effect is dependent on a specific receptor, monosialosyl ganglioside (GM1 ganglioside) present on the surface of intestinal mucosal cells. The bacterium produces an invasin, neuraminidase, during the colonization stage which has the interesting property of degrading gangliosides to the monosialosyl form, which is the specific receptor for the toxin.


The toxin has been characterized and contains **5 binding (B) subunits** of 11,500 daltons, an active **(A1) subunit** of 23,500 daltons, and a **bridging piece (A2)** of 5,500 daltons that links A1 to the 5B subunits. Once it has entered the cell, the A1 subunit enzymatically transfers ADP ribose from NAD to a protein (called Gs or Ns), that regulates the adenylate cyclase system which is located on the inside of the plasma membrane of mammalian cells.

Enzymatically, fragment A1 catalyzes the transfer of the ADP-ribosyl moiety of NAD to a component of the adenylate cyclase system. The process is complex. Adenylate cyclase (AC) is activated normally by a regulatory protein (GS) and GTP; however activation is normally brief because another regulatory protein (Gi), hydrolyzes GTP.

The normal situation is described as follows.



The A1 fragment catalyzes the attachment of ADP-Ribose (ADPR) to the regulatory protein forming Gs-ADPR from which GTP cannot be hydrolyzed. Since GTP hydrolysis is the event that inactivates the adenylate cyclase, the enzyme remains continually activated. This situation can be illustrated as follows.



Thus, the net effect of the toxin is to cause cAMP to be produced at an abnormally high rate which stimulates mucosal cells to pump large amounts of Cl^- into the intestinal contents. H_2O , Na^+ and other electrolytes follow due to the osmotic and electrical gradients caused by the loss of Cl^- .

The lost H_2O and electrolytes in mucosal cells are replaced from the blood. Thus, the toxin-damaged cells become pumps for water and electrolytes, causing the diarrhea, loss of electrolytes, and dehydration that are characteristic of cholera.


Last Word

E. coli produces a toxin, heat labile toxin (LT) that is very similar to the cholera toxin in structure and mode of action. The DNA that encodes the LT toxin is on a plasmid that can be transferred to other *E. coli* strains and probably to other enteric bacteria, as well. Close relationships between the genetic code for LT toxin and the cholera toxin undoubtedly exist but have not been documented as yet.

The genetic information for the toxin in *V. cholerae* is located on the bacterial chromosome. Other bacterial enterotoxins related to cholera toxin have been reported in non-group O *Vibrio* strains and a strain of *Salmonella*.

Enterotoxins, toxins which act in the GI tract, are produced by a wide variety of bacteria.

The family of heat-stable (ST) enterotoxins of *E. coli*, which activate guanylate cyclase, are unrelated to LT toxin or cholera toxin. Other enterotoxins, which elicit cytotoxic effects on intestinal epithelial cells, have been described from *Escherichia*, *Klebsiella*, *Enterobacter*, *Citrobacter*, *Aeromonas*, *Pseudomonas*, *Shigella*, *V. parahaemolyticus*, *Campylobacter*, *Yersinia enterocolitica*, *Bacillus cereus*, *Clostridium perfringens*, *C. difficile*, and *Staphylococcus aureus*.



Mechanism of action of cholera enterotoxin according to Finkelstein in <u>Baron, Chapter 24</u>. Cholera toxin approaches target cell surface. B subunits bind to oligosaccharide of GM1 ganglioside. Conformational alteration of holotoxin occurs, allowing the presentation of the A subunit to cell surface. The A subunit enters the cell. The disulfide bond of the A subunit is reduced by intracellular glutathione, freeing A1 and A2. NAD is hydrolyzed by A1, yielding ADP-ribose and nicotinamide. One of the G proteins of adenylate cyclase is ADP-ribosylated, inhibiting the action of GTPase and locking adenylate cyclase in the "on" mode.

Cholera Section Review

- 1. Cholera, which is derived from a Greek term meaning "Running to the bathroom," is caused by Vibrio cholerae and is the most feared epidemic diarrheal disease because of its severity. Dehydration and death can occur within a matter of minutes of infection.
- A. True
- B. False
- 2. In 1883, Louis Pasteur discovered V cholerae during a cholera outbreak in Egypt.
- A. True
- B. False
- 3. Cholera has been very common in industrialized nations for the last 100 years.
- A. True
- B. False
- 4. Cholera is always life-threatening, it is easily prevented and treated with choromines.
- A. True
- B. False
- 5. In the United States, because of advanced water and sanitation systems, cholera is not a major threat; however, everyone, especially travelers, should be aware of how the disease is transmitted and what can be done to prevent it.
- A. True
- B. False
- 6. The V cholerae organism is a comma-shaped, gram-negative aerobic bacillus whose size varies from 1-3 mm in length by 0.5-0.8 mm in diameter. Its antigenic structure consists of a flagellar H antigen and a somatic O antigen.
- A. True
- B. False
- 7. The differentiation of the latter allows for separation into pathogenic and nonpathogenic strains. V cholerae O1 or O139 are associated with epidemic cholera. V cholerae O1 has 2 major biotypes: classic and El Tor.
- A. True
- B. False
- 8. Currently, El Leche is the predominant cholera pathogen.
- A. True
- B. False
- 9. A person may get cholera by drinking water or eating food contaminated with the cholera bacterium. In an epidemic, the source of the contamination is usually the feces of an infected person. The disease can spread rapidly in areas with inadequate treatment of sewage and drinking water.
- A. True
- B. False

10. The cholera bacterium may also live in the environment in brackish rivers and coastal waters. Shellfish eaten raw have been a source of cholera, and a few persons in the United States have contracted cholera after eating raw or undercooked shellfish from the Gulf of Mexico. The disease is not likely to spread directly from one person to another; therefore, casual contact with an infected person is not a risk for becoming ill. A. True B. False
11. Cholera (also called Asiatic flu) is a disease of the respiratory tract caused by the Vibrio cholerae bacterium. These bacteria are typically ingested by drinking water contaminated by improper sanitation or by eating improperly cooked fish, especially shellfish. A. True B. False
12. About one hundred Vibrio cholerae bacteria must be ingested to cause cholera in normally healthy adults, although increased susceptibility may be observed in those with a strong immune system, individuals with increased gastric acidity, or those who are malnourished. A. True B. False
13. Vibrio cholerae causes disease by producing a toxin that disables the of G proteins which are part of G protein-coupled receptors in intestinal cells. This has the effect that the G proteins are locked in the "on position" binding GTP (normally, the G proteins quickly return to "off" by hydrolyzing GTP to GDP). A. GTPase function B. G proteins C. Bacterium D. Antigenic E. Flagellar antigens
14. The then cause adenylate cyclases to produce large amounts of cyclic AMP (cAMP) which results in the loss of fluid and salts across the lining of the gut. A. GTPase function B. G proteins C. Bacterium D. Antigenic E. Flagellar antigens
15. The resulting diarrhea allows the to spread to other people under unsanitary conditions. A. GTPase function B. G proteins C. Bacterium

D. AntigenicE. Flagellar antigens

16. When cholera appears in a community it is essential to ensure three things: hygienic disposal of human feces, an supply of safe drinking water, and good food hygiene. A. GTPase function B. G proteins C. Bacterium D. Antigenic E. None of the above
17 variation plays an important role in the epidemiology and virulence of cholera. The emergence of the Bengal strain is an example. A. GTPase function B. G proteins C. Bacterium D. Antigenic E. Flagellar antigens
18. The of V. cholerae are shared with many water vibrios and therefore are of no use in distinguishing strains causing epidemic cholera. A. GTPase function B. G proteins C. Bacterium D. Antigenic E. Flagellar antigens 19. O antigens, however, do distinguish strains of V. cholerae into 139 known
A. Serological strain B. Nonvirulent C. Serotypes D. Phenotype E. None of the above
20. Almost all strains of V. cholerae are A. Serological strain B. Nonvirulent C. Serotypes D. Phenotype E. None of the above
21. Until the emergence of the Bengal strain (which is "non-O1") a single serotype, designated O1, has been responsible for epidemic cholera. However, there are three distinct O1 biotypes, named Ogawa, Inaba and Hikojima, and each biotype may display the "classical" or El Tor A. Serological strain B. Nonvirulent C. Serotypes D. Phenotype E. None of the above

22. E. coli produces a toxin, heat labile toxin (LT) that is very similar to the cholera toxin in structure and mode of action. The DNA that encodes the LT is on a plasmid that can be transferred to other E. coli strains and probably to other enteric bacteria, as well. A. Toxin B. In vitro C. Adenylate cyclase enzyme D. Enterotoxins E. None of the above
23. Close relationships between the genetic code for LT and the cholera toxin un-doubtedly exist but have not been documented as yet. A. Toxin B. In vitro C. Adenylate cyclase enzyme D. Enterotoxins E. None of the above
24. The genetic information for the toxin in V. cholerae is located on the bacterial chromo-some. Other bacterial related to cholera toxin have been reported in non-group O Vibrio strains and a strain of Salmonella. A. Toxin B. In vitro C. Adenylate cyclase enzyme D. Enterotoxins E. None of the above
25, toxins which act in the GI tract, are produced by a wide variety of bacteria. The family of heat-stable (ST) enterotoxins of E. coli, which activate guanylate cyclase, are unrelated to LT toxin or cholera toxin. A. Toxin B. In vitro C. Adenylate cyclase enzyme D. Enterotoxins E. None of the above
26. Other, which elicit cytotoxic effects on intestinal epithelial cells, have been described from Escherichia, Klebsiella, Enterobacter, Citrobacter, Aeromonas, Pseudomonas, Shigella, V. parahaemolyticus, Campylobacter, Yersinia enterocolitica, Bacillus cereus, Clostridium perfringens, C. difficile, and Staphylococcus aureus. A. Toxin B. In vitro C. Adenylate cyclase enzyme D. Enterotoxins E. None of the above
1.B, 2.B, 3.B, 4.B, 5.A, 6.A, 7.A, 8.B, 9.A,10.A, 11.B, 12.B, 13.A, 14.B, 15.C, 16.E, 17.D, 18.E, 19.C, 20.B, 21.D,22.A, 23.A, 24.D, 25.D, 26.D

Legionnaires' Disease Legionella Section

Introduction Genus: Legionella Species: pneumophila

The first discovery of bacteria from genus Legionella came in 1976 when an outbreak of pneumonia at an American Legion convention led to 29 deaths. The causative agent, what would come to be known as Legionella pneumophila, was isolated and given its own genus. The organisms classified in this genus are Gram-negative bacteria that are considered intracellular parasites. The disease has two

considered intracellular parasites. The disease has two distinct forms:

- Legionnaires' disease, the more severe form of infection which includes pneumonia, and
- Pontiac fever, a milder illness.

What have been the water sources for Legionnaires' disease?

The major source is water distribution systems of large buildings, including hotels and hospitals. Cooling towers have long been thought to be a major source for

Legionella, but new data suggest that this is an overemphasized mode of transmission. Other sources include mist machines, humidifiers, whirlpool spas, and hot springs. Air conditioners are not a source for Legionnaires' disease. They were suspected to be the source in the original American Legion outbreak in a Philadelphia

hotel, but new data now suggests that the water in the hotel was the actual culprit.

Legionnaire's disease is caused most commonly by the inhalation of small droplets of water or fine aerosol containing Legionella bacteria. Legionella bacteria are naturally found in environmental water sources such as rivers, lakes and ponds and may colonize man-made water systems that include air conditioning systems, humidifiers, cooling tower waters, hot water systems, spas and pools.

How do people contract Legionella?

The most popular theory is that the organism is aerosolized

in water and people inhale the droplets containing *Legionella*. However, new evidence suggests that another way of contracting *Legionella* is more common. "Aspiration" is the most common way that bacteria enter into the lungs to cause pneumonia. Aspiration means choking such that secretions in the mouth get past the choking reflexes and instead of going into the esophagus and stomach, mistakenly, enter the lung. The protective mechanisms to prevent aspiration is defective in patients who smoke or have lung disease. Aspiration now appears to be the most common mode of transmission.

Legionella may multiply to high numbers in cooling towers, evaporative condensers, air washers, humidifiers, hot water heaters, spas, fountains, and plumbing fixtures.

Within one month, Legionella can multiply, in warm water-containing systems, from less than 10 per milliliter to over 1,000 per milliliter of water.

Once high numbers of Legionella have been found, a relatively simple procedure for disinfecting water systems with chlorine and detergent is available. This procedure is not part of a routine maintenance program because equipment may become corroded.

Property owners have been sued for the spread of Legionella, resulting in expensive settlements. Regular monitoring with a battery of DFA monoclonal antibodies for several serogroups and species of Legionella morphologically intact bacteria provides a means for exercising 'reasonable care' to deter potential litigation.

Currently, there are no United States government regulations concerning permissible numbers of legionella in water systems and there are no federal or state certification programs for laboratories that perform legionella testing of environmental samples.

Epifluorescence Microscopy DFA Method

The epifluorescence microscopy DFA method that most labs use was published in the British Journal, Water Research 19:839-848, 1985 "Disinfection of circulating water systems by ultraviolet light and halogenation", R. Gilpin, et al. so we can count viable-but-nonculturable (VBNC) legionella.

Most labs will provide a quantitative epifluorescence microscopic analysis of your cooling tower and potable water samples for 14 serogroups of Legionella pneumophila and 15 other Legionella species (listed below).

Legionella anisa	Legionella bozemanii sg 1 & 2
Legionella dumoffi	Legionella feeleii sg 1 & 2
Legionella gormanii	Legionella hackeliae sg 1 & 2
Legionella jordanis	Legionella longbeachae sg 1& 2
Legionella maceachernii	Legionella micdadei
Legionella oakridgensis	Legionella parisiensis
Legionella pneumophila sg 1-14	Legionella sainthelensi
Legionella santicrucis	Legionella wadsworthii

Heterotrophic bacterial CFU are often inversely proportional to numbers of Legionella in cooling tower samples, in our experience. Routine biocide treatments will not eradicate Legionella bacteria in the environment, only in laboratory studies.

Culture methods are good during outbreaks for biotyping; but culture methods lack sensitivity for routine, quantitative monitoring. Many factors will inhibit growth or identification of legionella on BCYE with or without antimicrobial agents, heat or acid treatment.

Culture methods will not identify non-culturable legionella that can still cause outbreaks (non-culturable, viable legionella have been reported in several peer-reviewed journals). Only DFA tests performed by trained laboratory personnel can identify these legionella.

Direct fluorescent antibody (**DFA**) tests using a battery of monoclonal antibodies provide more useful routine monitoring information than culture methods.

Legionella species of bacteria cause Legionnaire's disease. They are gram negative (but stain poorly), strictly aerobic rods.

The U.S. Environmental Protection Agency and the U.S. Occupational Safety and Health Administration recommend routine maintenance of water-containing equipment. Most State health departments recommend monthly testing for Legionella as part of a routine maintenance program.

As far as we know, there are no federal or state certification programs for laboratories that perform Legionella testing of environmental samples. Therefore, care must be taken when selecting a testing laboratory.

More on Legionnaires' Disease Medical Aspects

Legionnaires' disease is caused by bacteria that belong to the family Legionellaceae. This family now includes 48 species and over 70 serogroups. Approximately half of these species have been implicated in human disease. Legionella pneumophila is responsible for approximately 90% of infections.

Most cases are caused by L. pneumophila, serogroup 1. Legionella species are small (0.3 to 0.9 µm in width and approximately 2 µm in length) faintly staining Gram-negative rods with polar flagella (except L. oakridgensis). They generally appear as small coccobacilli in infected tissue or secretions. They are distinguished from other saccharolytic bacteria by their requirement for L-cysteine and iron salts for primary isolation on solid media and by their unique cellular fatty acids and ubiquinones.

They grow well on buffered charcoal yeast extract agar, but it takes about five days to get sufficient growth. When grown on this medium, Legionella colonies appear off-white in color and circular in shape. Laboratory identification can also include microscopic examination in conjunction with a direct flourescent antibody (DFA) test. Since the initial discovery, many species have been added to the Legionella genus, but only two are within the scope of our discussion.

L. pneumophila and L. micdadei

L. pneumophila

L. pneumophila is the bacterium associated with Legionnaires' disease and Pontiac fever. Respiratory transmission of this organism can lead to infection, which is usually characterized by a gradual onset of flu-like symptoms.

Patients may experience fever, chills, and a dry cough as part of the early symptoms. Patients can develop severe pneumonia which is not responsive to penicillins or aminoglycosides. Legionnaires' disease also has the potential to spread into other organ-systems of the body such as the gastrointestinal tract and the central nervous system. Accordingly, patients with advanced infections may experience diarrhea, nausea, disorientation, and confusion.

The 1200 or so cases of Legionnaires' disease per year in the United States usually involve middle-aged or immunosuppressed individuals. Pontiac fever is also caused by *L. pneumophila* but does not produce the severity of the symptoms found in Legionnaires' disease.

The flu-like symptoms are still seen in Pontiac fever patients, but pneumonia does not develop and infection does not spread beyond the lungs. Most *L. pneomophila* infections are easily treated with erythromycin.

Laboratory Indications

- Beta-lactamase +
- Hippurate hydrolysis +

L. micdadei

L. micdadei is the second most commonly isolated member of *Legionella*. This bacterium can cause the same flu-like symptoms and pneomonia which characterize an *L. pneumophila* infection. Unlike its relative, *L. micdadei* is sensitive to the penicillins because it does not produce beta-lactamase.

Laboratory Indications

- · Beta-lactamase -
- Hippurate hydrolysis -
- Acid fast



Chlorine Dioxide

Prevention and Control

In the prevention and control of Legionnaires disease (legionella) causing microbes, chlorine dioxide has taken an eminent roll. The specific characteristics of the disinfectant make sure CIO² gets the job done where others fail.

Biofilm in the piping can protect legionella from most of the disinfectants.

Chlorine dioxide however removes the biofilm and kills the bacteria, spores and viruses. Other advantages are:

- 1. The bactericidal efficiency is relatively unaffected by pH values between 4 and 10;
- 2. The required contact time for ClO² is lower;
- 3. Chlorine dioxide has better solubility;
- 4. Chlorine dioxide does not react with NH3 or NH4+;
- 5. It destroys THM precursors and increases coagulation;
- 6. CIO² destroys phenols and has no distinct smell.

Hot and cold water systems

The advantages in using chlorine dioxide with hot and cold water systems have already been shown at the descriptions on legionella. There are however more advantages:

- 1. The bactericidal efficiency is relatively unaffected by pH values between 4 and 10;
- 2. Chlorine dioxide is clearly superior to chlorine in the destruction of spores, bacteria's, viruses and other pathogen organisms on an equal residual base (even cryptosporidium and giardia);
- 3. The required contact time for CIO² is lower;
- 4. Chlorine dioxide has better solubility;
- 5. No corrosion associated with high chlorine concentrations. Reduces long term maintenance costs;
- 6. Chlorine dioxide does not react with NH3 or NH4+;
- 7. It destroys THM precursors and increases coagulation;
- 8. CIO² destroys phenols and has no distinct smell;
- 9. It is better at removing iron and magnesia compounds than chlorine, especially complex bounds.

Permission to use this information

Lenntech Water treatment & air purification Holding B.V.

Rotterdamseweg 402 M 2629 HH Delft the Netherlands Tel. +31-15-261.09.00 Fax. +31-15-261.62.89 www.lenntech.com info@lenntech.com



Here is one of TLC's professors Marcos Aparecido Silva Bueno showing microscopic views of commonly found MO's in a classroom setting. Professor Marcos Aparecido Silva Bueno is a world renowned microbiological expert.



Legionella Section Review

 The first discovery of bacteria from genus Legionella came in 1976 when an outbreak of at an American Legion convention led to 29 deaths. Legionnaires' disease Pneumonia Pontiac fever Legionella pneumophila None of the above
2. The causative agent, what would come to be known as
3. The organisms classified in this genus are Gram-negative bacteria that are considered A. Legionnaires' disease B. Pneumonia C. Pontiac fever D. Intracellular parasites E. None of the above
4. Legionnaires' disease is the more severe form of infection which includes pneumonia; is a milder illness. A. Legionnaires' disease B. Pneumonia C. Pontiac fever D. Legionella pneumophila E. None of the above
 5. The major source is water distribution systems of large buildings including hotels and hospitals. Cooling towers have long been thought to be a major source for, but new data suggest that this is an overemphasized mode of transmission. A. Legionnaires' disease B. Pneumonia C. Pontiac fever D. Legionella E. None of the above

springs. Air conditioners are not a source for They were suspected to be the source in the original American Legion outbreak in a Philadelphia hotel, but new data now suggests that the water in the hotel was the actual culprit. A. Legionnaires' disease B. Pneumonia C. Pontiac fever D. Legionella pneumophila E. None of the above
7 is the most common way that bacteria enter into the lungs to cause pneumonia. It means choking such that secretions in the mouth get past the choking reflexes and instead of going into the esophagus and stomach, mistakenly, enter the lung. The protective mechanisms to prevent it is defective in patients who smoke or have lung disease. A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply
8. Legionella may to high numbers in cooling towers, evaporative condensers, air washers, humidifiers, hot water heaters, spas, fountains, and plumbing fixtures. A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply
 9. Legionnaire's disease is caused most commonly by the inhalation of small droplets of water or fine containing Legionella bacteria. A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply
10. Legionella bacteria are in environmental water sources such as rivers, lakes and ponds and may colonise man-made water systems that include air conditioning systems, humidifiers, cooling tower waters, hot water systems, spas and pools. A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply

11. Within one month, Legionella can systems, from less than 10 per milliliter to over 1,000 per A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply	, in warm water-containing milliliter of water.
12. Once high numbers of Legionella have been found, a disinfecting water systems with chlorine and detergent is part of a because equipment may A. Routine maintenance program B. Aspiration C. Aerosol D. Naturally found E. Multiply	available. This procedure is not
13. Currently, there are no United States govern numbers of legionella in water system or state certification programs for laboratories that environmental samples. A. Serogroups B. Permissible C. Ultraviolet light D. Biocide E. Quantitative monitoring	stems and there are no federal
14. The epifluorescence microscopy DFA method that r the British Journal, Water Research 19:839-848, 1985 "I systems by and halogenation", R viable-but-nonculturable (VBNC) legionella. A. Serogroups B. Permissible C. Ultraviolet light D. Biocide E. Quantitative monitoring	Disinfection of circulating water
15. Most labs will provide a micro- tower and potable water samples for 14 serogroups of Le- other Legionella species. A. Serogroups B. Permissible C. Ultraviolet light D. Biocide E. Quantitative epifluorescence	scopic analysis of your cooling gionella pneumophila and 15

16. Culture methods will not identify
17. Direct antibody (DFA) tests using a battery of monoclonal antibodies provide more useful routine monitoring information than culture methods. A. Aerobic rods B. Non-culturable C. Ultraviolet light D. Fluorescent E. Quantitative monitoring
 18. Legionella species of bacteria cause Legionnaire's disease. They are gram negative (but stain poorly), strictly A. Aerobic rods B. Non-culturable C. Ultraviolet light D. Fluorescent E. Quantitative monitoring 19. Legionnaires' disease is caused by bacteria that belong to the family
A. Coccobacilli B. Legionella genus C. Legionellaceae D. Serogroups E. Legionella pneumophila
20. This family now includes 48 species and over 70 Approximately half of these species have been implicated in human disease. A. Coccobacilli B. Legionella genus C. Legionellaceae D. Serogroups E. Legionella pneumophila
21 is responsible for approximately 90% of infections. A. Coccobacilli B. Legionella genus C. Legionellaceae D. Serogroups E. Legionella pneumophila
1.B, 2.D, 3.D, 4.C, 5.D, 6.A, 7.B, 8.E, 9.C, 10.D, 11.E, 12.A, 13.B, 14.C, 15.E, 16.B, 17.D, 18.A, 19.C, 20.D, 21.E

Escherichia Coli Section

Fecal Coliform Bacteria. More information in the Laboratory section.

Fecal coliform bacteria are microscopic organisms that live in the intestines of warm-blooded animals. They also live in the waste material, or feces, excreted from the intestinal tract. When fecal coliform bacteria are present in high numbers in a water sample, it means that the water has received fecal matter from one source or another. Although not necessarily agents of disease, fecal coliform bacteria may indicate the presence of disease-carrying organisms, which live in the same environment as the fecal coliform bacteria.

Reasons for Natural Variation

Unlike the other conventional water quality parameters, fecal coliform bacteria are living organisms. They do not simply mix with the water and float straight downstream. Instead they multiply quickly when conditions are favorable for growth, or die in large numbers when conditions are not. Because bacterial concentrations are dependent on specific conditions for growth, and these conditions change quickly, fecal coliform bacteria counts are not easy to predict. For example, although winter rains may wash more fecal matter from urban areas into a stream, cool water temperatures may cause a major die-off. Exposure to sunlight (with its ultraviolet disinfection properties) may have the same effect, even in the warmer water of summertime.

Expected Impact of Pollution

The primary sources of fecal coliform bacteria to fresh water are wastewater treatment plant discharges, failing septic systems, and animal waste. Bacteria levels do not necessarily decrease as a watershed develops from rural to urban. Instead, urbanization usually generates new sources of bacteria. Farm animal manure and septic systems are replaced by domestic pets and leaking sanitary sewers. In fact, stormwater runoff in urbanized areas has been found to be surprisingly high in fecal coliform bacteria concentrations.

The presence of old, disintegrating storm and sanitary sewers, misplaced sewer pipes, and good breeding conditions are common explanations for the high levels measured.

Coliform Standards (in colonies/100ml)

Drinking water	1FC
Total body contact (swimming)	
Partial body contact (boating)	
Threatened sewage effluent	

*Total coliform (TC) includes bacteria from cold-blooded animals and various soil organisms. According to recent literature, total coliform counts are normally about 10 times higher than fecal coliform (FC) counts.

Indicator Connection Varies

General coliforms, E. Coli, and Enterococcus bacteria are the "indicator" organisms generally measured to assess microbiological quality of water. However, these aren't generally what get people sick. Other bacteria, viruses, and parasites are what we are actually worried about.

Because it is so much more expensive and tedious to do so, actual pathogens are virtually never tested for. Over the course of a professional lifetime pouring over indicator tests, in a context where all standards are based on indicators, water workers tend to forget that the indicators are not the things we actually care about.

What are these indicators? More information in the Laboratory section.

- **General coliforms** indicate that the water has come in contact with plant or animal life. General coliforms are universally present, including in pristine spring water. They are of little concern at low levels, except to indicate the effectiveness of disinfection. Chlorinated water and water from perfectly sealed tube wells is the only water I've tested which had zero general coliforms. At very high levels they indicate there is what amounts to a lot of compost in the water, which could easily include pathogens (Ten thousand general coliform bacteria will get you a beach closure, compared to two or four hundred fecal coliforms, or fifty enterococcus).
- **Fecal coliforms**, particularly E. coli, indicate that there are mammal or bird feces in the water.
- Enterococcus bacteria also indicate that there are feces from warm blooded animals in the water. Enterococcus are a type of fecal streptococci. They are another valuable indicator for determining the amount of fecal contamination of water.

According to studies conducted by the EPA, enterococci have a greater correlation with swimming-associated gastrointestinal illness in both marine and fresh waters than other bacterial indicator organisms, and are less likely to "die off" in saltwater.

The more closely related the animal, the more likely pathogens excreted with their feces can infect us. Human feces are the biggest concern, because anything which infects one human could infect another. There isn't currently a quantitative method for measuring specifically human fecal bacteria (expensive genetic studies can give a presence/absence result). Ingesting a human stranger's feces via contaminated water supply is a classic means for infections to spread rapidly. The more pathogens an individual carries, the more hazardous their feces. Ingesting feces from someone who is not carrying any pathogens may gross you out, but it can't infect you. Infection rates are around 5% in the US, and approach 100% in areas with poor hygiene and contaminated water supplies. Keep in the back of your mind that **the ratio of indicators to actual pathogens is not fixed**. It will always be different, sometimes very different. Whenever you are trying to form a mental map of reality based on water tests, you should include in the application of your water intuition an adjustment factor for your best guess of the ratio between indicators and actual pathogens.

Membrane Filter Total Coliform Technique

The membrane filter total Coliform technique is used at Medina County for drinking water quality testing. The following is a summary of this test. A sampling procedure sheet is given to all sample takers by Medina County.

The samples are taken in sterile 100 mL containers. These containers, when used for chlorinated water samples, have a sodium thiosulfate pill or solution to dechlorinate the sample.

The sample is placed in cold storage after proper sample taking procedures are

followed. (See sample procedures below)

The samples are taken to the laboratory with a chain of custody to assure no tampering of samples can occur.

These samples are logged in at the laboratory.

No longer than 30 hours can lapse between the time of sampling and time of test incubation. (8 hours for heterotrophic, nonpotable 6 hours, others not longer than 24 hours)



All equipment is sterilized by oven and autoclave.

Glassware in oven at 170°C + 10°C with foil (or other suitable wrap) loosely fitting and secured immediately after sterilization.

Filtration units in autoclave at 121°C for 30 minutes.

Use sterile petri dishes, grid, and pads bought from a reliable company – certified, quality assured - test for satisfactory known positive amounts.

Incubators – $35^{\circ}C \pm .5^{\circ}C$ (60% relative humidity)

M-endo medium is prepared and heated to

near boiling removed from heat cooled to 45°C pH adjusted to 7.2 + .2 and immediately dispensed 8ml to plates. Keep refrigerated and discard after 2 weeks.

Plates can be stored in a dated box with expiration date and discarded if not used. No denatured alcohol should be used. Everclear or 95% proof alcohol or absolute methyl may be used for sterilizing forceps by flame.

Procedure:

Counters are alcohol wiped.

Bench sheets are filled out.

Samples are removed from refrigeration.

Sterile wrapped utensils are placed on counters.

Filtration units are placed onto sterile membrane filters by aseptic technique using sterile forceps.

Sterile petri dishes are labeled.

The samples closures are clipped.

The sample is shaken 25 times 1 foot in length within 7 seconds.

100 mL is filtered and rinsed with sterile distilled water 3 times.

The membrane filter is aseptically removed from filter holder.

A sterile padded petri dish is used and the membrane filter is rolled onto the pad making sure no air bubbles form.

The sterile labeled lid is placed on the petri dish.

2 blanks and a known is run with each series of samples.

The samples are placed in the 35° C \pm .5°C incubator stacked no higher than 3 for 22 – 24 hours (Humidity can be maintained by saturated paper towels placed under containers holding petri dishes.)

After 22- 24 hours view the petri dishes under a 10 –15 power magnification with cool white fluorescent light.

Count all colonies that appear pink to dark red with a <u>metallic surface sheen</u> – the sheen may vary in size from a pin head to complete coverage.

Report as Total Coliform per 100 mL.

If no colonies are present report as <1 coliform/100mL.

Anything greater than 1 is over the limit for drinking water for 2 samples taken 24 hours apart. Further investigation may be necessary – follow Standard Methods accordingly.



Photograph and Credits to Mary McPherson AranTM Agua Analytical Laboratory Director.

More on Escherichia coli

Two types of pathogenic Escherichia coli, enteropathogenic E. coli (EPEC) and enterohemorrhagic E. coli (EHEC), cause diarrheal disease by disrupting the intestinal environment through the intimate attachment of the bacteria to the intestinal epithelium.

E. coli O157:H7

E. coli O157:H7 (bacterium) found in human feces. Symptoms vary with type caused gastroenteritis.

Escherichia coli O157:H7 is an emerging cause of foodborne illness. An estimated 73,000 cases of infection and 61 deaths occur in the United States each year. Infection often leads to bloody diarrhea, and occasionally to kidney failure. Most illnesses have been associated with eating undercooked, contaminated ground beef. Person-to-person contact in families and child care centers is also an important mode of transmission. Infection can also occur after drinking raw milk and after swimming in or drinking sewage-contaminated water.

Consumers can prevent *E. coli* O157:H7 infection by thoroughly cooking ground beef, avoiding unpasteurized milk, and washing hands carefully. Because the organism lives in the intestines of healthy cattle, preventive measures on cattle farms and during meat processing are being investigated.

What is Escherichia coli O157:H7?

E. coli O157:H7 is one of hundreds of strains of the bacterium Escherichia coli. Although most strains are harmless and live in the intestines of healthy humans and animals, this strain produces a powerful toxin and can cause severe illness.

E. coli O157:H7 was first recognized as a cause of illness in 1982 during an outbreak of severe bloody diarrhea; the outbreak was traced to contaminated hamburgers. Since then, most infections have come from eating undercooked ground beef.

The combination of letters and numbers in the name of the bacterium refers to the specific markers found on its surface and distinguishes it from other types of *E. coli*.

Currently, there are four recognized classes of enterovirulent *E. coli* (collectively referred to as the EEC group) that cause gastroenteritis in humans. Among these is the enterohemorrhagic (EHEC) strain designated *E. coli* O157:H7. *E. coli* is a normal inhabitant of the intestines of all animals, including humans. When aerobic culture methods are used, *E. coli* is the dominant species found in feces.

Normally *E. coli* serves a useful function in the body by suppressing the growth of harmful bacterial species and by synthesizing appreciable amounts of vitamins. A minority of *E. coli* strains are capable of causing human illness by several different mechanisms. *E. coli* serotype O157:H7 is a rare variety of *E. coli* that produces large quantities of one or more related, potent toxins that cause severe damage to the lining of the intestine. These toxins [verotoxin (VT), shiga-like toxin] are closely related or identical to the toxin produced by *Shigella dysenteriae*.

How does *E. coli* or other fecal coliforms get in the water?

E. coli comes from human and animal wastes. During rainfalls, snow melts, or other types of precipitation, *E. coli* may be washed into creeks, rivers, streams, lakes, or groundwater. When these waters are used as sources of drinking water and the water is not treated or inadequately treated, *E. coli* may end up in drinking water.

How is water treated to protect me from *E. coli*?

The water can be treated using chlorine, ultra-violet light, or ozone, all of which act to kill or inactivate *E. coli*. Systems using surface water sources are required to disinfect to ensure that all bacterial contamination such as *E. coli*. is inactivated. Systems using ground water sources are not required to disinfect, although many of them do.

How does the U.S. Environmental Protection Agency regulate E. coli?

According to EPA regulations, a system that operates at least 60 days per year, and serves 25 people or more or has 15 or more service connections, is regulated as a public water system under the Safe Drinking Water Act. If a system is not a public water system as defined by EPA regulations, it is not regulated under the Safe Drinking Water Act, although it may be regulated by state or local authorities.

Under the Safe Drinking Water Act, the EPA requires public water systems to monitor for coliform bacteria. Systems analyze first for total coliform, because this test is faster to produce results. Any time that a sample is positive for total coliform, the same sample must be analyzed for either fecal coliform or *E. coli*. Both are indicators of contamination with animal waste or human sewage.

The largest public water systems (serving millions of people) must take at least 480 samples per month. Smaller systems must take at least five samples a month unless the state has conducted a sanitary survey – a survey in which a state inspector examines system components and ensures they will protect public health – at the system within the last five years.

Systems serving 25 to 1,000 people typically take one sample per month. Some states reduce this frequency to quarterly for ground water systems if a recent sanitary survey shows that the system is free of sanitary defects. Some types of systems can qualify for annual monitoring. Systems using surface water, rather than ground water, are required to take extra steps to protect against bacterial contamination because surface water sources are more vulnerable to such contamination. At a minimum, all systems using surface waters must disinfect. Disinfection will kill *E. coli* O157:H7.

What can I do to protect myself from E. coli O157:H7 in drinking water?

Approximately 89 percent of Americans are receiving water from community water systems that meet all health-based standards. Your public water system is required to notify you if, for any reason, your drinking water is not safe. If you wish to take extra precautions, you can boil your water for one minute at a rolling boil, longer at higher altitudes.

To find out more information about your water, see the Consumer Confidence Report from your local water supplier or contact your local water supplier directly. You can also obtain information about your local water system on the EPA's website at www.epa.gov/safewater/dwinfo.htm.

Positive Tests

If you draw water from a private well, you can contact your state health department to obtain information on how to have your well tested for total coliforms and *E. coli* contamination. If your well tests positive for *E. coli*, there are several steps that you should take: (1) begin boiling all water intended for consumption, (2) disinfect the well according to procedures recommended by your local health department, and (3) monitor your water quality to make certain that the problem does not recur. If the contamination is a recurring problem, you should investigate the feasibility of drilling a new well or install a point-of-entry disinfection unit, which can use chlorine, ultraviolet light, or ozone.



How is *E. coli* O157:H7 spread?

The organism can be found on a small number of cattle farms and can live in the intestines of healthy cattle. Meat can become contaminated during slaughter, and organisms can be thoroughly mixed into beef when it is ground. Bacteria present on a cow's udders or on equipment may get into raw milk. Eating meat, especially ground beef that has not been cooked sufficiently to kill *E. coli* O157:H7 can cause infection. Contaminated meat looks and smells normal. Although the number of organisms required to cause disease is not known, it is suspected to be very small.

Among other known sources of infection are consumption of sprouts, lettuce, salami, unpasteurized milk and juice, and swimming in or drinking sewage-contaminated water. Bacteria in diarrheal stools of infected persons can be passed from one person to another if hygiene or hand washing habits are inadequate. This is particularly likely among toddlers who are not toilet trained. Family members and playmates of these children are at high risk of becoming infected. Young children typically shed the organism in their feces for a week or two after their illness resolves. Older children rarely carry the organism without symptoms.

What illness does *E. coli* O157:H7 cause?

E. coli O157:H7 infection often causes severe bloody diarrhea and abdominal cramps; sometimes the infection causes non-bloody diarrhea or no symptoms. Usually little or no fever is present, and the illness resolves in 5 to 10 days. Hemorrhagic colitis is the name of the acute disease caused by *E. coli* O157:H7.

In some persons, particularly children under 5 years of age and the elderly, the infection can also cause a complication called hemolytic uremic syndrome, in which the red blood cells are destroyed and the kidneys fail. About 2%-7% of infections lead to this complication. In the United States, hemolytic uremic syndrome is the principal cause of acute kidney failure in children, and most cases of hemolytic uremic syndrome are caused by *E. coli* O157:H7.



How is *E. coli* O157:H7 infection diagnosed?

Infection with *E. coli* O157:H7 is diagnosed by detecting the bacterium in the stool. Most laboratories that culture stool do not test for *E. coli* O157:H7, so it is important to request that the stool specimen be tested on sorbitol-MacConkey (SMAC) agar for this organism. All persons who suddenly have diarrhea with blood should get their stool tested for *E. coli* O157:H7.

How is the illness treated?

Most persons recover without antibiotics or other specific treatment in 5-10 days. There is no evidence that antibiotics improve the course of disease, and it is thought that treatment with some antibiotics may precipitate kidney complications. Antidiarrheal agents, such as loperamide (Imodium), should also be avoided. Hemolytic uremic syndrome is a life-threatening condition usually treated in an intensive care unit. Blood

transfusions and kidney dialysis are often required. With intensive care, the death rate for hemolytic uremic syndrome is 3%-5%.

What are the long-term consequences of infection?

Persons who only have diarrhea usually recover completely. About one-third of persons with hemolytic uremic syndrome have abnormal kidney function many years later, and a few require long-term dialysis. Another 8% of persons with hemolytic uremic syndrome have other lifelong complications, such as high blood pressure, seizures, blindness, paralysis, and the effects of having part of their bowel removed.

What can be done to prevent the infection?

E. coli O157:H7 will continue to be an important public health concern as long as it contaminates meat. Preventive measures may reduce the number of cattle that carry it and the contamination of meat during slaughter and grinding. Research into such prevention measures is just beginning.

What can you do to prevent *E. coli* O157:H7 infection?

Cook all ground beef and hamburger thoroughly. Because ground beef can turn brown before disease-causing bacteria are killed, use a digital instant-read meat thermometer to ensure thorough cooking. Ground beef should be cooked until a thermometer inserted into several parts of the patty, including the thickest part, reads at least 160° F. Persons who cook ground beef without using a thermometer can decrease their risk of illness by not eating ground beef patties that are still pink in the middle.

If you are served an undercooked hamburger or other ground beef product in a restaurant, send it back for further cooking. You may want to ask for a new bun and a clean plate, too. Avoid spreading harmful bacteria in your kitchen. Keep raw meat separate from ready-to-eat foods. Wash hands, counters, and utensils with hot soapy water after they touch raw meat. Never place cooked hamburgers or ground beef on the unwashed plate that held raw patties. Wash meat thermometers in between tests of patties that require further cooking. Drink only pasteurized milk, juice, or cider.

Commercial juice with an extended shelf-life that is sold at room temperature (e.g. juice in cardboard boxes, vacuum sealed juice in glass containers) has been pasteurized, although this is generally not indicated on the label. Juice concentrates are also heated sufficiently to kill pathogens.

Wash fruits and vegetables thoroughly, especially those that will not be cooked. Children under 5 years of age, immunocompromised persons, and the elderly should avoid eating alfalfa sprouts until their safety can be assured. Methods to decontaminate alfalfa seeds and sprouts are being investigated.

Drink municipal water that has been treated with chlorine or other effective disinfectants. Avoid swallowing lake or pool water while swimming. Make sure that persons with diarrhea, especially children, wash their hands carefully with soap after bowel movements to reduce the risk of spreading infection, and that persons wash hands after changing soiled diapers. Anyone with a diarrheal illness should avoid swimming in public pools or lakes, sharing baths with others, and preparing food for others.

References


Buchanan, Robert L. and M. P. Doyle. 1997. *Foodborne Disease Significance of Escherichia coli* 0157:H7 *and other Entrohemorrhagic E. coli*. Food Technology 51: 69-75.

Collins, Janet E. 1997. *Impact of Changing Consumer Lifestyles on the Emergence /Reemergence of Foodborne Pathogens*. Emerging Infectious Diseases 3(4): n. pag. Online. Internet. 23 Feb. 1998. Available: http://www.cdc.gov/ncidod/EID/vol3no4/collins.html.

FSIS: USDA Advises Consumers to Use a Thermometer when Cooking Hamburger. 1997. n. pag. Online. Internet. 26 Feb. 1998. Available: http://www/usda.gov/agency/fsis/thermopr.html.

Kendrick, Kathleen E. and E. A. Wrobel-Woerner. 1997. *Identification of Enteric Bacteria by Using Metabolic Characteristics: An Excerpt from a Bulletin Published by the Centers for Disease Control.* Microbiology 520 AU '97 Laboratory Manual.

Reed, Craig A. and B. Kaplan. 1996. S.O.S. ... HELP prevent E. coli 0157:H7 ... et al! Journal of the American Veterinary Medical Association 209:1213.



Pathogenic *Escherichia coli* MLST Database – Clonal Group Definition

Clonal Group	Class	Reference Strain	Comments
0	N/A	TW08017	Undefined Clonal Group
1	atypical B13	TW08889	cluster within E. coli with Boydii 13 (B13) antigen
2	STEC 13	TW08045	includes STEC R:H18 strain
3	EPEC 3	TW06584	O86:H34 strains from infant diarrhea
4	H51	TW08260	cluster with H51 antigen
5	NT-1	TW08997	no common traits
6	EPEC 1	TW06375	Classical EPEC with H6
7	EPEC 4	TW03173	O119:H6 strains, basal to EPEC 1
8	NT-2	TW08983	no common traits
9	NT-3	TW08990	no common traits
10	Shigella 3	TW08837	Reeves Shigella Group 3 including serotypes F1a, F2a, F3a, F3b, F4, F5a FY
11	EHEC 1	TW08264	O157:H7 and relatives including atypical EPEC O55:H7
12	STEC 12	TW00964	STEC 0145 strains
13	ETEC P	TW00601	ETEC from pigs including O157:H43 clone
14	EHEC 2	TW00970	O26:H11 and O111:H8 and relatives including RDEC
15	NT-4	TW09177	no common traits
16	EIEC 2	TW01095	Invasive strains with O type 29, 124, 152, 164
17	EPEC 2	TW01120	Classical EPEC with H2 antigen
18	STEC 8	TW04909	Serotype O104:H21, includes Montana outbreak strain G5506
19	STEC 9	TW08580	Serotype O174:H8
20	STEC 10	TW07618	Various serotypes
21	STEC 11	TW07613	Serotype O111:H28
22	EIEC 1	TW01116	Invasive strains with O types 29, 124, 152, 164
23	ECOR A	TW00073	Includes atypical EPEC O111:H12
24	STEC 3	TW08023	Serotype O121:H19
25	Shigella 1	TW07572	Reeves Shigella Group 1 including serotypes F6, D3, D6, D7, D9, D11, D12, B1, B2, B3, B4, B8, B10, B14, B15, B18
26	Shigella 2a	TW02615	Reeves Shigella Group 2 including serotypes D2, D4, B9, B15
27	Shigella 2b	TW01151	Reeves Shigella Group 2 including serotypes B5, B11, B17
28	EPEC 5	TW04892	Atypical EPEC with serotype O111:H9, includes Finland outbreak strain 921
29	Sonnei	TW01150	Shigella sonnei
30	STEC 2	TW01391	Includes serotype O113:H21 and ECOR 30
31	NT-5	TW00676	no common traits
32	NT-6	TW07795	no common traits

33	NT-13	TW09011	no common traits
34	STEC 1	TW01393	STEC with H21 antigen including B2F1
35	SMEC 1	TW02268	Extraintestinal strains including RS218
36	NT-7	TW07608	no common traits
37	Sand 2	TW09237	Environmental E. coli clone
38	UTI 1	TW08018	Uropathogens including CFT073
39	STEC 4	TW07995	Mix of serotypes O121, O116, also includes an EIEC 1758-70
40	NT-8	TW09214	no common traits
41	STEC 14	TW08574	Serotype O174:H2
42	NT-7	TW07612	no common traits
43	STEC	TW01670	serotype O8:H19
44	NT-10	TW10091	no comment traits
45	NT-11	TW08942	no comment traits
46	NT-12	TW09069	no comment traits



Quebec Colony Counter

Escherichia Coli Section Review


Although most strains are	_ is one of hundreds of strains of the bacterium Escherichia coli. e harmless and live in the intestines of healthy humans and animals, this ul toxin and can cause severe illness.
severe bloody diarrhea; t	was first recognized as a cause of illness in 1982 during an outbreak of he outbreak was traced to contaminated ham-burgers. Since then, most neating undercooked ground beef.
enterohemorrhagic E. col	nic, enteropathogenic E. coli (EPEC) and li (EHEC), cause diarrheal disease by disrupting the intestinal intimate attachment of the bacteria to the intestinal epithelium.
 gastroenteritis. A. Enterohemorrhagic B. Escherichia coli C. E. coli O157:H7 D. Bacterium E. None of the above 	_ (bacterium) found in human feces. Symptoms vary with type caused
cases of infection and 61	57:H7 is an emerging cause of foodborne illness. An estimated 73,000 deaths occur in the United States each year. Infection often leads to asionally to kidney failure.

Sp A. B. C. D.	The combination of letters and numbers in the name of the refers to the ecific markers found on its surface and distinguishes it from other types of E. coli. Enterohemorrhagic Escherichia coli E. coli O157:H7 Bacterium None of the above
the (EI A. B. C. D.	Currently, there are four recognized classes of enterovirulent E. coli (collectively referred to as e EEC group) that cause gastroenteritis in humans. Among these is the
A. B. C. D.	E. coli is a normal inhabitant of the intestines of all animals, including humans. When are used, E. coli is the dominant species found in feces. Enterohemorrhagic Escherichia coli E. coli O157:H7 Bacterium None of the above
inc A. B. C. D.	are bacteria that are associated with human or animal wastes. They ually live in human or animal intestinal tracts, and their presence in drinking water is a strong lication of recent sewage or animal waste contamination. Safe Drinking Water Act Vitamins Shigella dysenteriae Fecal coliforms Chlorine
wh dis gro A. B. C. D.	The water can be treated using, ultra-violet light, or ozone, all of sich act to kill or inactivate E. coli. Systems using surface water sources are required to sinfect to ensure that all bacterial contamination is inactivated, such as E. coli. Systems using bund water sources are not required to disinfect, although many of them do. Safe Drinking Water Act Vitamins Shigella dysenteriae Fecal coliforms Chlorine

 11. According to EPA regulations, a system that operates at least 60 days per year, and serves 25 people or more or has 15 or more service connections, is regulated as a public water system under the A. Safe Drinking Water Act B. Vitamins C. Shigella dysenteriae D. Fecal coliforms E. Chlorine
12. If a system is not a public water system as defined by EPA regulations, it is not regulated under the, although it may be regulated by state or local authorities. A. Safe Drinking Water Act B. Vitamins C. Shigella dysenteriae D. Fecal coliforms E. Chlorine
13. Under the, the EPA requires public water systems to monitor for coliform bacteria. Systems analyze first for total coliform, because this test is faster to produce results. Any time that a sample is positive for total coliform, the same sample must be analyzed for either fecal coliform or E. coli. Both are indicators of contamination with animal waste or human sewage. A. Safe Drinking Water Act B. Vitamins C. Shigella dysenteriae D. Fecal coliforms E. Chlorine
14. The largest public water systems (serving millions of people) must take at least 50 samples per month. Smaller systems must take at least 20 samples a month unless the state has conducted a sanitary survey – a survey in which a state inspector examines system components and ensures they will protect public health – at the system within the last year. A. True B. False
15. Systems serving 25 to 1,000 people typically take one sample per month. Some states reduce this frequency to quarterly for ground water systems if a recent sanitary survey shows that the system is free of sanitary defects. Some types of systems can qualify for annual monitoring. Systems using surface water, rather than ground water, are required to take extra steps to protect against bacterial contamination because surface water sources are more vulnerable to such contamination. At a minimum, all systems using surface waters must disinfect. A. True B. False
16. Disinfection will kill E. coli O157:H7.A. TrueB. False

 $1.C,\, 2.C,\, 3.B,\, 4.C,\, 5.B,\, 6.D,\, 7.A,\, 8.E,\, 9.D,\, 10.E,\, 11.A,\, 12.A,\, 13.A,\, 14.B,\, 15.A,\, 16.A$

HELD CONSERVE OUR WATER!!





More Safe Drinking Water Act Terms

Community Water System (CWS). A public water system that serves at least 15 service connections used by year-round residents of the area served by the system or regularly serves at least 25 year-round residents.

Class V Underground Injection Control (UIC) Rule. A rule under development covering wells not included in Class I, II, III or IV in which non-hazardous fluids are injected into or above underground sources of drinking water.

Contamination Source Inventory. The process of identifying and inventorying contaminant sources within delineated source water protection areas through recording existing data, describing sources within the source water protection area, targeting likely sources for further investigation, collecting and interpreting new information on existing or potential sources through surveys, and verifying accuracy and reliability of the information gathered.

Cryptosporidium A protozoan associated with the disease cryptosporidiosis in humans. The disease can be transmitted through ingestion of drinking water, person-to-person contact or other exposure routes. Cryptosporidiosis may cause acute diarrhea, abdominal pain, vomiting and fever that last 1-2 weeks in healthy adults, but may be chronic or fatal in immuno-compromised people.

Drinking Water State Revolving Fund (DWSRF). Under section 1452 of the SDWA, the EPA awards capitalization grants to states to develop drinking water revolving loan funds to help finance drinking water system infrastructure improvements, source water protection, to enhance operations and management of drinking water systems and other activities to encourage public water system compliance and protection of public health.

Exposure Contact between a person and a chemical. Exposures are calculated as the amount of chemical available for absorption by a person.

Giardia lamblia A protozoan, which can survive in water for 1 to 3 months, associated with the disease giardiasis. Ingestion of this protozoan in contaminated drinking water, exposure from person-to-person contact or other exposure routes may cause giardiasis. The symptoms of this gastrointestinal disease may persist for weeks or months and include diarrhea, fatigue and cramps.

Ground Water Disinfection Rule (GWDR). Under section 107 of the SDWA Amendments of 1996, the statute reads, ". . . the Administrator shall also promulgate national primary drinking water regulations requiring disinfection as a treatment technique for all public water systems, including surface water systems, and as necessary, ground water systems."

Maximum Contaminant Level (MCL). In the SDWA, an MCL is defined as "the maximum permissible level of a contaminant in water which is delivered to any user of a public water system." MCLs are enforceable standards.

Maximum Contaminant Level Goal (MCLG). The maximum level of a contaminant in drinking water at which no known or anticipated adverse effect on the health effect of persons would occur and which allows for an adequate margin of safety. MCLGs are non-enforceable public health goals.

Nephelolometric Turbidity Units (NTU). A unit of measure used to describe the turbidity of water. Turbidity is the cloudiness in water.

Nitrates. Inorganic compounds which can enter water supplies from fertilizer runoff and sanitary wastewater discharges. Nitrates in drinking water are associated with methemoglobanemia, or blue baby syndrome, which results from interferences in the blood's ability to carry oxygen.

Non-Community Water System (NCWS). A public water system which is not a community water system. There are two types of NCWSs: transient and non-transient.

Organics. Chemical molecules containing carbon and other elements such as hydrogen. Organic contaminants of concern to drinking water include chlorohydrocarbons, pesticides and others.

Phase I Contaminants. The Phase I Rule became effective January 9, 1989. This rule, also called the Volatile Organic Chemical Rule, or VOC Rule, set water quality standards for 8 VOCs and required all community and non-transient, non-community water systems to monitor for, and if necessary, treat their supplies for these chemicals. The 8 VOCs regulated under this rule are: benzene, carbon tetrachloride, para-dichlorobenzene, trichloroethylene, vinyl chloride, 1,1, 2-trichlorethane, 1,1-dichloroethylene and 1,2-dichlorothane.

Per capita. Per person; generally used in expressions of water use, gallons per capita per day (gpcd).

Point-of-Use Water Treatment. Refers to devices used in the home or office on a specific tap to provide additional drinking water treatment.

Point-of-Entry Water Treatment. Refers to devices used in the home where water pipes enter to provide additional treatment of drinking water used throughout the home.

Primacy State. State that has the responsibility for ensuring a law is implemented, and has the authority to enforce the law and related regulations. State has adopted rules at least as stringent as federal regulations and has been granted primary enforcement responsibility.

Radionuclides. Elements that undergo a process of natural decay. As radionuclides decay, they emit radiation in the form of alpha or beta particles and gamma photons. Radiation can cause adverse health effects, such as cancer, so limits are placed on radionuclide concentrations in drinking water.

Risk. The potential for harm to people exposed to chemicals. In order for there to be risk, there must be hazard and there must be exposure.

SDWA - The Safe Drinking Water Act. The Safe Drinking Water Act was first passed in 1974 and established the basic requirements under which the nation's public water supplies were regulated. The EPA is responsible for setting the national drinking water regulations while individual states are responsible for ensuring public water systems under their jurisdiction are complying with the regulations. The SDWA was amended in 1986 and again in 1996.

Significant Potential Source of Contamination. A facility or activity that stores, uses, or produces chemicals or elements, and that has the potential to release contaminants identified in a state program (contaminants with MCLs plus any others a state considers a health threat) within a source water protection area in an amount which could contribute significantly to the concentration of the contaminants in the source waters of the public water supply.

Sole Source Aquifer (SSA) Designation. The surface area above a sole source aquifer and its recharge area.

Source Water Protection Area (SWPA). The area delineated by the state for a PWS or including numerous PWSs, whether the source is ground water or surface water or both, as part of the state SWAP approved by the EPA under section 1453 of the SDWA.

Sub watershed. A topographic boundary that is the perimeter of the catchment area of a tributary of a stream.

State Source Water Petition Program. A state program implemented in accordance with the statutory language at section 1454 of the SDWA to establish local voluntary incentive-based partnerships for SWP and remediation.

State Management Plan (SMP) Program. A state management plan under FIFRA required by the EPA to allow states (i.e. states, tribes and U.S. territories) the flexibility to design and implement approaches to manage the use of certain pesticides to protect ground water.

Surface Water Treatment Rule (SWTR). The rule specifies maximum contaminant level goals for *Giardia lamblia*, viruses and *Legionella*, and promulgated filtration and disinfection requirements for public water systems using surface water sources, or by ground water sources under the direct influence of surface water. The regulations also specify water quality, treatment and watershed protection criteria under which filtration may be avoided.

Susceptibility Analysis. An analysis to determine, with a clear understanding of where the significant potential sources of contamination are located, the susceptibility of the public water systems in the source water protection area to contamination from these sources. This analysis will assist the state in determining which potential sources of contamination are "significant."

To the Extent Practical. States must inventory sources of contamination to the extent they have the technology and resources to complete an inventory for a Source Water Protection Area delineated as described in the guidance. All information sources may be used, particularly previous federal and state inventories of sources.

Transient/Non-Transient, Non-Community Water Systems (T/NT,NCWS). Water systems which are non-community systems: transient systems serve 25 non-resident persons per day for 6 months or less per year. Transient non-community systems typically are restaurants, hotels, large stores, etc. Non-transient systems regularly serve at least 25 of the same non-resident persons per day for more than 6 months per year. These systems typically are schools, offices, churches, factories, etc.

Treatment Technique. A specific treatment method required by the EPA to be used to control the level of a contaminant in drinking water. In specific cases where the EPA has determined it is not technically or economically feasible to establish an MCL, the EPA can instead specify a treatment technique. A treatment technique is an enforceable procedure or level of technical performance which public water systems must follow to ensure control of a contaminant.

Total Coliform. Bacteria that are used as indicators of fecal contaminants in drinking water.

Toxicity. The property of a chemical to harm people who come into contact with it.


Underground Injection Control (UIC) Program. The program is designed to prevent underground injection which endangers drinking water sources. The program applies to injection well owners and operators on federal facilities, Native American lands, and on all U.S. land and territories.

Watershed. A topographic boundary area that is the perimeter of the catchment area of a stream.

Watershed Approach. A watershed approach is a coordinating framework for environmental management that focuses public and private sector efforts to address the highest priority problems within hydrologically-defined geographic areas, taking into consideration both ground and surface water flow.

Watershed Area. A topographic area that is within a line drawn connecting the highest points uphill of a drinking water intake, from which overland flow drains to the intake.

Wellhead Protection Area (WHPA). The surface and subsurface area surrounding a well or well field, supplying a PWS, through which contaminants are reasonably likely to move toward and reach such water well or well field.



Groundwater and Wells

A well can be easily contaminated if it is not properly constructed or if toxic materials are released into the well. Toxic material spilled or dumped near a well can leach into the aquifer and contaminate the groundwater drawn from that well.

Contaminated wells used for drinking water are especially dangerous. Wells can be tested to see what chemicals may be present in dangerous quantities.

Groundwater is withdrawn from wells to provide water for everything from drinking water for the home and business to water for irrigating crops. When water is pumped from the ground, the dynamics of groundwater flow change in response to this withdrawal.

Groundwater flows slowly through water-bearing formations (aquifers) at different rates. In some places, where groundwater has dissolved limestone to form caverns and large openings, its rate of flow can be relatively fast, but this is exceptional.




Well with a mineral oil sealed vertical turbine pump.

Many terms are used to describe the nature and extent of the groundwater resource. The level below which all the spaces are filled with water is called the *water table*. Above the water table lies the *unsaturated zone*. Here the spaces in the rock and soil contain both air and water. Water in this zone is called *soil moisture*. The entire region below the water table is called the *saturated zone* and water in this saturated zone is called *groundwater*.

Fractured aquifers are rocks in which the groundwater moves through cracks, joints or fractures in otherwise solid rock. Examples of fractured aquifers include granite and basalt. Limestones are often fractured aquifers, but here the cracks and fractures may be enlarged by solution, forming large channels or even caverns.

Limestone terrain where solution has been very active is termed *karst*. Porous media such as sandstone may become so highly cemented or recrystalized that all of the original space is filled. In this case, the rock is no longer a porous medium. However, if it contains cracks it can still act as a fractured aguifer.

Most of the aquifers of importance to us are unconsolidated porous media such as sand and gravel. Some very porous materials are not permeable. Clay, for instance, has many spaces between its grains, but the spaces are not large enough to permit free movement of water.




Groundwater usually flows downhill with the slope of the water table. Like surface water, groundwater flows toward, and eventually drains into, streams, rivers, lakes and the oceans. Groundwater flow in the aquifer's underlying surface drainage basins, however, does not always mirror the flow of water on the surface. Therefore, groundwater may move in different directions below the ground than the water flowing on the surface.

Unconfined aquifers are those bounded by the water table. Some aquifers, however, lie beneath layers of impermeable materials. These are called **confined aquifers**, or sometimes **artesian aquifers**.

A well in such an aquifer is called an *artesian well*. The water in these wells, rises higher than the top of the aquifer because of confining pressure. If the water level rises above the ground surface a *flowing artesian well* occurs. The *piezometric surface* is the level to which the water in an artesian aquifer will rise.

Water Sources

Before we discuss the types of treatment it is easier to first understand how the source of water arrives.



Water Cycle Terms

- ➤ **Precipitation:** The process by which atmospheric moisture falls onto the land or water surface as rain, snow, hail or other forms of moisture.
- ➤ **Infiltration:** The gradual flow or movement of water into and through the pores of the soil.
- **Evaporation:** The process by which the water or other liquids become a gas.
- **Condensation:** The collection of the evaporated water in the atmosphere.
- **Runoff:** Water that drains from a saturated or impermeable surface into stream channels or other surface water areas. Most lakes and rivers are formed this way.
- **Transpiration**: Moisture that will come from plants as a byproduct of photosynthesis.

Once the precipitation begins, water is no longer in its purest form. Water will be collected as surface supplies or circulate to form in the ground. As it becomes rain or snow it may be polluted with organisms, organic compounds and inorganic compounds. Because of this, we must treat the water for human consumption.

Where Does Drinking Water Come From?

A clean, constant supply of drinking water is essential to every community. People in large cities frequently drink water comes from surface water sources, such as lakes, rivers, and reservoirs. Sometimes these sources are close to the community. Other times, drinking water suppliers get their water from sources many miles away. In either case, when you think about where your drinking water comes from, it's important to consider not just the part of the river or lake you can see, but the entire watershed.

The watershed is the land area over which water flows into the river, lake or reservoir. In rural areas, people are more likely to drink ground water pumped from a well. These wells tap into aquifers--the natural reservoirs under the earth's surface--that may be only a few miles wide or may span the borders of many states. As with surface water, it is important to remember that activities many miles away from you may affect the quality of ground water. Your annual drinking water quality report will tell you where your water supplier gets your water.

Your water will normally contain chlorine and varying amounts of dissolved minerals including calcium, magnesium, sodium, chlorides, sulfates and bicarbonates, depending on its source. It is also not uncommon to find traces of iron, manganese, copper, aluminum, nitrates, insecticides and herbicides, although the maximum amounts of all these substances are strictly limited by the regulations. These are usually referred to as *'contaminants'*.

Most of these substances are of natural origin and are picked up as water passes around the water cycle. Some are present due to the treatment processes which are used make the water suitable for drinking and cooking. The water will also contain a relatively low level of bacteria, which are not generally a risk to health.

Insecticides and herbicides (sometimes referred to as pesticides)

Are widely used in agriculture, industry, leisure facilities and gardens to control weeds and insect pests and may enter the water cycle in many ways.

Aluminium

Aluminium salts are added during water treatment to remove color and suspended solids.

Lead

Lead does not usually occur naturally in water supplies but is derived from lead distribution and domestic pipework and fittings. Although water suppliers have removed most of the original lead piping from the main distribution system, many older properties still have lead service pipes and internal lead pipework. The pipework (including the service pipe) within the boundary of the property is the responsibility of the owner of the property, not the water supplier.

Water Hardness

There are two types of hardness: temporary and permanent. Temporary hardness comes out of the water when it's heated and is deposited as scale and fur on kettles, coffee makers and taps and appears as a scum or film on tea and coffee. Permanent hardness is unaffected by heating.

Cysts

These are associated with the reproductive stages of parasitic micro-organisms (protozoans) which can cause acute diarrhea type illnesses; they come from farm animals, wild animals and people. They are very resistant to normal disinfection processes but can be removed by advanced filtration processes installed in water treatment works. Cysts are rarely present in the public water supply.

Particles and rust

These come from the gradual breakdown of the lining of concrete or iron main water pipes or from sediment which has accumulated over the years and is disturbed in some way.

Source Water Quality

Groundwater

Groundwater contributes most of all of the water that is derived from wells or springs. It occurs in the natural open spaces (i.e., fractures or pore spaces between grains) in sediments and rocks below the surface. Groundwater is distributed fairly evenly throughout the crust of the earth but is not readily accessible or extractable everywhere. More than 90 percent of the world's total supply of drinkable water is groundwater.

Groundwater originates as precipitation that sinks into the ground. Some of this water percolates down to the water table (shallowest surface of the groundwater) and recharges the aquifer. For shallow wells (i.e., less than 50-75 feet), the recharge area is often the immediate vicinity around the well or "wellhead." Some wells are recharged in areas that may be a great distance from the well itself.

If the downward percolating precipitation encounters any source of contamination, at the surface or below it, the water may dissolve some of that contaminant and carry it to the aquifer. Groundwater moves from areas where the water table is high to where the water table is low. Consequently, a contaminant may enter the aquifer some distance upgradient from you and still move toward your well. When a well is pumping, it lowers the water table in the immediate vicinity of the well, increasing the tendency for water to move toward the well.

Contaminants can be lumped into three categories: microorganisms (bacteria, viruses, Giardia, etc.), inorganic chemicals (nitrate, arsenic, metals, etc.) and organic chemicals (solvents, fuels, pesticides, etc.).

Although it is common practice to associate contamination with highly visible features such as landfills, gas stations, industry or agriculture, potential contaminants are widespread and often come from common everyday activities as well, such as septic systems, lawn and garden chemicals, pesticides applied to highway right-of-ways, stormwater runoff, auto repair shops, beauty shops, dry cleaners, medical institutions, photo processing labs, etc. Importantly, it takes only a very small amount of some chemicals in drinking water to raise health concerns. For example, one gallon of pure trichloroethylene, a common solvent, will contaminate approximately 292 million gallons of water.

Wellhead Protection

Wellhead protection refers to programs designed to maintain the quality of groundwater used as public drinking water sources, by managing the land uses around the wellfield. The theory is that management of land use around the well, and over water moving (underground) toward the well, will help to minimize damage to subsurface water supplies by spills or improper use of chemicals. The concept usually includes several stages.

Wellhead Protection Sequence

- > Build a community-wide planning team.
- > Delineate geologically the protection zone.
- Perform a contaminant use inventory.
- Create a management plan for the protection zone.
- Plan for the future.

Water Rights

Appropriative: Acquired water rights for exclusive use.

Prescriptive: Rights based upon legal prescription or long use or custom.

Riparian: Water rights because property is adjacent to a river or surface water.

Surface Water

Some of the rainwater will be immediately impounded in lakes and reservoirs, and some will collect as runoff to form streams and rivers that will then flow into the ocean. Water is known as the universal solvent because most substances that come in contact with it will dissolve. What's the difference between lakes and reservoirs? Reservoirs are lakes with man-made dams.

Surface water is usually contaminated and unsafe to drink. Depending on the region, some lakes and rivers receive discharge from sewer facilities or defective septic tanks. Runoff could produce mud, leaves, decayed vegetation, and human and animal refuse. The discharge from industry could increase volatile organic compounds. Some lakes and reservoirs may experience seasonal turnover. Changes in the dissolved oxygen, algae, temperature, suspended solids, turbidity and carbon dioxide will change because of biological activities.

Quality of Water

Here are the different classifications or the way water characteristics change as it passes on the surface and below the ground:

Physical characteristics such as taste, odor, temperature and turbidity; this is how the consumer judges how well the provider is treating the water.

Chemical characteristics are the elements found that are considered alkali, metals and non-metals such as fluoride, sulfides or acids. The consumer relates it to scaling of faucets or staining.

Biological characteristics are the presence of living or dead organisms. This will also interact with the chemical

composition of the water. The consumer can become sick or complain about hydrogen sulfide odors, the rotten egg smell.

Radiological characteristics are the result of water coming in contact with radioactive materials. This could be associated with atomic energy.

Managing Water Quality at the Source

Depending on the region, source water may have several restrictions of use as part of a Water Shed Management Plan. In some areas it may be restricted from recreational use, discharge or runoff from agriculture, industrial and wastewater discharge.

Another aspect of quality control is aquatic plants. The ecological balance in lakes and reservoirs plays a natural part in purifying and sustaining the life of the lake. For example, algae and rooted aquatic plants are essential in the food chain of fish and birds.

Algae growth is the result of photosynthesis. Algae growth is supplied by the energy of the sun. As algae absorbs this energy, it converts carbon dioxide to oxygen. This creates **aerobic** conditions that supply fish with oxygen. Without sun light, the algae would consume oxygen and release carbon dioxide. The lack of dissolved oxygen in water is known as **anaerobic** conditions. Certain vegetation removes the excess nutrients that would promote the growth of algae. Too much algae will imbalance the lake and kill fish

Most treatment plant upsets such as taste, odor, color and filter clogging is due to algae. The type of algae determines the problem it will cause: for instance slime, corrosion, color and toxicity. Algae can be controlled by using chemicals such as copper sulfate. Depending on federal regulations and the amount of copper found naturally in water, operators have used potassium permanganate, powdered activated carbon (**PAC**), grander activated carbon (**GAC**) and chlorine. The Power of Hydrogen (PH) and alkalinity of the water will determine how these chemicals will react. Most systems no longer use chlorine because it reacts with the organics in the water to form trihalomethanes.

Disinfection Byproducts (DBPS)

Disinfection byproducts form when disinfectants added to drinking water to kill germs react with naturally-occurring organic matter in water.

Total Trihalomethanes. Some people who drink water containing trihalomethanes in excess of EPA's standard over many years may experience problems with their liver, kidneys or central nervous systems, and may have an increased risk of developing cancer.




Water Treatment

For thousands of years, people have treated water intended for drinking to remove particles of solid matter, reduce health risks and improve aesthetic qualities such as appearance, odor, color and taste. As early as 2000 B.C., medical lore of India advised, "Impure water should be purified by being boiled over a fire, or being heated in the sun, or by dipping a heated iron into it, or it may be purified by filtration through sand and coarse gravel and then allowed to cool."

The treatment needs of a water system are likely to differ depending on whether the system uses a groundwater or surface water source. Common surface water contaminants include turbidity, microbiological contaminants (*Giardia*, viruses and bacteria) and low levels of a large number of organic chemicals. Groundwater contaminants include naturally occurring inorganic chemicals (such as arsenic, fluoride, radium, radon and nitrate) and a number of volatile organic chemicals (**VOCs**) that have recently been detected in localized areas.

When selecting among the different treatment options, the water supplier must consider a number of factors. These include regulatory requirements, characteristics of the raw water, configuration of the existing system, cost, operating requirements and future needs of the service area.



HORIZONTAL BASIN CLARIFIER

Preliminary Treatment

Most lakes and reservoirs are not free of logs, tree limbs, sticks, gravel, sand, rocks, weeds, leaves and trash. If not removed, these will cause problems to the treatment plant's pumps and equipment. The best way to protect the plant is screening.

Bar screens are made of straight steel bars at the intake of the plant. The spacing of the horizontal bars will rank the size. Wire mesh screens are woven stainless steel material and the opening of the fabric is narrow. Both require manual cleaning.

Mechanical bar screens vary in size and use some type of raking mechanism that travels horizontally down the bars to scrape the debris off. The type of screening used depends on the raw water and the size of the intake.



Mechanical bar screen



Non-automated bar screen


Pre-Treatment

Once the water passes the bar screens, sand and grit are still present. This will damage plant equipment and pipes, so it must be removed. This is generally done with either rectangular or round shaped clarifiers. Sedimentation basins are also used after the flocculation process.



Clarifiers

Let's first look at the components of a rectangular clarifier. Most are designed with scrapers on the bottom to move the settled sludge to one or more hoppers at the influent end of the tank. It could have a screw conveyor or traveling bridge used to collect the sludge. The most common is a chain and flight collector. Most designs will have baffles to prevent short-circuiting and scum from entering the effluent.




Flights and Chains

The most important thing to consider is the sludge and scum collection mechanism known as the "flights and chains". They move the settled sludge to the hopper in the clarifier for return and they also remove the scum from the surface of the clarifier. The flights are usually wood or nonmetallic flights mounted on parallel chains. The motor shaft is connected through a gear reducer to a shaft which turns the drive chain. The drive chain turns the drive sprockets and the head shafts. The shafts can be located overhead or below.

Some clarifiers may not have scum removal equipment so the configuration of the shaft may vary. As the flights travel across the bottom of the clarifier, wearing shoes are used to protect the flights. The shoes are usually metal and travel across a metal track.

To prevent damage due to overloads, a shear pin is used. The shear pin holds the gear solidly on the shaft so that no slippage occurs. Remember, the gear moves the drive chain. If a heavy load is put on the sludge collector system, then the shear pin should break. This means the gear would simply slide around the shaft and movement of the drive chain would stop.



Rectangular basin flights and chains.



Rectangular basin flights and chains.



Circular Clarifiers


In some circular or square tanks, rotating scrapers are used. The diagram below shows a typical circular clarifier.


The most common type has a center pier or column. The major mechanic parts of the clarifier are the drive unit, the sludge collector mechanism and the scum removal system.

Circular clarifier and collector mechanism.→



CLARIFIER






Backwashing filters



Conventional Treatment Overview & Direct Filtration

Improving the clarity of surface water has always presented a challenge because source quality varies. Traditional treatments rely on expensive, construction-intensive processes with lengthy times.



Suspended particles carry an electrical charge which causes them to repel one another. The conventional process uses alum (aluminum sulfate) and cationic polymer to neutralize the charge. That allows suspended particles to clump together to form more easily filtered particles.

Alum combines with alkalinity in the raw water to form a white precipitate that neutralizes suspended particles' electrical charge and forms a base for coagulating those particles. Conventional technology uses a 30 to 50 mg/L alum dosage to form a large **floc** that requires extensive retention time to permit settling.

Traditional filter systems use graded silica sand filter media. Since the sand grains all have about the same density, larger grains lay toward the bottom of the filter bed and finer grains lay at the top of the filter bed. As a result, filtration occurs only within the first few inches of the finer grains at the top of the bed.

A depth filter has four layers of filtration media, each of different size and density. Light, coarse material lies at the top of the filter bed. The media become progressively finer and denser in the lower layers. Larger suspended particles are removed by the upper layers while smaller particles are removed in the lower layers.


Particles are trapped throughout the bed, not in just the top few inches. That allows a depth filter to run substantially longer and use less backwash water than a traditional sand filter.

As suspended particles accumulate in a filter bed, the pressure drop through the filter increases. When the pressure difference between filter inlet and outlet increases by 5 - 10 psi (34 to 68 kPa) from the beginning of the cycle, the filter should be reconditioned. Operating beyond this pressure drop increases the chance of fouling - called "mud-balling" - within the filter.

The reconditioning cycle consists of an up-flow backwash followed by a down-flow rinse. Backwash is an up-flow operation, at about 14 gpm per square foot (34m/hr) of filter bed area that lasts about 10 minutes. Turbidity washes out of the filter bed as the filter media particles scour one another. The down-flow rinse settles the bed before the filter returns to service. Fast rinse lasts about 5 to 10 minutes.

Chemical pretreatment is often used to enhance filter performance, particularly when turbidity includes fine colloidal particles. Suspended particles are usually electrically charged. Feeding chemicals such as alum, ferric chloride or a cationic polymer neutralizes the charge, allowing the particles to cling to one another and to the filter media.

Chemical pretreatment may increase filtered water clarity, measured in NTU, by 90% compared with filtration alone. If an operator is present to make adjustments for variations in the raw water, filtered water clarity improvements in the range of 93 to 95% are achievable.



Small water treatment package plant Coagulation, flocculation and filtration all within a 20 foot area.

Package Plants

Representing a slight modification of conventional filtration technology, package plants are usually built in a factory, mounted on skids and transported virtually assembled to the operation site. These are appropriate for small community systems where full water treatment is desired, but without the construction costs and space requirements associated with separately constructed sedimentation basins, filter beds, clear wells, etc. In addition to the conventional filtration processes, package plants are found as two types: tube-type clarifiers and adsorption clarifiers.

Direct Filtration Plant vs. Conventional Plant

The only difference is that the sedimentation process or step is omitted from the Direct Filtration plant.

Conventional Treatment

This is the most prevalent form of water treatment technology in use today. This filtration process employs a combination of physical and chemical processes in order to achieve maximum effectiveness, as follows:

Coagulation

At the water treatment plant, aluminum sulfate, commonly called alum, is added to the water in the "flash mix" to cause microscopic impurities in the water to clump together. The alum and the water are mixed rapidly by the flash mixer. The resulting larger particles will be removed by filtration.

Coagulation is the process of joining together particles in water to help remove organic matter. When solid matter is too small to be removed by a depth filter, the fine particles must be coagulated, or "stuck together" to form larger particles which can be filtered. This is achieved through the use of coagulant chemicals. Coagulant chemicals are required since colloidal particles by themselves have the tendency to stay suspended in water and not settle out. This is primarily due to a negative charge on the surface of the particles. All matter has a residual surface charge to a certain degree. But since colloidal particles are so small, their charge per volume is significant. Therefore, the like charges on the particles repel each other and stay suspended in water.

Coagulant chemicals such as **alum** (Aluminum Sulfate) work by neutralizing the negative charge, which allows the particles to come together. Other coagulants are called **cationic polymers**, which can be thought of as positively charged strings that attract the particles to them and in the process, form a larger particle. Also, new chemicals have been developed which combine the properties of alum-type coagulants and cationic polymers. Which chemical is used depends on the application and will usually be chosen by the engineer designing the water treatment system.

Aluminum Sulfate is the most widely used coagulant in water treatment. Coagulation is necessary to meet the current regulations for almost all potable water plants using surface water. Aluminum Sulfate is also excellent for removing nutrients such as phosphorous in wastewater treatment. Liquid Aluminum Sulfate is a 48.86% solution. Large microorganisms, including algae and amoebic cysts, are readily removed by coagulation and filtration. Bacterial removals of 99% are also achievable. More than 98% of poliovirus type I was removed by conventional coagulation and filtration. Several recent studies have shown that bacteria and viral agents are attached to organic and inorganic particulates. Hence, removal of these particulates by conventional coagulation and filtration is a major component of effective treatment for the removal of pathogens.

Flocculation

The process of bringing together destabilized or coagulated particles to form larger masses which can be settled and/or filtered out of the water being treated. In this process, which follows the rapid mixing, the chemically treated water is sent into a basin where the suspended particles can collide, agglomerate (stick together) and form heavier particles called **floc**. Gentle agitation of the water and appropriate detention times (the length of time water remains in the basin) help facilitate this process. The water is slowly mixed in contact chambers allowing the coagulated particles, now called **floc**, to become larger and stronger. As these floc particles mix in the water, bacteria and other microorganisms are caught in the floc structure.

Pre-Sedimentation

Depending on the quality of the source water, some plants have pre-sedimentation.

- A. To allow larger particles time to settle in a reservoir or lake (sand, heavy silt) reducing solid removal loads.
- B. Provides an equalization basin which evens out fluctuations in concentrations of suspended solids.

Sedimentation Basin Zones

- A. Inlet Zone
- B. Settling Zone
- C. Sludge Zone
- D. Outlet Zone

Shapes for a Sedimentation Basin

- A. Rectangular Basins
- B. Circular Basins
- C. Square Basins
- D. Double deck Basins



Sedimentation

The process of suspended solid particles settling out (going to the bottom of the vessel) in water.

Following flocculation, a sedimentation step may be used. During sedimentation, the velocity of the water is decreased so that the suspended material, including flocculated particles, can settle out by gravity. Once settled, the particles combine to form a sludge that is later removed from the bottom of the basin.

Filtration Types

A water treatment step used to remove turbidity, dissolved organics, odor, taste and color.

The water flows by gravity through large filters of anthracite coal, silica sand, garnet and gravel. The floc particles are removed in these filters. The rate of filtration can be adjusted to meet water consumption needs.

Filters for suspended particle removal can also be made of graded sand, granular synthetic material, screens of various materials and fabrics.

The most widely used are rapid-sand filters in tanks. In these units, gravity holds the material in place and the flow is downward. The filter is periodically cleaned by a reversal of flow and the discharge of back-flushed water into a drain.

Cartridge filters made of fabric, paper or plastic material are also common and are often much smaller and cheaper, as well as disposable. Filters are available in several ratings, depending on the size of particles to be removed. Activated carbon filters, described earlier, will also remove turbidity, but would not be recommended for that purpose only.

With most of the larger particles settled out, the water now goes to the filtration process. At a rate of between 2 and 10 gpm per square foot, the water is filtered through an approximate 36" bed of graded sand. Anthracite coal or activated carbon may also be included in the sand to improve the filtration process, especially for the removal of organic contaminants, taste and odor problems.

The filtration process removes the following types of particles

- Silts and clay
- Colloids
- Biological forms
- Floc

Four desirable characteristics of filter media

- A. Good hydraulic characteristics (permeable)
- B. Does not react with substances in the water (inert and easy to clean)
- C. Hard and durable
- D. Free of impurities and insoluble in water

Evaluation of overall filtration process performance should be conducted on a routine basis, at least once per day. Poor chemical treatment can often result in either early turbidity breakthrough or rapid head loss buildup. The more uniform the media, the slower head loss buildup.

All water treatment plants that use surface water are governed by the U.S. EPA's Surface Water Treatment Rules (**SWTR**).

Declining Rate Filters

The flow rate will vary with head loss. Each filter operates at the same rate, but can have a variable water level. This system requires an effluent control structure (weir) to provide adequate media submergence.

Detention Time

The actual time required for a small amount of water to pass through a sedimentation basin at a given rate of flow, or the calculated time required for a small amount of liquid to pass through a tank at a given rate of flow.



Detention Time = (Basin Volume, Gallons) (24 Hours/day)
Flow, Gallons/day

Disinfection

Chlorine is added to the water at the flash mix for pre-disinfection. The chlorine kills or inactivates harmful microorganisms. Chlorine is added again after filtration for post-disinfection.

Jar Testing (More information later in manual)

Jar testing traditionally has been done on a routine basis in most water treatment plants to control the coagulant dose. Much more information, however, can be obtained with only a small modification in the conventional method of jar testing. It is the quickest and most economical way to obtain good reliable data on the many variables which affect the treatment process. These include:

- Determination of most effective coagulant.
- > Determination of optimum coagulation pH for the various coagulants.
- Evaluation of most effective polymers.
- Optimum point of application of polymers in the treatment train.
- > Optimum sequence of application of coagulants, polymers, and pH adjustment chemicals.
- Best flocculation time.

pН

Expression of a basic or acid condition of a liquid. The range is from 0-14, zero being the most acid and 14 being the most alkaline. A pH of 7 is considered to be neutral. Most natural water has a pH between 6.0 and 8.5.

Caustic

NaOH (also called Sodium Hydroxide) is a strong chemical used in the treatment process to neutralize acidity, increase alkalinity or raise the pH value.

Polymer

A type of chemical when combined with other types of coagulants aid in binding small suspended particles to larger particles to help in the settling and filtering processes.

Post-Chlorine

Where the water is chlorinated to make sure it holds a residual in the distribution system.

Pre-Chlorine

Where the raw water is dosed with a large concentration of chlorine.

Prechlorination:

The addition of chlorine before the filtration process will help:

- Control algae and slime growth
- Control mud ball formation
- > Improve coagulation
- > Precipate iron

Raw Turbidity

The turbidity of the water coming to the treatment plant from the raw water source.

Settled Solids

Solids that have been removed from the raw water by the coagulation and settling processes.

Hydrofluosilicic Acid

(H2SiF6) a clear, fuming corrosive liquid with a pH ranging from 1 to 1.5. Used in water treatment to fluoridate drinking water.

Corrosion Control

The pH of the water is adjusted with sodium carbonate, commonly called soda ash. Soda ash is fed into the water after filtration.

Zinc Orthophosphate

A chemical used to coat the pipes in the distribution system to inhibit corrosion.

Taste and Odor Control

PAC Powered Activated Charcoal is occasionally added for taste and odor control. PAC is added to the flash mix.

Water Quality

Water testing is conducted throughout the treatment process. Items like turbidity, pH and chlorine residual are monitored and recorded continuously. Some items are tested several times per day, some once per quarter and others once per year.



Sampling

Collect the water sample at least 6 inches

under the surface by plunging the container mouth down into the water and turning the mouth towards the current by dragging the container slowly horizontal. Care should be taken not to disturb the bottom of the water source or along the sides so as not to stir up any settled solids. This would create erroneous results.

Chemical Feed and Rapid Mix

Chemicals are added to the water in order to improve the subsequent treatment processes. These may include pH adjusters and coagulants. Coagulants are chemicals, such as alum, that neutralize positive or negative charges on small particles, allowing them to stick together and form larger particles that are more easily removed by sedimentation (**settling**) or filtration. A variety of devices, such as baffles, static mixers, impellers and in-line sprays, can be used to mix the water and distribute the chemicals evenly.

Short-Circuiting

Short-Circuiting is a condition that occurs in tanks or basins when some of the water travels faster than the rest of the flowing water. This is usually undesirable since it may result in shorter contact, reaction or settling times in comparison with the presumed detention times.

Tube Settlers

This modification of the conventional process contains many metal **tubes** that are placed in the sedimentation basin, or clarifier. These tubes are approximately 1 inch deep and 36 inches long, split-hexagonal shape and installed at an angle of 60 degrees or less.

These tubes provide for a very large surface area upon which particles may settle as the water flows upward. The slope of the tubes facilitates gravity settling of the solids to the bottom of the basin, where they can be collected and removed. The large surface settling area also means that adequate clarification can be obtained with detention times of 15 minutes or less. As with conventional treatment, this sedimentation step is followed by filtration through mixed media.

Adsorption Clarifiers

The concept of the adsorption clarifier package plant was developed in the early 1980s. This technology uses an up-flow clarifier with low-density plastic bead media, usually held in place by a screen. This adsorption media is designed to enhance the sedimentation/clarification process by combining flocculation and sedimentation into one step. In this step, turbidity is reduced by adsorption of the coagulated and flocculated solids onto the adsorption media and onto the solids already adsorbed onto the media.

Air scouring cleans adsorption clarifiers followed by water flushing. Cleaning of this type of clarifier is initiated more often than filter backwashing because the clarifier removes more solids. As with the tube-settler type of package plant, the sedimentation/clarification process is followed by mixed-media filtration and disinfection to complete the water treatment.

Clearwell

The final step in the conventional filtration process, the clearwell provides temporary storage for the treated water. The two main purposes for this storage are to have filtered water available for backwashing the filter and to provide detention time (or contact time) for the chlorine (or other disinfectant) to kill any microorganisms that may remain in the water.



Public education is a key to a water treatment facility's image. This is a difficult balance because of new security rules that are in place since 9/11 made it difficult to open the plant to tours.

EPA Filter Backwash Rule

The EPA has finalized the Long Term I Enhanced Surface Water Treatment Rule and Filter Backwash Rule (**LT1FBR**) to increase protection of finished drinking water supplies from contamination by *Cryptosporidium* and other microbial pathogens.

This rule will apply to public water systems using surface water or ground water under the direct influence of surface water. This rule proposes to extend protections against *Cryptosporidium* and other disease-causing microbes to the 11,500 small water systems which serve fewer than 10,000 people annually. This rule also establishes filter backwash requirements for certain public water systems of all sizes. The filter backwash requirements will reduce the potential risks associated with recycling contaminants removed during the filtration process.

Background

The **SDWA** requires the EPA to set enforceable standards to protect public health from contaminants which may occur in drinking water. The EPA has determined that the presence of microbiological contaminants is a health concern. If finished water supplies contain microbiological contaminants, disease outbreaks may result. Disease symptoms may include diarrhea, cramps, nausea, possibly jaundice and headaches and fatigue. The EPA has set enforceable drinking water treatment requirements to reduce the risk of waterborne disease outbreaks. Treatment technologies such as filtration and disinfection can remove or inactivate microbiological contaminants.

Physical removal is critical to the control of *Cryptosporidium* because it is highly resistant to standard disinfection practice. Cryptosporidiosis may manifest itself as a severe infection that can last several weeks and may cause the death of individuals with compromised immune systems. In 1993, *Cryptosporidium* caused over 400,000 people in Milwaukee to experience intestinal illness. More than 4,000 were hospitalized, and at least 50 deaths were attributed to the cryptosporidiosis outbreak.

The 1996 Amendments to SDWA require the EPA to promulgate an Interim Enhanced Surface Water Treatment Rule (IESWTR) and a Stage I Disinfection Byproducts Rule (announced in December 1998). The IESWTR set the first drinking water standards to control *Cryptosporidium* in large water systems, by establishing filtration and monitoring requirements for systems serving more than 10,000 people each. The LT1FBR proposal builds on those standards by extending the requirements to small systems.

The 1996 Amendments also require the EPA to promulgate a Long Term I Enhanced Surface Water Treatment Rule (for systems serving less than 10,000 people) by November, 2000 ((1412(b)(2)(C)) and also required the EPA to "promulgate a regulation to govern the recycling of filter backwash water within the treatment process of a public water system" by August, 2000 ((1412(b)(14)). The current proposed rule includes provisions addressing both of these requirements.

What will the LT1FBR require?

The LT1FBR provisions will apply to public water systems using surface water or ground water under the direct influence of surface water systems.

LT1 Provisions - Apply to systems serving fewer than 10,000 people, and fall into the three following categories:

> Turbidity


- Conventional and direct filtration systems must comply with specific combined filter effluent turbidity requirements.
- Conventional and direct filtration systems must comply with individual filter turbidity requirements.

> Disinfection Benchmarking

- Public water systems will be required to develop a disinfection profile unless they
 perform applicability monitoring which demonstrates their disinfection byproduct
 levels are less than 80% of the maximum contaminant levels.
- If a system considers making a significant change to their disinfection practice they must develop a disinfection benchmark and receive State approval for implementing the change.

> Other Requirements

- Finished water reservoirs for which construction begins after the effective date of the rule must be covered.
- Unfiltered systems must comply with updated watershed control requirements that add Cryptosporidium as a pathogen of concern.
- FBR Provisions Apply to all systems which recycle regardless of population served:
 - Recycle systems will be required to return spent filter backwash water, thickener supernatant, and liquids from the dewatering process prior to the point of primary coagulant addition unless the State specifies an alternative location.
 - Direct filtration systems recycling to the treatment process must provide detailed recycle treatment information to the State, which may require that modifications to the recycle practice be made.
 - Conventional systems that practice direct recycle, employ 20 or fewer filters to meet production requirements during a selected month, and recycle spent filter backwash water, thickener supernatant, and/or liquids from the dewatering process within the treatment process must perform a one month, one-time recycle self-assessment. The self-assessment requires hydraulic flow monitoring and that certain data be reported to the State, which may require that modifications to the recycle practice be made to protect public health.



SLOW SAND FILTER

The Jar Test

Jar testing, to determine the proper coagulant dosage, continues to be one of the most effective tools available to surface water plant operators. Finished water quality, cost of production, length of filter runs, and overall filter life all depend on the proper application of chemicals to the raw water entering the treatment plant.

Before You Start

The jar test, as with any coagulant test, will only provide accurate results when properly performed.

Because the jar test is intended to simulate conditions in your plant, developing the proper procedure is very important. Take time to observe what happens to the raw water in your plant after the chemicals have been added, then simulate this during the jar test. THE RPM OF THE STIRRER AND THE MINUTES TO COMPLETE THE TEST DEPEND ON CONDITIONS IN YOUR PLANT. If, for instance, your plant does not have a static or flash mixer, starting the test at high rpm would provide misleading results. This rule applies to flocculator speed, length of settling time and floc development. Again, operate the jar test to simulate conditions in your plant.

1. Scope

1.1 This practice covers a general procedure for the evaluation of a treatment to reduce dissolved, suspended, colloidal, and non-settleable matter from water by chemical coagulation-flocculation, followed by gravity settling. The procedure may be used to evaluate color, turbidity, and hardness reduction.

1.2 The practice provides a systematic evaluation of the variables normally encountered

in the coagulation-flocculation process.

1.3 This standard does not purport to address the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

Terms

Flocculation - Agglomeration of particles into groups, thereby increasing the effective diameter.



Coagulation - A chemical technique directed toward destabilization of colloidal particles.

Turbidity - A measure of the presence of suspended solid material.

Turbidity

Particles less than or about 1 to 10 μm in diameter (primarily colloidal particles) will not settle out by gravitational forces, therefore making them very difficult to remove. These particles are the primary contributors to the turbidity of the raw water causing it to be *cloudy.* The most important factor(s) contributing to the stability of colloidal particles is not their mass, but their surface properties.

This idea can be better understood by relating the colloidal particles' large surface area to their small volume (S/V) ratio resulting from their very small size. In order to remove these small particles, we must either filter the water or somehow incorporate gravitational forces such that these particles will settle out. In order to have gravity affect these particles, we must somehow make them larger, somehow have them come together (conglomerate); in other words somehow make them stick together, thereby increasing their size and mass.

The two primary forces that control whether or not colloidal particles will agglomerate are:

Repulsive Force

$$\zeta = \frac{4\pi q d}{D}$$

An electrostatic force called the Zeta Potential -

Where:

ζ = Zeta Potential

q = charge per unit area of the particle

d = thickness of the layer surrounding the shear surface through which the charge is effective

D = dielectric constant of the liquid

Attractive Force


Force due to van der Waals forces

asymmetrical arrangement of the nucleus.

Van der Waals forces are weak forces based on a polar characteristic induced by neighboring molecules. When two or more nonpolar molecules, such as He, Ar, H₂, are in close proximity, the nucleus of each atom will weakly attract electrons in the counter atom resulting, at least momentarily, in an

This force, van der Waals force, is inversely proportional to the sixth power of the distance (1/d⁶) between the particles.

As can clearly be seen from this relationship, decay of this force occurs exponentially with distance.



Ways to Measure Turbidity

- Jackson Candle Test
- Secchi Disk a black and white disk divided like a pie in 4 quadrants about 6" in diameter.
- ➤ Turbidimeter Light is passed through a sample. A sensitive photomultiplier tube at a 90° angle from the incident light beam detects the light scattered by the particles in the sample. The photomultiplier tube converts the light energy into an electrical signal, which is amplified and displayed on the instrument.
- Units Nephelometric Turbidity Unit (NTU) or Formazin Turbidity Unit (FTU).

How to Treat Turbidity

Supercharge the water supply - By supercharging the water supply momentarily with a positive charge, we can upset the charge effect of the particle enough to reduce the Zeta potential (repulsive force) thereby allowing van der Waals forces (attractive forces) to take over.

By introducing aluminum (AI_3^+) into the water in the form of Alum $(AI_2(SO_4)_3 \bullet nH_20)$ we can accomplish the supercharging of the water. This is the *coagulation* part of the coagulation/flocculation process; flocculation follows coagulation. During the *flocculation* process the particles join together to form flocs; the larger the flocs, the faster they will settle within a clarifier.

Other chemical coagulants used are Ferric Chloride and Ferrous Sulfate. Alum works best in the pH range of natural waters, 5.0 - 7.5. Ferric Chloride works best at lower pH values, down to pH 4.5. Ferrous Sulfate works well through a range of pH values, 4.5 to 9.5.

During the coagulation process, charged hydroxy-metallic complexes are formed momentarily (i.e. $Al(OH)_2^+$, $Al(OH)_2^{1+}$ etc). These complexes are charged highly positive, therefore upsetting the stable negative charge of the target particles, thereby momentarily displacing the water layer surrounding the charged particle. This upset decreases the distance "d," in turn decreasing the Zeta potential.

The particles are then able to get close enough together for van der Waals forces to take over and the particles begin to flocculate. The chemical reaction continues until the aluminum ions (AI_3^+) reach their final form, $AI(OH)_3$ (s), and settle out (note – the flocculated particles settle out separately from the precipitated $AI(OH)_3$ (s)).

If too much alum is added, then the opposite effect occurs--the particles form sub complexes with the Al⁺³ and gain a positive charge about them, and the particles restabilize.

The final key to obtaining good flocs is the added energy put into the system by way of rotating paddles in the flocculator tanks. By **pushing** (adding energy) the particles together we can aid in the flocculation process forming larger flocs. It is important to understand that too much energy (i.e. rotating the paddles too fast), would cause the particles to shear (breakup), thereby reducing the size of the particles and increasing the settling time in the clarifier.

Key Equations

$$AI_2(SO_4)_3 \bullet 14.3H_2O + 6H_2O \rightarrow 2AI(OH)_3(s) + 14.3H_2O + 3H_2SO_4$$
(2)

$$AI_2(SO_4)_3 \bullet 14.3H_2O + 6Na(HCO_3) \rightarrow 2AI(OH)_3(s) + 3Na_2SO_4 + 14.3H_2O + 6CO_2$$
(3)

$$AI_2(SO_4)_3 \bullet 14.3H_2O + 6Na(OH) \rightarrow 2AI(OH)_3(s) + 3Na_2SO_4 + 14.3H_2O$$
(4)

Apparatus

- Jar Test Apparatus
- > 6 1500 mL Beakers
- > pH meter
- Pipettes
- Conductivity Meter
- > Turbidimeter

Procedure

- Make up a 10-g/L solution of alum.
- Make up a 0.1 N solution of NaOH (buffer). (Na⁺¹ = 23 mg/mmol, O⁻² = 16 mg/mmol, H⁺ = 1 mg/mmol)
- Fill each of the six 1500 mL beakers with one-liter of river water.
- Measure the temperature and conductivity.
- Measure the initial pH
- Add alum and NaOH solutions in equal portions as specified by instructor.
- Mixing protocol:
 - o rapid mix 1 minute (100 rpm)
 - o slow mix 15 minutes (20 rpm)
 - o off, settling 30 minutes
- Measure final turbidity. Take the sample from the center, about 2" down for each one liter sample. Be careful not to disturb the flocs that have settled.
- Measure final pH



Information to be Recorded

Initial Turbidity = ? NTU
- 0.1 N

Alum - g/L

Buffer

Beaker	Alum (ml)	Buffer (ml)	Turbidity (NTU)	pH-Before	pH-After	Temp. °C



Several different types of chemical and various storage tanks are found in water treatment facilities. Always have an MSDS nearby.



Preparing Polymers for the Jar Test

A successful Jar Test is very reliant upon the proper preparation of the polymers being tested. Dilution technique *(make down)* is especially critical, since it involves compactly coiled large molecules in emulsions, prior to activation. The polymer must be uncoiled to provide maximum contact with the colloidal particles to be flocculated. If the following procedures are not followed, the Jar Test results will be very unreliable.

Required equipment:


- > 250 mL bottles with lids.
- ➤ High speed hand mixer (for emulsion polymers).
- > Syringes (1cc, 5cc, 10cc).
- > 250 and 500 mL beakers.
- Water (it is recommended that the make-down water from the plant be used).
- Graduated cylinder (100 mL).


Emulsion polymers (Prepare 1.0% solution.)

- > Add 198 mL of water to a beaker.
- Insert Braun mixer into water and begin mixing.
- Using a syringe, inject 2 mL of neat polymer into vortex.
- Mix for 20 seconds. Do not exceed 20 seconds!
- ➤ Allow dilute polymer to age for at least 20 minutes, but preferably overnight.
- Prepare 0.1% solution.
- Add 180 mL of water to 250 mL bottle.
- Add 20 mL of 1.0% polymer solution.
- Shake vigorously for at least one minute.

Solution polymers and Inorganics (Prepare a 1.0% solution.)

- Add 198 mL of water to 250 mL bottle.
- > Using a syringe, add 2 mL of neat product to bottle.
- > Shake vigorously for at least 1 minute.
- Prepare 0.1% solution.
- > Add 180 mL to 250 mL bottle.
- Add 20 mL of 1 % solution.
- Shake vigorously for at least one minute.





The jar test is an attempt to duplicate plant conditions.



Potassium Permanganate Jar Test

Potassium Permanganate has been used for a number of years in both water and wastewater treatment. KMnO₄ is a strong oxidizer which can be used to destroy many organic compounds of both the natural and man-made origin. KMnO₄ is also used to oxidize iron, manganese and sulfide compounds and other taste and odor producing substances usually due to the presence of very small quantities of secretions given off by microscopic algae, which develop on the surface waters and on beds of lakes and rivers under certain conditions of temperature and chemical composition.

KMnO₄ must be used with caution, as this material produces an intense purple color when mixed with water. As the permanganate ion is reduced during its reaction with compounds it oxidizes, it changes color from purple, to yellow or brown. The final product formed is manganese dioxide (MnO₂), an insoluble precipitate that can be removed by sedimentation and filtration.

All KMnO4 applied must be converted to manganese dioxide (MnO₂) prior to filtration. If it is not all converted and is still purple or pink, it will pass through the filter into the clearwell or distribution system. This may cause the customer to find pink tap water, or

the reaction may continue in the system and the same conditions as exist with naturally occurring manganese may cause staining of the plumbing fixtures.

Stock Solutions

(Strong Stock Solution)

5 grams potassium permanganate dissolved in 500 ml distilled water.

(Test Stock Solution)

4 ml strong stock solution thoroughly mixed in 100 ml distilled water.

Each 5 ml of the test stock solution added to a 2000 ml sample equals 1 mg/l.



Jar Testing Example

If you have a six position stirrer:

Using a graduated cylinder, measure 2000 ml of the sample to be tested into each of the six beakers. Dose each beaker to simulate plant practices in pre-treatment, pH adjustment, coagulant,- etc. Do not add carbon or chlorine. Using a graduated pipette, dose each beaker with the test stock solution in the following manner.

Jar#	KMnO₄ml	KMnO₄ mg/l	Color
1	0.50	0.10	no pink
2	0.75	0.15	no pink
3	1.00	0.20	no pink
4	1.25	0.25	no pink
5	1.50	0.30	pink
6	1.75	0.35	pink

Stir the beakers to simulate the turbulence where the KMnO₄ is to be added and observe the color change.

As the iron and manganese begin to oxidize, the sample will turn varying shades of brown, indicating the presence of oxidized iron and or manganese. Samples which retain a brown or yellow color indicate that the oxidation process is incomplete and will require a higher dosage of KMnO₄.

The end point has been reached when a pink color is observed and remains for at least 10 minutes. In the preceding table a pink color first developed in beaker number 5 which had been dosed with 1.5 ml/ 0.3 mg/l. If the first jar test does not produce the correct color change, continue with increased dosages.

When applying potassium permanganate to raw water, care must be taken not to bring pink water to the filter unless you have *greensand*. Also, permanganate generally reacts more quickly at pH levels above 7.0.

Quick Test

A quick way to check the success of a KMnO₄ application is by adding 1.25 ml of the test stock solution to 1000 ml finished water. If the sample turns brown there is iron or manganese remaining in the finished water. If the sample remains pink, oxidation is complete.

With proper application, potassium permanganate is an extremely useful chemical treatment.

As well as being a strong oxidizer for iron and manganese. KMnO₄ used as a disinfectant in pre-treatment could help control the formation of trihalomethanes by allowing chlorine to be added later in the treatment process or after filtration. Its usefulness also extends to algae control, as well as many taste/odor problems.

To calculate the dosage of KMnO₄ for iron and manganese removal, here is the formula to use.

 $KMnO_4$ Dose, mg/I = 0.6(iron, mg/I) + 2.0(Manganese, mg/I)

Example:

Calculate the KMnO₄ dose in mg/l for a water with 0.4 of iron. The manganese concentration

is 1.2 mg/l.

Known Unknown

Iron, $mg/I = 0.4 mg/I KMnO_4 Dose, mg/I$ Manganese, mg/l = 1.2 mg/l Calculate the KMnO₄ dose in mg/l. KMnO₄ Dose. ma/l = 0.6(Iron.mg/l) 2.0(Manganese, mg/l)

= 0.6(0.4 mg/l) + 2.0(1.2 mg/l)

= 2.64 mg/l



Note: The calculated 2.64 mg/l KMnO₄ dose is the minimum dose. This dose assumes there are no oxidizable compounds in the raw water. Therefore, the actual dose may be higher. Jar testing should be done to determine the required dose.

198

1	IA H Li	IIA 4 Be]	Periodic Table of Elements									IIIA 5 B	IVA 6 C	7 N	VIA 8	VIIA 9 F	0 2 He 10 Ne
3	Na	Mg	IIIB	IVB	٧В	VIB	VIIB	_	— VII –		IB	IB	ĂΙ	si	P	16 S	CI	År
4	19 K	20 Ca	21 Sc	22 Ti	23 Y	24 Cr	25 Mn	²⁶ Fe	27 Co	28 Ni	29 Cu	30 Z n	31 Ga	32 Ge	33 As	34 Se	35 Br	36 Kr
5	37 Rb	38 Sr	39 Y	40 Zr	41 Nb	42 M o	43 Tc	44 Ru	45 Rh	⁴⁶ Pd	47 Ag	48 Cd	49 In	50 S n	51 Sb	52 Te	53 	54 Xe
6	55 Cs	56 Ba	57 *La	72 Hf	73 Ta	74 W	75 Re	⁷⁶ Os	77 ir	78 Pt	79 Au	80 Hg	81 TI	82 Pb	83 Bi	84 Po	85 At	86 Rn
7	87 Fr	88 Ra	89 +Ac	104 Rf	105 Ha	106 1 0 6	107 1 0 7	108 1 0 8	109 1 0 9	110 110								
	antha eries	nide	58 Ce	59 Pr	60 Nd	61 Pm	62 Sm	63 Eu	64 Gd	65 Tb	66 Dy	67 Ho	68 Er	69 Tm	70 Yb	71 Lu		
	ctinide eries	e	90 Th	91 Pa	92 U	93 Np	94 Pu	95 Am	96 Cm	97 Bk	98 Cf	99 Es	100 Fm	101 Md	102 No	103 Lr		

How is the Periodic Table Organized?

The periodic table is organized with eight principal vertical columns called groups and seven horizontal rows called periods (the groups are numbered I to VIII from left to right, and the periods are numbered 1 to 7 from top to bottom).

All the metals are grouped together on the left side of the periodic table, and all the nonmetals are grouped together on the right side of the periodic table. Semimetals are found in between the metals and nonmetals.

What are the Eight Groups of the Periodic Table?

➢ Group I: Alkali Metals - Li, Na, K, Rb, Cs, Fr known as alkali metals most reactive of the metals react with all nonmetals except the noble gases contain typical physical properties of metals (i.e., shiny solids and good conductors of heat and electricity) softer than most familiar metals; can be cut with a knife

Group II: Alkaline Earth Metals-Be, Mg, Ca, Sr, Ba, Ra known as alkaline earth metals react with nonmetals, but more slowly than the Group I metals solids at room temperature have typical metallic properties

harder than the Group I metals

higher melting points than the Group I metals

Group III: B, AI, Ga, In, TI boron is a semimetal; all the others are metals

- Group IV: C, Si, Ge, Sn, Pb carbon is a nonmetal; silicon and germanium are semimetals; tin and lead are metals
- Group V: N, P, As, Sb, Bi nitrogen and phosphorus are nonmetals; arsenic and antimony are semimetals; bismuth is a metal
- Group VI: O, S, Se, Te, Po oxygen, sulfur, and selenium are nonmetals; tellurium and polonium are semimetals
- Group VII: Halogens-F, CI, Br, I, At very reactive nonmetals
- Group VIII: Noble Gases-He, Ne, Ar, Kr, Xe, Rn very unreactive

Properties of Metals

Solids at room temperature

Conduct heat very well

Have electrical conductivities that increase with decreasing temperature

Have a high flexibility and a shiny metallic luster


Are malleable-can be beaten out into sheets or foils

Are ductile-can be pulled into thin wires without breaking

Emit electrons when they are exposed to radiation of sufficiently high energy or when They are heated (known as photoelectric effect and thermionic effect)


Properties of Nonmetals

May be gases, liquids, or solids at room temperature Poor conductors of heat Are insulators-very poor conductors of electricity Do not have a high reflectivity or a shiny metallic appearance In solid form generally brittle and fracture easily under stress Do not exhibit photoelectric or thermionic effects



LABORATORY FILTRATION SYSTEM

The pH Scale



pH: A measure of the acidity of water. The pH scale runs from 0 to 14 with 7 being the mid-point or neutral. A pH of less than 7 is on the acid side of the scale with 0 as the point of greatest acid activity. A pH of more than 7 is on the basic (alkaline) side of the scale with 14 as the point of greatest basic activity.

pH = (Power of Hydroxyl Ion Activity).

The acidity of a water sample is measured on a pH scale. This scale ranges from $\bf 0$ (maximum acidity) to $\bf 14$ (maximum alkalinity). The middle of the scale, $\bf 7$, represents the neutral point. The acidity increases from neutral toward $\bf 0$.

Because the scale is logarithmic, a difference of one pH unit represents a tenfold change. For example, the acidity of a sample with a pH of **5** is ten times greater than that of a sample with a pH of **6**. A difference of 2 units, from **6** to **4**, would mean that the acidity is one hundred times greater, and so on.

Normal rain has a pH of **5.6** – slightly acidic because of the carbon dioxide picked up in the earth's atmosphere by the rain.

Modern Water Treatment Disinfectants

Many water suppliers add a disinfectant to drinking water to kill germs such as giardia and e coli. Especially after heavy rainstorms, your water system may add more disinfectant to guarantee that these germs are killed.

Chlorine

Some people who use drinking water containing chlorine well in excess of EPA standards could experience irritating effects to their eyes and nose. Some people who drink water containing chlorine well in excess of the EPA standards could experience stomach discomfort.

Chloramine

Some people who use drinking water containing chloramines well in excess of EPA standards could experience irritating effects to their eyes and nose. Some people who drink water containing chloramines well in excess of the EPA standards could experience stomach discomfort or anemia.

Chlorine Dioxide

Some infants and young children who drink water containing chlorine dioxide in excess of the EPA standards could experience nervous system effects. Similar effects may occur in fetuses of pregnant women who drink water containing chlorine dioxide in excess of the EPA standards. Some people may experience anemia.

Disinfectant alternatives will include Ozone, and Ultraviolet light. You will see an increase of these technologies in the near future.

Disinfection Byproducts (DBPS)

Disinfection byproducts form when disinfectants added to drinking water to kill germs react with naturally-occurring organic matter in water.

Total Trihalomethanes

Some people who drink water containing trihalomethanes in excess of the EPA standards over many years may experience problems with their livers, kidneys, or central nervous systems, and may have an increased risk of developing cancer.

Haloacetic Acids

Some people who drink water containing haloacetic acids in excess of the EPA standards over many years may have an increased risk of developing cancer.

Bromate

Some people who drink water containing bromate in excess of the EPA standards over many years may have an increased risk of developing cancer.

Chlorite

Some infants and young children who drink water containing chlorite in excess of the EPA standards could experience nervous system effects. Similar effects may occur in fetuses of pregnant women who drink water containing chlorite in excess of the EPA standards. Some people may experience anemia.

Chapter Key Words

COLONY-FORMING UNITS (CFU): In microbiology, colony-forming unit (CFU) is a measure of viable bacterial or fungal numbers. Unlike in direct microscopic counts where all cells, dead and living, are counted, CFU measures viable cells. By convenience the results are given as colony-forming units per milliliter.

DISTRIBUTED CONTROL SYSTEM (DCS): It refers to a control system usually of a manufacturing system, process or any kind of dynamic system, in which the controller elements are not central in location (like the brain) but are distributed throughout the system with each component sub-system controlled by one or more controllers. The entire system of controllers is connected by networks for communication and monitoring.

DCS is a very broad term used in a variety of industries, to monitor and control distributed equipment.

GRANULAR ACTIVATED CARBON (GAC): A highly porous adsorbent material, produced by heating organic matter, such as coal, wood and coconut shell, in the absence of air, which is then crushed into granules. Activated carbon is positively charged and therefore able to remove negative ions from the water such as ozone, chlorine, fluorides and dissolved organic solutes by absorption onto the activated carbon. The activated carbon must be replaced periodically as it may become saturated and unable to absorb. Activated carbon is not effective in removing heavy metals.

HARD WATER: A type of water that has high mineral content (in contrast with soft water). Hard water minerals primarily consist of calcium (Ca_2+), and magnesium (Mg_2+) metal cations, and sometimes other dissolved compounds such as bicarbonates and sulfates. Calcium usually enters the water as either calcium carbonate ($CaCO_3$), in the form of limestone and chalk, or calcium sulfate ($CaSO_4$), in the form of other mineral deposits. The predominant source of magnesium is dolomite ($CaMg(CO_3)2$). Hard water is generally not harmful.

The simplest way to determine the hardness of water is the lather/froth test: soap or toothpaste, when agitated, lathers easily in soft water but not in hard water. More exact measurements of hardness can be obtained through a wet titration. The total water 'hardness' (including both Ca2+ and Mg2+ ions) is read as parts per million or weight/volume (mg/L) of calcium carbonate ($CaCO_3$) in the water.

NEGATIVE SUCTION HEAD: Two priming methods are available for a negative suction head condition--that is, when the pump lifts water to the intake (suction lift).

- a. Vacuum Pump or Ejection Method. When steam, high-pressure water, or compressed air is available, prime the pump by attaching an ejector to the highest point in the pump casing for evacuating the air from the suction piping and casing. A vacuum may be substituted for the above equipment. Start the ejector or vacuum pump to exhaust the air from the pump casing and suction pipe. When water discharges from the ejector or vacuum pump, start the centrifugal pump, but continue priming until the centrifugal pump has reached operating speed.
- b. Priming a Pump with a Foot Valve. A foot valve is used at the lowest point on the suction pipe. The foot valve retains water in the suction pipe and pump casing after the pump has been initially primed. To prime, open the suction valve, if one is installed. Open vent valves at the highest points on the pump casing. Fill the pump and suction line from an independent water supply. Allow to fill until a steady steam flows from the vent valves.

POSITIVE SUCTION HEAD: When the intake (suction) side of the pump is under pressure, use the following priming sequence:

- a. Open all suction valves to allow water to enter the suction pipe and pump casing.
- b. Open all vents located on the highest point of the pump casing to allow trapped air to be released.

Note: The pump is properly primed when water flows from all open vents in a steady stream.

PPE: Personal protective equipment, or PPE, is designed to protect employees from serious workplace injuries or illnesses resulting from contact with chemical, radiological, physical, electrical, mechanical, or other workplace hazards. Besides face shields, safety glasses, hard hats, and safety shoes, PPE includes a variety of devices and garments such as goggles, coveralls, gloves, vests, earplugs, and respirators.

PROGRAMMABLE LOGIC CONTROLLER (PLC): A digital computer used for automation of industrial processes, such as control of machinery on factory assembly lines. Unlike general-purpose computers, the PLC is designed for multiple inputs and output arrangements, extended temperature ranges, immunity to electrical noise, and resistance to vibration and impact. Programs to control machine operation are typically stored in battery-backed or non-volatile memory. A PLC is an example of a real time system since output results must be produced in response to input conditions within a bounded time, otherwise unintended operation will result.

SHORT TERM EXPOSURE LIMIT (STEL): It is defined by ACGIH as the concentration to which workers can be exposed continuously for a short period of time without suffering from: irritation; chronic or irreversible tissue damage; narcosis of sufficient degree to increase the likelihood of accidental injury, impair self-rescue or materially reduce work efficiency.

SOFT WATER: The term used to describe types of water that contains few or no calcium or magnesium metal cations. The term is usually related to hard water, which does contain significant amounts of these ions. Soft water usually comes from peat or igneous rock sources, such as granite but may also derive from sandstone sources, since such sedimentary rocks are usually low in calcium and magnesium.

THRESHOLD LIMIT VALUE (TLV): It is a level to which it is believed a worker can be exposed day after day for a working lifetime without adverse health effects. Strictly speaking, TLV is a reserved term of the American Conference of Governmental Industrial Hygienists (**ACGIH**).

TRIHALOMETHANES (THM): Four separate compounds including chloroform, dichlorobromomethane, dibromochloromethane, and bromoform. The most common class of disinfection by-products created when chemical disinfectants react with organic matter in water during the disinfection process. See Disinfectant Byproducts.

UNCONFINED AQUIFER: One that is open to receive water from the surface, and whose water table surface is free to fluctuate up and down, depending on the recharge/discharge rate. There are no overlying "confining beds" of low permeability to physically isolate the groundwater system.

VOLATILE ORGANIC CHEMICALS (VOCs): Carbon-containing compounds that evaporate easily from water into air at normal air temperatures. (This is why the distinctive odor of gasoline and many solvents can easily be detected.) VOCs are contained in a wide variety of commercial, industrial and residential products including fuel oils, gasoline, solvents, cleaners and degreasers, paints, inks, dyes, refrigerants and pesticides.

Chlorine Section




1-ton Chlorine Gas Containers

The top valves or lines are for extracting the gas, and the bottom valves or lines are for extracting the Cl₂ liquid. Never place water on a leaking metal container. The water will help create acid which will make the leak larger.





150-pound Chlorine Cylinder



Chlorine

Formula: Cl₂

Structure: Not applicable.

Synonyms: Bertholite, molecular chlorine

Identifiers

1. CAS No.: 7782-50-5 2. RTECS No.: FO2100000 3. DOT UN: 1017 20 4. DOT label: Poison gas

Appearance and odor

Chlorine is a greenish-yellow gas with a characteristic pungent odor. It condenses to an

amber liquid at approximately -34 degrees C (-29.2 degrees F) or at high pressures. Odor thresholds ranging from 0.08 to part per million (ppm) parts of air have been reported. Prolonged exposures may result in olfactory fatigue.



Physical data

- 1. Molecular weight: 70.9
- 2. Boiling point (at 760 mm Hg): -34.6 degrees C (-30.28 degrees F)
- 3. Specific gravity (liquid): 1.41 at 20 degrees C (68 degrees F) and a pressure of 6.86 atm
- 4. Vapor density: 2.5
- 5. **Melting point:** -101 degrees C (-149.8 degrees F)
- 6. Vapor pressure at 20 degrees C (68 degrees F): 4,800 mm Hg
- 7. **Solubility**: Slightly soluble in water; soluble in alkalies, alcohols and chlorides.
- 8. Evaporation rate: Data not available.

Reactivity

- 1. **Conditions contributing to instability**: Cylinders of chlorine may burst when exposed to elevated temperatures. Chlorine in solution forms a corrosive material.
- 2. Incompatibilities: Flammable gases and vapors form explosive mixtures with chlorine. Contact between chlorine and many combustible substances (such as gasoline and petroleum products, hydrocarbons, turpentine, alcohols, acetylene, hydrogen, ammonia, and sulfur), reducing agents, and finely divided metals may cause fires and explosions. Contact between chlorine and arsenic, bismuth, boron, calcium, activated carbon, carbon disulfide, glycerol, hydrazine, iodine, methane, oxomonosilane, potassium, propylene, and silicon should be avoided. Chlorine reacts with hydrogen sulfide and water to form hydrochloric acid, and it reacts with carbon monoxide and sulfur dioxide to form phosgene and sulfuryl chloride. Chlorine is also incompatible with moisture, steam, and water.
- 3. Hazardous decomposition products: None reported.
- 4. **Special precautions:** Chlorine will attack some forms of plastics, rubber, and coatings.

Flammability

Chlorine is a non-combustible gas.

The National Fire Protection Association has assigned a flammability rating of 0 (no fire hazard) to chlorine; however, most combustible materials will burn in chlorine.

- 1. Flash point: Not applicable.
- 2. Autoignition temperature: Not applicable.
- 3. Flammable limits in air: Not applicable.
- 4. **Extinguishant:** For small fires use water only; do not use dry chemical or carbon dioxide. Contain and let large fires involving chlorine burn. If fire must be fought, use water spray or fog.

Fires involving chlorine should be fought upwind from the maximum distance possible.

Keep unnecessary people away; isolate the hazard area and deny entry. For a massive fire in a cargo area, use unmanned hose holders or monitor nozzles; if this is impossible, withdraw from the area and let the fire burn. Emergency personnel should stay out of low areas and ventilate closed spaces before entering.

Containers of chlorine may explode in the heat of the fire and should be moved from the fire area if it is possible to do so safely. If this is not possible, cool fire exposed containers from the sides with water until well after the fire is out. Stay away from the ends of containers. Firefighters should wear a full set of protective clothing and self-contained breathing apparatus when fighting fires involving chlorine.

Exposure Limits

* OSHA PEL

The current **OSHA** permissible exposure limit (**PEL**) for chlorine is 1 ppm (3 milligrams per cubic meter (mg/m⁽³⁾)) as a ceiling limit. A worker's exposure to chlorine shall at no time exceed this ceiling level [29 CFR 1910.1000, Table Z-1].

* NIOSH REL

The National Institute for Occupational Safety and Health (**NIOSH**) has established a recommended exposure limit (**REL**) for chlorine of 0.5 ppm $mg/m^{(3)}$) as a TWA for up to a 10-hour workday and a 40-hour workweek and a short-term exposure limit (**STEL**) of 1 ppm (3 $mg/m^{(3)}$)[NIOSH 1992].

* ACGIH TLV

The American Conference of Governmental Industrial Hygienists (**ACGIH**) has assigned chlorine a threshold limit value (**TLV**) of 0.5 ppm (1.5 mg/m⁽³⁾) as a TWA for a normal 8-hour workday and a 40-hour workweek and a **STEL** of 1 ppm (2.9 mg/m⁽³⁾) for periods not to exceed 15 minutes. Exposures at the STEL concentration should not be repeated more than four times a day and should be separated by intervals of at least 60 minutes [ACGIH 1994, p. 15].

* Rationale for Limits

The NIOSH limits are based on the risk of severe eye, mucous membrane and skin irritation [NIOSH 1992]. The ACGIH limits are based on the risk of eye and mucous membrane irritation [ACGIH 1991, p. 254].

Chlorine (DDBP)

Today, most of our drinking water supplies are free of the micro-organisms — viruses, bacteria and protozoa — that cause serious and life-threatening diseases, such as cholera and typhoid fever. This is largely due to the introduction of water treatment, particularly chlorination, at the turn of the century. Living cells react with chlorine and reduce its concentration while they die. The organic matter and other substances that are present, convert to chlorinated derivatives, some of which are effective killing agents. Chlorine present as CI, HOCI, and OCI is called *free available chlorine* and that which is bound but still effective is *combined chlorine*. A particularly important group of compounds with combined chlorine is the chloramines formed by reactions with ammonia.

One especially important feature of disinfection using chlorine is the ease of overdosing to create a **residual** concentration. There is a constant danger that safe water leaving the treatment plant may become contaminated later. There may be breaks in water mains, loss of pressure that permits an inward leak or plumbing errors. This residual concentration of chlorine provides some degree of protection right to the water faucet. With free available chlorine, a typical residual is from 0.1 to 0.5 ppm. Because chlorinated organic compounds are less effective, a typical residual is 2 ppm for combined chlorine.

There will be no chlorine residual unless there is an excess over the amount that reacts with the organic matter present. However, reaction kinetics complicates interpretation of chlorination data. The correct excess is obtained in a method called **Break Point Chlorination.**

Chlorine By-Products

Chlorination by-products are the chemicals formed when the chlorine used to kill disease-causing micro-organisms reacts with naturally occurring organic matter (i.e., decay products of vegetation) in the water. The most common chlorination by-products found in U.S. drinking water supplies are the trihalomethanes (**THMs**).

The Principal Trihalomethanes are:

Chloroform, bromodichloromethane, chlorodibromomethane and bromoform. Other less common chlorination by-products includes the haloacetic acids and haloacetonitriles.

The amount of THMs formed in drinking water can be influenced by a number of factors, including the season and the source of the water. For example, THM concentrations are generally lower in winter than in summer, because concentrations of natural organic matter are lower and less chlorine is required to disinfect at colder temperatures. THM levels are also low when wells or large lakes are used as the drinking water source, because organic matter concentrations are generally low in these sources. The opposite — high organic matter concentrations and high THM levels — is true when rivers or other surface waters are used as the source of the drinking water.

Health Effects

Laboratory animals exposed to very high levels of THMs have shown increased incidences of cancer. Also, several studies of cancer incidence in human populations have reported associations between long-term exposure to high levels of chlorination by-products and an increased risk of certain types of cancer.

For instance, a recent study conducted in the Great Lakes basin reported an increased risk of bladder and possibly colon cancer in people who drank chlorinated surface water for 35 years or more.

Possible relationships between exposure to high levels of THMs and adverse reproductive effects in humans have also been examined recently. In a California study, pregnant women who consumed large amounts of tap water containing elevated levels of THMs were found to have an increased risk of spontaneous abortion.

The available studies on health effects do not provide conclusive proof of a relationship between exposure to THMs and cancer or reproductive effects, but indicate the need for further research to confirm their results and to assess the potential health effects of chlorination by-products other than THMs.



Chlorine gas cylinder storage room, notice the vents at the bottom and top. The bottom vent will allow the gas to ventilate because Cl₂ gas is heavier than air.

Risks and Benefits of Chlorine

Current evidence indicates the benefits of chlorinating our drinking water — reduced incidence of water-borne diseases — are much greater than the risks of health effects from THMs. Although other disinfectants are available, chlorine continues to be the choice of water treatment experts. When used with modern water filtration practices, chlorine is effective against virtually all infective agents — bacteria, viruses, and protozoa. It is easy to apply, and most importantly, small amounts of chlorine remain in the water and continue to disinfect throughout the distribution system. This ensures the water remains free of microbial contamination on its journey from the treatment plant to the consumer's tap.

A number of cities use ozone to disinfect their source water and to reduce THM formation. Although ozone is a highly effective disinfectant, it breaks down quickly, so small amounts of chlorine or other disinfectants must be added to the water to ensure continued disinfection as the water is piped to the consumer's tap. Modifying water treatment facilities to use ozone can be expensive, and ozone treatment can create other undesirable by-products that may be harmful to health if they are not controlled (i.e., bromate).

Examples of other disinfectants include chloramines and chlorine dioxide. Chloramines are weaker disinfectants than chlorine, especially against viruses and protozoa; however, they are very persistent and, as such, can be useful for preventing re-growth of microbial pathogens in drinking water distribution systems.

Chlorine dioxide can be an effective disinfectant, but it forms chlorate and chlorite, compounds whose toxicity has not yet been fully determined. Assessments of the health risks from these and other chlorine-based disinfectants and chlorination by-products are currently under way.

In general, the preferred method of controlling chlorination by-products is removal of the naturally occurring organic matter from the source water so it cannot react with the chlorine to form by-products. THM levels may also be reduced through the replacement of chlorine with alternative disinfectants. A third option is removal of the by-products by adsorption on activated carbon beds. It is extremely important that water treatment plants ensure the methods used to control chlorination by-products do not compromise the effectiveness of water disinfection.



Chlorine piping and chlorine cylinder yoke.

Health Hazard Information

Routes of Exposure

Exposure to chlorine can occur through inhalation, ingestion, and eye or skin contact [Genium 1992].

Summary of toxicology

- 1. Effects on animals: Chlorine is a severe irritant of the eyes, mucous membranes, skin, and lungs in experimental animals. The 1 hour Lethal Concentration (50) is 239 ppm in rats and 137 ppm in mice [Sax and Lewis 1989]. Animals surviving sub-lethal inhalation exposures for 15 to 193 days showed marked emphysema, which was associated with bronchiolitis and pneumonia [Clayton and Clayton 1982]. Chlorine injected into the anterior chamber of rabbits' eyes resulted in severe damage with inflammation, opacification of the cornea, atrophy of the iris, and injury to the lens [Grant 1986].
- 2. Effects on humans: Severe acute effects of chlorine exposure in humans have been well documented since World War I when chlorine gas was used as a chemical warfare agent. Other severe exposures have resulted from the accidental rupture of chlorine tanks. These exposures have caused death, lung congestion, and pulmonary edema, pneumonia, pleurisy, and bronchitis [Hathaway et al. 1991]. The lowest lethal concentration reported is 430 ppm for 30 minutes [Clayton and Clayton 1982].

Exposure to 15 ppm causes throat irritation, exposures to 50 ppm are dangerous, and exposures to 1000 ppm can be fatal, even if exposure is brief [Sax and Lewis 1989; Clayton and Clayton 1982]. Earlier literature reported that exposure to a concentration of about 5 ppm caused respiratory complaints, corrosion of the teeth, inflammation of the mucous membranes of the nose and susceptibility to tuberculosis among chronically-exposed workers.

However, many of these effects are not confirmed in recent studies and are of very dubious significance [ACGIH 1991]. A study of workers exposed to chlorine for an average of 10.9 years was published in 1970. All but six workers had exposures below 1 ppm; 21 had TWAs above 0.52 ppm.

No evidence of permanent lung damage was found, but 9.4 percent had abnormal EKGs compared to 8.2 percent in the control group. The incidence of fatigue was greater among those exposed above 0.5 ppm [ACGIH 1991]. In 1981, a study was published involving 29 subjects exposed to chlorine concentrations up to 2.0 ppm for 4- and 8-hour periods. Exposures of 1.0 ppm for 8 hours produced statistically significant changes in pulmonary function that were not observed at a 0.5 ppm exposure concentration. Six of 14 subjects exposed to 1.0 ppm for 8 hours showed increased mucous secretions from the nose and in the hypopharynx.

Responses for sensations of itching or burning of the nose and eyes, and general discomfort were not severe, but were perceptible, especially at the 1.0 ppm exposure level [ACGIH 1991]. A 1983 study of pulmonary function at low concentrations of chlorine exposure also found transient decreases in pulmonary function at the 1.0 ppm exposure level, but not at the 0.5 ppm level [ACGIH 1991]. Acne (chloracne) is not unusual among persons exposed to low concentrations of chlorine for long periods of time. Tooth enamel damage may also occur [Parmeggiani 1983]. There has been one confirmed case of myasthenia gravis associated with chlorine exposure [NLM 1995].

Signs and Symptoms of Exposure

- 1. Acute exposure: Acute exposure to low levels of chlorine results in eye, nose, throat irritation, sneezing, excessive salivation, general excitement, and restlessness. Higher concentrations causes difficulty in breathing, violent coughing, nausea, vomiting, cyanosis, dizziness, headache, choking, laryngeal edema, acute tracheobronchitis, chemical pneumonia. Contact with the liquid can result in frostbite burns of the skin and eyes [Genium 1992].
- 2. Chronic exposure: Chronic exposure to low levels of chlorine gas can result in a dermatitis known as chloracne, tooth enamel corrosion, coughing, severe chest pain, sore throat, hemoptysis and increased susceptibility to tuberculosis [Genium 1992].

Emergency Medical Procedures: [NIOSH to supply]

- Rescue: Remove an incapacitated worker from further exposure and implement appropriate emergency procedures (i.e., those listed on the Material Safety Data Sheet required by OSHA's Hazard Communication Standard [29 CFR 1910.1200]).
- All workers should be familiar with emergency procedures, the location and proper use of emergency equipment, and methods of protecting themselves during rescue operations.

Exposure Sources and Control Methods

The following operations may involve chlorine and lead to worker exposures to this substance:

The Manufacture and Transportation of Chlorine

- Used as a chlorinating and oxidizing agent in organic and inorganic synthesis, in the manufacture of chlorinated solvents, automotive antifreeze and antiknock compounds, polymers (synthetic rubber and plastics), resins, elastomers, pesticides, refrigerants, and in the manufacture of rocket fuel.
- Used as a fluxing, purification and extraction agent in metallurgy.
- Used as a bacteriostat, disinfectant, odor control and demulsifier in treatment of drinking water, swimming pools, and in sewage.
- Used in the paper and pulp, and textile industries for bleaching cellulose for artificial fibers; used in the manufacture of chlorinated lime; used in detinning and dezincing iron; used to shrink-proof wool.
- ➤ Used in the manufacture of pharmaceuticals, cosmetics, lubricants, flameproofing, adhesives, in special batteries containing lithium or zinc and in hydraulic fluids; used in the processing of meat, fish, vegetables and fruit.
- ➤ Used as bleaching and cleaning agents, and as a disinfectant in laundries, dishwashers, cleaning powders, cleaning dairy equipment and bleaching cellulose.

Methods that are effective in controlling worker exposures to chlorine, depending on the feasibility of implementation, are as follows: process enclosure, local exhaust ventilation, general dilution ventilation, personal protective equipment.

Workers responding to a release or potential release of a hazardous substance must be protected as required by paragraph (q) of OSHA's Hazardous Waste Operations and Emergency Response Standard 29 CFR.

Good Sources of Information about Control Methods are as Follows:

- 1. ACGIH [1992]. Industrial ventilation--a manual of recommended practice. 21st ed. Cincinnati, OH: American Conference of Governmental Industrial Hygienists.
- 2. Burton DJ [1986]. Industrial ventilation--a self-study companion. Cincinnati, OH: American Conference of Governmental Industrial Hygienists.
- 3. Alden JL, Kane JM [1982]. Design of industrial ventilation systems. New York, NY: Industrial Press, Inc.
- 4. Wadden RA, Scheff PA [1987]. Engineering design for control of workplace hazards. New York, NY: McGraw-Hill.
- 5. Plog BA [1988]. Fundamentals of industrial hygiene. Chicago, IL: National Safety Council.

Chlorine Storage

Chlorine should be stored in a cool, dry, well-ventilated area in tightly sealed containers that are labeled in accordance with OSHA's Hazard Communication Standard [29 CFR 1910.1200]. Containers of chlorine should be protected from exposure to weather, extreme temperatures changes, and physical damage. They should be stored separately from flammable gases and vapors, combustible substances (such as gasoline and petroleum products, hydrocarbons, turpentine, alcohols, acetylene, hydrogen, ammonia and sulfur), reducing agents, finely divided metals, arsenic, bismuth, boron, calcium, activated carbon, carbon disulfide, glycerol, hydrazine, iodine, methane, oxomonosilane, potassium, propylene, silicon, hydrogen sulfide and water, carbon monoxide and sulfur dioxide, moisture, steam, and water.

Workers handling and operating chlorine containers, cylinders and tank wagons should receive special training in standard safety procedures for handling compressed corrosive gases. All pipes and containment used for chlorine service should be regularly inspected and tested. Empty containers of chlorine should have secured protective covers on their valves and should be handled appropriately.

Spills and Leaks

In the event of a spill or leak involving chlorine, persons not wearing protective equipment and fully-encapsulating, vapor-protective clothing should be restricted from contaminated areas until cleanup has been completed. The following steps should be undertaken following a spill or leak:

- 1. Notify safety personnel.
- 2. Remove all sources of heat and ignition.
- 3. Keep all combustibles (wood, paper, oil, etc.) away from the leak.
- 4. Ventilate potentially explosive atmospheres.
- 5. Evacuate the spill area for at least 50 feet in all directions.
- 6. Find and stop the leak if this can be done without risk; if not, move the leaking container to an isolated area until gas has dispersed. The cylinder may be allowed to empty through a reducing agent such as sodium bisulfide and sodium bicarbonate.
- 7. Use water spray to reduce vapors; do not put water directly on the leak or spill area.



Special Requirements

The EPA requirements for emergency planning, reportable quantities of hazardous releases, community right-to-know and hazardous waste management may change over time. Users are therefore advised to determine periodically whether new information is available.

Emergency Planning Requirements

Employers owning or operating a facility at which there are 100 pounds or more of chlorine must comply with the EPA's emergency planning requirements [40 CFR Part 355.30].

Reportable Quantity Requirements for Hazardous Releases

A hazardous substance release is defined by the EPA as any spilling, leaking, pumping, pouring, emitting, emptying, discharging, injecting, escaping, leaching, dumping or disposing into the environment including the abandonment or discarding of contaminated containers) of hazardous substances. In the event of a release that is above the reportable quantity for that chemical, employers are required to notify the proper federal, state and local authorities [40 CFR].

The Reportable Quantity of Chlorine is 10 Pounds.

If an amount equal to or greater than this quantity is released within a 24-hour period in a manner that will expose persons outside the facility, employers are required to do the following:

Notify the National Response Center immediately at (800) or at 202-426-2675 in Washington, D.C. [40 CFR 302.6]. Notify the emergency response commission of the State likely to be affected by the release [40 CFR 355.40]. Notify the community emergency coordinator of the local emergency planning committee (or relevant local emergency response personnel) of any area likely to be affected by the release [40 CFR 355.40].

Community Right-to-Know Requirements

Employers who own or operate facilities in SIC codes 20 to 39 that employ 10 or more workers and that manufacture 25,000 pounds or more of chlorine per calendar year or otherwise use 10,000 pounds or more of chlorine per calendar year are required by the EPA [40 CFR Part 372.30] to submit a Toxic Chemical Release Inventory form (Form R) to the EPA reporting the amount of chlorine emitted or released from their facility annually.

Hazardous Waste Management Requirements

The EPA considers a waste to be hazardous if it exhibits any of the following characteristics: ignitability, corrosivity, reactivity or toxicity as defined in 40 CFR 261.21-261.24. Under the Resource Conservation and Recovery Act (**RCRA**) [40 USC 6901 et seq.], the EPA has specifically listed many chemical wastes as hazardous.

Although chlorine is not specifically listed as a hazardous waste under RCRA, the EPA requires employers to treat waste as hazardous if it exhibits any of the characteristics discussed above.

Providing detailed information about the removal and disposal of specific chemicals is beyond the scope of this guideline. The U.S. Department of Transportation (DOT), the EPA, state and local regulations should be followed to ensure that removal, transport and disposal of this substance are conducted in accordance with existing regulations.




To be certain chemical waste disposal meets the EPA regulatory requirements, employers should address any questions to the RCRA hotline at 703-412-9810 (in the Washington, D.C. area) or toll-free at 800-424-9346 (outside Washington, D.C.). In addition, relevant state and local authorities should be contacted for information on any requirements they may have for the waste removal and disposal of this substance.

More on Chlorine Gas

Chlorine gas is a pulmonary irritant with intermediate water solubility that causes acute damage in the upper and lower respiratory tract. Chlorine gas was first used as a chemical weapon at Ypres, France in 1915. Of the 70,552 American soldiers poisoned with various gasses in World War I, 1843 were exposed to chlorine gas. Approximately 10.5 million tons and over 1 million containers of chlorine are shipped in the U.S. each year.





Chlorine is a yellowish-green gas at standard temperature and pressure. It is extremely reactive with most elements. Because its density is greater than that of air, the gas settles low to the ground. It is a respiratory irritant and burns the skin. Just a few breaths of it are fatal. Cl2 gas does not occur naturally, although chlorine can be found in a number of compounds.

Pathophysiology: Chlorine is a greenish-yellow, noncombustible gas at room temperature and atmospheric pressure. The intermediate water solubility of chlorine accounts for its effect on the upper airway and the lower respiratory tract.

Exposure to chlorine gas may be prolonged because its moderate water solubility may not cause upper airway symptoms for several minutes. In addition, the density of the gas is greater than that of air, causing it to remain near ground level and increasing exposure time.

The odor threshold for chlorine is approximately 0.3-0.5 ppm; however, distinguishing toxic air levels from permissible air levels may be difficult until irritative symptoms are present.

Mechanism of Activity

The mechanisms of the above biological activity are poorly understood and the predominant anatomic site of injury may vary, depending on the chemical species produced. Cellular injury is believed to result from the oxidation of functional groups in cell components, from reactions with tissue water to form hypochlorous and hydrochloric acid, and from the generation of free oxygen radicals.

Although the idea that chlorine causes direct tissue damage by generating free oxygen

radicals was once accepted, this idea is now controversial. The cylinders on the right contain chlorine gas. The gas comes out of the cylinder through a gas regulator. The cylinders are on a scale that operators use to measure the amount used each day. The chains are used to prevent the tanks from falling over. Chlorine gas is stored in vented rooms that have panic bar equipped doors. Operators have the equipment necessary to reduce the impact of a gas leak but rely on trained emergency response teams to contain leaks.

Solubility Effects

Hydrochloric acid is highly soluble in water. The predominant targets of the acid are the epithelia of the ocular conjunctivae and upper respiratory mucus membranes. Hypochlorous acid is also highly water soluble with an injury pattern similar to hydrochloric acid. Hypochlorous acid may account for the toxicity of elemental chlorine and hydrochloric acid to the human body.

Early Response to Chlorine Gas

Chlorine gas, when mixed with ammonia, reacts to form chloramine gas. In the presence of water, chloramines decompose to ammonia and hypochlorous acid or hydrochloric acid.

The early response to chlorine exposure depends on the concentration of chlorine gas, duration of exposure, water content of the tissues exposed and individual susceptibility.

Immediate Effects

The immediate effects of chlorine gas toxicity include acute inflammation of the conjunctivae, nose, pharynx, larynx, trachea, and bronchi. Irritation of the airway mucosa leads to local edema secondary to active arterial and capillary hyperemia. Plasma exudation results in filling the alveoli with edema fluid, resulting in pulmonary congestion.

Pathological Findings

Pathologic findings are nonspecific. They include severe pulmonary edema, pneumonia, hyaline membrane formation, multiple pulmonary thromboses and ulcerative tracheobronchitis.

The hallmark of pulmonary injury associated with chlorine toxicity is pulmonary edema, manifested as hypoxia. Non-cardiogenic pulmonary edema is thought to occur when there is a loss of pulmonary capillary integrity.

Using DPD Method for Chlorine Residuals

N, N – diethyl-p-phenylenediame



Small portable chlorine measuring kit. The redder the mixture color, the hotter or stronger the chlorine in solution.

Measuring Chlorine Residual

Chlorine residual is the amount of chlorine remaining in water that can be used for disinfection. A convenient, simple and inexpensive way to measure chlorine residual is to use a small portable kit with pre-measured packets of chemicals that are added to water.

(Make sure you buy a test kit using the **DPD method**, and not the outdated orthotolodine method.)

Chlorine test kits are very useful in adjusting the chlorine dose you apply. You can measure what chlorine levels are being found in your system (especially at the far ends).

Free chlorine residuals need to be checked and recorded daily. These results should be kept on file for a health or regulatory agency inspection during a regular field visit.

The most accurate method for determining chlorine residuals is to use the laboratory amperometric titration method.

Amperometric Titration

The chlorination of water supplies and polluted waters serves primarily to destroy or deactivate disease-producing microorganisms. A secondary benefit, particularly in treating drinking water, is the overall improvement in water quality resulting from the reaction of chlorine with ammonia, iron, manganese, sulfide and some organic substances.

Chlorination may produce adverse effects. Taste and odor characteristics of phenols and other organic compounds present in a water supply may be intensified. Potentially carcinogenic chloro-organic compounds such as chloroform may be formed.

Combined chlorine formed on chlorination of ammonia or amine-bearing waters adversely affects some aquatic life. To fulfill the primary purpose of chlorination and to minimize any adverse effects, it is essential that proper testing procedures be used with a foreknowledge of the limitations of the analytical determination.

Chlorine applied to water in its molecular or hypochlorite form initially undergoes hydrolysis to form free chlorine consisting of aqueous molecular chlorine, hypochlorous acid and hypochlorite ion. The relative proportion of these free chlorine forms is pH and temperature-dependent. At the pH of most waters, hypochlorous acid and hypochlorite ion will predominate.



Free chlorine reacts readily with ammonia and certain nitrogenous compounds to form combined chlorine. With ammonia, chlorine reacts to form the chloramines: monochloramine, dichloramine and nitrogen trichloride.

The presence and concentrations of these combined forms depend chiefly on pH, temperature, initial chlorine-to-nitrogen ratio, absolute chlorine demand and reaction time. Both free and combined chlorine may be present simultaneously. Combined chlorine in water supplies may be formed in the treatment of raw waters containing ammonia or by the addition of ammonia or ammonium salts.

Chlorinated wastewater effluents, as well as certain chlorinated industrial effluents, normally contain only combined chlorine. Historically the principal analytical problem has been to distinguish between free and combined forms of chlorine.

Hach's AutoCAT 9000™ Automatic Titrator is the newest solution to hit the disinfection industry – a comprehensive, benchtop chlorine-measurement system that does it all: calibration, titration, calculation, real-time graphs, graphic print output, even electrode cleaning. More a laboratory assistant than an instrument, the AutoCAT 9000 gives you:

- High throughput: performs the titration and calculates concentration, all automatically.
- Forward titration: USEPA-accepted methods for free and total chlorine and chlorine dioxide with chlorite.
- Back titration: USEPA-accepted method for total chlorine in wastewater.
- Accurate, yet convenient: the easiest way to complete ppb-level amperometric titration.

Chemical Equations, Oxidation States, and Balancing of Equations

Before we breakdown chlorine and other chemicals, let's start with this review of basic chemical equations.

Beginning

The common chemical equation could be A + B --> C + D. This is chemical A + chemical B, the two reacting chemicals will go to products C + D, etc.

Oxidation

The term "oxidation" originally meant a reaction in which oxygen combines chemically with another substance, but its usage has long been broadened to include any reaction in which electrons are transferred.

Oxidation and reduction always occur simultaneously (redox reactions), and the substance which gains electrons is termed the oxidizing agent. For example, cupric ion is the oxidizing agent in the reaction: Fe (metal) + Cu++ --> Fe++ + Cu (metal); here, two electrons (negative charges) are transferred from the iron atom to the copper atom; thus the iron becomes positively charged (is oxidized) by loss of two electrons, while the copper receives the two electrons and becomes neutral (is reduced).

Electrons may also be displaced within the molecule without being completely transferred away from it. Such partial loss of electrons likewise constitutes oxidation in its broader sense and leads to the application of the term to a large number of processes, which at first sight might not be considered to be oxidation. Reaction of a hydrocarbon with a halogen, for example, $CH_4 + 2 CI --> CH_3CI + HCI$, involves partial oxidation of the methane; halogen addition to a double bond is regarded as an oxidation.

Dehydrogenation is also a form of oxidation, when two hydrogen atoms, each having one electron, are removed from a hydrogen-containing organic compound by a catalytic reaction with air or oxygen, as in oxidation of alcohol to aldehyde.

Oxidation Number

The number of electrons that must be added to or subtracted from an atom in a combined state to convert it to the elemental form; i.e., in barium chloride (BaCl₂) the oxidation number of barium is +2 and of chlorine is -1. Many elements can exist in more than one oxidation state.

Now, let us look at some common ions. An ion is the reactive state of the chemical, and is dependent on its place within the periodic table.

Have a look at the "periodic table of the elements". It is arranged in columns of elements, there are 18 columns. You can see column one, H, Li, Na, K, etc. These all become ions as H^+ , Li^+ , K^+ , etc. The next column, column 2, Be, Mg, Ca etc. become ions Be_2^+ , Mg_2^+ , Ca_2^+ , etc. Column 18, He, Ne, Ar, Kr are inert gases. Column 17, F, Cl, Br, I, ionize to a negative F^- , Cl^- , Br^- , l^- , etc.

What you now need to do is memorize the table of common ions, both positive ions and negative ions.

Table of Common Ions Positive Ions

Valency 1		Valency 2		Valency 3	
lithium	Li ⁺	magnesium	Mg ₂ ⁺	aluminum	Al ₃ ⁺
sodium	Na⁺	calcium	Ca ₂ ⁺	iron III	Fe ₃ ⁺
potassium	K ⁺	strontium	Sr ₂ ⁺	chromium	Cr ₃ ⁺
silver	Ag⁺	barium	Ba ₂ ⁺		
hydronium	H ₃ O⁺	copper II	Cu ₂ ⁺		
(or hydrogen)	H⁺	lead II	Pb ₂ ⁺		
ammonium	NH ₄ ⁺	zinc	Zn ₂ ⁺		
copper I	Cu⁺	manganese II	Mn ₂ ⁺		
mercury I	Hg⁺	iron II	Fe ₂ ⁺		
		tin II	Sn ₂ ⁺		

Negative Ions

Valency 1		Valency 2		Valency 3	
fluoride	F-	oxide	O ₂ -	phosphate	PO ₄ ³⁻
chloride	Cl	sulfide	S ₂ -		
bromide	Br ⁻	carbonate	CO ₃ ²⁻		
iodide	I-	sulfate	SO ₄ ²⁻		
hydroxide	OH ⁻	sulfite	SO ₃ ²⁻		
nitrate	NO ₃	dichromate	Cr ₂ O ₇		
bicarbonate	HCO ₃	chromate	CrO ₄ ²⁻		
bisulphate	HSO ₄	oxalate	C ₂ O ₄ ²⁻		
nitrite	NO ₂	thiosulfate	S ₂ O ₃ ²⁻		
chlorate	CIO ₃	tetrathionate	S ₄ O ₆ ²⁻		
permanganate	MnO ₄	monohydrogen phosphate	HPO ₄ ²⁻		
hypochlorite	OCI ⁻				
dihydrogen phosphate	H ₂ PO ₄				

Positive ions will react with negative ions, and vice versa. This is the start of our chemical reactions. For example:

Na⁺ + OH⁻ --> NaOH (sodium hydroxide)

Na⁺ + Cl⁻ --> NaCl (salt)

 $3H^+ + PO_4^{3-} --> H_3PO_4$ (phosphoric acid) $2Na^+ + S_2O_3^{2-} --> Na_2S_2O_3$

You will see from these examples, that if an ion of one (+), reacts with an ion of one (-) then the equation is balanced. However, an ion like PO_4^{3-} (phosphate) will require an ion of 3+ or an ion of one (+) (but needs three of these) to neutralize the 3- charge on the phosphate. So, what you are doing is balancing the charges (+) or (-) to make them zero, or cancel each other out.

For example, since aluminum exists in its ionic state as Al_3^+ , it will react with many negatively charged ions; for example: Cl^- , Od_3^- , POd_3^- .

Let us do these examples and balance them.

```
Al^{3+} + Cl^{-} --> AlCl (incorrect)

Al^{3+} + 3Cl^{-} --> AlCl_3 (correct)
```

How did we work this out?

Al³⁺ has three positives (3+)

Cl⁻ has one negative (-)

It will require **3 negative charges** to cancel out the **3 positive charges** on the aluminum (Al_3^+) .

When the **left hand side** of the equation is written, to balance the number of chlorine's (Cl⁻) required, the number 3 is placed in front of the ion concerned, in this case Cl⁻, becomes 3Cl⁻.

On the **right hand side** of the equation, where the ions have become a compound (a chemical compound), the number is transferred to after the relevant ion, Cl₃.

Another example:

$$Al_3^+ + SO_4^{2^-} --> AlSO_4$$
 (incorrect)
 $2Al_3^+ + 3SO_4^{2^-} --> Al_2(SO_4)_3$ (correct)

Let me give you an easy way of balancing:

Al is 3+ SO₄ is 2-

Simply transpose the number of positives (or negatives) for each ion, to the other ion, by placing this value of one ion, in front of the other ion. That is, Al^{3+} the 3 goes in front of the SO_4^{2-} as $3SO_4^{2-}$, and SO_4^{2-} , the 2 goes in front of the Al^{3+} to become $2Al^{3+}$. Then on the **right hand side** of the equation, this same number (now in front of each ion on the **left side** of the equation), is placed after each "ion" entity.

Let us again look at:

```
Al_3^+ + SO_4^{2^-} --> AlSO_4 (incorrect)

Al_3^+ + SO_4^{2^-} --> Al_2(SO_4)_3 (correct)
```

Put the three from the \overline{Al} in front of the SO_4^{2-} and the 2 from the SO_4^{2-} in front of the Al_3^+ . Equation becomes:

 $2\dot{Al_3}^+ + 3SO_4^{2^-} --> Al_2(SO_4)_3$. You simply place the valency of one ion, as a whole number, in front of the other ion, and vice versa.

Remember to encase the SO₄ in brackets. **Why?** Because we are dealing with the sulfate ion, SO₄²⁻, and it is this ion that is 2- charged (not just the O₄), so we have to ensure that the "ion" is bracketed. Now to check, the 2 times $3^+ = 6^+$, and 3 times $2^- = 6^-$. We have equal amounts of positive ions, and equal amounts of negative ions.

Another example:

NaOH + HCI --> ?

Na is Na⁺, OH is OH⁻, so this gave us NaOH. Originally, the one positive canceled the one negative.

HCl is H⁺ + Cl , this gave us HCl.

Reaction is going to be the Na⁺ reacting with a negatively charged ion. This will have to be the chlorine, Cl⁻, because at the moment the Na⁺ is tied to the OH⁻. **So:** Na⁺ + Cl⁻ --> NaCl The H+ from the HCl will react with a negative (-) ion this will be the OH⁻ from the NaOH. **So:** H⁺ + OH⁻ --> H₂O (water).

The complete reaction can be written:

NaOH + HCl --> NaCl + H_2O . We have **equal amounts** of all atoms **each side** of the equation, so the equation is **balanced**.

or

Na⁺OH⁻ + H⁺Cl⁻ --> Na⁺Cl⁻ + H⁺OH⁻

Something More Difficult:

 $Mg(OH)_2 + H_3PO_4 --> ?$ (equation on left **not** balanced)

 Mg^{2^+} 2OH⁻ + 3H⁺PO₄³⁻ --> ? (equation on left **not** balanced), so let us rewrite the equation in **ionic form**.

The Mg^{2+} needs to react with a negatively charged ion, this will be the PO_4^{3-} , so: $3Mq^{2+} + 2PO_4^{3-} --> Mq_3(PO_4)_2$

(**Remember** the **swapping** of the positive or negative charges on the ions in the **left side** of the equation, and placing it in front of each ion, and then placing this number after each ion on the **right side** of the equation)

What is left is the H $^+$ from the H $_3$ PO $_4$ and this will react with a negative ion, we only have the OH $^-$ from the Mg(OH) $_2$ left for it to react with. 6H $^+$ + 6OH $^-$ --> 6H $_2$ O

Where did I get the 6 from? When I balanced the $\rm Mg^{2^+}$ with the $\rm PO_4^{3^-}$, the equation became $\rm 3Mg^{2^+} + 2PO_4^{3^-} --> Mg_3(PO_4)_2$

Therefore, I must have required $3Mg(OH)_2$ to begin with, and $2H_3PO_4$, (because we originally had $(OH)_2$ attached to the Mg, and H_3 attached to the PO_4 . I therefore have $2H_3$ reacting with $3(OH)_2$. We have to write this, on the **left side** of the equation, as $6H^+ + 6OH^-$ because we need it in ionic form.

The equation becomes:

 $6H^{+} + 6OH^{-} --> 6H_{2}O$

The full equation is now balanced and is:

 $3Mg(OH)_2 + 2H_3PO_4 --> Mg_3(PO_4)_2 + 6H_2O$

I have purposely split the equation into segments of reactions. This is showing you which ions are reacting with each other. Once you get the idea of equations you will not need this step.


.The balancing of equations is simple. You need to learn the valency of the common ions (see tables). The rest is pure mathematics; you are balancing valency charges, positives versus negatives. You have to have the **same number** of **negatives**, or **positives**, each side of the equation, and the **same number** of **ions** or **atoms** each side of the equation.

If one ion, example Al_3^+ , (3 positive charges) reacts with another ion, example OH^- (one negative ion) then we require 2 more negatively charged ions (in this case OH^-) to counteract the 3 positive charges the Al_3^+ contains.

Take my earlier hint, place the 3 from the Al_3^+ in front of the OH^- , now reads $3OH^-$, place the 1 from the hydroxyl OH^- in front of the Al_3^+ , now stays the same, Al_3^+ (the 1 is **never** written in chemistry equations).

 $Al_3^+ + 3OH^- --> Al(OH)_3$

The 3 is simply written in front of the OH^- , a recognized ion, there are no brackets placed around the OH^- . On the right hand side of the equation, all numbers in front of each ion on the left hand side of the equation are placed after each same ion on the right side of the equation. Brackets are used in the right side of the equation because the result is a compound. Brackets are also used for compounds (**reactants**) in the left side of equations, as in $3Mg(OH)_2 + 2H_3PO_4 \longrightarrow ?$





Hard to tell, but these are one-ton chlorine gas containers. Notice the five gallon bucket of motor oil in the bottom photograph. Also notice this photograph is the only eye wash station that we found during our inspection of 10 different facilities. Do you have an eye wash and emergency shower?



Chemistry of Chlorination

Chlorine can be added as sodium hypochlorite, calcium hypochlorite or chlorine gas. When any of these is added to water, chemical reactions occur as these equations show:

CI 2 + H 2 O → HOCI + HCI (chlorine gas) (water) (hypochlorous acid) (hydrochloric acid)

CaOCI + H 2 O → 2HOCI + Ca(OH) (calcium hypochlorite) (water) (hypochlorous acid) (calcium hydroxide)

NaOCI + H 2 O → HOCI + Na(OH) (sodium hypochlorite) (water) (hypochlorous acid) (sodium hydroxide)

All three forms of chlorine produce hypochlorous acid (HOCI) when added to water. Hypochlorous acid is a weak acid but a strong disinfecting agent. The amount of hypochlorous acid depends on the pH and temperature of the water. Under normal water conditions, hypochlorous acid will also chemically react and break down into a hypochlorite ion.

(OCI -): HOCI H + + OCI - Also expressed HOCI \rightarrow H + + OCI - (hypochlorous acid) (hydrogen) (hypochlorite ion)

The hypochlorite ion is a much weaker disinfecting agent than hypochlorous acid, about 100 times less effective.

Let's now look at how pH and temperature affect the ratio of hypochlorous acid to hypochlorite ions. As the temperature is decreased, the ratio of hypochlorous acid increases. Temperature plays a small part in the acid ratio. Although the ratio of hypochlorous acid is greater at lower temperatures, pathogenic organisms are actually harder to kill. All other things being equal, higher water temperatures and a lower pH are more conducive to chlorine disinfection.

Types of Residual

If water were pure, the measured amount of chlorine in the water should be the same as the amount added. But water is not 100% pure. There are always other substances (interfering agents) such as iron, manganese, turbidity, etc., which will combine chemically with the chlorine.

This is called the *chlorine demand*. Naturally, once chlorine molecules are combined with these interfering agents, they are not capable of disinfection. It is free chlorine that is much more effective as a disinfecting agent.

So let's look now at how free, total, and combined chlorine are related. When a chlorine residual test is taken, either a total or a free chlorine residual can be read.

Total residual is all chlorine that is available for disinfection.

Total chlorine residual = free + combined chlorine residual.

Free chlorine residual is a much stronger disinfecting agent. Therefore, most water regulating agencies will require that your daily chlorine residual readings be of free chlorine residual.

Break-point chlorination is where the chlorine demand has been satisfied; any additional chlorine will be considered *free chlorine*.

Residual Concentration/Contact Time (CT) Requirements

Disinfection to eliminate fecal and coliform bacteria may not be sufficient to adequately reduce pathogens such as Giardia or viruses to desired levels. Use of the *CT* disinfection concept is recommended to demonstrate satisfactory treatment, since monitoring for very low levels of pathogens in treated water is analytically very difficult.

The CT concept, as developed by the EPA (Federal Register, 40 CFR, Parts 141 and 142, June 29, 1989), uses the combination of disinfectant residual concentration (mg/L) and the effective disinfection contact time (in minutes) to measure effective pathogen reduction. The residual is measured at the end of the process, and the contact time used is the T10 of the process unit (time for 10% of the water to pass).

CT = Concentration (mg/L) x Time (minutes)

The effective reduction in pathogens can be calculated by reference to standard tables of



500 pound chlorine gas container and 150-pound cylinders. The 1/2 ton is on a scale. Cylinders stand upright and containers on their sides.

Required Giardia/Virus Reduction

All surface water treatment systems shall ensure a minimum reduction in pathogen levels: 3-log reduction in *Giardia* and 4-log reduction in viruses.

These requirements are based on unpolluted raw water sources with *Giardia* levels of = 1 cyst/100 L, and a finished water goal of 1 cyst/100,000 L (equivalent to 1 in 10,000 risk of infection per person per year). Higher raw water contamination levels may require greater removals as shown on Table 4.1.

TABLE 4.1

Level of Giardia Reduction Raw Water Giardia Levels* Recommended Giardia Log Reduction

< 1 cyst/100 L 3-log

1 cyst/100 L - 10 cysts/100 L 3-log - 4-log

10 cysts/100 L - 100 cysts/100 L 4-log - 5-log

> 100 cysts/100 L > 5-log

*Use geometric means of data to determine raw water *Giardia* levels for compliance.

Required CT Value


Required CT values are dependent on pH, residual concentration, temperature and the disinfectant used. The tables attached to Appendices A and B shall be used to determine the required CT.

Calculation and Reporting of CT Data

Disinfection CT values shall be calculated daily, using either the maximum hourly flow and the disinfectant residual at the same time, or by using the lowest CT value if it is calculated more frequently. Actual CT values are then compared to required CT values.

Results shall be reported as a reduction Ratio, along with the appropriate pH, temperature, and disinfectant residual. The reduction Ratio must be greater than 1.0 to be acceptable.

Users may also calculate and record actual log reductions. Reduction Ratio = CT actual ÷ CT required



Chlorinator Parts

- A. Ejector
- **B. Check Valve Assembly**
- C. Rate Valve
- D. Diaphragm Assembly
- E. Interconnection Manifold
- F. Rotameter Tube and Float
- G. Pressure Gauge
- H. Gas Supply



Chlorine measurement devices or Rotameters.



Safety Information: There is a fusible plug on every chlorine tank. This metal plug will melt at 158° to 165° F. This is to prevent a build-up of excessive pressure and the possibility of cylinder rupture due to fire or high temperatures.

Chlorination Equipment Requirements

For all water treatment facilities, chlorine gas under pressure shall not be permitted outside the chlorine room. A chlorine room is where chlorine gas cylinders and/or ton containers are stored. Vacuum regulators shall also be located inside the chlorine room. The chlorinator, which is the mechanical gas proportioning equipment, may or may not be located inside the chlorine room.

For new and upgraded facilities, from the chlorine room, chlorine gas vacuum lines should be run as close to the point of solution application as possible. Injectors should be located to minimize the length of pressurized chlorine solution lines. A gas pressure relief system shall be included in the gas vacuum line between the vacuum regulator(s) and the chlorinator(s) to ensure that pressurized chlorine gas does not enter the gas vacuum lines leaving the chlorine room.

The gas pressure relief system shall vent pressurized gas to the atmosphere at a location that is not hazardous to plant personnel; the vent line should be run in such a manner that moisture collecting traps are avoided. The vacuum regulating valve(s) shall have positive shutdown in the event of a break in the downstream vacuum lines.

As an alternative to chlorine gas, it is permissible to use hypochlorite with positive displacement pumping. Anti-siphon valves shall be incorporated in the pump heads or in the discharge piping.

Capacity

The chlorinator shall have the capacity to dose enough chlorine to overcome the demand and maintain the required concentration of the *free* or *combined* chlorine.

Methods of Control

The chlorine feed system shall be automatic proportional controlled, automatic residual controlled or compound loop controlled. In the automatic proportional controlled system, the equipment adjusts the chlorine feed rate automatically in accordance with the flow changes to provide a constant pre-established dosage for all rates of flow. In the automatic residual controlled system, the chlorine feeder is used in conjunction with a chlorine residual analyzer which controls the feed rate of the chlorine feeders to maintain a particular residual in the treated water.

In the compound loop control system, the feed rate of the chlorinator is controlled by a flow proportional signal and a residual analyzer signal to maintain particular chlorine residual in the water.

A manual chlorine feed system may be installed for groundwater systems with constant flow rates.

Standby Provision

As a safeguard against malfunction and/or shut-down, standby chlorination equipment having the capacity to replace the largest unit shall be provided. For uninterrupted chlorination, gas chlorinators shall be equipped with an automatic changeover system. In addition, spare parts shall be available for all chlorinators.

Weigh Scales

Scales for weighing cylinders shall be provided at all plants using chlorine gas to permit an accurate reading of total daily weight of chlorine used. At large plants, scales of the recording and indicating type are recommended. At a minimum, a platform scale shall be provided. Scales shall be of corrosion-resistant material.

Securing Cylinders

All chlorine cylinders shall be securely positioned to safeguard against movement. Tag the cylinder *empty* and store upright and chained.

Ton containers may not be stacked.

Chlorine Leak Detection

Automatic chlorine leak detection and related alarm equipment shall be installed at all water treatment plants using chlorine gas. Leak detection shall be provided for the chlorine rooms. Chlorine leak detection equipment should be connected to a remote audible and visual alarm system and checked on a regular basis to verify proper operation.

Leak detection equipment shall not automatically activate the chlorine room ventilation system in such a manner as to discharge chlorine gas. During an emergency, if the chlorine room is unoccupied, the chlorine gas leakage shall be contained within the chlorine room itself in order to facilitate a proper method of clean-up.

Consideration should also be given to the provision of caustic soda solution reaction tanks for absorbing the contents of leaking one-ton cylinders where such cylinders are in use.

Chlorine leak detection equipment may not be required for very small chlorine rooms with an exterior door (i.e., floor area less than 3m²).

You can use a spray solution of Ammonia or a rag soaked with Ammonia to detect a small Cl₂ leak. If there is a leak, the ammonia will create a white colored smoke. Ammonium Chloride.



The facility shall be provided with personnel safety equipment including the following: Respiratory equipment, safety shower, eyewash, gloves, eye protection, protective clothing, cylinder and/or ton repair kits.

Respiratory equipment shall be provided which has been approved under the OHSA, General Safety Regulation - Selection of Respiratory Protective Equipment. Equipment shall be in close proximity to the access door(s) of the chlorine room.



Chlorine Room Design Requirements

Where gas chlorination is practiced, the gas cylinders and/or the ton containers up to the vacuum regulators shall be housed in a gas-tight, well illuminated, corrosion resistant, and mechanically ventilated enclosure. The chlorinator may or may not be located inside the chlorine room. The chlorine room shall be located at the ground floor level.

Ventilation

Gas chlorine rooms shall have entirely separate exhaust ventilation systems capable of delivering one complete air change per minute during periods of chlorine room occupancy only. The air outlet from the room shall be 150 mm above the floor and the point of discharge located to preclude contamination of air inlets to buildings or areas used by people. The vents to the outside shall have insect screens.

Air inlets should be louvered near the ceiling, the air being of such temperature as to not adversely affect the chlorination equipment. Separate switches for fans and lights shall be outside the room at all entrance or viewing points, and a clear wire-reinforced glass window shall be installed in such a manner as to allow the operator to inspect from the outside of the room.

Heating

Chlorine rooms shall have separate heating systems, if a forced air system is used to heat the building. The hot water heating system for the building will negate the need for a separate heating system for the chlorine room. The heat should be controlled at approximately 15°C.

Cylinders or containers shall be protected to ensure that the chlorine maintains its gaseous state when entering the chlorinator.

Access

All access to the chlorine room shall only be from the exterior of the building. Visual inspection of the chlorination equipment from inside may be provided by the installation of glass window(s) in the walls of the chlorine room. Windows should be at least 0.20 m2 in area and be made of clear wire reinforced glass.

There should also be a **panic bar** on the inside of the chlorine room door for emergency exit.

Storage of Chlorine Cylinders

If necessary, a separate storage room may be provided to simply store the chlorine gas cylinders, with no connection to the line. The chlorine cylinder storage room shall have access either to the chlorine room or from the plant exterior, and arranged to prevent the uncontrolled release of spilled gas.

The chlorine gas storage room shall have provision for ventilation at thirty air changes per hour. Viewing glass windows and a panic button on the inside of door should also be provided.

In very large facilities, entry into the chlorine rooms may be through a vestibule from outside.

Scrubbers

For facilities located within residential or densely populated areas, consideration shall be given to provide scrubbers for the chlorine room.



Chlorine Demand

Chlorine combines with a wide variety of materials. These side reactions complicate the use of chlorine for disinfecting purposes. Their demand for chlorine must be satisfied before chlorine becomes available to accomplish disinfection. Chlorine demand is the amount of chlorine required to react on various water impurities before a residual is obtained. Also, the amount of chlorine required to produce a free chlorine residual of 0.1 mg/l after a contact time of 15 minutes as measured by iodmetic method of a sample at a temperature of 20 degrees in conformance with standard methods.

Chlorine Questions and Answer Review

Downstream from the point of post chlorination, what should the concentration of a free chlorine residual be in a clear well or distribution reservoir? 0.5 mg/L.

True or False. Even brief exposure to 1,000 ppm of Cl₂ can be fatal. True

How does one determine the ambient temperature in a chlorine room? Use a regular thermometer because ambient temperature is simply the air temperature of the room.

How is the effectiveness of disinfection determined? From the results of coliform testing.

How often should chlorine storage ventilation equipment be checked? Daily.

Alternate Disinfectants

Chloramine

Chloramine is a very weak disinfectant for Giardia and virus reduction. It is recommended that it be used in conjunction with a stronger disinfectant. It is best utilized as a stable distribution system disinfectant.

In the production of chloramines, the ammonia residuals in the finished water, when fed in excess of the stoichiometric amount needed, should be limited to inhibit growth of nitrifying bacteria.

Chlorine Dioxide

Chlorine dioxide may be used for either taste and odor control or as a pre-disinfectant. Total residual oxidants (including chlorine dioxide and chlorite, but excluding chlorate) shall not exceed 0.30 mg/L during normal operation or 0.50 mg/L (including chlorine dioxide, chlorite and chlorate) during periods of extreme variations in the raw water supply.

Chlorine dioxide provides good Giardia and virus protection but its use is limited by the restriction on the maximum residual of 0.5 mg/L ClO₂/chlorite/chlorate allowed in finished water. This limits usable residuals of chlorine dioxide at the end of a process unit to less than 0.5 mg/L.

Where chlorine dioxide is approved for use as an oxidant, the preferred method of generation is to entrain chlorine gas into a packed reaction chamber with a 25% aqueous solution of sodium chlorite (NaClO₂).

Warning: Dry sodium chlorite is explosive and can cause fires in feed equipment if leaking solutions or spills are allowed to dry out.

Ozone

Ozone is a very effective disinfectant for both Giardia and viruses. Ozone CT(Contact time) values must be determined for the ozone basin alone; an accurate T10 value must be obtained for the contact chamber, residual levels measured through the chamber and an average ozone residual calculated.

Ozone does not provide a system residual and should be used as a primary disinfectant only in conjunction with free and/or combined chlorine.

Ozone does not produce chlorinated byproducts (such as trihalomethanes) but it may cause an increase in such byproduct formation if it is fed ahead of free chlorine; ozone may also produce its own oxygenated byproducts such as aldehydes, ketones or carboxylic acids. Any installed ozonation system must include adequate ozone leak detection alarm systems, and an ozone offgas destruction system.

Ozone may also be used as an oxidant for removal of taste and odor or may be applied as a predisinfectant.

Method	Method Focus	Title	Order Number	Source
4500-Cl⁻ B	Chloride by Silver Nitrate Titration	Standard Methods for the Examination of Water and Wastewater, 18th & 19th Ed.	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-Cl⁻ D	Chloride by Potentiometric Method	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI D	Chlorine Residual by Amperometric Titration (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI E	Chlorine Residual by Low Level Amperometric Titration (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI F	Chlorine Residual by DPD Ferrous Titration (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI G	Chlorine Residual by DPD Colorimetric Method (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI H	Chlorine Residual by Syringaldazine (FACTS) Method (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CI I	Chlorine Residual by lodometric Electrode Technique (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CIO ₂ C	Chlorine Dioxide by the Amperometric Method I	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CIO ₂ D	Chlorine Dioxide by the DPD Method (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)
4500-CIO ₂ E	Chlorine Dioxide by the Amperometric Method II (Stage 1 DBP use SM 19th Ed. only)	Standard Methods for the Examination of Water and Wastewater, 18th, 19th & 20th Editions	Included in Standard Methods	American Water Works Assn. (AWWA)

Chlorine Dioxide Methods

Most tests for chlorine dioxide rely upon its oxidizing properties. Consequently, numerous test kits are readily available that can be adapted to measure chlorine dioxide. In addition, new methods that are specific for chlorine dioxide are being developed. The following are the common analytical methods for chlorine dioxide:

	DPD glycine	Chlorophenol Red	Direct Absorbance	lodometric Titration	Amperometric Titration
Method Type:	Colorimetric	Colorimetric	Colorimetric	Titrimetric	Titrimetric
How It Works	Glycine removes Cl ₂ ; ClO ₂ forms a pink color, whose intensity is proportional to the ClO ₂ concentration.	CIO ₂ bleaches chlorophenol red indicator. The degree of bleaching is proportional to the concentration of CIO ₂ .	The direct measurement of CIO ₂ is determined between 350 and 450 nM.	Two aliquots are taken one is sparged with N ₂ to remove CIO ₂ . KI is added to the other sample at pH7 and titrated to a colorless endpoint. The pH is lower to 2, the color allowed to reform and the titration continued. These titrations are repeated on the sparged sample.	
Range	0.5 to 5.0 ppm.	0.1 to 1.0 ppm	100 to 1000 ppm	> 1 ppm	< 1ppm
Interferences	Oxidizers	None	Color, turbidity	Oxidizers	
Complexity	Simple	Moderate	Simple	Moderate	High
Equipment Required	Spectrophotometer or Colorimeter			Titration equipment	Amperometric Titrator
EPA Status	Approved	Not approved	Not approved	Not Approved	
Recommendation	Marginal	Yes	Marginal	Yes	Marginal

Chlorine Exposure Limits

This information is necessary to pass your certification exam.

* OSHA PEL 1 PPM - IDLH 10 PPM and Fatal Exposure Limit 1,000 PPM

The current **OSHA PEL** for chlorine is 1 ppm (3 milligrams per cubic meter (mg/m⁽³⁾)) as a ceiling limit. A worker's exposure to chlorine shall at no time exceed this ceiling level. * **IDLH 10 PPM**

Physical and chemical properties of chlorine: A yellowish green, nonflammable and liquefied gas with an unpleasant and irritating smell. It can be readily compressed into a clear, amber-colored liquid, a noncombustible gas, and a strong oxidizer. Solid chlorine is about 1.5 times heavier than water and gaseous chlorine is about 2.5 times heavier than air. Atomic number of chlorine is 17. Cl is the elemental symbol and Cl_2 is the chemical formula.

Monochloramine, dichloramine, and trichloramine are also known as Combined Available Chlorine. $Cl_2 + NH_4$

HOCl and OCl-: The **OCL-** is the hypochlorite ion and both of these species are known as free available chlorine. These are the two main chemical species formed by chlorine in water and they are known by collectively as hypochlorous acid and the hypochlorite ion. When chlorine gas is added to water, it rapidly hydrolyzes. The chemical equations best describes this reaction is **CI2 + H2O --> H+ + CI- + HOCl.** Hypochlorous acid is the most germicidal of the chlorine compounds with the possible exception of chlorine dioxide.

Yoke-type connectors should be used on a chlorine cylinder's valve ,assuming that the threads on the valve may be worn.

The connection from a chlorine cylinder to a chlorinator should be replaced by using a new, approved gasket on the connector. Always follow your manufacturer's instructions.

On a one-ton container, the chlorine pressure reducing valve should be located downstream of the evaporator when using an evaporator. This is the liquid chlorine supply line and it is going to be made into chlorine gas.

In water treatment, chlorine is added to the effluent before the contact chamber (before the clear well) for complete mixing. One reason for not adding it directly to the chamber is that the chamber has very little mixing due to low velocities.

Here are several safety precautions when using chlorine gas: in addition to protective clothing and goggles, chlorine gas should be used only in a well-ventilated area so that any leaking gas cannot concentrate. Emergency procedures in the case of a large uncontrolled chlorine leak are to: notify local emergency response team, warn and evacuate people in adjacent areas, and be sure that no one enters the leak area without adequate self-contained breathing equipment.



Here are several symptoms of chlorine exposure: burning of eyes, nose, and mouth; coughing, sneezing, choking; nausea and vomiting; headaches and dizziness; fatal pulmonary edema, pneumonia, and skin blisters. A little Cl₂ will corrode the teeth and then progress to throat cancer.

Approved method for storing a 150 - 200 pound chlorine cylinder: secure each cylinder in an upright position, attach the protective bonnet over the valve and firmly secure each cylinder. Never store near heat. Always store the empty in an upright, secure position with proper signage.

Respiratory Protection Section

Conditions for Respirator Use

Good industrial hygiene practice requires that engineering controls be used where feasible to reduce workplace concentrations of hazardous materials to the prescribed exposure limit.

However, some situations may require the use of respirators to control exposure. Respirators must be worn if the ambient concentration of chlorine exceeds prescribed exposure limits. Respirators may be used before engineering controls have been installed, during work operations such as maintenance or repair activities that involve unknown exposures, during operations that require entry into tanks or closed vessels, and during emergencies. Workers should only use respirators that have been approved by NIOSH and the Mine Safety and Health Administration (MSHA).

Respiratory Protection Program

Employers should institute a complete respiratory protection program that, at a minimum, complies with the requirements of OSHA's Respiratory Protection Standard [29 CFR 1910.134]. Such a program must include respirator selection, an evaluation of the worker's ability to perform the work while wearing a respirator, the regular training of personnel; respirator fit testing, periodic workplace monitoring, and regular respirator maintenance, inspection, and cleaning. The implementation of an adequate respiratory protection program (including selection of the correct respirator) requires that a knowledgeable person be in charge of the program and that the program be evaluated regularly.

For additional information on the selection and use of respirators and on the medical screening of respirator users, consult the latest edition of the NIOSH Respirator Decision Logic [NIOSH 1987b] and the NIOSH Guide to Industrial Respiratory Protection [NIOSH 1987a].

Personal Protective Equipment

Workers should use appropriate personal protective clothing and equipment that must be carefully selected, used, and maintained to be effective in preventing skin contact with chlorine. The selection of the appropriate personal protective equipment (PPE) (i.e., gloves, sleeves, encapsulating suits) should be based on the extent of the worker's potential exposure to chlorine.

The resistance of various materials to permeation by both chlorine liquid and chlorine gas is shown below:

Material Breakthrough Time (hr.) Chlorine Liquid Responder

Chlorine gas butyl rubber neoprene Teflon viton saranex barricade chemrel responder trellchem HPS nitrile rubber H (**PE/EVAL**) polyethylene polyvinyl chloride. Material is estimated (but not tested) to provide at least four hours of protection. Not recommended, degradation may occur.

To evaluate the use of these PPE materials with chlorine, users should consult the best available performance data and manufacturers' recommendations. Significant differences have been demonstrated in the chemical resistance of generically similar PPE materials (i.e., butyl) produced by different manufacturers. In addition, the chemical resistance of a mixture may be significantly different from that of any of its neat components.

Any chemical-resistant clothing that is used should be periodically evaluated to determine its effectiveness in preventing dermal contact. Safety showers and eye wash stations should be located close to operations that involve chlorine.


Splash-proof chemical safety goggles or face shields (20 to 30 cm long, minimum) should be

worn during any operation in which a solvent, caustic or other


toxic substance may be splashed into the eyes.

In addition to the possible need for wearing protective outer apparel (i.e., aprons, encapsulating suits), workers should wear work uniforms, coveralls, or similar full-body coverings that are laundered each day. Employers should provide lockers or other closed areas to store work and street clothing separately. Employers should collect work clothing at the end of each work shift and provide for its laundering. Laundry personnel should be informed about the potential hazards of handling contaminated clothing and instructed about measures to minimize their health risk.

Protective clothing should be kept free of oil and grease and should be inspected and maintained regularly to preserve its effectiveness. Protective clothing may interfere with the body's heat dissipation, especially during hot weather or during work in hot or poorly ventilated work environments.



Recommendations for Preparing/Handling/Feeding Sodium Hypochlorite Solutions



As a result of the pressures brought to bear by Health and Safety requirements, some users of gas have chosen to seek alternative forms of disinfectants for their water and wastewater treatment plants. One of these alternative forms is sodium hypochlorite (**NaOCI**). This is often purchased commercially at 10 to 15% strength.

The handling and storage of NaOCI presents the plant with a new and sometimes unfamiliar, set of equipment installation configurations and operating conditions.

Product Stability The oxidizing nature of this substance means that it should be handled with extreme care. As NaOCI is relatively unstable, it degrades over time.

There are Three Ways in Which NaOCI Solutions Degrade

- > Chlorate-forming reaction due to age, temperature, light and minor reduction in pH.
- Oxygen-producing reaction that occurs when metals, such as iron, copper, nickel or metal oxides are brought into contact with the solution.
- > Chlorine-producing reaction when solution pH falls below 6.

There are Many Factors that Affect the Stability of a NaOCI Solution

- Initial solution strength.
- > pH solution.
- > Temperature of the solution.
- > Exposure of the solution to sunlight.

Shock Chlorination — Well Maintenance

Shock chlorination is a relatively inexpensive and straightforward procedure used to control bacteria in water wells. Many types of bacteria can contaminate wells, but the most common are iron and sulfate-reducing bacteria.

Although not a cause of health problems in humans, bacteria growth will coat the inside of the well casing, water piping and pumping equipment, creating problems such as:

- > Reduced well yield
- Restricted water flow in distribution lines
- Staining of plumbing fixtures and laundry
- Plugging of water treatment equipment
- > "Rotten egg" odor.

Bacteria may be introduced during drilling of a well or when pumps are removed for repair and laid on the ground. However, iron and sulfate-reducing bacteria (as well as other bacteria) can exist naturally in groundwater.

A well creates a direct path for oxygen to travel into the ground where it would not normally exist. When a well is pumped, the water flowing in will also bring in nutrients that enhance bacterial growth.

Note: All iron staining problems are not necessarily caused by iron bacteria. The iron naturally present in the water can be the cause.

Ideal Conditions for Iron Bacteria

Water wells provide ideal conditions for iron bacteria. To thrive, iron bacteria require 0.5-4 mg/L of dissolved oxygen, as little as 0.01 mg/L dissolved iron and a temperature range of 5 to 15°C. Some iron bacteria use dissolved iron in the water as a food source.

Signs of Iron and Sulfate-Reducing Bacteria

There are a number of signs that indicate the presence of iron and sulfate-reducing bacteria. They include:

- Slime growth
- > Rotten egg odor
- Increased staining.

Slime Growth

The easiest way to check a well and water system for iron bacteria is to examine the inside surface of the toilet flush tank. If you see a greasy slime or growth, iron bacteria are probably present. Iron bacteria leave this slimy by-product on almost every surface the water is in contact with.

Rotten Egg Odor

Sulfate-reducing bacteria can cause a rotten egg odor in water. Iron bacteria aggravate the problem by creating an environment that encourages the growth of sulfate-reducing bacteria in the well. Sulfate-reducing bacteria prefer to live underneath the slime layer that the iron bacteria form.



Some of these bacteria produce hydrogen sulfide as a by-product, resulting in a **rotten egg** or sulfur odor in the water. Others produce small amounts of sulfuric acid which can corrode the well casing and pumping equipment.

Increased Staining Problems

Iron bacteria can concentrate iron in water sources with low iron content. It can create a staining problem where one never existed before or make an iron staining problem worse as time goes by.

Use the following checklist to determine if you have an iron or sulfate-reducing bacteria problem. The first three are very specific problems related to these bacteria. The last two problems can be signs of other problems as well.

Checklist to Determine an Iron or Sulfate-Reducing Bacteria Problem

- > Greasy slime on inside surface of toilet flush tank
- Increased red staining of plumbing fixtures and laundry
- Sulfur odor
- > Reduced well yield
- Restricted water flow

Mixing a Chlorine Solution

Add a half gallon of bleach to a clean pail with about 3 gallons of water. This is generally sufficient to disinfect a 4 inch diameter well 100 feet deep or less. For wells greater than 100 feet deep or with a larger casing diameter, increase the amount of bleach proportionately.

If you have a dug well with a diameter greater than 18 inches, use 2 to 4 gallons of bleach added directly to the well. Please note that many dug wells are difficult or impossible to disinfect due to their unsanitary construction.

Shock Chlorination — Well Maintenance

Shock Chlorination Method

Shock chlorination is used to control iron and sulfate-reducing bacteria and to eliminate fecal coliform bacteria in a water system. To be effective, shock chlorination must disinfect the following:

- > The entire well depth
- > The formation around the bottom of the well
- > The pressure system
- > Some water treatment equipment
- > The distribution system.

To accomplish this, a large volume of super chlorinated water is siphoned down the well to displace all the water in the well and some of the water in the formation around the well.

Effectiveness of Shock Chlorination

With shock chlorination, the entire system (from the water-bearing formation, through the well-bore and the distribution system) is exposed to water which has a concentration of chlorine strong enough to kill iron and sulfate reducing bacteria. Bacteria collect in the pore spaces of the formation and on the casing or screened surface of the well.

To be effective, you must use enough chlorine to disinfect the entire cased section of the well and adjacent water-bearing formation.

The procedure described below does not completely eliminate iron bacteria from the water system, but it will hold it in check.

To control the iron bacteria, you may have to repeat the procedure each spring and fall as a regular maintenance procedure. If your well has never been shock chlorinated or has not been done for some time, it may be necessary to use a stronger chlorine solution, applied two or three times, before you notice a significant improvement in the water.

You might also consider hiring a drilling contractor to thoroughly clean and flush the well before chlorinating in order to remove any buildup on the casing.

In more severe cases, the pump may have to be removed and chemical solutions added to the well and vigorous agitation carried out using special equipment. This is to dislodge and remove the bacterial slime, and should be done by a drilling contractor.

Shock Chlorination Procedure for Small Drilled Wells

A modified procedure is also provided for large diameter wells.


Caution: If your well is low yielding or tends to pump any silt or sand, you must be very careful using the following procedure because over pumping may damage the well.

When pumping out the chlorinated solution, monitor the water discharge for sediment.

Follow these steps to shock chlorinate your well:

Store sufficient water to meet farm and family needs for 8 to 48 hours.

Pump the recommended amount of water (see Amount of Chlorine Required to Obtain a Chlorine Concentration of 1000 PPM) into clean storage. A clean galvanized stock tank or pickup truck box lined with a 4 mil thick plastic sheet is suitable. The recommended amount of water to use is twice the volume of water present in the well casing. To measure how much water is in the casing, subtract the non-pumping water level from the total depth of the well.



12% industrial sodium hypochlorite and 70% high test hypochlorite are available from:

- Water treatment suppliers
- Drilling contractor
- Swimming pool maintenance suppliers
- Dairy equipment suppliers
- Some hardware stores.

Amount of chlorine required to obtain a chlorine concentration of 1000 PPM. Since a dry chemical is being used, it should be mixed with water to form a chlorine solution before placing it in the well.

Calculate the amount of chlorine that is required. Mix the chlorine with the previously measured water to obtain a 1000 ppm chlorine solution.

Calculating Amount of Chlorine Example

If your casing is 6 in. and you are using 12% industrial sodium hypochlorite, you will require .091 L per ft. of water in the casing. If you have 100 ft. of water in the casing, you will use 0.091 L x 100 ft. = 9.1 L of 12% chlorine.

Calculate the amount of chlorine you will need for your well.

Casing diameter	Chlorine strength		
L needed per 1 ft. of wate	er x	ft. of water in casing =	L of chlorine.

Caution: Chlorine is corrosive and can even be deadly.

If your well is located in a pit, you must make sure there is proper ventilation during the chlorination procedure. Well pits are no longer legal to construct. Use a drilling contractor who has the proper equipment and experience to do the job safely.

Shock Chlorination — Well Maintenance

Siphon this solution into the well.

Open each hydrant and faucet in the distribution system (including all appliances that use water such as dishwasher, washing machine, furnace humidifier) until the water coming out has a chlorine odor. This will ensure all the plumbing fixtures are chlorinated.

Allow the hot water tank to fill completely. Consult your water treatment equipment supplier to find out if any part of your water treatment system should be bypassed to prevent damage.

Leave the chlorine solution in the well and distribution system for 8 to 48 hours. The longer the contact time, the better the results.

- Open an outside tap and allow the water to run until the chlorine odor is greatly reduced. Make sure to direct the water away from sensitive plants or landscaping.
- Flush the chlorine solution from the hot water heater and household distribution system. The small amount of chlorine in the distribution system will not harm the septic tank.

Backwash and regenerate any water treatment equipment.

If you have an old well that has not been routinely chlorinated, consider hiring a drilling contractor to thoroughly clean the well prior to chlorinating. Any floating debris should be removed from the well and the casing should be scrubbed or hosed to disturb the sludge buildup.

Modified Procedure for Large Diameter Wells

Due to the large volume of water in many bored wells the above procedure can be impractical. A more practical way to shock chlorinate a bored well is to mix the recommended amount of chlorine right in the well. The chlorinated water is used to force some of the chlorine solution into the formation around the well. Follow these steps to shock chlorinate a large diameter bored well.

Pump 200 gal. (1000 L) of water into a clean storage tank at the well head.

Mix 20 L of 5 1/4% domestic chlorine bleach (or 8 L of 12% bleach or 1.4 kg of 70% calcium hypochlorite) into the 200 gal. of stored water.

Calculate the amount of chlorine you require per foot of water in the casing and add directly into the well. (Note that the 70% hypochlorite powder should be dissolved in water to form a solution before placing in the well.)

Circulate chlorine added to the water in the well by hooking a garden hose up to an outside faucet and placing the other end back down the well. This circulates the chlorinated water through the pressure system and back down the well. Continue for at least 15 minutes.

Siphon the 200 gal. bleach and water solution prepared in Steps 1 and 2 into the well. Complete the procedure as described in Steps 5 to 9 for drilled wells.

Don't mix acids with chlorine. This is dangerous.

Calculating Water and Chlorine Requirements for Shock Chlorination

Complete the following table using your own figures to determine how much water and chlorine you need to shock chlorinate your well.

Since a dry chemical is being used, it should be mixed with water to form a chlorine solution prior to placing it in the well.

What Should I do if my Well Water is Contaminated with Bacteria?


First, don't panic! Bacterial contamination is very common. Studies have found that over 40 percent of private water supplies are contaminated with coliform bacteria. Spring water supplies are the most frequently contaminated, with over 70 percent containing coliform bacteria.

Improving protection of a well or spring from the inflow of surface water is an important option to consider if the supply is contaminated with bacteria. It is important to remember the groundwater is not necessarily contaminated in these cases; rather, the well is acting to funnel contaminants down into the groundwater.

Although well pits were the common method of construction several years ago, they are no longer considered sanitary construction. A properly protected well is evidenced by the well casing extending above the surface of the ground and the ground sloping away from the well to prevent water from collecting around the casing. A properly protected spring is developed underground and the water channeled to a sealed spring box. At no time should the water be exposed to the ground surface.


Keeping the plumbing system clean is an important part of maintaining a sanitary water supply. Anytime work is performed on the plumbing or pump, the entire water system should be disinfected with chlorine. Simply pulling the pump out of the well, setting it on the grass to work on it, and returning it to the well is enough to contaminate the well with bacteria. The procedure for cleaning and sanitizing a well or spring with chlorine is called **shock chlorination**. Concentrations of chlorine ranging from 50 to 200 mg/1 are used in the shock chlorination process. This is 100 to 400 times the amount of chlorine found in *city water*. The highly chlorinated water is held in the pipes for 12 to 24 hours before it is flushed out and the system is ready to be used again.

WELL PROTECTION



Periodic shock chlorination also may be effective in reducing an **iron bacteria** problem. The amount of chlorine needed to shock chlorinate a water system is determined by the amount of water standing in the well.

Only use the amount of chlorine laundry bleach or powdered high-test hypochlorite (**HTH**) that is needed for wells. If in doubt, it is better to use more chlorine rather than less.



Fluoride Treatment and Addition

Some water providers will add fluoride to the water to help prevent cavities in children. Too much fluoride will mottle the teeth.

Chemical Feed

The equipment used for feeding the fluoride to water shall be accurately calibrated before being placed in operation, and at all times shall be capable of maintaining a rate of feed within 5% of the rate at which the machine is set.

The following chemical feed practices apply:

- 1. Where a dry feeder of the volumetric or gravimetric type is used, a suitable weighing mechanism shall be provided to check the daily amount of chemical feed.
- 2. Hoppers should be designed to hold a 24 hour supply of the fluoride compound and designed, so the dust hazard to operators is minimized.



- 3. Vacuum dust filters shall be installed with the hoppers to prevent dust from rising into the room when the hopper is filled.
- 4. Dissolving chambers are required for use with dry feeders, and dissolving chambers shall be designed, so the required rate of feed of the chemical the solution strength will not be greater than 1/4 of that of a saturated solution at the temperature of the dissolving water. The construction material of the dissolving chamber and associated piping shall be compatible with the fluoride solution to be fed.
- 5. Solution feeders shall be of the positive displacement type and constructed of material compatible with the fluoride solution being fed.
- 6. The weight of the daily amount of fluoride fed to water shall be accurately determined.
- 7. Feeders shall be provided with anti-siphon valves on the discharge side. Wherever possible, positive anti-siphon breakers other than valves shall be provided.
- 8. A *day tank* capable of holding a 24 hour supply of solution should be provided.
- 9. All equipment shall be sized, so it will be operated in the 20 to 80 percent range of the scale, and be capable of feeding over the entire pumpage range of the plant.
- 10. Alarm signals are recommended to detect faulty operation of equipment.
- 11. The fluoride solution should be added to the water supply at a point where the fluoride will not be removed by any following treatment processes and where it will be mixed with the water. It is undesirable to inject the fluoride compound or solution directly on-line unless there are provisions for adequate mixing.

Metering

Metering of the total water to be fluoridated shall be provided, and the operation of the feeding equipment is to be controlled.

Control of the feed rate shall be automatic/ proportional controlled, whereby the fluoride feed rate is automatically adjusted in accordance with the flow changes to provide a constant preestablished dosage for all rates of flow, or automatic/ residual controlled, whereby a continuous automatic fluoride analyzer determines the residual fluoride level and adjusts the rate of feed accordingly, or compound loop controlled, whereby the feed rate is controlled by a flow proportional signal and residual analyzer signal to maintain a constant residual.

Alternate Compounds

Any one of the following fluoride compounds may be used:

- 1. Hydrofluosilicic acid,
- 2. Sodium fluoride or.
- 3. Sodium silicofluoride.

Other fluoride compounds may be used if approved by the EPA.

Chemical Storage and Ventilation

The fluoride chemicals shall be stored separately from other chemicals, and the storage area shall be marked "FLUORIDE CHEMICALS ONLY". The storage area should be in close proximity to the feeder, kept relatively dry, and provided with



pallets (if using bagged chemical) to allow circulation of air and to keep the containers off the floor.

Record of Performance

Accurate daily records shall be kept. These records shall include:

- 1. The daily reading of the water meter which controls the fluoridation equipment or that which determines the amount of water to which the fluoride is added.
- 2. The daily volume of water fluoridated.
- 3. The daily weight of fluoride compound in the feeder.
- 4. The daily weight of fluoride compound in stock.
- 5. The daily weight of the fluoride compound fed to the water.
- 6. The fluoride content of the raw and fluoridated water determined by laboratory analysis, with the frequency of measurement as follows:
 - (i) treated water being analyzed continuously or once daily, and
 - (ii) raw water being analyzed at least once a week.

Sampling

In keeping the fluoride records, the following sampling procedures are required:

- 1. A sample of raw water and a sample of treated water shall be forwarded to an approved independent laboratory for fluoride analysis once a month.
- 2. On new installations or during start-ups of existing installations, weekly samples of raw and treated water for a period of not less than four consecutive weeks.
- 3. In addition to the reports required, the EPA may require other information that is deemed necessary.

Safety


The following safety procedures shall be maintained:

- 1. All equipment shall be maintained at a high standard of efficiency, and all areas and appliances shall be kept clean and free of dust. Wet or damp cleaning methods shall be employed wherever practicable.
- 2. Personal protective equipment shall be used during the clean-up, and appropriate covers shall be maintained over all fluoride solutions.
- 3. At all installations, safety features are to be considered and the necessary controls built into the installation to prevent an overdose of fluoride in the water. This shall be done either by use of day tanks or containers, anti-siphon devices, over-riding flow switches, sizing of pump and feeders, determining the length and duration of impulses, or other similar safety devices.
- 4. Safety features shall also be provided to prevent spills and overflows.
- 5. Individual dust respirators, chemical safety face shields, rubber gloves, and protective clothing shall be worn by all personnel when handling or being exposed to the fluoride dust.
- 6. Chemical respirators, rubber gloves, boots, chemical safety goggles and acid proof aprons shall be worn where acids are handled.
- 7. After use, all equipment shall be thoroughly cleaned and stored in an area free of fluoride dusts. Rubber articles shall be washed in water, and hands shall be washed after the equipment is stored; and,
- 8. All protective devices, whether for routine or emergency use, shall be inspected periodically and maintained in good operating condition.

Repair and Maintenance

Upon notifying the appropriate local board of health, a fluoridation program may be discontinued when necessary to repair or replace equipment, but shall be placed in operation immediately after the repair or replacement is complete. Records shall be maintained and submitted during the period that the equipment is not in operation.





Surface Water Treatment Rule (SWTR). The rule specifies maximum contaminant level goals for *Giardia lamblia*, viruses and *Legionella*, and promulgated filtration and disinfection requirements for public water systems using surface water sources or by ground water sources under the direct influence of surface water. The regulations also specify water quality, treatment and watershed protection criteria under which filtration may be avoided.

Water Quality What's That Stuff in the Tap Water?

by Jameel Rahman and Gary A. Burlingame

Jameel Rahman is a retired analytical chemist supervisor for the Materials Testing Laboratory at the Philadelphia Water Department, where Gary A. Burlingame is the supervisor of water quality and research. Contact Burlingame at gary.burlingame@phila.gov or (215) 685-1417.

Reprinted from Opflow, Vol. 29, No. 2 (February 2003), by permission. Copyright 2003, American Water Works Association.

Almost every water utility employee responsible for solving customer problems has fielded a complaint about particles in a bathtub or faucet aerator. Although particles can come from cold or hot water systems, household plumbing, water distribution systems, and water treatment, the water supplier—at least in customers' eyes—is usually "guilty until proven innocent."

The Philadelphia Water Department has standardized procedures in place that can identify offending materials and help pinpoint their source.

Collecting and Identifying Particulates

Typically, the suspended matter customers complain about is particulate in form. The most important step in solving a particulate complaint is to collect as much suspect material as possible, making sure it represents the customer's actual concern. Sometimes enough material for analysis can be collected from faucet aerators. A container may be left with the customer for sample collection during normal tap use.

Particulates can also accumulate in the toilet tank

Particulate matter can be extracted from water samples by using nitrocellulose membrane filters. A 0.45 μm filter can be used if the water's colloidal matter doesn't clog the filter before enough particulate material is collected for analysis. Enough particulate matter can usually be captured with a water sample of approximately 250 mL.

When samples have low turbidity, larger volumes will need to be filtered.

Granular Rust→



Under a microscope, examine the particulate matter captured on a filter. Use a zoom microscope with at least 40×, preferably 75×, magnification to identify matter on the membrane filter disk, which can be stored in a Plexiglas Petri dish. For optimum observation, illuminate the particulates from above with a fiber-optic light.

Some particulates can be identified by their appearance and, sometimes, by touching them with a sharp needle and observing their physical properties, such as softness, stickiness, or solubility in a solvent. Particulates can be quantified as few, several, or numerous. If particulates cannot be identified by their appearance, perform simple chemical tests on the filter. A characteristic evolution of a gas, such as carbon dioxide from scale particulates or marble, can be observed under the microscope. Color formed by chemical reactions can be seen by the unaided eye. If these tests still fail to identify the debris, or further delineation is required, use infrared spectroscopy (**IR**).

Visual Identification

Sand particulates have a characteristic vitreous appearance and irregular shape with smooth facets. They can be colorful but usually appear translucent to whitish.

Mica particulates have a characteristic platelet shape and shine under reflected light. You will need to understand the common soil minerals in your area to identify them.

Man-made fibers, found in all colors and with a characteristic wrinkled strip shape, are present in single strands, have significant length, and often are visible to the unaided eye. Usually, fibers are not present in large numbers — at most, 10 per filter. Fibers used in apparel are round, but fibers found in water typically have a strip shape, indicating a common source, such as pump packing.

Glass chips are transparent, may have smooth facets with sharp edges, and may be colorful.

Relatively large amounts of similar particulates often indicate a problem within a plumbing system. Usually the source of such particulates is disintegrating plastic, a rubber gasket, or a corroding component of the plumbing system.

Heat Identification

Activated carbon (AC) particulates are black and usually coated with debris. They can show porosity but, appear dull compared to anthracite particulates, which display a shiny luster under reflected light. Pick up a few particulates on the tip of a wetted platinum wire and burn them in the blue part of a Bunsen burner flame. AC particulates will burn instantaneously with a glitter and no visible smoke or residue.

Disintegrated plastic particulates are usually white, large, and may be present in large numbers. Pick up a few particulates and burn them in a Bunsen burner flame. Plastic burns with a smoke. With fine-tipped tweezers, remove sufficient particulates from the disk and further identify them by IR. Most often they are polypropylene plastic.

Disintegrated rubber gasket particulates are usually black, relatively large and do not smear the filter disk with black when a drop of toluene is applied. If pressed with a needle, they flex. Remove a few particulates and burn them; rubber burns with a black smoke. Identify them further by IR.

Often these particulates are ethylene-propylene-diene monomer, used in gaskets.

Acid Identification

Rust particulates are usually abundant and are easy to identify with their typically brown and rough irregular shapes. Large particulates may have yellow and black streaks or inclusions, while fine rust particulates form a uniform brown film on the filter disk. To confirm rust, add a drop of (1+1) hydrochloric acid (500 mL of 11.5N hydrochloric acid [HCl] solution plus 500 mL of distilled water) to the filter. Yellow staining indicates the presence of ferric chloride. Add a drop of 2 percent solution of potassium thiocyanate on the yellow area where HCl was added. Brick-red staining confirms the presence of potassium ferrithiocyanate.



Large Rust Particles

Lead solder particulates are gray and may have a whitish coating, are usually brittle and can be easily pulverized. Often, they are relatively large in size compared to most other particulates on the filter disk. If lead particulates are suspected, add a drop of pH 2.8 tartrate-buffer solution followed by a drop of 0.2 percent solution of freshly prepared sodium rhodizonate. If the particulates turn scarlet red, lead solder is present.

Prepare a pH 2.8 buffer solution by dissolving 1.9 g of sodium bitartrate and 1.5 g of tartaric acid in 100 mL of distilled water. To prepare the sodium rhodizonate reagent, dissolve 0.2 g of rhodizonic acid disodium salt in 100 mL of distilled water.

Patina is hydrated basic copper carbonate and has a greenish color. These irregularly shaped particulates result from corrosion of copper and copper alloys. To confirm their presence, add a drop of (1+1) HCl from a Pasture pipette. If tiny bubbles of carbon dioxide form under the microscope, the presence of patina is indicated. Remove a few particulates and place them in the cavity of a spot-test plate. Add a drop of (1+1) HCl followed by a drop of ammonia. Appearance of a blue precipitate or blue color confirms the presence of patina particulates. Rust particulates will interfere with this test if it is performed on the rust-coated filter.

Calcium carbonate can develop as a white scale through evaporation of hard water or can occur as a particulate of limestone or calcite. Scales can form in water heaters.

Limestone can come from water treatment processes. Add a drop of HCl (1+1) on the particulates and observe the evolution of carbon dioxide under the microscope. The brisk evolution of gas confirms the presence of carbonates.

Solvent Identification

Asphalt pipe-coating compounds are black. To differentiate between various black particulates, add a drop of toluene or chloroform to the filter disk under the microscope. If the disk becomes smeared with black around the particulates, the particulates are classified as pipe-coating of an asphaltic nature. Anthracite, activated carbon, and rubber particulates are insoluble in the solvents used.

Anthracite particulates appear shiny compared with other black particulates and do not smear the filter disk if a drop of toluene is applied. These particulates can be removed from the filter disk and burned in a crucible; they will leave a solid residue.

Grease particulates are black and may be shiny. They are usually present as tiny heaps on the filter disk because of their softness and hydrophobic nature. They are soft and sticky when touched with a needle and can be smeared easily on the disk. Add a drop of toluene; grease will dissolve and a black color will spread around the particulates.

Let the toluene evaporate or use an oven to expedite drying. Touch the particulates with a needle in the area where toluene was added; they should no longer be sticky and may behave like a black powder. All greases may not behave this way, but their stickiness and extreme softness differentiates them from other black particulates.

Infrared Spectroscopy

When particulates cannot be completely identified by the above means, use IR to identify organic and inorganic materials. Inorganic compounds include calcium carbonate, calcium sulfate, barium sulfate, lead carbonate, metal oxides, silicates, or phosphates. Visually, and with the aid of heat, you might suspect a particulate is plastic in nature, but various types of plastics can occur in water systems, including polypropylene, polyvinyl chloride, and polyethylene. IR can differentiate between plastic materials.

Atoms in a molecule are in constant motion, changing bond angles by bending and bond lengths by stretching. Among these motions only certain vibrations absorb infrared radiation of specific energy. When portions of electromagnetic radiation are absorbed by such vibrations, an IR absorption band spectrum appears, which an infrared spectrometer records.

Each compound has a unique infrared absorption spectrum, and various compounds can be identified by comparing absorption band positions in the IR spectrum of an unknown compound to band positions of known compounds.

Particulates are removed with fine-tipped tweezers one by one from the filter disk and transferred to a small vial for dissolving in a solvent, or to a small agate mortar for grinding and mixing with KBr for making a potassium bromide (KBr) pellet.

The usually brittle plastic fragments can be powdered easily, and 10 mg of sample is all that is commonly needed to produce a good infrared absorption spectrum. Inorganic materials are identified by IR scanning of the KBr pellet of the sample alone; organic materials are identified by scanning a pellet or a film of the sample cast on a KBr plate.



Zeolite Particles from a Water Softener

Most plastics are readily soluble in hot o-dichlorobenzene; try dissolving the sample in this solvent first. If soluble, cast a film of the sample on a KBr plate and scan it. If the sample is insoluble, evaporate the solvent completely and transfer the particulates to an agate mortar, make a KBr pellet, and scan the pellet. After obtaining a reasonably strong infrared spectrogram, the sample is identified by manual means or a computer search of a commercially available online IR library.

Standard Chemical Analyses

Chemical analyses available in most full-service water testing laboratories can be used to identify particulates when sufficient material is available. For example, hydrated aluminum oxide can occur as white slurry and be analyzed by inductively coupled plasma emission spectrometry after dissolving in mineral acids.

Similarly, granules of lead solder can also be analyzed by wet chemical or instrumental methods. After a sample is dissolved in a mineral acid, it can be analyzed for various elements by atomic absorption spectrophotometry. A variety of materials, including iron oxides, manganese dioxides, aluminum oxides, calcium carbonates, and copper and silicate particulates, can be identified by common chemical analyses.

During the late 1990s, customers in Philadelphia and across the country complained about white particulates clogging faucet aerators. Infrared spectroscopy revealed the particulates to be polypropylene, a plastic not used in the distribution system. The only common source for this plastic was found to be the dip tubes in residential gas hot-water heaters (see Opflow, December 1998).

Eventually, the dip-tube manufacturer admitted to changing materials to a less-durable plastic, prompting water heater manufacturers to give rebates to customers for dip-tube replacements. When this issue made the TV news, Philadelphia was in a good position to explain the situation to customers because our procedure was already in place for testing and characterizing particulates.



Dip Tube Particles

Table 1. Potential sources for particulate matter found in tap water

	From	From
	Customer	Water Supplier
Particulate	Plumbing	Piping
Activated carbon fines		X
Asphaltic lining fragments		X
Backfill sand		X
Calcium carbonate scale	X	X
Cast iron rust		X
Cement lining fragments		X
Copper fragments	X	
Glass chips		X
Greases and lubricants	X	X
Lead fragments	X	
Manganese dioxide deposits		X
Man-made fibers		X
On-site treatment device media	X	
Plastic fragments	X	
Rubber gasket fragments	X	X
Soil minerals, mica		X

Table 2. Suspended matter classified by size

Soluble $< 0.45 \mu m$

Colloidal $< 1.0 \mu m \text{ but} > 0.45 \mu m$


Particulate $> 1.0 \mu m$

End of Article by Jameel Rahman and Gary A. Burlingame

Granular Activated Carbon / Powdered Activated Carbon

Along with aeration, granular activated carbon (**GAC**) and powdered activated carbon (**PAC**) are suitable treatments for removal of organic contaminants such as VOCs, solvents, PCBs, herbicides, and pesticides.

Activated carbon is carbon that has been exposed to very high temperature, creating a vast network of pores with a very large internal surface area; one gram of activated carbon has a surface area equivalent to that of a football field. It removes contaminants through adsorption, a process in which dissolved contaminants adhere to the surface of the carbon particles. GAC can be used as a replacement for existing media (such as sand) in a conventional filter or it can be used in a separate contactor such as a



ACTIVATED CARBON ABSORBS GASES AND CHEMICALS

vertical steel pressure vessel used to hold the activated carbon bed.

After a period of a few months or years, depending on the concentration of the contaminants, the surface of the pores in the GAC can no longer adsorb contaminants and the carbon must be replaced. Several operational and maintenance factors affect the performance of granular activated carbon. Contaminants in the water can occupy adsorption sites, whether or not they are targeted for removal. Also, adsorbed contaminants can be replaced by other contaminants with which GAC has a greater affinity, so their presence might interfere with removal of contaminants of concern.

A significant drop in the contaminant level in influent water can cause a GAC filter to desorb, or slough off adsorbed contaminants, because GAC is essentially an equilibrium process. As a result, raw water with frequently changing contaminant levels can result in treated water of unpredictable quality. Bacterial growth on the carbon is another potential problem. Excessive bacterial growth, may cause clogging and higher bacterial counts in the treated water. The disinfection process must be carefully monitored in order to avoid this problem.

Powdered activated carbon consists of finely ground particles and exhibits the same adsorptive properties as the granular form. PAC is normally applied to the water in a slurry and then filtered out. The addition of PAC can improve the organic removal effectiveness of conventional treatment processes and also remove tastes and odors.

The advantages of PAC are that it can be used on a short-term or emergency basis with conventional treatment, it creates no headloss, it does not encourage microbial growth and it has relatively small capital costs. The main disadvantage is that some contaminants require large doses of PAC for removal. It is also somewhat ineffective in removing natural organic matter due to the competition from other contaminants for surface adsorption, and the limited contact time between the water and the carbon.

Corrosion Control

Corrosion is the deterioration of a substance by chemical action. Lead, cadmium, zinc, copper and iron might be found in water when metals in water distribution systems corrode. Drinking water contaminated with certain metals (**such as lead and cadmium**) can harm human health.

Corrosion also reduces the useful life of water distribution systems and can promote the growth of microorganisms, resulting in disagreeable tastes, odors, slimes, and further corrosion. Because it is widespread and highly toxic, lead is the corrosion product of greatest concern.

The EPA has banned the use of lead solders, fluxes, and pipes in the installation or repair of any public water system. In the past, solder used in plumbing has been 50% tin and 50% lead. Using lead-free solders, such as silver-tin and antimony-tin is a key factor in lead corrosion control.

The highest level of lead in consumers' tap water will be found in water that has been standing in the pipes after periods of nonuse (**overnight or longer**). This is because standing water tends to leach lead or copper out of the metals in the distribution system more readily than does moving water. Therefore, the simplest short-term or immediate measure that can be taken to reduce exposure to lead in drinking water is to let the water run for two to three minutes before each use. Also, drinking water should not be taken from the hot water tap, as hot water tends to leach lead more readily than cold. Long-term measures for addressing lead and other corrosion by-products include pH and alkalinity adjustment; corrosion inhibitors; coatings and linings; and cathodic protection.



Cathodic Protection

Cathodic protection protects steel from corrosion which is the natural electrochemical process that results in the deterioration of a material because of its reaction with its environment.

Metallic structures, components, and equipment exposed to aqueous environments, soil or seawater can be subject to corrosive attack and accelerated deterioration. Therefore, it is often necessary to utilize either impressed current or sacrificial anode cathodic protection (**CP**) in combination with coatings as a means of suppressing the natural degradation phenomenon to provide a long and useful service life. However, if proper considerations are not given, problems can arise which can produce unexpected, premature failure.

There are Two Types of Cathodic Protection:

Ø Sacrificial Anodes (Galvanic Systems) Ù Impressed (Induced) Current Systems

How Does Cathodic Protection Work?

Sacrificial anodes are pieces of metal more electrically active than the steel piping system.

Because these anodes are more active, the corrosive current will exit from them rather than the piping system.

Thus, the system is protected while the attached anode is **sacrificed**.

Sacrificial anodes can be attached to the existing piping system or coated steel for a preengineered Cathodic protection system.

An asphalt coating is not considered a suitable dielectric coating.

Depleted anodes must be replaced for continued Cathodic protection of the system.

Impressed or Induced Current Systems

An impressed current Cathodic protection system consists of anodes, cathodes, a rectifier and the soil.

The rectifier converts the alternating current to direct current. The direct current is then sent through an insulated copper wire to anodes that are buried in the soil near the piping system.

Typical anode materials are ceramic, high silicon cast iron, or graphite. Ceramic anodes are not consumed, whereas high silicon cast iron and graphite anodes partially dissolve each year and must be replaced over time.

The direct current then flows from the anode through the soil to the piping system, which acts as the cathode, and back to the rectifier through another insulated copper wire.

As a result of the electrochemical properties of the impressed current Cathodic protection system, corrosion takes place only at the anodes and not at the piping system. Depleted anodes must be replaced for continued Cathodic protection of the piping system.

Sacrificial Anode System

In this system, a metal or alloy reacting more vigorously than the corroding specimen acts as an anode and the corroding structure as a whole is rendered Cathodic. These anodes are made of materials such as magnesium, aluminum or zinc which are anodic with respect to the protected structure. The sacrificial anodes are connected directly to the structure.

Advantages

- 1. Needs no external power source.
- 2. Does not involve maintenance work.
- 3. If carefully designed, it can render protection for anticipated period.
- 4. Installation is simple.
- 5. Does not involve expensive accessories like rectifier unit, etc.
- 6. Economical for small structures.

Disadvantages

- 1. The driving voltage is small and therefore the anodes have to be fitted close to the structure or on the structure, thereby increasing the weight or load on the structure.
- 2. The anodes have to be distributed all over the structure (as throwing power is lower) and therefore have design limitations in certain applications.
- 3. Once designed and installed, protection current cannot be altered or increased as may be needed in case of cathode area extension (unprotected) or foreign structure interference (physical contact).

Impressed Current System

The impressed current anode system, on the other hand, has several advantages over the sacrificial anode systems. In this system the protection current is *Forced* through the environment to the structure (cathode) by means of an external D.C. source. Obviously we need some material to function as anodes. It can be high silicon chromium cast iron anodes, graphite anodes, or lead-silver alloy anodes.

Advantages

- 1. Since the driving voltage is large, this system offers freedom of installation design and location.
- 2. Fewer anodes can protect a large structure.
- 3. Variations in protection current requirements can be adjusted to some extent (to be incorporated at design stage).

Disadvantages

- 1. Shut down of D.C. supply for a long time allows structure to corrode again.
- 2. Reversal of anode cathode connection at D.C. source will be harmful, as structure will dissolve anodic
- 3. Needs trained staff for maintenance of units and for monitoring.
- 4. Initial investments are higher and can pay off only in long run and economic only for large structures.
- 5. Power cost must be incorporated in all economic considerations.
- 6. Possibility of overprotection should be avoided as it will affect the life of the paint.
- 7. Any foreign structure coming within this field will cause an interference problem.

Alkalinity and pH Adjustment

Adjusting pH and alkalinity is the most common corrosion control method because it is simple and inexpensive. pH is a measure of the concentration of hydrogen ions present in water; alkalinity is a measure of water's ability to neutralize acids.

Generally, water pH less than 6.5 is associated with uniform corrosion, while pH between 6.5 and 8.0 can be associated with pitting corrosion. Some studies have suggested that systems using only pH to control corrosion should maintain a pH of at least 9.0 to reduce the availability of hydrogen ions as electron receptors. However, pH is not the only factor in the corrosion equation; carbonate and alkalinity levels affect corrosion as well.

Generally, an increase in pH and alkalinity can decrease corrosion rates and help form a protective layer of scale on corrodible pipe material. Chemicals commonly used for pH and alkalinity adjustment are hydrated lime (CaOH₂ or calcium hydroxide), caustic soda (NaOH or sodium hydroxide), soda ash (Na₂CO₃ or sodium carbonate), and sodium bicarbonate (NaHCO₃, essentially baking soda). Care must be taken, however, to maintain pH at a level that will control corrosion but not conflict with optimum pH levels for disinfection and control of disinfection byproducts.

Corrosion Inhibitors

Inhibitors reduce corrosion by forming protective coatings on pipes. The most common corrosion inhibitors are inorganic phosphates, sodium silicates and mixtures of phosphates and silicates. These chemicals have proven successful in reducing corrosion in many water systems.

The phosphates used as corrosion inhibitors include polyphosphates, orthophosphates, glassy phosphates and bimetallic phosphates. In some cases, zinc is added in conjunction with orthophosphates or polyphosphates.



Glassy phosphates, such as sodium hexametaphosphate, effectively reduce iron corrosion at dosages of 20 to 40 mg/l. Glassy phosphate has an appearance of broken glass and can cut the operator. Sodium silicates have been used for more than 50 years to inhibit corrosion. The effectiveness depends on the water pH and carbonate concentration.

Sodium silicates are particularly effective for systems with high water velocities, low hardness, low alkalinity and a pH of less than 8.4. Typical coating maintenance doses range from 2 to 12 mg/1.

They offer advantages in hot water systems because of their chemical stability. For this reason, they are often used in the boilers of steam heating systems.



Detention Time

The actual time required for a small amount of water to pass through a sedimentation basin at a given rate of flow, or the calculated time required for a small amount of liquid to pass through a tank at a given rate of flow.

Detention Time = (Basin Volume, Gallons) (24 Hours/day)
Flow, Gallons/day

Water Storage Section

Water storage facilities and tanks vary in size, shape, and application. There are different types that are used in the water distribution systems, such as standpipes, elevated tanks and reservoirs, hydropneumatic tanks and surge tanks.

These tanks serve multiple purposes in the distribution system. Just the name alone can give you an idea of its purpose.

- SURGE tanks
- RESERVOIRS
- ELEVATED tanks Water towers and Standpipes

Surge Tanks

What really causes water main breaks - **ENERGY** - when released in a confined space, such as a water distribution system? Shock waves are created when hydrants, valves, or pumps are opened and closed quickly, trapping the kinetic energy of moving water within the confined

space of a piping system.

These shock waves can create a turbulence that travels at the speed of sound, seeking a point of release. The release the surge usually finds is an elevated tank, but the surge doesn't always find this release quickly enough. Something has to give, and often times, it's your pipe fittings.

Distribution operators are aware of this phenomenon! It's called **WATER HAMMER**.

This banging can be heard as water hammer. Try it at home




- turn on your tap, then turn it off very quickly. You should hear a bang, and maybe even several. If you turn the tap off more slowly, it should stay quiet, as the liquid in the pipes slows down more gradually.

A Surge tank should not be used for water storage.

The goal of the water tower or standpipe is to store water high in the air, where it has lots of gravitational potential energy. This stored energy can be converted to pressure potential energy or kinetic energy for delivery to homes.

Since height is everything, building a cylindrical water tower is inefficient. Most of the water is then near the ground. By making the tower wider near the top, it puts most of its water high up.



Normal day for a Distribution Worker after a Water Hammer broke a water main. Aren't you glad to work in a nice plant? This is one good reason never to complain about working at a water plant. Unless you have to work shift work.

Cross-Connections, Backflow, Backsiphonage and Backpressure

- Cross connection occurs when a potable water line and a nonpotable water line connect. The nonpotable water line may contain waste water or other liquids that are not safe to drink. Backflow is the waste water that enters potable water lines through a cross connection. Backflow from cross connections can cause serious illness.
- ➤ Backsiphonage occurs when a water main or a plumbing system in a building loses water pressure. The water may drain from a building back to the potable water line. Such pressure drops can cause siphoning of waste water or other fluids into the potable water line. This can happen when a water main breaks or when a fire hydrant is used.





A large Fireline RP backflow Preventer.


Backpressure occurs when water pressure in a building or fixture is greater than the water pressure in the water supply. This condition can force waste water or other fluids back into the potable water line. Common causes of backpressure involve connecting plumbing to a pump or to steam and/or air pressure.

Substantial changes in water quality can occur as drinking water is transported through a distribution system from the point of major treatment and/or disinfection to consumers' taps.

Hopefully, you will attain an understanding of the mechanisms by which water flow, biofilms and pathogens interact in pipes and service reservoirs to affect health-related and aesthetic dimensions of water quality at consumers' taps.







Commonly found Cross-Connections.

Hard Water Section

Water contains various amounts of dissolved minerals, some of which impart a quality known as hardness. Consumers frequently complain about problems attributed to hard water, such as the formation of scale on cooking utensils and hot water heaters.

In this section, we will examine the occurrence, effects of hard water, and the hard water treatment or softening process that removes the hardness-causing minerals.

The precipitation process most frequently used is generally known as the lime process or lime soda process. Because of the special facilities required and the complexity of the process, it is generally applicable only to medium or large-size water systems where all treatment can be accomplished at a central location. This process will provide softened water at the lowest cost. Lime softening can be used for treatment of either groundwater or surface water sources.

The other commonly used method of softening involves the ion exchange process. This process has the advantages of a considerably lower initial cost and ease of use by small systems or by large systems at multiple locations. The principal disadvantage is that operating costs are considerably higher. Ion exchange processes can typically be used for direct treatment of groundwater, so long as turbidity and iron levels are not excessive. For treatment of surface water, the process normally must be preceded by conventional treatment.

Softening can also be accomplished using membrane technology, electrodialysis, distillation, and freezing. Of these, membrane methods seem to have the greatest potential.

Distillers

Various sizes of distillers are available for home use. They all work on the principle of vaporizing water and then condensing the vapor. In the process, dissolved solids such as salt, metals, minerals, asbestos fibers, and other particles are removed. Some organic chemicals are also removed, but those that are more volatile are often vaporized and condensed with the product water. Distillers are effective in killing all microorganisms.

The principal problem with a distiller is that a small unit can produce only 2-3 gal (7.5 -11 Lt) a day, and the power cost for operation will be substantially higher than the operating cost of other types of treatment devices.

Water Distillers have a high energy cost (approximately 20-30 cents per gallon). They must be carbon filtered before and/or after to remove volatile chemicals. It is considered *dead* water because the process removes all extra oxygen and energy. It has no taste. It is still second only to reverse osmosis water for health. Diet should be rich in electrolytes, as the aggressive nature of distilled water can **leach** electrolytes from the body.



Occurrence of Hard Water

Hard water is caused by soluble, divalent, metallic cations, (positive ions having valence of 2). The principal chemicals that cause water hardness are calcium (**Ca**) and magnesium (**Mg**). Strontium, aluminum, barium, and iron are usually present in large enough concentrations to contribute significantly to the total hardness.

Water hardness varies considerably in different geographic areas of the contiguous 48 states. This is due to different geologic formations, and is also a function of the contact time between water and limestone deposits. Magnesium is dissolved as water passes over and through dolomite and other magnesium-bearing minerals. Because groundwater is in contact with these formations for a longer period of time than surface water, groundwater is normally harder than surface water.

Expressing Hardness Concentration

Water hardness is generally expressed as a concentration of calcium carbonate, in terms of milligrams per liter as CaCO₃. The degree of hardness that consumers consider objectionable will vary, depending on other qualities of the water and on the hardness to which they have become accustomed. We will show two different classifications of the relative hardness of water:

Comparative classifications of water for softness and hardness

Classification	mg/L as CaCO₃ [*]	mg/L as CaCO₃⁺
Soft	0 – 75	0 – 60
Moderately hard	75 – 150	61 – 120
Hard	150 – 300	121 – 180
Very hard	Over 300	Over 180

Source: Adapted from sawyer 1960 and Briggs and Ficke 1977.

Types of Hardness

Hardness can be categorized by either of two methods: calcium versus magnesium hardness and carbonate versus non-carbonate hardness.

The calcium-magnesium distinction is based on the minerals involved. Hardness caused by calcium is called calcium hardness, regardless of the salts associated with it, which include calcium sulfate (CaSO₄), calcium chloride (CaCl₂) and others. Likewise, hardness caused by magnesium is called magnesium hardness. Calcium and magnesium are normally the only significant minerals that cause harness, so it is generally assumed that:

Total hardness = Calcium hardness + Magnesium hardness

The carbonate-noncarbonate distinction, however, is based on hardness from either the bicarbonate salts of calcium or the normal salts of calcium and magnesium involved in causing water hardness.

^{*} Per Sawyer (1960)

⁺ Per Briggs and Ficke (1977)

Carbonate hardness is caused primarily by the bicarbonate salts of calcium and magnesium, which are calcium bicarbonate, Ca(HCO₃)₂, and magnesium bicarbonate Mg(HCO₃)₂. Calcium and magnesium combined with carbonate (CO₃) also contribute to carbonate hardness. Noncarbonate hardness is a measure of calcium and magnesium salts other than carbonate and bicarbonate salts. These salts are calcium sulfate, calcium chloride, magnesium sulfate (MgSO₄), and magnesium chloride (MgCl₂). Calcium and magnesium combined with nitrate may also contribute to noncarbonate hardness, although it is a very rare condition. For carbonate and noncarbonate hardness:

Total hardness = Carbonate hardness + Noncarbonate hardness

When hard water is boiled, carbon dioxide (CO₂) is driven off, and Bicarbonate salts of calcium and magnesium then settle out of the water to form calcium and magnesium carbonate precipitates. These precipitates form the familiar chalky deposits on teapots. Because it can be removed by heating, carbonate hardness is sometimes called **temporary hardness**. Because noncarbonated hardness cannot be removed or precipitated by prolonged boiling, it is sometimes called **permanent hardness**.

Objections to Hard Water

Scale Formation

Hard water forms scale, usually calcium carbonate, which causes a variety of problems. Left to dry on the surface of glassware and plumbing fixtures, including showers doors, faucets, and sink tops; hard water leaves unsightly white scale known as water spots. Scale that forms on the inside of water pipes will eventually reduce the flow capacity or possibly block it entirely. Scale that forms within appliances and water meters causes wear on moving parts.

When hard water is heated, scale forms much faster. In particular, when the magnesium hardness is more than about 40 mg/l (as CaCO₃), magnesium hydroxide scale will deposit in hot water heaters that are operated at normal temperatures of 140-150°F (60-66°C). A coating of only 0.04 in. (1 mm) of scale on the heating surfaces of a hot water heater creates an insulation effect that will increase heating costs by about 10 percent.



Effect on Soap

The historical objection to hardness has been its effect on soap. Hardness ions form precipitates with soap, causing unsightly **curd**, such as the familiar bathtub ring, as well as reduced efficiency in washing and laundering. To counteract these problems, synthetic detergents have been developed and are now used almost exclusively for washing clothes and dishes. These detergents have additives known as sequestering agents that **tie up** the hardness ions so that they cannot form the troublesome precipitates. Although modern detergents counteract many of the problems of hard water, many customers prefer softer water.


Water Softening

Water softening is a method of removing minerals from water which make the water hard. Hard water does not dissolve soap readily. It forms scale in pipes, boilers, and other equipment in which it is used. The principal methods of softening water are the lime soda process and the ion exchange process.

In the *lime soda process*, soda ash and lime are added to the water in amounts determined by chemical tests. These chemicals combine with the calcium and magnesium in the water to make insoluble compounds that settle to the bottom of the water tank.

In the *ion exchange process*, the water filters through minerals called *zeolites*. As the water passes through the filter, the sodium ions in the zeolite are exchanged for the calcium and magnesium ions in the water, and the water is softened.

After household softeners become exhausted, a strong solution of **sodium chloride** (salt) is passed through the filter to replace the sodium that has been lost. The use of two exchange materials makes it possible to remove both metal and acid ions from water.



Some cities and towns, however, prohibit or restrict the use of ion exchange equipment on drinking water, pending the results of studies on how people are affected by the consumption of the added sodium in softened water.

Calcium and magnesium in water create hard water, and high levels can clog pipes. The best way to soften water is to use a water softener unit connected into the water supply line. You may want to consider installing a separate faucet for unsoften water for drinking and cooking.


Water softening units also remove iron. The most common way to soften household water is to use a water softener. Softeners may also be safely used to remove up to about 5 milligrams per


liter of dissolved iron if the water softener is rated for that amount of iron removal. Softeners are automatic, semi-automatic, or manual. Each type is available in several sizes and is rated on the amount of hardness it can remove before regeneration is necessary.

Using a softener to remove iron in naturally soft water is not advised; a green-sand filter is a better method. When the resin is filled to capacity, it must be recharged. Fully automatic softeners regenerate on a preset schedule and return to service automatically. Regeneration is usually started by a preset time clock; some units are started by water use meters or hardness detectors. Semi-automatic softeners have automatic controls for everything except for the start of regeneration. Manual units require manual operation of one or more valves to control back washing, brining and rinsing. In many areas, there are companies that provide a water softening service. For a monthly fee the company installs a softener unit and replaces it periodically with a freshly charged unit.

The principle behind water softening is really just simple chemistry. A water softener contains resin beads which hold electrically charged ions. When hard water passes through the softener, calcium and magnesium ions are attracted to the charged resin beads. It's the resulting removal of calcium and magnesium ions that produces **soft water**. The diagram shows the exchange that takes place during the water softening process.

When the resin beads in your softener become saturated with calcium and magnesium ions, they need to be recharged. Sodium ions from the water softening salt reactivate the resin beads so they can continue to do their job. Without sufficient softening salt, your water softener is less efficient. As a rule, you should check your water softener once a week to be sure the salt level is always at least one quarter full.





Nollet's First Osmosis Machine

Membrane Filtration Processes

In 1748, the French physicist Nollet first noted that water would diffuse through a pig bladder membrane into alcohol. This was the discovery of osmosis, a process in which water from a dilute solution will naturally pass through a porous membrane into a concentrate solution. Over

the years, scientists have attempted to develop a membrane that would be useful in industrial processes, but it wasn't until the late 1950s that membranes were produced that could be used for what is known as reverse osmosis. In reverse osmosis, water is forced to move through a membrane from a concentrate solution to a dilute solution.

Since that time, continual improvements and new developments have been made in membrane technology, resulting in ever-increasing uses in many industries. In potable water treatment, membranes have been used for desalinization, removal of dissolved inorganic and organic chemicals, water softening, and removal of the fine solids.

In particular, membrane technology enables some water systems having contaminated water sources to meet new, more stringent regulations. In some cases, it can also allow secondary sources, such as brackish groundwater, to be used. There is great potential for



the continuing wide use of membrane filtration processes in potable water treatment, especially as technology improves and costs are reduced.

Description of Membrane Filtration Processes

In the simplest membrane processes, water is forced through a porous membrane under pressure while suspended solids, large molecules or ions are held back or rejected.

Types of Membrane Filtration Processes


The two general classes of membrane processes, based on the driving force used to make the process work, are:

- Pressure-driven processes
- > Electric-driven processes

Pressure-Driven Processes

The four general membrane processes that operate by applying pressure to the raw water are:

- Microfiltration
- Ultrafiltration
- Nanofiltration
- Reverse Osmosis



Microfiltration

Microfiltration (**MF**) is a process in which water is forced under pressure through a porous membrane. Membranes with a pore size of 0.45 μm are normally used; this size is relatively large compared with the other membrane filtration processes. This process has not been generally applicable to drinking water treatment because it either does not remove substances that require removal from potable water, or the problem substances can be removed more economically using other processes. The current primary use of MF is by industries to remove very fine particles from process water, such as in electronic manufacturing. In addition, the process has also been used as a pretreatment for other membrane processes. In particular, Reverse Osmosis (**RO**) membranes are susceptible to clogging or binding unless the water being processed is already quite clean.

However, in recent years, microfiltration has been proposed as a filtering method for particles resulting from the direct filtration process. Traditionally, this direct filtration process has used the injection of coagulants such as alum or polymers into the raw water stream to remove turbidity such as clay or silts. The formed particles were then removed by rapid sand filters. This was done to improve filtering efficiency, especially for small particles that could contain bacterial and protozoan life.

Ultrafiltration

Ultrafiltration (**UF**) is a process that uses a membrane with a pore size generally below 0.1 μ m. The smaller pore size is designed to remove colloids and substances that have larger molecules, which are called high-molecular-weight materials. UF membranes can be designed to pass material that weighs less than or equal to a certain molecular weight. This weight is called the molecular weight cutoff (**MWC**) of the membrane. Although UF does not generally work well for removal of salt or dissolved solids, it can be used effectively for removal of most organic chemicals.


Nanofiltration

Nanofiltration (**NF**) is a process using a membrane that will reject even smaller molecules that UF. The process has been used primarily for water softening and reduction of total dissolved solids (**TDS**). NF operates with less pressure than reverse osmosis and is still able to remove a significant proportion of inorganic and organic molecules. This capability will undoubtedly increase the use of NF for potable water treatment.

Reverse Osmosis

Reverse Osmosis (**RO**) is a membrane process that has the highest rejection capability of all the membrane processes. These RO membranes have very low MWC pore size that can reject ions at very high rates, including chloride and sodium. Water from this process is very pure due to the high reject rates. The process has been used primarily in the water industry for desalinization of seawater because the capital and operating costs are competitive with other processes for this service. The RO also works with most organic chemicals, radionuclides and microorganisms. Industrial water uses such as semiconductor manufacturing also utilize the RO process. RO is discussed in more detail later.

Membrane Configurations



Electric-Driven Processes

There are two membrane processes that purify a water stream by using an electric current to move ions across a membrane.

These processes are

- Electrodialysis
- Electrodialysis reversal

Electrodialysis

Electrodialysis (**ED**) is a process in which ions are transferred through a membrane as a result of direct electric current applied to the solution. The current carries the ions through a membrane from the less concentrated solution to the more concentrated one.

Electrodialysis Reversal

Electrodialysis Reversal (**EDR**) is a process similar to ED, except that the polarity of the direct current is periodically reversed. The reversal in polarity reverses the flow of ions between demineralizing compartments, which provides automatic flushing of scale-forming materials from the membrane surface.

As a result, EDR can often be used with little or no pretreatment of feedwater to prevent fouling. So far, ED and EDR have been used at only a few locations for drinking water treatment.



Carbon vessels are commonly used to remove tastes and odors from water.

Reverse Osmosis

Osmosis is a natural phenomenon in which a liquid - water in this case - passes through a semipermeable membrane from a relatively dilute solution toward a more concentrated solution. This flow produces a measurable pressure, called osmotic pressure.

If pressure is applied to the more concentrated solution, and if that pressure exceeds the osmotic pressure, water flows through the membrane from the more concentrated solution toward the dilute solution. This process is called RO. It removes up to 98% of dissolved minerals, and virtually 100% of colloidal and suspended matter. RO produces high quality water at low cost compared to other purification processes.

The membrane must be physically strong enough to stand up to high osmotic pressure - in the case of sea water, 2500 kg/m. Most membranes are made of cellulose acetate or polyamide composites cast into a thin film, either as a sheet or fine hollow fibers.

The membrane is constructed into a cartridge called a reverse osmosis module.



RO Skid


After filtration to remove suspended particles, incoming water is pressurized with a pump to 200 - 400 psi (1380 - 2760 kPa) depending on the RO system model.

This exceeds the water's osmotic pressure. A portion of the water (**permeate**) diffuses through the membrane leaving dissolved salts and other contaminants behind with the remaining water where they are sent to drain as waste (**concentrate**).

Pretreatment is important because it influences permeate quality and quantity. It also affects the module's life because many water-borne contaminants can deposit on the membrane and foul it. Generally, the need for pretreatment increases as systems become larger and operate at higher pressures, and as permeate quality requirements become more demanding.

Because reverse osmosis is the principal membrane filtration process used in water treatment, it is described here in greater detail.

To understand Reverse Osmosis, one must begin by understanding the process of osmosis, which occurs in nature. In living things, osmosis is frequently seen. The component parts include a pure or relatively pure water solution and a saline or contaminated water solution, separated by a semi-permeable membrane, and a container or transport mechanism of some type.



The semi-permeable membrane is so designated because it permits certain elements to pass through, while blocking others. The elements that pass through include water, usually smaller molecules of dissolved solids, and most gases. The dissolved solids are usually further restricted based on their respective electrical charge.

In osmosis, naturally occurring in living things, the pure solution passes through the membrane until the osmotic pressure becomes equalized, at which point osmosis ceases. The osmotic pressure is defined as the pressure differential required to stop osmosis from occurring. This pressure differential is determined by the total dissolved solids content of the saline solution or, contaminated solution on one side of the membrane. The higher the content of dissolved solids, the higher the osmotic pressure.

Each element that may be dissolved in the solution contributes to the osmotic pressure, in that the molecular weight of the element affects the osmotic pressure.

Generally, higher molecular weights result in higher osmotic pressures. Hence the formula for calculating osmotic pressure is very complex. However, approximate osmotic pressures are usually sufficient to design a system. Common tap water as found in most areas may have an osmotic pressure of about 10 Pounds per Square Inch (**PSI**), or about 1.68 Bar. Seawater at 36,000 PPM typically has an osmotic pressure of about 376 PSI (26.75 Bar).

Thus, to reach the point at which osmosis stops for tap water, a pressure of 10 PSI would have to be applied to the saline solution. To stop osmosis in seawater, a pressure of 376 PSI would have to be applied to the seawater side of the membrane.

Several decades ago, U.S. Government scientists had the idea that the principles of osmosis could be harnessed to purify water from various sources, including brackish water and seawater. In order to transform this process into one that purifies water, osmosis would have to be reversed, and suitable synthetic membrane materials would have to be developed. Additionally, ways of configuring the membranes would have to be engineered to handle a continuous flow of raw and processed water without clogging or scaling the membrane material. These ideas were crystallized and, fueled by U.S. Government funding, usable membrane materials and designs resulted.

One of the membrane designs was the spiral wound membrane element. This design enabled the engineers to construct a membrane element that could contain a generous amount of membrane area in a small package, and to permit the flow of raw water to pass along the length of the membrane. This permits flows and pressures to be developed to the point that ample processed or purified water is produced, while keeping the membrane surface relatively free from particulate, colloidal, bacteriological or mineralogical fouling.

The design features a perforated tube in the center of the element, called the product or permeate tube, and wound around this tube are one or more **envelopes** of membrane material, opening at the permeate tube. Each envelope is sealed at the incoming and exiting edge. Thus when water penetrates or permeates though the membrane, it travels, aided by a fine mesh called the permeate channel, around the spiral and collects in the permeate tube. The permeate or product water is collected from the end of each membrane element, and becomes the product or result of the purification process.


Meanwhile, as the raw water flows along the *brine channel* or coarse medium provided to facilitate good flow characteristics, it gets more and more concentrated. This concentrated raw water is called the reject stream or concentrate stream. It may also be called brine if it is coming from a salt water source. The concentrate, when sufficient flows are maintained, serves to carry away the impurities removed by the membrane, thus keeping the membrane surface clean and functional. This is important, as buildup on the membrane surface, called fouling, impedes or even prevents the purification process.

The membrane material itself is a special thin film composite (**TFC**) polyamide material, cast in a microscopically thin layer on another, thicker cast layer of Polysulfone, called the microporous support layer. The microporous support layer is cast on sheets of paper-like material that are made from synthetic fibers such as polyester, and manufactured to the required tolerances.

Each sheet of membrane material is inspected at special light tables to ensure the quality of the membrane coating, before being assembled into the spiral wound element design.

To achieve Reverse Osmosis, the osmotic pressure must be exceeded, and to produce a reasonable amount of purified water, the osmotic pressure is generally doubled. Thus with seawater osmotic pressure of 376 PSI, a typical system operating pressure is about 800 PSI. Factors that affect the pressure required include raw water temperature, raw water TDS (Total Dissolved Solids), membrane age, and membrane fouling.

REVERSE OSMOSIS



The effect of temperature is that with higher temperatures, the salt passage increases, flux (permeate flow) increases, and operating pressure required is lower. With lower temperatures, the inverse occurs, in that salt passage decreases (reducing the TDS in the permeate or product water), while operating pressures increase. Or, if operating pressures do not increase, then the amount of permeate or product water is reduced. In general, RO systems are designed for raw water temperatures of 25° C (77° F). Higher temperatures or lower temperatures can be accommodated with appropriate adjustments in the system design.

Membranes are available in **standard rejection** or **high rejection** models for seawater and brackish water. The rejection rate is the percentage of dissolved solids rejected, or prevented from passing through the membrane. For example, a membrane with a rejection rate of 99% (usually based on Na (**Sodium**) will allow only 1% of the concentration of dissolved solids to pass through into the permeate. Hence, product water from a source containing 10,000 PPM would have 100 PPM remaining. Of course, as the raw water is processed, the concentrations of TDS increase as it passes along the membrane's length, and usually multiple membranes are employed, with each membrane in the series seeing progressively higher dissolved solids levels.

Typically, starting with seawater of 36,000 PPM, standard rejection membranes produce permeate below 500 PPM, while high rejection membranes under the same conditions produce drinking water TDS of below 300 PPM. There are many considerations when designing RO systems that competent engineers are aware of. These include optimum flows and pressures, optimum recovery rates (the percentage of permeate from a given stream of raw water), prefiltration and other pretreatment considerations, and so forth.

Membrane systems in general cannot handle the typical load of particulate contaminants without prefiltration. Often, well designed systems employ multiple stages of prefiltration, tailored to the application, including multi-media filtration and one or more stages of cartridge filtration. Usually the last stage would be 5m or smaller, to provide sufficient protection for the membranes.

RO systems typically have the following components: A supply pump or pressurized raw water supply; prefiltration in one or more stages; chemical injection of one or more pretreatment agents may be added; a pressure pump suited to the application, sized and driven appropriately for the flow and pressure required; a membrane array including one or more membranes installed in one or more pressure tubes (also called pressure vessels, RO pressure vessels, or similar); various gauges and flow meters; a pressure regulating valve, relief valve(s) and/or safety pressure switches; and possibly some form of post treatment. Post treatment should usually include a form of sterilization such as Chlorine. Bromine, Ultra-Violet (UV), or Ozone.

Other types of post treatment may include carbon filters, pH adjustment, or mineral injection for some applications.



Packaged skid with instrumentation, UV, and softening unit.

Clean-In-Place

Some very low cost RO systems may dispense with most of the controls and instruments. However, systems installed in critical applications should be equipped with a permeate or product flow meter, a reject, concentrate or brine flow meter, multiple pressure gauges to indicate the pressure before and after each filtration device and the system operation pressure in the membrane loop, preferably both before and after the membrane array. Another feature found in better systems is a provision to clean the membranes in place, commonly known as a **Clean In Place** (**CIP**) system. Such a system may be built right into the RO system or may be provided as an attachment for use as required.

Reverse Osmosis has proven to be the most reliable and cost effective method of desalinating water, and hence its use has become more and more widespread. Energy consumption is usually about 70% less than comparable evaporation technologies. Advancements have been made in membrane technology, resulting in stable, long lived membrane elements. Component parts have been improved as well, reducing maintenance and down time. Additional advancements in pretreatment have been made in recent years, further extending membrane life and improving performance.

Reverse Osmosis delivers product water or permeate having essentially the same temperature as the raw water source (an increase of 1° C or 1.8° F may occur due to pumping and friction in the piping). This is more desirable than the hot water produced by evaporation technologies. RO systems can be designed to deliver virtually any required product water quality. For these and other reasons, RO is usually the preferred method of desalination today.

Reverse Osmosis, also known as hyperfiltration, is the finest filtration known. This process will allow the removal of particles as small as ions from a solution. Reverse osmosis is used to purify water and remove salts and other impurities in order to improve the color, taste or properties of the fluid. It can be used to purify fluids such as ethanol and glycol, which will pass through the reverse osmosis membrane, while rejecting other ions and contaminants from passing. The most common use for reverse osmosis is in purifying water. It is used to produce water that meets the most demanding specifications that are currently in place.

Reverse osmosis uses a membrane that is semi-permeable, allowing the fluid that is being purified to pass through it, while rejecting the contaminants that remain. Most Reverse Osmosis technology uses a process known as cross-flow to allow the membrane to continually clean itself. As some of the fluid passes through the membrane the rest continues downstream, sweeping the rejected species away from the membrane. The process of Reverse Osmosis requires a driving force to push the fluid through the membrane, and the most common force is pressure from a pump. The higher the pressure, the larger the driving force. As the concentration of the fluid being rejected increases, the driving force required to continue concentrating the fluid increases.

Reverse osmosis is capable of rejecting bacteria, salts, sugars, proteins, particles, dyes, and other constituents that have a molecular weight greater than 150-250 daltons. The separation of ions with Reverse Osmosis is aided by charged particles.

This means that dissolved ions that carry a charge, such as salts, are more likely to be rejected by the membrane than those that are not charged, such as organics. The larger the charge and the larger the particle, the more likely it will be rejected.

Reverse Osmosis, when properly configured with sediment, carbon and/or carbon block technology, produces pure water that is clearly the body's choice for optimal health. It is the best tasting because it is oxygen-rich.

A Reverse Osmosis system removes virtually all of the following: bad taste, odor, turbidity, organic compounds, herbicides, insecticides, pesticides, chlorine and THM's, bacteria, virus, cysts, parasites, arsenic, heavy metals, lead, cadmium, aluminum, dissolved solids, sodium, calcium, magnesium, inorganic minerals, fluoride, sulfates, nitrates, phosphates, detergents, radioactivity and asbestos.



Commonly found packaged filter system components.

Ozone

Ozone (O_3) is probably the strongest oxidizing agent available for water treatment. Although it is widely used throughout the world, it has not found much application in the United States. Ozone is obtained by passing a flow of air or oxygen between two electrodes that are subjected to an alternating current in the order of 10,000 to 20,000 volts.

$$3O_2$$
 + electrical discharge $\rightarrow 2O_3$

Liquid ozone is very unstable and can readily explode. As a result, it is not shipped and must be manufactured on-site. Ozone is a light blue gas at room temperature. It has a self-policing pungent odor similar to that sometimes noticed during and after heavy electrical storms. In use, ozone breaks down into oxygen and nascent oxygen.

$$O_3 \rightarrow O_2 + O$$

It is the nascent oxygen that produces the high oxidation, disinfections, and even sterilization. Each water has its own ozone demand, in the order of 0.5 ppm to 5.0 ppm. Contact time, temperature, and pH of the water are factors to be determined.

Ozone acts as a complete disinfectant. It is an excellent aid to the flocculation and coagulation process, and will remove practically all color, taste, odor, iron, and manganese. It does not form chloramines or THMs, and while it may destroy some THMs, it may produce others when followed by chlorination.

Ozone is not practical for complete removal of chlorine or chloramines, or of THM and other inorganics. Further, because of the possibility of formation of other carcinogens (such as aldehydes or phthalates) it falls into the same category as other disinfectants, because it can produce DBPs.



An onsite Oxygen tank is necessary to generate O₃

Ultraviolet Radiation

The enormous temperatures on the sun create UV rays in great amounts. This radiation is so powerful that all life on earth would be destroyed if these ray were not scattered by the atmosphere and filtered out by the layers of ozone gas that float some 20 miles above the earth.

This radiation can be artificially produced by sending strong electric currents thorough various substances. A sun lamp, for example, sends out UV rays that when properly controlled result in a suntan. Of course, too much will cause sunburn.

The UV lamp that can be used for the disinfection of water depends upon the low-pressure mercury vapor lamp to produce the ultraviolet energy. A mercury vapor lamp is one in which an electric arc is passed through an inert gas. This, in turn, will vaporize the mercury contained in the lamp resulting in the production of UV rays.






The lamp itself does not come into contact with water. The lamp is placed inside a quartz tube, and the water is in contact with the outside of the quartz tube. Quartz is used in this case since practically none of the UV rays are absorbed by the quartz, allowing all of the rays to reach the water. Ordinary glass cannot be used since it will absorb the UV rays, leaving little for disinfection.

The water flows around the quartz tube. The UV sterilizer will consist of a various number of lamps and tubes, depending upon the amount of water to be treated. As water enters the sterilizer, it is given a tangential flow pattern so that the water spins over and around the guartz sleeves. In this way the microorganisms spend maximum time and contact with the outside of the quartz tube and the source of the UV rays.

The basic design flow of water of certain UV units is in the order of 2.0 gpm for each inch of the lamp. Further, the units are designed, so the contact or retention time of the water in the unit is not less than 15 seconds.

Most manufacturers claim the UV lamps have a life of about 7,500 hours, which is about 1 year's time. The lamp must be replaced when it loses about 40% to 50% of its UV output. In any installation this is determined by means of a photoelectric cell and a meter that shows the output of the lamp. Each lamp is outfitted with its own photoelectric cell, and with an alarm that will be activated when the penetration drops to a present level.

Ultraviolet radiation is an excellent disinfectant that is highly effective against viruses, molds, and yeasts; and it is safe to use. It adds no chemicals to the water, it leaves no residual, and it does not form THMs. It is used to remove traces of ozone and chloramines from the finished water. Alone, UV radiation will not remove precursors, but in combination with ozone, it is said to be effective in the removal of THM precursors and THMs.



The germicidal effect of UV is thought to be associated with its absorption by various organic components essential to the cell's functioning. For effective use of ultraviolet, the water to be disinfected must be clean and free of any suspended solids. The water must also be colorless and free of any colloids, iron, manganese, taste, and odor. These are conditions that must be met. Also, although water may appear to be clear, such substances as excesses of chlorides, bicarbonates, and sulfates affect absorption of the ultraviolet ray. These parameters will probably require at least filtration of one type or another. The UV manufacturer will, of course, stipulate which pretreatment may be necessary.

Removal of Disinfection By-products			
Disinfectant	Disinfectant By- product	Disinfectant By-product Removal	
Chlorine (HOCI)	Trialomethane (THM)	Granular Activated Carbon (GAC), resins, controlled coagulation, aeration.	
	Chloramine Chlorophenol	GAC-UV GAC	
Chloramine (NH _x Cl _y)	Probably no THM Others?	GAC UV?	
Chlorine dioxide (CIO ₂)	Chlorites Chlorates	Use of Fe2+ in coagulation, RO, ion-exchange	
Permanganate (KMnO ₄)	No THMs		
Ozone (O ₃)	Aldehydes, Carboxylics, Phthalates	GAC	
Ultraviolet (UV)	None known	GAC	

The table indicates that most of the disinfectants will leave a by-product that is or would possibly be inimical to health. This may aid with a decision as to whether or not precursors should be removed before these disinfectants are added to water.

If it is decided that removal of precursors is needed, research to date indicates that this removal can be attained through the application of controlled chlorination plus coagulation and filtration, aeration, Reverse Osmosis, nanofiltration, GAC or combinations of others processes.





pН

Expression of a basic or acid condition of a liquid. The range is from 0-14, zero being the most acid and 14 being the most alkaline. A pH of 7 is considered to be neutral. Most natural water has a pH between 6.0 and 8.5.

Caustic

NaOH (also called Sodium Hydroxide) is a strong chemical used in the treatment process to neutralize acidity, increase alkalinity or raise the pH value.

Polymer

A type of chemical when combined with other types of coagulants aid in binding small suspended particles to larger particles to help in the settling and filtering processes.

Common Water Treatment and Distribution Chemicals

Common Water In	eatment and Distri	bution Chemicals
Chemical Name	Common Name	Chemical Formula
Aluminum hydroxide		Al(OH) ₃
Aluminum sulfate	Alum, liquid	$AL_2(SO_4)3 . 14(H_2O)$
Ammonia		NH_3
Ammonium		NH ₄
Bentonitic clay	Bentonite	
Calcium bicarbonate		Ca(HCO ₃)2
Calcium carbonate	Limestone	CaCO ₃
Calcium chloride		CaCl ₂
Calcium Hypochlorite	HTH	Ca(OCI) ₂ . 4H ₂ O
Calcium hydroxide	Slaked Lime	Ca(OH) ₂
Calcium oxide Calcium sulfate	Unslaked (Quicklime) Gypsum	CaO CaSO ₄
Carbon Carbon dioxide	Activated Carbon	C CO ₂
Carbonic acid		H2CO ₃
Chlorine gas		Cl_2
Chlorine Dioxide		CIO ₂
Copper sulfate	Blue vitriol	CuSO ₄ . 5H ₂ O
Dichloramine		NHCl ₂
Ferric chloride	Iron chloride	FeCl ₃
Ferric hydroxide		Fe(OH) ₃
Ferric sulfate	Iron sulfate	$Fe_2(SO_4)_3$
Ferrous bicarbonate		Fe(HCO ₃) ₂
Ferrous hydroxide		Fe(OH) ₃
Ferrous sulfate	Copperas	FeSO ₄ .7H ₂ 0
Hydrofluorsilicic acid		H_2SiF_6
Hydrochloric acid Hydrogen sulfide	Muriatic acid	HCI H ₂ S
Hypochlorus acid Magnesium bicarbonate		HOCL Mg(HCO₃)2
Magnesium carbonate		$MgCO_3$
Magnesium chloride		MgCl ₂
Magnesium hydroxide		$Mg(OH)_2$
Magnesium dioxide		MgO_2
Manganous bicarbonate		Mn(HCO₃)2
Manganous sulfate		MnSO₄
Monochloramine		NH ₂ CI
Potassium bicarbonate		KHCO ₃
Potassium permanganate		KMnO₄

Chemical Name	Common Name	Chemical Formula
Sodium carbonate	Soda ash	Na ₂ CO ₃
Sodium chloride Sodium chlorite	Salt	NaCl NaClO₂
Sodium fluoride Sodium fluorsilicate		NaF Na ₂ SiF ₆
Sodium hydroxide Sodium hypochlorite Sodium Metaphosphate	Lye Hexametaphosphate	NaOH NaOCI NaPO₃
Sodium phosphate	Disodium phosphate	Na ₃ PO ₄
Sodium sulfate		Na ₂ SO ₄
Sulfuric acid		H ₂ SO ₄



Fluoride. Many communities add fluoride to their drinking water to promote dental health. Each community makes its own decision about whether or not to add fluoride. The EPA has set an enforceable drinking water standard for fluoride of 4 mg/L (some people who drink water containing fluoride in excess of this level over many years could develop bone disease, including pain and tenderness of the bones). The EPA has also set a secondary fluoride standard of 2 mg/L to protect against dental fluorosis.

Number	Element	Valence
1	Hydrogen	(-1), +1
2	Helium	0
3	Lithium	+1
4	Beryllium	+2
5	Boron	-3, +3
6	Carbon	(+2), +4
7	Nitrogen	-3, -2, -1, (+1), +2, +3, +4, +5
8	Oxygen	-2
9	Fluorine	-1, (+1)
10	Neon	0
11	Sodium	+1
12	Magnesium	+2
13	Aluminum	+3
14	Silicon	-4, (+2), +4
15	Phosphorus	-3, +1, +3, +5
16	Sulfur	-2, +2, +4, +6
17	Chlorine	-1, +1, (+2), +3, (+4), +5, +7
18	Argon	0
19	Potassium	+1
20	Calcium	+2
21	Scandium	+3
22	Titanium	+2, +3, +4
23	Vanadium	+2, +3, +4, +5
24	Chromium	+2, +3, +6
25	Manganese	+2, (+3), +4, (+6), +7
26	Iron	+2, +3, (+4), (+6)
27	Cobalt	+2, +3, (+4)
28	Nickel	(+1), +2, (+3), (+4)
29	Copper	+1, +2, (+3)
30	Zinc	+2
31	Gallium	(+2). +3
32	Germanium	-4, +2, +4
33	Arsenic	-3, (+2), +3, +5
34	Selenium	-2, (+2), +4, +6
35	Bromine	-1, +1, (+3), (+4), +5
36	Krypton	0
37	Rubidium	+1
38	Strontium	+2
39	Yttrium	+3
40	Zirconium	(+2), (+3), +4
41	Niobium	, , , ,
42		(+2), +3, (+4), +5 (+2), +3, (+4), (+5), +6
	Molybdenum	(+2), +3, (+4), (+5), +6
43	Technetium	+6
	Rubidium Rhodium	(+2), +3, +4, (+6), (+7), +8
45	Palladium	(+2), (+3), +4, (+6)
46		+2, +4, (+6)
47	Silver	+1, (+2), (+3)
48	Cadmium	(+1), +2
49	Indium	(+1), (+2), +3
50	Tin	+2, +4
51	Antimony	-3, +3, (+4), +5

52	Tellurium	-2, (+2), +4, +6
53	lodine	-1, +1, (+3), (+4), +5, +7
54	Xenon	0
55	Cesium	+1
56	Barium	+2
57	Lanthanum	+3
58	Cerium	+3, +4
59	Praseodymium	+3
60	Neodymium	+3, +4
61	Promethium	+3
62	Samarium	(+2), +3
63	Europium	(+2), +3
64	Gadolinium	+3
65	Terbium	+3, +4
66	Dysprosium	+3
67	Holmium	+3
68	Erbium	+3
69	Thulium	(+2), +3
70	Ytterbium	(+2), +3
71	Lutetium	+3
72	Hafnium	+4
73	Tantalum	(+3), (+4), +5
74	Tungsten	(+2), (+3), (+4), (+5), +6
75	Rhenium	(-1), (+1), +2, (+3), +4, (+5), +6, +7
76	Osmium	(+2), +3, +4, +6, +8
77	Iridium	(+1), (+2), +3, +4, +6
78	Platinum	(+1), +2, (+3), +4, +6
79	Gold	+1, (+2), +3
80	Mercury	+1, +2
81	Thallium	+1, (+2), +3
82	Lead	+2, +4
83	Bismuth	(-3), (+2), +3, (+4), (+5)
84	Polonium	(-2), +2, +4, (+6)
85	Astatine	?
86	Radon	0
87	Francium	?
88	Radium	+2
89	Actinium	+3
90	Thorium	+4
91	Protactinium	+5
92	Uranium	(+2), +3, +4, (+5), +6

Reference: Lange's Handbook of Chemistry, 8th Ed., Norbert A. Lange (Ed.), Handbook Publishers, Inc. 1952.

Common Used Products	Chemical Name
acetone	dimethyl ketone
acid of sugar	oxalic acid
alcohol, grain	ethyl alcohol
alcohol, wood	methyl alcohol
alum	aluminum potassium sulfate
alumina	aluminum oxide
antichlor	sodium thiosulfate
aqua ammonia	aqueous solution of ammonium hydroxide
aqua regia	nitrohydrochloric acid
aqua fortis	nitric acid
aromatic spirit of ammonia	ammonia in alcohol
asbestos	magnesium silicate
	acetylsalicylic acid
aspirin baking soda	sodium bicarbonate
banana oil (artificial)	
, ,	isoamyl acetate
benzol	benzene marauria ablarida
bichloride of mercury black copper oxide	mercuric chloride
black copper oxide	cupric oxide
	graphite (carbon) chlorinated lime
bleaching powder blue vitriol	
	copper sulfate
bluestone	copper sulfate
borax	sodium borate
brimstone	sulfur
brine	aqueous sodium chloride solution
butter of antimony	antimony trichloride
butter of tin	anhydrous stannic chloride
calomel	mercury chloride
carbolic acid	phenol
carbonic acid gas	carbon dioxide
caustic potash	potassium hydroxide
caustic soda	sodium hydroxide
chalk	calcium carbonate
Chile saltpeter	sodium nitrate
chrome, alum	chromic potassium sulfate
chrome, yellow	lead (VI) chromate
copperas	ferrous sulfate
cream of tartar	potassium bitartrate
crocus powder	ferric oxide
emery powder	impure aluminum oxide
Epsom salts	magnesium sulfate
ethanol	ethyl alcohol
fluorspar	natural calcium fluoride
formalin	aqueous formaldehyde solution
French chalk	natural magnesium silicate
galena	natural lead sulfide
Glauber's salt	sodium sulfate
gypsum	natural calcium sulfate
hydrocyanic acid	hydrogen cynanide
hypo (photography)	sodium thiosulfate solution
lime	calcium oxide

Common Used Products	Chemical Name
limewater	aqueous solution of calcium hydroxide
lunar caustic	silver nitrate
magnesia	magnesium oxide
mercury oxide, black	mercurous oxide
methanol	methyl alcohol
methylated spirits	methyl alcohol
muriatic acid	hydrochloric acid
oil of vitriol	sulfuric acid
oil of wintergreen (artificial)	methyl salicylate
Paris green	copper acetoarsenite
Paris white	powdered calcium carbonate
pear oil (artificial)	isoamyl acetate
pearl ash	potassium carbonate
plaster of Paris	calcium sulfate
plumbago	graphite
potash	potassium carbonate
potassa	potassium hydroxide
Prussic acid	hydrogen cyanide
pyro	tetrasodium pyrophosphate
quicklime	calcium oxide
quicksilver	mercury
red lead	lead tetraoxide
Rochelle salt	potassium sodium tartrate
rouge, jeweler's	ferric oxide
rubbing alcohol	isopropyl alcohol
sal ammoniac	ammonium chloride
sal soda	sodium carbonate
salt, table	sodium chloride
salt of lemon	potassium binoxalate
salt of tartar	potassium carbonate
saltpeter	potassium nitrate
silica	silicon dioxide
soda ash	sodium carbonate
soda lye	sodium hydroxide
soluble glass	sodium silicate
spirit of hartshorn	ammonium hydroxide solution
sugar, table	sucrose
talc or talcum	magnesium silicate
vinegar	impure dilute acetic acid
vitamin C	ascorbic acid
washing soda	sodium carbonate
water glass	sodium silicate

Math Conversion Factors

1 PSI = 2.31 Feet of Water 1 Foot of Water = .433 PSI

1.13 Feet of Water = 1 Inch of Mercury

454 Grams = 1 Pound

1 Gallon of Water = 8.34 lbs/gallon

1 mg/L = 1 PPM

Foot

17.1 mg/L = 1 Grain/Gallon

1% = 10,000 mg/L

694 Gallons per Minute = MGD

1.55 Cubic Feet per Second = 1 MGD

60 Seconds = 1 Minute

1440 Minutes = 1 Day

Water

.746 kW = 1 Horsepower

Water

LENGTH

12 Inches = 1 Foot

3 Feet = 1 Yard

5,280 Feet = 1 Mile

AREA

144 Square Inches = 1 Square

43,560 Square Feet = 1 Acre

VOLUME

1000 Milliliters = 1 Liter

3.785 Liters = 1 Gallon 231 Cubic Inches = 1 Gallon

7.48 Gallons = 1 Cubic Foot of

62.38 Pounds = 1 Cubic Foot of

Dimensions

SQUARE: Area (sq. ft.) = Length X Width

Volume (cu.ft) = Length (ft) X Width (ft) X Height (ft)

CIRCLE: Area (sq. ft.) = 3.14 X Radius (ft) X Radius (ft)

CYLINDER: Volume (Cu. Ft.) = 3.14 X Radius (ft) X Radius (ft) X Depth (ft)

SPHERE: (3.14) (Diameter)³ Circumference = 3.14 X Diameter

(6)

General

POUNDS PER DAY AKA SOLIDS APPLIED = Concentration (mg/L) X Flow (MG) X 8.34

Percent Efficiency = $\frac{In - Out}{In}$ X 100

TEMPERATURE: ${}^{0}F = ({}^{0}C \times 9/5) + 32$ ${}^{0}C = ({}^{0}F - 32) \times 5/9$

CONCENTRATION: Conc. (A) X Volume (A) = Conc. (B) X Volume (B)

FLOW RATE (Q): Q = A X V (Quantity = Area X Velocity)

FLOW RATE (gpm): Flow Rate (gpm) = $\frac{2.83 \text{ (Diameter, in)}^2 \text{ (Distance, in)}}{\text{Height, in}}$

ACTUAL LEAKAGE = <u>Leak Rate (GPD)</u> Length (mi.) X Diameter (in)

VELOCITY = <u>Distance (ft)</u> Time (Sec)

WATER HORSEPOWER = Flow (gpm) X Head (ft) 3960

BRAKE HORSEPOWER = Flow (gpm) X Head (ft)
3960 X Pump Efficiency

MOTOR HORSEPOWER = Flow (gpm) X Head (ft)
3960 X Pump Eff. X Motor Eff.

MEAN OR AVERAGE = <u>Sum of the Values</u> Number of Values

TOTAL HEAD (ft) = Suction Lift (ft) X Discharge Head (ft)

SURFACE LOADING RATE = Flow Rate (gpm)
(gal/min/sq.ft) Surface Area (sq. ft)

MIXTURE = (Volume 1, gal) (Strength 1, %) + (Volume 2, gal) (Strength 2,%)

STRENGTH (%) (Volume 1, gal) + (Volume 2, gal)

FLUORIDE ION PURITY = (Molecular weight of Fluoride) (100%)
(%) Molecular weight of Chemical

INJURY FREQUENCY RATE = (Number of Injuries) 1,000,000

Number of hours worked per year

DETENTION TIME (hrs) = Volume of Basin (gals) X 24 hrs Flow (GPD)

BY-PASS WATER (gpd) = <u>Total Flow (GPD) X Plant Effluent Hardness (gpg)</u>
Filtered Hardness (gpg)

Hardness

HARDNESS (mg/L as $CaCO_3$) = A (mls of titrant) X 1000 Mls of Sample

Ca HARDNESS as mg/L $CaCo_3 = 2.5 \text{ X}$ (Ca, mg/L)

Mg HARDNESS as mg/L $CaCo_3 = 4.12$ (Mg, mg/L)

ALKALINITY-TOTAL = \underline{Mls} of $\underline{Titrant}$ X Normality X 50,000 (mg/L) Mls of Sample

EXCHANGE CAPACITY (grains) = Resin Volume (cu. ft.) X Removal Capacity

HARDNESS TO GRAIN/GALLON = $\frac{\text{Hardness (mg/L)} \times \text{gr./gal}}{17.1 \text{ mg/L}}$

LANGELIER INDEX = pH - pH_s

Chemical Addition

CHEMICAL FEED RATE = <u>Chemical Feed (ml/min)</u> (gpm) 3785 ml/gal

CHLORINE DOSE (mg/L) = Chlorine Demand (mg/L) + Chlorine Residual (mg/L)

POLYMER % = <u>Dry Polymer (lbs.)</u> Dry Polymer (lbs.) + Water (lbs.)

DESIRED PAC = $\underline{\text{Volume (MG)}}$ X $\underline{\text{Dose (mg/L)}}$ X 8.34 (lbs./MG) 1 MG


PAC (lbs./gal) = $\frac{PAC (mg/L) \times 3.785 (1/gallon)}{1000 (mg/g) \times 454 (g/lb.)}$

Filtration

FILTRATION RATE = Flow Rate (gpm) (gpm/sq. ft) Surface Area (sq. ft.)

BACKWASH PUMPING RATE = Filter Area (sq. ft) X Backwash Rate (gpm/sq. ft) (gpm)


Microorganism Appendix




BACTERIA TYPES



This section will give a close-up and short explanation of the major microorganisms found in water and in wastewater.



Protozoa



PROTOZOAN CELL

Protozoa are around 10–50 micrometer, but can grow up to 1 mm and can easily be seen under a microscope. Protozoa exist throughout aqueous environments and soil. Protozoa occupy a range of trophic levels. As predators, they prey upon unicellular or filamentous algae, bacteria, and microfungi.

Protozoa play a role both as herbivores and as consumers in the decomposer link of the food chain. Protozoa also play a vital role in controlling bacteria populations and biomass. As components of the micro- and meiofauna, protozoa are an important food source for microinvertebrates. Thus, the ecological role of protozoa in the transfer of bacterial and algal production to successive trophic levels is important. Protozoa such as the malaria parasites (Plasmodium spp.), trypanosomes and leishmania are also important as parasites and symbionts of multicellular animals.

Most protozoa exist in 5 stages of life which are in the form of trophozoites and cysts. As cysts, protozoa can survive harsh conditions, such as exposure to extreme temperatures and harmful chemicals, or long periods without access to nutrients, water, or oxygen for a period of time. Being a cyst enables parasitic species to survive outside of the host, and allows their transmission from one host to another. When protozoa are in the form of trophozoites (Greek, tropho=to nourish), they actively feed and grow. The process by which the protozoa takes its cyst form is called encystation, while the process of transforming back into trophozoite is called excystation.

Protozoa can reproduce by binary fission or multiple fission. Some protozoa reproduce sexually, some asexually, and some both (e.g. Coccidia). An individual protozoan is hermaphroditic.

Classification

Protozoa were commonly grouped in the kingdom of Protista together with the plant-like algae and fungus-like water molds and slime molds. In the 21st-century systematics, protozoans, along with ciliates, mastigophorans, and apicomplexans, are arranged as animal-like protists. However, protozoans are neither Animalia nor Metazoa (with the possible exception of the enigmatic, moldy Myxozoa).

Sub-groups

Protozoa have traditionally been divided on the basis of their means of locomotion, although this is no longer believed to represent genuine relationships:

- * Flagellates (e.g. Giardia lambia)
- * Amoeboids (e.g. Entamoeba histolytica)
- * Sporozoans (e.g. Plasmodium knowlesi)
- * Apicomplexa
- * Myxozoa
- * Microsporidia
- * Ciliates (e.g. Balantidium coli)


There are many ways that infectious diseases can spread. Pathogens usually have specific routes by which they are transmitted, and these routes may depend on the type of cells and tissue that a particular agent targets. For example, because cold viruses infect the respiratory tract, they are dispersed into the air via coughing and sneezing.

Once in the air, the viruses can infect another person who is unlucky enough to inhale air containing the virus particles.

Agents vary greatly in their stability in the environment. Some viruses may survive for only a few minutes outside of a host, while some spore-forming bacteria are extremely durable and may survive in a dormant state for a decade or more.

Protozoa Section

EUGLENA




The diverse assemblage of organisms that carry out all of their life functions within the confines of a single, complex eukaryotic cell are called protozoa.

Paramecium, Euglena, and Amoeba are well-known examples of these major groups of organisms. Some protozoa are more closely related to animals, others to plants, and still others are relatively unique. Although it is not appropriate to group them together into a single taxonomic category, the research tools used to study any unicellular organism are usually the same, and the field of protozoology has been created to carry out this research. The unicellular photosynthetic protozoa are sometimes also called algae and are addressed elsewhere. This report considers the status of our knowledge of heterotrophic protozoa (protozoa that cannot produce their own food).

Free-living Protozoa

Protozoans are found in all moist habitats within the United States, but we know little about their specific geographic distribution. Because of their small size, production of resistant cysts, and ease of distribution from one place to another, many species appear to be cosmopolitan and may be collected in similar microhabitats worldwide (Cairns and Ruthven 1972). Other species may have relatively narrow limits to their distribution.

Marine ciliates inhabit interstices of sediment and beach sands, surfaces, deep sea and cold Antarctic environments, planktonic habitats, and the algal mats and detritus of estuaries and wetlands.



AMOEBA



Amoeba proteus, pseudopods slowly engulf the small desmid Staurastrum.

Amoebas

Amoebas (Phylum Rhizopoda) are unicellular protists that are able to change their shape constantly. Each species has its own distinct repertoire of shapes.

How does an amoeba locomote?

Amoebas locomote by way of cytoplasmic movement. (cytoplasm is the cell content around the nucleus of the cell) The amoeba forms pseudopods (false feet) with which they 'flow' over a surface. The cytoplasma not only flows, it also changes from a fluid into a solid state.

These pseudopods are also used to capture prey, they simply engulf the food. They can detect the kind of prey and use different 'engulfing tactics'.

The image from the last page shows several cell organelles. Left from the center we can see aspherical water expelling vesicle and just right of it, the single nucleus of this species can be seen. Other species may have many nuclei. The cell is full of brown food vacuoles and also contains small crystals.

Protozoa Information

Our actual knowledge of salinity, temperature, and oxygen requirements of marine protozoa is poor (although some groups, such as the foraminifera, are better studied than others), and even the broadest outlines of their biogeographic ranges are usually a mystery. In general, freshwater protozoan communities are similar to marine communities except the specialized interstitial fauna of the sand is largely missing. In freshwater habitats, the foraminifera and radiolaria common in marine environments are absent or low in numbers while testate amoebae exist in greater numbers. Relative abundance of species in the marine versus freshwater habitat is unknown.

Soil-dwelling protozoa have been documented from almost every type of soil and in every kind of environment, from the peat-rich soil of bogs to the dry sands of deserts. In general, protozoa are found in greatest abundance near the soil surface, especially in the upper 15 cm (6 in), but occasional isolates can be obtained at depths of a meter (yard) or more.

Protozoa do not constitute a major part of soil biomass, but in some highly productive regions such as forest litter, the protozoa are a significant food source for the microinvertebrates, with a biomass that may reach 20 g/m2 of soil surface area there.

Environmental Quality Indicators

Polluted waters often have a rich and characteristic protozoan fauna. The relative abundance and diversity of protozoa are used as indicators of organic and toxic pollution (Cairns et al. 1972; Foissner 1987; Niederlehner et al. 1990; Curds 1992). Bick (1972), for example, provided a guide to ciliates that are useful as indicators of environmental quality of European freshwater systems, along with their ecological distribution with respect to parameters such as amount of organic material and oxygen levels.

Foissner (1988) clarified the taxonomy of European ciliates as part of a system for classifying the state of aquatic habitats according to their faunas.

Symbiotic Protozoa

Parasites

Protozoa are infamous for their role in causing disease, and parasitic species are among the best-known protozoa. Nevertheless, our knowledge has large gaps, especially of normally free-living protozoa that may become pathogenic in immunocompromised individuals. For example, microsporidia comprise a unique group of obligate, intracellular parasitic protozoa. Microsporidia are amazingly diverse organisms with more than 700 species and 80 genera that are capable of infecting a variety of plant, animal, and even other protist hosts.

They are found worldwide and have the ability to thrive in many ecological conditions. Until the past few years, their ubiquity did not cause a threat to human health, and few systematists worked to describe and classify the species. Since 1985, however, physicians have documented an unusual rise in worldwide infections in AIDS patients caused by four different genera of microsporidia (Encephalitozoon, Nosema, Pleistophora, and Enterocytozoon). According to the Centers for Disease Control in the United States, difficulties in identifying microsporidian species are impeding diagnosis and effective treatment of AIDS patients.

Protozoan Reservoirs of Disease

The presence of bacteria in the cytoplasm of protozoa is well known, whereas that of viruses is less frequently reported. Most of these reports simply record the presence of bacteria or viruses and assume some sort of symbiotic relationship between them and the protozoa. Recently, however, certain human pathogens were shown to not only survive but also to multiply in the cytoplasm of free-living, nonpathogenic protozoa. Indeed, it is now believed that protozoa are the natural habitat for certain pathogenic bacteria. To date, the main focus of attention has been on the bacterium Legionella pneumophila, the causative organism of Legionnaires' disease; these bacteria live and reproduce in the cytoplasm of some free-living amoebae (Curds 1992). More on this subject in the following pages.

Symbionts

Some protozoa are harmless or even beneficial symbionts. A bewildering array of ciliates, for example, inhabit the rumen and reticulum of ruminates and the cecum and colon of equids. Little is known about the relationship of the ciliates to their host, but a few may aid the animal in digesting cellulose.

Data on Protozoa

While our knowledge of recent and fossil foraminifera in the U.S. coastal waterways is systematically growing, other free-living protozoa are poorly known. There are some regional guides and, while some are excellent, many are limited in scope, vague on specifics, or difficult to use. Largely because of these problems, most ecologists who include protozoa in their studies of aquatic habitats do not identify them, even if they do count and measure them for biomass estimates (Taylor and Sanders 1991).

Parasitic protozoa of humans, domestic animals, and wildlife are better known although no attempt has been made to compile this information into a single source. Large gaps in our knowledge exist, especially for haemogregarines, microsporidians, and myxosporidians (see Kreier and Baker 1987).

Museum Specimens

For many plant and animal taxa, museums represent a massive information resource. This is not true for protozoa. In the United States, only the National Natural History Museum (Smithsonian Institution) has a reference collection preserved on microscope slides, but it does not have a protozoologist curator and cannot provide species' identification or verification services. The American Type Culture Collection has some protozoa in culture, but its collection includes relatively few kinds of protozoa.

Ecological Role of Protozoa

Although protozoa are frequently overlooked, they play an important role in many communities where they occupy a range of trophic levels. As predators upon unicellular or filamentous algae, bacteria, and microfungi, protozoa play a role both as herbivores and as consumers in the decomposer link of the food chain. As components of the micro- and meiofauna, protozoa are an important food source for microinvertebrates. Thus, the ecological role of protozoa in the transfer of bacterial and algal production to successive trophic levels is important.

Factors Affecting Growth and Distribution

Most free-living protozoa reproduce by cell division (exchange of genetic material is a separate process and is not involved in reproduction in protozoa). The relative importance for population growth of biotic versus chemical-physical components of the environment is difficult to ascertain from the existing survey data. Protozoa are found living actively in nutrient-poor to organically rich waters and in fresh water varying between 0°C (32°F) and 50°C (122°F). Nonetheless, it appears that rates of population growth increase when food is not constrained and temperature is increased (Lee and Fenchel 1972; Fenchel 1974; Montagnes et al. 1988).

Comparisons of oxygen consumption in various taxonomic groups show wide variation (Laybourn and Finlay 1976), with some aerobic forms able to function at extremely low oxygen tensions and to thereby avoid competition and predation.

Many parasitic and a few free-living species are obligatory anaerobes (grow without atmospheric oxygen). Of the free-living forms, the best known are the plagiopylid ciliates that live in the anaerobic sulfide-rich sediments of marine wetlands (Fenchel et al. 1977). The importance of plagiopylids in recycling nutrients to aerobic zones of wetlands is potentially great.

Because of the small size of protozoa, their short generation time, and (for some species) ease of maintaining them in the laboratory, ecologists have used protozoan populations and communities to investigate competition and predation.

The result has been an extensive literature on a few species studied primarily under laboratory conditions. Few studies have been extended to natural habitats with the result that we know relatively little about most protozoa and their roles in natural communities. Intraspecific competition for common resources often results in cannibalism, sometimes with dramatic changes in morphology of the cannibals (Giese 1973). Field studies of interspecific competition are few and most evidence for such species interactions is indirect (Cairns and Yongue 1977).

Contractile Vacuoles

Many protozoa have contractile vacuoles, which collect and expel excess water, and extrusomes, which expel material used to deflect predators or capture prey. In multicellular organisms, hormones are often produced in vesicles. In higher plants, most of a cell's volume is taken up by a central vacuole or tonoplast, which maintains its osmotic pressure. Many eukaryotes have slender motile projections, usually called flagella when long and cilia when short. These are variously involved in movement, feeding, and sensation. These are entirely distinct from prokaryotic flagella. They are supported by a bundle of microtubules arising from a basal body, also called a kinetosome or centriole, characteristically arranged as nine doublets surrounding two singlets. Flagella also may have hairs or mastigonemes, scales, connecting membranes, and internal rods. Their interior is continuous with the cell's cytoplasm.

Centrioles

Centrioles are often present even in cells and groups that do not have flagella. They generally occur in groups of one or two, called kinetids that give rise to various microtubular roots. These form a primary component of the cytoskeletal structure, and are often assembled over the course of several cell divisions, with one flagellum retained from the parent and the other derived from it. Centrioles may also be associated in the formation of a spindle during nuclear division. Some protists have various other microtubule-supported organelles. These include the radiolaria and heliozoa, which produce axopodia used in flotation or to capture prey, and the haptophytes, which have a peculiar flagellum-like organelle called the haptonema.





Figure 1. A diagram of *Paramecium* sp. with major organelles indicated.




Contractile Vacuoles

Figure 2. The contractile vacuole when full (top) and after contraction (bottom).

Paramecium

Members of the genus *Paramecium* are single-celled, freshwater organisms in the kingdom Protista. They exist in an environment in which the osmotic concentration in their external environment is much lower than that in their cytoplasm. More specifically, the habitat in which they live is **hypotonic** to their cytoplasm. As a result of this, *Paramecium* is subjected to a continuous influx of water, as water diffuses inward to a region of higher osmotic concentration.

If *Paramecium* is to maintain homeostasis, water must be continually pumped out of the cell (against the osmotic gradient) at the same rate at which it moves in. This process, known as **osmoregulation**, is carried out by two organelles in *Paramecium* known as **contractile vacuoles** (Figures 1 and 2).





Here is a wastewater Inspector is utilizing the auto sampler's manual to help adjust the time and adjust for the correct flow for a composite sample. You can see that she is pouring off the pickle jar. This inspector is also the course author.

Protozoan Diseases

Protozoan pathogens are larger than bacteria and viruses, but still microscopic. They invade and inhabit the gastrointestinal tract. Some parasites enter the environment in a dormant form, with a protective cell wall called a "*cyst*." The cyst can survive in the environment for long periods of time and be extremely resistant to conventional disinfectants such as chlorine. Effective filtration treatment is therefore critical to removing these organisms from water sources.


Giardiasis


Giardiasis is a commonly reported protozoan-caused disease. It has also been referred to as "backpacker's disease" and "beaver fever" because of the many cases reported among hikers and others who consume untreated surface water. Symptoms include chronic diarrhea, abdominal cramps, bloating, frequent loose and pale greasy stools, fatigue and weight loss. The incubation period is 5-25 days or longer, with an average of 7-10 days. Many infections are asymptomatic (no symptoms). Giardiasis occurs worldwide. Waterborne outbreaks in the United States occur most often in communities receiving their drinking water from streams or rivers without adequate disinfection or a filtration system. The organism, *Giardia lamblia*, has been responsible for more community-wide outbreaks of disease in the U.S. than any other pathogen. Drugs are available for treatment but are not 100% effective.

Cryptosporidiosis


Cryptosporidiosis is an example of a protozoan disease that is common worldwide, but was only recently recognized as causing human disease. The major symptom in humans is diarrhea, which may be profuse and watery. The diarrhea is associated with cramping abdominal pain. General malaise, fever, anorexia, nausea, and vomiting occur less often. Symptoms usually come and go, and end in fewer than 30 days in most cases. The incubation period is 1-12 days, with an average of about seven days. *Cryptosporidium* organisms have been identified in human fecal specimens from more than 50 countries on six continents. The mode of transmission is fecal-oral, either by person-to-person or animal-to-person. There is no specific treatment for *Cryptosporidium* infections.

All of these diseases, with the exception of hepatitis A, have one symptom in common: diarrhea. They also have the same mode of transmission, fecal-oral, whether through person-to-person or animal-to-person contact, and the same routes of transmission, being either foodborne or waterborne. Although most pathogens cause mild, self-limiting disease, on occasion, they can cause serious, even life threatening illness. Particularly vulnerable are persons with weak immune systems such as those with HIV infections or cancer. By understanding the nature of waterborne diseases, the importance of properly constructed, operated and maintained public water systems becomes obvious. While water treatment cannot achieve sterile water (no microorganisms), the goal of treatment must clearly be to produce drinking water that is as pathogen-free as possible at all times. For those who operate water systems with inadequate source protection or treatment facilities, the potential risk of a waterborne disease outbreak is real. For those operating systems that currently provide adequate source protection and treatment, operating and maintaining the system at a high level on a continuing basis is critical to prevent disease.





Giardia Lamblia



GIARDIA LAMBLIA


Giardia lamblia (synonymous with Lamblia intestinalis and Giardia duodenalis) is a flagellated protozoan parasite that colonizes and reproduces in the small intestine, causing giardiasis. The giardia parasite attaches to the epithelium by a ventral adhesive disc, and reproduces via binary fission. Giardiasis does not spread via the bloodstream, nor does it spread to other parts of the gastro-intestinal tract, but remains confined to the lumen of the small intestine. Giardia trophozoites absorb their nutrients from the lumen of the small intestine, and are anaerobes.

Giardia infection can occur through ingestion of dormant cysts in contaminated water, or by the fecal-oral route (through poor hygiene practices). The Giardia cyst can survive for weeks to months in cold water and therefore can be present in contaminated wells and water systems, and even clean-looking mountain streams, as well as city reservoirs, as the Giardia cysts are resistant to conventional water treatment methods, such as chlorination and ozonolysis. Zoonotic transmission is also possible, and therefore Giardia infection is a concern for people camping in the wilderness or swimming in contaminated streams or lakes, especially the artificial lakes formed by beaver dams (hence the popular name for giardiasis, "Beaver Fever"). As well as water-borne sources, fecal-oral transmission can also occur, for example in day care centers, where children may have poorer hygiene practices.

Those who work with children are also at risk of being infected, as are family members of infected individuals. Not all Giardia infections are symptomatic, so some people can unknowingly serve as carriers of the parasite.


The life cycle begins with a non-infective cyst being excreted with feces of an infected individual. Once out in the environment, the cyst becomes infective. A distinguishing characteristic of the cyst is 4 nuclei and a retracted cytoplasm. Once ingested by a host, the trophozoite emerges to an active state of feeding and motility. After the feeding stage, the trophozoite undergoes asexual replication through longitudinal binary fission. The resulting trophozoites and cysts then pass through the digestive system in the feces. While the trophozoites may be found in the feces, only the cysts are capable of surviving outside of the host.

Distinguishing features of the trophozoites are large karyosomes and lack of peripheral chromatin, giving the two nuclei a halo appearance. Cysts are distinguished by a retracted cytoplasm. This protozoa lacks mitochondria, although the discovery of the presence of mitochodrial remnant organelles in one recent study "indicate that Giardia is not primitively amitochondrial and that it has retained a functional organelle derived from the original mitochondrial endosymbiont"



PROTOZOAN PARASITE

Cryptosporidium



Cryptosporidium is a protozoan pathogen of the Phylum Apicomplexa and causes a diarrheal illness called cryptosporidiosis. Other apicomplexan pathogens include the malaria parasite Plasmodium, and Toxoplasma, the causative agent of toxoplasmosis. Unlike Plasmodium, which transmits via a mosquito vector, Cryptosporidium does not utilize an insect vector and is capable of completing its life cycle within a single host, resulting in cyst stages which are excreted in feces and are capable of transmission to a new host.

A number of species of Cryptosporidium infect mammals. In humans, the main causes of disease are C. parvum and C. hominis (previously C. parvum genotype 1). C. canis, C. felis, C. meleagridis, and C. muris can also cause disease in humans. In recent years, cryptosporidiosis has plagued many commercial Leopard gecko breeders. Several species of the Cryptosporidium family (C. serpentes and others) are involved, and outside of geckos it has been found in monitor lizards, iguanas, tortoises as well as several snake species.

Cryptosporidiosis is typically an acute short-term infection but can become severe and non-resolving in children and immunocompromised individuals. The parasite is transmitted by environmentally hardy cysts (oocysts) that, once ingested, excyst in the small intestine and result in an infection of intestinal epithelial tissue.

The genome of Cryptosporidium parvum was sequenced in 2004 and was found to be unusual amongst Eukaryotes in that the mitochondria seem not to contain DNA. A closely-related species, C. hominis, also has its genome sequence available. CryptoDB.org is a NIH-funded database that provides access to the Cryptosporidium genomics data sets.




CRYPTO-PARVUM

When *C. parvum* was first identified as a human pathogen, diagnosis was made by a biopsy of intestinal tissue (Keusch, *et al.*, 1995). However, this method of testing can give false negatives due the "patchy" nature of the intestinal parasitic infection (Flanigan and Soave, 1993). Staining methods were then developed to detect and identify the oocysts directly from stool samples. The modified acid-fast stain is traditionally used to most reliably and specifically detect the presence of cryptosporidial oocysts.

There have been six major outbreaks of cryptosporidiosis in the United States as a result of contamination of drinking water (Juranek, 1995). One major outbreak in Milwaukee in 1993 affected over 400,000 persons. Outbreaks such as these usually result from drinking water taken from surface water sources such as lakes and rivers (Juranek, 1995). Swimming pools and water park wave pools have also been associated with outbreaks of cryptosporidiosis. Also, untreated groundwater or well water public drinking water supplies can be sources of contamination.

The highly environmentally resistant cyst of *C. parvum* allows the pathogen to survive various drinking water filtrations and chemical treatments such as chlorination. Although municipal drinking water utilities may meet federal standards for safety and quality of drinking water, complete protection from cryptosporidial infection is not guaranteed. In fact, *all* waterborne outbreaks of cryptosporidiosis have occurred in communities where the local utilities met all state and federal drinking water standards (Juranek, 1995).

Entamoeba histolytica




Entamoeba histolytica, another water-borne pathogen, can cause diarrhea or a more serious invasive liver abscess. When in contact with human cells, these amoebae are cytotoxic. There is a rapid influx of calcium into the contacted cell, it quickly stops all membrane movement save for some surface blebbing. Internal organization is disrupted, organelles lyse, and the cell dies. The ameba may eat the dead cell or just absorb nutrients released from the cell.

On average, about one in 10 people who are infected with *E. histolytica* becomes sick from the infection. The symptoms often are quite mild and can include loose stools, stomach pain, and stomach cramping. Amebic dysentery is a severe form of amebiasis associated with stomach pain, bloody stools, and fever. Rarely, *E. histolytica* invades the liver and forms an abscess. Even less commonly, it spreads to other parts of the body, such as the lungs or brain.


Scientific classification

Domain: Eukaryota Phylum: Amoebozoa Class: Archamoebae Genus: Entamoeba Species: E. histolytica



Mitochondria


The bacterial cell is surrounded by a lipid membrane, or cell membrane, which encloses the contents of the cell and acts as a barrier to hold nutrients, proteins and other essential components of the cytoplasm within the cell. As they are prokaryotes, bacteria do not tend to have membrane-bound organelles in their cytoplasm and thus contain few large intracellular structures. They consequently lack a nucleus, mitochondria, chloroplasts and the other organelles present in eukaryotic cells, such as the Golgi apparatus and endoplasmic reticulum.



PARAMECIUM


Paramecia

Paramecia are a group of unicellular ciliate protozoa formerly known as slipper animalcules from their slipper shape. They are commonly studied as a representative of the ciliate group. Simple cilia cover the body which allows the cell to move with a synchronous motion (like a caterpilla). There is also a deep oral groove containing inconspicuous compound oral cilia (as found in other peniculids) that is used to draw food inside. They generally feed upon bacteria and other small cells. Osmoregulation is carried out by a pair of contractile vacuoles, which actively expel water absorbed by osmosis from their surroundings. Paramecia are widespread in freshwater environments, and are especially common in scums. Paramecia are attracted by acidic conditions. Certain single-celled eukaryotes, such as Paramecium, are examples for exceptions to the universality of the genetic code (translation systems where a few codons differ from the standard ones).



Amoeba

Amoeba (sometimes amœba or ameba, plural amoebae) is a genus of protozoa that moves by means of pseudopods, and is well-known as a representative unicellular organism. The word amoeba or ameba is variously used to refer to it and its close relatives, now grouped as the Amoebozoa, or to all protozoa that move using pseudopods, otherwise termed amoeboids.



VORTICELLA
(TYPE OF PROTOZOAN FOUND IN STAGNANT WATER)


Vorticella

Vorticella is a genus of protozoa, with over 100 known species. They are stalked inverted bell-shaped ciliates, placed among the peritrichs. Each cell has a separate stalk anchored onto the substrate, which contains a contracile fibril called a myoneme. When stimulated this shortens, causing the stalk to coil like a spring. Reproduction is by budding, where the cell undergoes longitudinal fission and only one daughter keeps the stalk. Vorticella mainly lives in freshwater ponds and streams - generally anywhere protists are plentiful. Other genera such as Carchesium resemble Vorticella but are branched or colonial.

Domain: Eukaryota **Phylum**: Ciliophora

Class: Oligohymenophorea

Subclass: Peritrichia Order: Sessilida Family: Vorticellidae Genus: Vorticella



Rotifer

The rotifers make up a phylum of microscopic and near-microscopic pseudocoelomate animals. They were first described by John Harris in 1696 (Hudson and Gosse, 1886). Leeuwenhoek is mistakenly given credit for being the first to describe rotifers but Harris had produced sketches in 1703. Most rotifers are around 0.1-0.5 mm long, and are common in freshwater throughout the world with a few saltwater species. Rotifers may be free swimming and truly planktonic, others move by inch worming along the substrate, whilst some are sessile, living inside tubes or gelatinous holdfasts. About 25 species are colonial (e.g. Sinantherina semibullata), either sessile or planktonic.

Rotifers get their name (derived from Greek and meaning "wheel-bearer"; they have also been called wheel animalcules) from the corona, which is composed of several ciliated tufts around the mouth that in motion resemble a wheel. These create a current that sweeps food into the mouth, where it is chewed up by a characteristic pharynx (called the mastax) containing a tiny, calcified, jaw-like structure called the trophi. The cilia also pull the animal, when unattached, through the water. Most free-living forms have pairs of posterior toes to anchor themselves while feeding. Rotifers have bilateral symmetry and a variety of different shapes. There is a well-developed cuticle which may be thick and rigid, giving the animal a box-like shape, or flexible, giving the animal a worm-like shape; such rotifers are respectively called loricate and illoricate.

Like many other microscopic animals, adult rotifers frequently exhibit eutely - they have a fixed number of cells within a species, usually on the order of one thousand. Males in the class Monogononta may be either present or absent depending on the species and environmental conditions. In the absence of males, reproduction is by parthenogenesis and results in clonal offspring that are genetically identical to the parent. Individuals of some species form two distinct types of parthenogenetic eggs; one type develops into a normal parthenogenetic female, while the other occurs in response to a changed environment and develops into a degenerate male that lacks a digestive system, but does have a complete male reproductive system that is used to inseminate females thereby producing fertilized 'resting eggs'. Resting eggs develop into zygotes that are able to survive extreme environmental conditions such as may occur during winter or when the pond dries up. These eggs resume development and produce a new female generation when conditions improve again. The life span of monogonont females varies from a couple of days to about three weeks.

Bdelloid rotifers are unable to produce resting eggs, but many can survive prolonged periods of adverse conditions after desiccation. This facility is termed anhydrobiosis, and organisms with these capabilities are termed anhydrobionts. Under drought conditions, bdelloid rotifers contract into an inert form and lose almost all body water; when rehydrated, however, they resume activity within a few hours. Bdelloids can survive the dry state for prolonged periods, with the longest well-documented dormancy being nine years. While in other anhydrobionts, such as the brine shrimp, this desiccation tolerance is thought to be linked to the production of trehalose, a non-reducing disaccharide (sugar), bdelloids apparently lack the ability to synthesize trehalose. Bdelloid rotifer genomes contain two or more divergent copies of each gene. Four copies of hsp82 are, for example, found. Each is different and found on a different chromosome, excluding the possibility of homozygous sexual reproduction.


Waterborne Diseases


Name	Causative organism	Source of organism	Disease
Viral gastroenteritis	Rotavirus (mostly in young children)	Human feces	Diarrhea or vomiting
Norwalk Agent	Noroviruses (genus Norovirus, family Caliciviridae) *1	Human feces; also, shellfish; lives in polluted waters	Diarrhea and vomiting
Salmonellosis	Salmonella (bacterium)	Animal or human feces	Diarrhea or vomiting
Gastroenteritis Escherichia <i>coli</i>	E. coli O1 57:H7 (bacterium): Other E. coli organisms:	Human feces	Symptoms vary with type caused
Typhoid	Salmonella typhi (bacterium)	Human feces, urine	Inflamed intestine, enlarged spleen, high temperature- sometimes fatal
Shigellosis	Shigella (bacterium)	Human feces	Diarrhea
Cholera	Vibrio choleras (bacterium)	Human feces; also, shellfish; lives in many coastal waters	Vomiting, severe diarrhea, rapid dehydration, mineral loss-high mortality
Hepatitis A	Hepatitis A virus	Human feces; shellfish grown in polluted waters	Yellowed skin, enlarged liver, fever, vomiting, weight loss, abdominal pain- low mortality, lasts up to four months
Amebiasis	Entamoeba histolytica (protozoan)	Human feces	Mild diarrhea, dysentery, extra intestinal infection
Giardiasis	Giardia lamblia (protozoan)	Animal or human feces	Diarrhea, cramps, nausea, and general weakness — lasts one week to months
Cryptosporidiosis	Cryptosporidium parvum	Animal or human feces	Diarrhea, stomach pain — lasts (protozoan) days to weeks

Notes:


^{*1} http://www.cdc.gov/ncidod/dvrd/revb/gastro/norovirus.htm http://www.cdc.gov/mmwr/preview/mmwrhtml/rr5009a1.htm

Bacteria Section






Peritrichous Bacteria




BACTERIA TYPES

Microbiologists broadly classify bacteria according to their shape: spherical, rod-shaped, and spiral-shaped. Pleomorphic bacteria can assume a variety of shapes. Bacteria may be further classified according to whether they require oxygen (aerobic or anaerobic) and how they react to a test with Gram's stain. Bacteria in which alcohol washes away Gram's stain are called gram-negative, while bacteria in which alcohol causes the bacteria's walls to absorb the stain are called gram-positive.



COLORLESS FILAMENTOUS
SULFUR BACTERIA

Shigella dysenteriae




SHIGELLA DYSENTERIAE

Shigella dysenteriae is a species of the rod-shaped bacterial genus Shigella. Shigella can cause shigellosis (bacillary dysentery). Shigellae are Gram-negative, non-spore-forming, facultatively anaerobic, non-motile bacteria.

S. dysenteriae, spread by contaminated water and food, causes the most severe dysentery because of its potent and deadly Shiga toxin, but other species may also be dysentery agents. Shigella infection is typically via ingestion (fecal–oral contamination); depending on age and condition of the host as few as ten bacterial cells can be enough to cause an infection. Shigella causes dysentery that result in the destruction of the epithelial cells of the intestinal mucosa in the cecum and rectum. Some strains produce enterotoxin and Shiga toxin, similar to the verotoxin of E. coli O157:H7. Both Shiga toxin and verotoxin are associated with causing hemolytic uremic syndrome.

Shigella invades the host through epithelial cells of the large intestine. Using a Type III secretion system acting as a biological syringe, the bacterium injects IpaD protein into cell, triggering bacterial invasion and the subsequent lysis of vacuolar membranes using IpaB and IpaC proteins. It utilizes a mechanism for its motility by which its IcsA protein triggers actin polymerization in the host cell (via N-WASP recruitment of Arp2/3 complexes) in a "rocket" propulsion fashion for cell-to-cell spread.

The most common symptoms are diarrhea, fever, nausea, vomiting, stomach cramps, and straining to have a bowel movement. The stool may contain blood, mucus, or pus (e.g. dysentery). In rare cases, young children may have seizures. Symptoms can take as long as a week to show up, but most often begin two to four days after ingestion. Symptoms usually last for several days, but can last for weeks. Shigella is implicated as one of the pathogenic causes of reactive arthritis worldwide.



Туре	Characteristics		
Acetic acid	Rod-shaped, gram-negative, aerobic; highly tolerant of acidic conditions; generate organic acids		
Actinomycete	Rod-shaped or filamentous, gram-positive, aerobic; common in soils; essential to growth of many plants; source of much of original antibiotic production in pharmaceutical industry		
Coccoid	Spherical, sometimes in clusters or strings, gram-positive, aerobic and anaerobic; resistant to drying and high-salt conditions; <i>Staphylococcus</i> species common on human skin, certain strains associated with toxic shock syndrome		
Coryneform	Rod-shaped, form club or V shapes, gram-positive, aerobic; found in wide variety of habitats, particularly soils; highly resistant to drying; include <i>Arthrobacter</i> , among most common forms of life on earth		
Endospore- forming	Usually rod-shaped, can be gram-positive or gram-negative; have highly adaptable, heat-resistant spores that can go dormant for long periods, possibly thousands of years; include <i>Clostridium</i> (anaerobic) and <i>Bacillus</i> (aerobic)		
Enteric	Rod-shaped, gram-negative, aerobic but can live in certain anaerobic conditions; produce nitrite from nitrate, acids from glucose; include <i>Escherichia coli, Salmonella</i> (over 1000 types), and <i>Shigella</i>		
Gliding	Rod-shaped, gram-negative, mostly aerobic; glide on secreted slimy substances; form colonies, frequently with complex fruiting structures		
Lactic acid	Gram-positive, anaerobic; produce lactic acid through fermentation; include <i>Lactobacillus</i> , essential in dairy product formation, and <i>Streptococcus</i> , common in humans		
Mycobacterium	Pleomorphic, spherical or rod-shaped, frequently branching, no gram m stain, aerobic; commonly form yellow pigments; include <i>Mycobacterium tuberculosis</i> , cause of tuberculosis		
Mycoplasma	Spherical, commonly forming branching chains, no gram stain, aerobic but can live in certain anaerobic conditions; without cell walls yet structurally resistant to lysis; among smallest of bacteria; named for superficial resemblance to fungal hyphae (<i>myco</i> - means 'fungus')		
Nitrogen-fixing	Rod-shaped, gram-negative, aerobic; convert atmospheric nitrogen gas to ammonium in soil; include <i>Azotobacter</i> , a common genus		
Propionic acid	Rod-shaped, pleomorphic, gram-positive, anaerobic; ferment lactic acid; fermentation produces holes in Swiss cheese from the production of carbon dioxide		
Pseudomonad	Rod-shaped (straight or curved) with polar flagella, gram-negative, aerobic; can use up to 100 different compounds for carbon and energy		
Rickettsia	Spherical or rod-shaped, gram-negative, aerobic; cause Rocky Mountain spotted fever and typhus; closely related to <i>Agrobacterium</i> , a common gall-causing plant bacterium		
Sheathed	Filamentous, gram-negative, aerobic; 'swarmer' (colonizing) cells form and break out of a sheath; sometimes coated with metals from environment		

Spirillum Spiral-shaped, gram-negative, aerobic; include *Bdellovibrio*, predatory

on other bacteria

Spiral-shaped, gram-negative, mostly anaerobic; common in moist environments, from mammalian gums to coastal mudflats; complex

Spirochete environments, from mammalian gums to coastal mudilats; con

internal structures convey rapid movement; include

Treponemapallidum, cause of syphilis

Sulfate- and Sulfurreducing

Commonly rod-shaped, mostly gram-negative, anaerobic; include

Desulfovibrio, ecologically important in marshes

Sulfur- and iron-oxidizing

Vibrio

Commonly rod-shaped, frequently with polar flagella, gram-negative, mostly anaerobic; most live in neutral (nonacidic) environment

Rod- or comma-shaped, gram-negative, aerobic; commonly with a

single flagellum; include *Vibrio cholerae*, cause of cholera, and luminescent forms symbiotic with deep-water fishes and squids

Gram⁺




Lactobacillus acidophilus




Streptococcus thermophilus

Gram-



Escherichia coli

Salmonella



Salmonella is a Gram-negative bacterium. It is found in many turtles and other reptiles. In clinical laboratories, it is usually isolated on MacConkey agar, XLD agar, XLT agar, DCA agar, or Önöz agar. Because they cause intestinal infections and are greatly outnumbered by the bacteria normally found in the healthy bowel, primary isolation requires the use of a selective medium, so use of a relatively non-selective medium such as CLED agar is not often practiced. Numbers of salmonella may be so low in clinical samples that stools are routinely also subjected to "enrichment culture", where a small volume of stool is incubated in a selective broth medium, such as selenite broth or Rappaport Vassiliadis soya peptone broth, overnight. These media are inhibitory to the growth of the microbes normally found in the healthy human bowel, while allowing salmonellae to become enriched in numbers. Salmonellae may then be recovered by inoculating the enrichment broth on one or more of the primary selective media. On blood agar, they form moist colonies about 2 to 3 mm in diameter.

When the cells are grown for a prolonged time at a range of 25—28°C, some strains produce a biofilm, which is a matrix of complex carbohydrates, cellulose and proteins. The ability to produce biofilm (a.k.a. "rugose", "lacy", or "wrinkled") can be an indicator of dimorphism, which is the ability of a single genome to produce multiple phenotypes in response to environmental conditions. Salmonellae usually do not ferment lactose; most of them produce hydrogen sulfide which, in media containing ferric ammonium citrate, reacts to form a black spot in the centre of the creamy colonies.

Classification

Salmonella taxonomy is complicated. As of December 7, 2005, there are two species


within the genus: S. bongori (previously subspecies V) and S. enterica (formerly called S. choleraesuis), which is divided into six subspecies:

- * I—enterica
- * II—salamae
- * Illa—arizonae
- * IIIb—diarizonae
- * IV—houtenae
- * V—obsolete (now designated
- S. bongori)
- * VI—indica

There are also numerous (over 2500) serovars within both species, which are found in a disparate variety of environments and which are associated with many different diseases. The vast majority of human isolates (>99.5%) are subspecies S. enterica. For the sake of simplicity, the CDC recommends that Salmonella species be referred to only by their genus and serovar, e.g.

Salmonella Typhi instead of the more technically correct

designation, Salmonella enterica subspecies enterica serovar Typhi.



Escherichia Coli Section

Fecal Coliform Bacteria

Fecal coliform bacteria are microscopic organisms that live in the intestines of warm-blooded animals. They also live in the waste material, or feces, excreted from the intestinal tract. When fecal coliform bacteria are present in high numbers in a water sample, it means that the water has received fecal matter from one source or another. Although not necessarily agents of disease, fecal coliform bacteria may indicate the presence of disease-carrying organisms, which live in the same environment as the fecal coliform bacteria.

Reasons for Natural Variation

Unlike the other conventional water quality parameters, fecal coliform bacteria are living organisms. They do not simply mix with the water and float straight downstream. Instead they multiply quickly when conditions are favorable for growth, or die in large numbers when conditions are not. Because bacterial concentrations are dependent on specific conditions for growth, and these conditions change quickly, fecal coliform bacteria counts are not easy to predict. For example, although winter rains may wash more fecal matter from urban areas into a stream, cool water temperatures may cause a major die-off. Exposure to sunlight (with its ultraviolet disinfection properties) may have the same effect, even in the warmer water of summertime.

Expected Impact of Pollution

The primary sources of fecal coliform bacteria to fresh water are wastewater treatment plant discharges, failing septic systems, and animal waste. Bacteria levels do not necessarily decrease as a watershed develops from rural to urban. Instead, urbanization usually generates new sources of bacteria. Farm animal manure and septic systems are replaced by domestic pets and leaking sanitary sewers. In fact, stormwater runoff in urbanized areas has been found to be surprisingly high in fecal coliform bacteria concentrations.

The presence of old, disintegrating storm and sanitary sewers, misplaced sewer pipes, and good breeding conditions are common explanations for the high levels measured.

Coliform Standards (in colonies/100ml)

Drinking water	1FC
Total body contact (swimming)	
Partial body contact (boating)	
Threatened sewage effluent	

*Total coliform (TC) includes bacteria from cold-blooded animals and various soil organisms. According to recent literature, total coliform counts are normally about 10 times higher than fecal coliform (FC) counts.

Indicator Connection Varies

General coliforms, E. Coli, and Enterococcus bacteria are the "indicator" organisms generally measured to assess microbiological quality of water. However, these aren't generally what get people sick. Other bacteria, viruses, and parasites are what we are actually worried about.

Because it is so much more expensive and tedious to do so, actual pathogens are virtually never tested for. Over the course of a professional lifetime pouring over indicator tests, in a context where all standards are based on indicators, water workers tend to forget that the indicators are not the things we actually care about.

What are these indicators? More information in the Laboratory section.

- **General coliforms** indicate that the water has come in contact with plant or animal life. General coliforms are universally present, including in pristine spring water. They are of little concern at low levels, except to indicate the effectiveness of disinfection. Chlorinated water and water from perfectly sealed tube wells is the only water I've tested which had zero general coliforms. At very high levels they indicate there is what amounts to a lot of compost in the water, which could easily include pathogens (Ten thousand general coliform bacteria will get you a beach closure, compared to two or four hundred fecal coliforms, or fifty enterococcus).
- **Fecal coliforms**, particularly E. coli, indicate that there are mammal or bird feces in the water.
- Enterococcus bacteria also indicate that there are feces from warm blooded animals in the water. Enterococcus are a type of fecal streptococci. They are another valuable indicator for determining the amount of fecal contamination of water.

According to studies conducted by the EPA, enterococci have a greater correlation with swimming-associated gastrointestinal illness in both marine and fresh waters than other bacterial indicator organisms, and are less likely to "die off" in saltwater.

The more closely related the animal, the more likely pathogens excreted with their feces can infect us. Human feces are the biggest concern, because anything which infects one human could infect another. There isn't currently a quantitative method for measuring specifically human fecal bacteria (expensive genetic studies can give a presence/absence result). Ingesting a human stranger's feces via contaminated water supply is a classic means for infections to spread rapidly. The more pathogens an individual carries, the more hazardous their feces. Ingesting feces from someone who is not carrying any pathogens may gross you out, but it can't infect you. Infection rates are around 5% in the US, and approach 100% in areas with poor hygiene and contaminated water supplies. Keep in the back of your mind that **the ratio of indicators to actual pathogens is not fixed**. It will always be different, sometimes very different. Whenever you are trying to form a mental map of reality based on water tests, you should include in the application of your water intuition an adjustment factor for your best guess of the ratio between indicators and actual pathogens.

Membrane Filter Total Coliform Technique

The membrane filter total Coliform technique is used at Medina County for drinking water quality testing. The following is a summary of this test. A sampling procedure sheet is given to all sample takers by Medina County.

The samples are taken in sterile 100 mL containers. These containers, when used for chlorinated water samples, have a sodium thiosulfate pill or solution to dechlorinate the sample.


The sample is placed in cold storage after proper sample taking procedures are

followed. (See sample procedures below)

The samples are taken to the laboratory with a chain of custody to assure no tampering of samples can occur.

These samples are logged in at the laboratory.

No longer than 30 hours can lapse between the time of sampling and time of test incubation. (8 hours for heterotrophic, nonpotable 6 hours, others not longer than 24 hours)



All equipment is sterilized by oven and autoclave.

Glassware in oven at 170°C ± 10°C with foil (or other suitable wrap) loosely fitting and secured immediately after sterilization.

Filtration units in autoclave at 121°C for 30 minutes.

Use sterile petri dishes, grid, and pads bought from a reliable company – certified, quality assured - test for satisfactory known positive amounts.

Incubators – $35^{\circ}C \pm .5^{\circ}C$ (60% relative humidity)

M-endo medium is prepared and heated to near boiling removed from heat cooled to 45° C pH adjusted to $7.2 \pm .2$ and immediately dispensed 8ml to plates. Keep refrigerated and discard after 2 weeks.



Plates can be stored in a dated box with expiration date and discarded if not used. No denatured alcohol should be used. Everclear or 95% proof alcohol or absolute methyl may be used for sterilizing forceps by flame.

Procedure:

Counters are alcohol wiped.

Bench sheets are filled out.

Samples are removed from refrigeration.

Sterile wrapped utensils are placed on counters.

Filtration units are placed onto sterile membrane filters by aseptic technique using sterile forceps.

Sterile petri dishes are labeled.

The samples closures are clipped.

The sample is shaken 25 times 1 foot in length within 7 seconds.

100 mL is filtered and rinsed with sterile distilled water 3 times.

The membrane filter is aseptically removed from filter holder.

A sterile padded petri dish is used and the membrane filter is rolled onto the pad making sure no air bubbles form.

The sterile labeled lid is placed on the petri dish.

2 blanks and a known is run with each series of samples.

The samples are placed in the 35° C \pm .5°C incubator stacked no higher than 3 for 22 – 24 hours (Humidity can be maintained by saturated paper towels placed under containers holding petri dishes.)

After 22- 24 hours view the petri dishes under a 10 –15 power magnification with cool white fluorescent light.

Count all colonies that appear pink to dark red with a <u>metallic surface sheen</u> – the sheen may vary in size from a pin head to complete coverage.

Report as Total Coliform per 100 mL.

If no colonies are present report as <1 coliform/100mL.

Anything greater than 1 is over the limit for drinking water for 2 samples taken 24 hours apart. Further investigation may be necessary – follow Standard Methods accordingly.



Photograph and Credits to Mary McPherson AranTM Aqua Analytical Laboratory Director.

Escherichia coli EPEC

Two types of pathogenic Escherichia coli, enteropathogenic E. coli (EPEC) and enterohemorrhagic E. coli (EHEC), cause diarrheal disease by disrupting the intestinal environment through the intimate attachment of the bacteria to the intestinal epithelium.

E. coli O157:H7

E. coli O157:H7 (bacterium) found in human feces. Symptoms vary with type caused gastroenteritis.

Escherichia coli O157:H7 is an emerging cause of foodborne illness. An estimated 73,000 cases of infection and 61 deaths occur in the United States each year. Infection often leads to bloody diarrhea, and occasionally to kidney failure. Most illnesses have been associated with eating undercooked, contaminated ground beef. Person-to-person contact in families and child care centers is also an important mode of transmission. Infection can also occur after drinking raw milk and after swimming in or drinking sewage-contaminated water.

Consumers can prevent *E. coli* O157:H7 infection by thoroughly cooking ground beef, avoiding unpasteurized milk, and washing hands carefully. Because the organism lives in the intestines of healthy cattle, preventive measures on cattle farms and during meat processing are being investigated.

What is Escherichia coli O157:H7?

E. coli O157:H7 is one of hundreds of strains of the bacterium Escherichia coli. Although most strains are harmless and live in the intestines of healthy humans and animals, this strain produces a powerful toxin and can cause severe illness.

E. coli O157:H7 was first recognized as a cause of illness in 1982 during an outbreak of severe bloody diarrhea; the outbreak was traced to contaminated hamburgers. Since then, most infections have come from eating undercooked ground beef.

The combination of letters and numbers in the name of the bacterium refers to the specific markers found on its surface and distinguishes it from other types of *E. coli*.

Currently, there are four recognized classes of enterovirulent *E. coli* (collectively referred to as the EEC group) that cause gastroenteritis in humans. Among these is the enterohemorrhagic (EHEC) strain designated *E. coli* O157:H7. *E. coli* is a normal inhabitant of the intestines of all animals, including humans. When aerobic culture methods are used, *E. coli* is the dominant species found in feces.

Normally *E. coli* serves a useful function in the body by suppressing the growth of harmful bacterial species and by synthesizing appreciable amounts of vitamins. A minority of *E. coli* strains are capable of causing human illness by several different mechanisms. *E. coli* serotype O157:H7 is a rare variety of *E. coli* that produces large quantities of one or more related, potent toxins that cause severe damage to the lining of the intestine. These toxins [verotoxin (VT), shiga-like toxin] are closely related or identical to the toxin produced by *Shigella dysenteriae*.

How does *E. coli* or other fecal coliforms get in the water?

E. coli comes from human and animal wastes. During rainfalls, snow melts, or other types of precipitation, *E. coli* may be washed into creeks, rivers, streams, lakes, or groundwater. When these waters are used as sources of drinking water and the water is not treated or inadequately treated, *E. coli* may end up in drinking water.

How is water treated to protect me from *E. coli*?

The water can be treated using chlorine, ultra-violet light, or ozone, all of which act to kill or inactivate *E. coli*. Systems using surface water sources are required to disinfect to ensure that all bacterial contamination such as *E. coli*. is inactivated. Systems using ground water sources are not required to disinfect, although many of them do.

How does the U.S. Environmental Protection Agency regulate E. coli?

According to EPA regulations, a system that operates at least 60 days per year, and serves 25 people or more or has 15 or more service connections, is regulated as a public water system under the Safe Drinking Water Act. If a system is not a public water system as defined by EPA regulations, it is not regulated under the Safe Drinking Water Act, although it may be regulated by state or local authorities.

Under the Safe Drinking Water Act, the EPA requires public water systems to monitor for coliform bacteria. Systems analyze first for total coliform, because this test is faster to produce results. Any time that a sample is positive for total coliform, the same sample must be analyzed for either fecal coliform or *E. coli*. Both are indicators of contamination with animal waste or human sewage.

The largest public water systems (serving millions of people) must take at least 480 samples per month. Smaller systems must take at least five samples a month unless the state has conducted a sanitary survey – a survey in which a state inspector examines system components and ensures they will protect public health – at the system within the last five years.

Systems serving 25 to 1,000 people typically take one sample per month. Some states reduce this frequency to quarterly for ground water systems if a recent sanitary survey shows that the system is free of sanitary defects. Some types of systems can qualify for annual monitoring. Systems using surface water, rather than ground water, are required to take extra steps to protect against bacterial contamination because surface water sources are more vulnerable to such contamination. At a minimum, all systems using surface waters must disinfect. Disinfection will kill *E. coli* O157:H7.

What can I do to protect myself from E. coli O157:H7 in drinking water?

Approximately 89 percent of Americans are receiving water from community water systems that meet all health-based standards. Your public water system is required to notify you if, for any reason, your drinking water is not safe. If you wish to take extra precautions, you can boil your water for one minute at a rolling boil, longer at higher altitudes. To find out more information about your water, see the Consumer Confidence Report from your local water supplier or contact your local water supplier directly. You can also obtain information about your local water system on the EPA's website at www.epa.gov/safewater/dwinfo.htm.

Positive Tests

If you draw water from a private well, you can contact your state health department to obtain information on how to have your well tested for total coliforms, and *E. coli* contamination. If your well tests positive for *E. coli*, there are several steps that you should take: (1) begin boiling all water intended for consumption, (2) disinfect the well according to procedures recommended by your local health department, and (3) monitor your water quality to make certain that the problem does not recur. If the contamination is a recurring problem, you should investigate the feasibility of drilling a new well or install a point-of-entry disinfection unit, which can use chlorine, ultraviolet light, or ozone.



How is *E. coli* O157:H7 spread?

The organism can be found on a small number of cattle farms and can live in the intestines of healthy cattle. Meat can become contaminated during slaughter, and organisms can be thoroughly mixed into beef when it is ground. Bacteria present on a cow's udders or on equipment may get into raw milk. Eating meat, especially ground beef that has not been cooked sufficiently to kill *E. coli* O157:H7 can cause infection. Contaminated meat looks and smells normal. Although the number of organisms required to cause disease is not known, it is suspected to be very small.

Among other known sources of infection are consumption of sprouts, lettuce, salami, unpasteurized milk and juice, and swimming in or drinking sewage-contaminated water. Bacteria in diarrheal stools of infected persons can be passed from one person to another if hygiene or hand washing habits are inadequate. This is particularly likely among toddlers who are not toilet trained. Family members and playmates of these children are at high risk of becoming infected. Young children typically shed the organism in their feces for a week or two after their illness resolves. Older children rarely carry the organism without symptoms.

What illness does E. coli O157:H7 cause?

E. coli O157:H7 infection often causes severe bloody diarrhea and abdominal cramps; sometimes the infection causes non-bloody diarrhea or no symptoms. Usually little or no fever is present, and the illness resolves in 5 to 10 days. Hemorrhagic colitis is the name of the acute disease caused by *E. coli* O157:H7.

In some persons, particularly children under 5 years of age and the elderly, the infection can also cause a complication called hemolytic uremic syndrome, in which the red blood cells are destroyed and the kidneys fail. About 2%-7% of infections lead to this complication. In the United States, hemolytic uremic syndrome is the principal cause of acute kidney failure in children, and most cases of hemolytic uremic syndrome are caused by *E. coli* O157:H7.



How is *E. coli* O157:H7 infection diagnosed?

Infection with *E. coli* O157:H7 is diagnosed by detecting the bacterium in the stool. Most laboratories that culture stool do not test for *E. coli* O157:H7, so it is important to request that the stool specimen be tested on sorbitol-MacConkey (SMAC) agar for this organism. All persons who suddenly have diarrhea with blood should get their stool tested for *E. coli* O157:H7.

How is the illness treated?

Most persons recover without antibiotics or other specific treatment in 5-10 days. There is no evidence that antibiotics improve the course of disease, and it is thought that treatment with some antibiotics may precipitate kidney complications. Antidiarrheal agents, such as loperamide (Imodium), should also be avoided. Hemolytic uremic syndrome is a life-threatening condition usually treated in an intensive care unit. Blood transfusions and kidney dialysis are often required. With intensive care, the death rate for hemolytic uremic syndrome is 3%-5%.

Legionnaires' Disease Legionella Section


Introduction Genus: Legionella Species: pneumophila

The first discovery of bacteria from genus Legionella came in 1976 when an outbreak of pneumonia at an American Legion convention led to 29 deaths. The causative agent, what would come to be known as Legionella pneumophila, was isolated and given its own genus. The organisms classified in this genus are Gram-negative bacteria that are considered intracellular parasites. The disease has two distinct forms:

- Legionnaires' disease, the more severe form of infection which includes pneumonia, and
- Pontiac fever, a milder illness.

What have been the water sources for Legionnaires' disease?

The major source is water distribution systems of large buildings, including hotels and hospitals. Cooling towers have long been thought to be a major source for *Legionella*, but new data suggest that this is an



Philadelphia hotel, but new data now suggests that the water in the hotel was the actual culprit.

Legionnaire's disease is caused most commonly by the inhalation of small droplets of water or fine aerosol containing Legionella bacteria. Legionella bacteria are naturally found in environmental water sources such as rivers, lakes and ponds and may colonize man-made water systems that include air conditioning systems, humidifiers, cooling tower waters, hot water systems, spas and pools.

How do people contract Legionella?

The most popular theory is that the organism is aerosolized in water and people inhale the droplets containing

Legionella. However, new evidence suggests that another way of contracting Legionella is more common. "Aspiration" is the most common way that bacteria enter into the lungs to cause pneumonia. Aspiration means choking such that secretions in the mouth get past the choking reflexes and instead of going into the esophagus and stomach, mistakenly, enter the lung. The protective mechanisms to prevent aspiration is defective in patients who smoke or have lung disease. Aspiration now appears to be the most common mode of transmission.

Legionella may multiply to high numbers in cooling towers, evaporative condensers, air washers, humidifiers, hot water heaters, spas, fountains, and plumbing fixtures. Within one month, Legionella can multiply, in warm water-containing systems, from less than 10 per milliliter to over 1,000 per milliliter of water. Once high numbers of Legionella have been found, a relatively simple procedure for disinfecting water systems with chlorine and detergent is available. This procedure is not part of a routine maintenance program because equipment may become corroded. Property owners have been sued for the spread of Legionella, resulting in



expensive settlements. Regular monitoring with a battery of DFA monoclonal antibodies for several serogroups and species of Legionella morphologically intact bacteria provides a means for exercising 'reasonable care' to deter potential litigation.

Currently, there are no United States government regulations concerning permissible numbers of legionella in water systems and there are no federal or state certification programs for laboratories that perform legionella testing of environmental samples.

Epifluorescence Microscopy DFA Method

The epifluorescence microscopy DFA method that most labs use was published in the British Journal, Water Research 19:839-848, 1985 "Disinfection of circulating water systems by ultraviolet light and halogenation", R. Gilpin, et al. so we can count viable-but-nonculturable (VBNC) legionella.


Most labs will provide a quantitative epifluorescence microscopic analysis of your cooling tower and potable water samples for 14 serogroups of Legionella pneumophila and 15 other Legionella species (listed below).

Legionella anisa	Legionella bozemanii sg 1 & 2
Legionella dumoffi	Legionella feeleii sg 1 & 2
Legionella gormanii	Legionella hackeliae sg 1 & 2
Legionella jordanis	Legionella longbeachae sg 1& 2
Legionella maceachernii	Legionella micdadei
Legionella oakridgensis	Legionella parisiensis
Legionella pneumophila sg 1-14	Legionella sainthelensi
Legionella santicrucis	Legionella wadsworthii

Heterotrophic bacterial CFU are often inversely proportional to numbers of Legionella in cooling tower samples, in our experience. Routine biocide treatments will not eradicate Legionella bacteria in the environment, only in laboratory studies. Culture methods are good during outbreaks for bio-typing; but culture methods lack sensitivity for routine, quantitative monitoring. Many factors will inhibit growth or identification of legionella on BCYE with or without antimicrobial agents, heat or acid treatment.

Culture methods will not identify non-culturable legionella that can still cause outbreaks (non-culturable, viable legionella have been reported in several peer-reviewed journals). Only DFA tests performed by trained laboratory personnel can identify these legionella. Direct fluorescent antibody (DFA) tests using a battery of monoclonal antibodies provide more useful routine monitoring information than culture methods. Legionella species of bacteria cause Legionnaire's disease. They are gram negative (but stain poorly), strictly aerobic rods.

The U.S. Environmental Protection Agency and the U.S. Occupational Safety and Health Administration recommend routine maintenance of water-containing equipment. Most State health departments recommend monthly testing for Legionella as part of a routine maintenance program.



BACTERIOPHAGE


Bacteriophage


A bacteriophage (from 'bacteria' and Greek phagein, 'to eat') is any one of a number of viruses that infect bacteria. The term is commonly used in its shortened form, phage.

Typically, bacteriophages consist of an outer protein hull enclosing genetic material. The genetic material can be ssRNA (single stranded RNA), dsRNA, ssDNA, or dsDNA between 5 and 500 kilo base pairs long with either circular or linear arrangement. Bacteriophages are much smaller than the bacteria they destroy - usually between 20 and 200 nm in size.

Phages are estimated to be the most widely distributed and diverse entities in the biosphere. Phages are ubiquitous and can be found in all reservoirs populated by bacterial hosts, such as soil or the intestine of animals. One of the densest natural sources for phages and other viruses is sea water, where up to 9×108 virions per milliliter have been found in microbial mats at the surface, and up to 70% of marine bacteria may be infected by phages.

VIRUS CAPSID (BACTERIOPHAGES)






Release of Virions

Phages may be released via cell lysis or by host cell secretion. In the case of the T4 phage, in just over twenty minutes after injection upwards of three hundred phages will be released via lysis within a certain timescale. This is achieved by an enzyme called endolysin which attacks and breaks down the peptidoglycan. In contrast, "lysogenic" phages do not kill the host but rather become long-term parasites and make the host cell continually secrete more new virus particles. The new virions bud off the plasma membrane, taking a portion of it with them to become enveloped viruses possessing a viral envelope. All released virions are capable of infecting a new bacterium.

Viruses

Viruses are acellular microorganisms. They are made up of only genetic material and a protein coat. Viruses depend on the energy and metabolic machinery of the host cell to reproduce. A virus is an infectious agent found in virtually all life forms, including humans, animals, plants, fungi, and bacteria. Viruses consist of genetic material—either deoxyribonucleic acid (DNA) or ribonucleic acid (RNA)—surrounded by a protective coating of protein, called a capsid, with or without an outer lipid envelope. Viruses are between 20 and 100 times smaller than bacteria and hence are too small to be seen by light microscopy.



CROSS SECTIONAL VIEW

Viruses vary in size from the largest poxviruses of about 450 nanometers (about 0.000014 in) in length to the smallest polioviruses of about 30 nanometers (about 0.000001 in). Viruses are not considered free-living, since they cannot reproduce outside of a living cell; they have evolved to transmit their genetic information from one cell to another for the purpose of replication. Viruses often damage or kill the cells that they infect, causing disease in infected organisms. A few viruses stimulate cells to grow uncontrollably and produce cancers. Although many infectious diseases, such as the common cold, are caused by viruses, there are no cures for these illnesses. The difficulty in developing antiviral therapies stems from the large number of variant viruses that can cause the same disease, as well as the inability of drugs to disable a virus without disabling healthy cells. However, the development of antiviral agents is a major focus of current research, and the study of viruses has led to many discoveries important to human health.

Virions

Individual viruses, or virus particles, also called virions, contain genetic material, or genomes, in one of several forms. Unlike cellular organisms, in which the genes always are made up of DNA, viral genes may consist of either DNA or RNA. Like cell DNA, almost all viral DNA is double-stranded, and it can have either a circular or a linear arrangement. Almost all viral RNA is single-stranded; it is usually linear, and it may be either segmented (with different genes on different RNA molecules) or non-segmented (with all genes on a single piece of RNA).

Capsids

The viral protective shell, or capsid, can be either helical (spiral-shaped) or icosahedral (having 20 triangular sides). Capsids are composed of repeating units of one or a few different proteins. These units are called protomers or capsomers. The proteins that make up the virus particle are called structural proteins. Viruses also carry genes for making proteins that are never incorporated into the virus particle and are found only in infected cells. These viral proteins are called nonstructural proteins; they include factors required for the replication of the viral genome and the production of the virus particle.

Capsids and the genetic material (DNA or RNA) they contain are together referred to as nucleocapsids. Some virus particles consist only of nucleocapsids, while others contain additional structures.

Some icosahedral and helical animal viruses are enclosed in a lipid envelope acquired when the virus buds through host-cell membranes. Inserted into this envelope are glycoproteins that the viral genome directs the cell to make; these molecules bind virus particles to susceptible host cells.

Bacteriophages

The most elaborate viruses are the bacteriophages, which use bacteria as their hosts. Some bacteriophages resemble an insect with an icosahedral head attached to a tubular sheath. From the base of the sheath extend several long tail fibers that help the virus attach to the bacterium and inject its DNA to be replicated, direct capsid production, and virus particle assembly inside the cell.


Viroids and Prions

Viroids and prions are smaller than viruses, but they are similarly associated with disease. Viroids are plant pathogens that consist only of a circular, independently replicating RNA molecule. The single-stranded RNA circle collapses on itself to form a rod-like structure. The only known mammalian pathogen that resembles plant viroids is the deltavirus (hepatitis D), which requires hepatitis B virus proteins to package its RNA into virus particles. Co-infection with hepatitis B and D can produce more severe disease than can infection with hepatitis B alone. Prions are mutated forms of a normal protein found on the surface of certain animal cells.

Virus Classification

Viruses are classified according to their type of genetic material, their strategy of replication, and their structure. The International Committee on Nomenclature of Viruses (ICNV), established in 1966, devised a scheme to group viruses into families, subfamilies, genera, and species. The ICNV report published in 1995 assigned more than 4000 viruses into 71 virus families. Hundreds of other viruses remain unclassified because of the lack of sufficient information.

Cyanobacteria



Cyanobacteria

Cyanobacteria, also known as blue-green algae, blue-green bacteria or Cyanophyta, is a phylum of bacteria that obtain their energy through photosynthesis. The name "cyanobacteria" comes from the color of the bacteria (Greek: kyanós = blue). They are a significant component of the marine nitrogen cycle and an important primary producer in many areas of the ocean, but are also found on land.

Cyanobacteria include unicellular and colonial species. Colonies may form filaments, sheets or even hollow balls. Some filamentous colonies show the ability to differentiate into several different cell types: vegetative cells, the normal, photosynthetic cells that are formed under favorable growing conditions; akinetes, the climate-resistant spores that may form when environmental conditions become harsh; and thick-walled heterocysts, which contain the enzyme nitrogenase, vital for nitrogen fixation. Heterocysts may also form under the appropriate environmental conditions (anoxic) wherever nitrogen is necessary. Heterocyst-forming species are specialized for nitrogen fixation and are able to fix nitrogen gas, which cannot be used by plants, into ammonia (NH₃), nitrites (NO₂) or nitrates (NO₃), which can be absorbed by plants and converted to protein and nucleic acids.

The rice paddies of Asia, which produce about 75% of the world's rice, could not do so were it not for healthy populations of nitrogen-fixing cyanobacteria in the rice paddy fertilizer too.


Many cyanobacteria also form motile filaments, called hormogonia, that travel away from the main biomass to bud and form new colonies elsewhere. The cells in a hormogonium are often thinner than in the vegetative state, and the cells on either end of the motile chain may be tapered. In order to break away from the parent colony, a hormogonium often must tear apart a weaker cell in a filament, called a necridium.

Each individual cell of a cyanobacterium typically has a thick, gelatinous cell wall. They differ from other gram-negative bacteria in that the quorum sensing molecules autoinducer-2[4] and acyl-homoserine lactones are absent. They lack flagella, but hormogonia and some unicellular species may move about by gliding along surfaces. In water columns some cyanobacteria float by forming gas vesicles, like in archaea.



TAKING A SAMPLE FROM A STREAM

EUGLENA



Euglena

Euglenas are common protists, of the class Euglenoidea of the phylum Euglenophyta. Currently, over 1000 species of Euglena have been described. Marin et al. (2003) revised the genus so, and including several species without chloroplasts, formerly classified as Astasia and Khawkinea. Euglena sometimes can be considered to have both plant and animal features.


Euglena gracilis has a long hair-like thing that stretches from its body. You need a very powerful microscope to see it. This is called a flagellum, and the euglena uses it to swim. It also has a red eyespot. Euglena gracilis uses its eyespot to locate light. Without light, it cannot use its chloroplasts to make itself food. In order for Euglena gracilis to make more Euglena gracilis it will complete a process called mitosis. That means it can split itself in half and become two Euglena gracilis. It can only do this if it is well-fed and if the temperature is right. Euglena gracilis can reproduce better in warm temperatures.

Euglena gracilis, and other euglena, are harmless to people, but they are often signs that water is polluted, since they do well where there is a lot of green algae to eat. Green algae does well where there is a lot of nitrogen (comes from waste) in the water. If you don't clean your swimming pool, leaves and twigs get in the water and turn into waste. Then algae and euglena show up.

KINGDOM: Protist, PHYLUM: Euglenophyta, CLASS: Euglenophyceae, ORDER: Euglenales, FAMILY: Euglenidae, GENUS: Euglena, SPECIES: Euglena gracilis

Peptidoglycan

Peptidoglycan, also known as murein, is a polymer consisting of sugars and amino acids that forms a mesh-like layer outside the plasma membrane of eubacteria. The sugar component consists of alternating residues of β -(1,4) linked N-acetylglucosamine and N-acetylmuramic acid residues. Attached to the N-acetylmuramic acid is a peptide chain of three to five amino acids. The peptide chain can be cross-linked to the peptide chain of another strand forming the 3D mesh-like layer.



Hepatitis



HEPATITUS VIRUS

There are five types of hepatitis -- A through E -- all of which cause inflammation of the liver. Type D affects only those who also have hepatitis B, and hepatitis E is extremely rare in the United States.

- > Type A hepatitis is contracted through anal-oral contact, by coming in contact with the feces of someone with hepatitis A, or by eating or drinking hepatitis A contaminated food or water.
- > Type B hepatitis can be contracted from infected blood, seminal fluid, vaginal secretions, or contaminated drug needles, including tattoo or body-piercing equipment. It can also be spread from a mother to her newborn.
- ➤ Type C hepatitis is not easily spread through sex. You're more likely to get it through contact with infected blood, contaminated razors, needles, tattoo and body-piercing equipment, or manicure or pedicure tools that haven't been properly sanitized, and a mother can pass it to her baby during delivery.
- > Type D hepatitis can be passed through contact with infected blood, contaminated needles, or by sexual contact with an HIV-infected person.
- > Type E hepatitis is most likely to be transmitted in feces, through oral contact, or in water that's been contaminated.

Common Water Quality and Sampling Statements

These statements will be more explained in the previous chapters.

1. What are the correct procedures to follow in collecting bacteriological samples?

Use a sterile plastic or glass bottle. Sodium thiosulfate should be added to neutralize the chorine residual. Refrigerate the sample to 4° C. The regulations call for a minimum of five samples for the month from any system that has positive sample results. Small systems that take only one sample per month have to take four (4) repeats when they get a total coliform positive test result. If any system has to take repeat samples, it must also take a minimum of five (5) routine samples the following month. Small systems that normally take less than 5 samples/month will have to increase the number to 5 samples. They can return to normal sampling schedules the following month if no repeats are required.

2. What are the proper sampling techniques for microbiological sampling?

Proper sampling techniques are extremely important in obtaining accurate water quality information. An improperly taken coliform sample may indicate bacteriological contamination of your water when the water is actually safe. You can avoid the cost of additional testing by using good sampling procedures. Carefully follow these steps in taking a sample for bacteriological testing:

1. Select the sampling point. The sampling point must be a faucet from which water is commonly taken for public use.

The sampling point should be a non-swivel faucet.

Remove any aerator or screen and flush.

It should not be a faucet that leaks, permitting water to run over the outside of the faucet. Leaking faucets can promote bacterial growth.

If an outside faucet must be used, disconnect any hoses or other attachments and be sure to flush the line thoroughly.

Do not use fire hydrants as sampling points. Do not dip the bottle in reservoirs, spring boxes or storage tanks in order to collect the sample.

3. What do the following abbreviations stand for and what do they mean: gpm, MGD, TTHM, psi, HAA, NTU, and mg/L.

Gallons per minute- Million Gallons a Day - Total Trihalomethanes – Pounds Per Square Inch – Haloacetic acids - Nephelometric turbidity unit - Milligrams Per Liter

4. What is the relationship between mg/L and ppm; ug/L and ppb?

Milligram per liter: Milligram per liter of substance and part per million are equals amounts in water. While you can easily convert between micrograms/liter and milligrams/liter, and between PPM and PPB, its not so easy to convert between the different types of units such as milligrams/liter to PPM.

To convert micrograms per liter to milligrams per liter, divide by 1000.

To convert to PPM, you would first need to know the density of the substance, and the density of what the substance is in.

5. Ug/L: Represents the concentration of something in water or soil. One ppb represents one microgram of something per liter of water (ug/l), or one microgram of something per kilogram of soil (ug/kg).

Parts per million (ppm) or Milligrams per liter (mg/l) - one part per million corresponds to one minute in two years or a single penny in \$10,000.

Parts per billion (ppb) or Micrograms per liter - one part per billion corresponds to one minute in 2,000 years, or a single penny in \$10,000,000.

Parts per trillion (ppt) or Nanograms per liter (nanograms/l) - one part per trillion corresponds to one minute in 2,000,000 years, or a single penny in \$10,000,000,000.

6. What do the following terms represent in reference to water quality.

Total coliform: The coliform family has been divided into two groups. Results may come back as either total coliform positive (TC positive) or fecal coliform positive, or (FC positive or *E. coli* positive.) Total coliform positive means that no human coliform are present.

- **7. Fecal Coliform:** Fecal coliform positive indicates the presence of *E. coli*, which means there is a greater chance of pathogens being present. The laboratory tests for coliform include the MPN method, the Membrane Filter test, the Colilert test, and the presence-absence test.
- **8. Presence-absence Test:** Presence-Absence Broth is used for the detection of coliform bacteria in water treatment plants or distribution systems using the presence-absence coliform test.
- **9. Physical Characteristics of Water:** A characteristic of water defined by the temperature, turbidity, color, taste, and odor of the water.
- **10. Point-of-entry sample (POE)**: A type of water sample taken after treatment and before reaching the first consumer.
- **11. Acute Health Effect:** An immediate (i.e. within hours or days) effect that may result from exposure to certain drinking water contaminants (e.g., pathogens).
- **12. Non-acute violation:** If the MCL is exceeded and none of the positive results indicated a presence of Fecal Coliform, a Tier 2 violation has occurred. This level of violation used to be called a non-acute violation.
- **13. Routine Sample:** Samples collected on a routine basis to monitor for contamination. Collection should be in accordance with an approved sampling plan.

14. Repeat Sample: Short answer... Samples collected following a 'coliform present' routine sample. The number of repeat samples to be collected is based on the number of routine samples you normally collect. Long Answer. Anytime a microbiological sample result comes back positive, indicating the presence of total or fecal coliform/ E.coli, repeat samples must be taken. Three repeats are usually required. One must be taken at the site of the positive sample. The two samples must be taken upstream and downstream of the original site (within five service connections). These repeat samples must be taken within 24 hours of notification of positive results. They must be identified as a Repeat Sample on the sample form. Repeat samples may be required to be sealed with a red evidentiary seal tape. The tape must cover the cap and extend down the sides of the bottle. The sample forms must also include the reference number for the positive sample.

There is an important exception to the three repeat samples rule. The regulations also state that when repeats are taken the minimum number of samples is raised to five for the month. A system that collects just one sample a month must collect four repeat samples, when the sample is positive, in order to have five samples as required.

Whenever a system has to take repeat samples, a minimum of five routine samples must also be submitted the following month. This is only an issue for systems that normally turn in four or fewer samples each month. If the five samples are negative the system can return to its normal sampling schedule the next month.

Small systems that have fewer than four sampling sites have a problem complying with the "upstream and downstream" aspects of the repeat sampling requirements. In this case, samples should be taken at as many separate sites as possible and then wait a minimum of 2 hours before resampling enough sites to get the required number of samples. Repeat sample with red seal tape.

- **15. Treatment technique:** An enforceable procedure or level of technical performance which public water systems must follow to ensure control of a contaminant.
- **16. Action level:** The level of lead or copper which, if exceeded, triggers treatment or other requirements that a water system must follow.

17. What does the membrane filter test analyze with regards to bacteriological sampling?

Membrane Filter Technique: A standard test used for measuring coliform numbers (quantity) in water is the membrane filter technique. This technique involves filtering a known volume of water through a special sterile filter. These filters are made of nitrocellulose acetate and polycarbonate, are 150 μ m thick, and have 0.45 μ m diameter pores. A grid pattern is printed on these filter disks in order to facilitate colony counting. When the water sample is filtered, bacteria (larger than 0.45 μ m) in the sample are trapped on the surface of the filter. The filter is then carefully removed, placed in a sterile petri plate on a pad saturated with a liquid medium, and incubated for 20-24 hours at 37°C.


One assumes that each bacterium trapped on the filter will then grow into a separate colony. By counting the colonies one can directly determine the number of bacteria in the water sample that was filtered. The broth medium usually employed in detecting total coliforms is M-Endo Broth MF. Total coliform colonies will be pink to dark red in color and will appear to have a golden green color.

- 18. What do the following terms mean in relation to drinking water quality: disinfection, pathogenic, toxic, pH, aesthetic, culinary and potable.
- **Disinfection:** The chemical process of killing or inactivating most microorganisms in water. See also Sterilization.
- **19. Pathogenic:** Organisms or bugs that cause disease. These include bacteria, viruses, cysts and anything capable of causing disease in humans, like cryptosporidiosis, typhoid, cholera and so on. There are other organisms that do not create disease, these are called non-pathogenic organisms.
- **20. Toxic:** Stuff that will kill you. A substance which is poisonous to living organisms.
- **21. pH:** A measure of the acidity of water. The pH scale runs from 0 to 14 with 7 being the mid point or neutral. A pH of less than 7 is on the acid side of the scale with 0 as the point of greatest acid activity. A pH of more than 7 is on the basic (alkaline) side of the scale with 14 as the point of greatest basic activity. For example, the acidity of a sample with a pH of **5** is ten times greater than that of a sample with a pH of **6**. A difference of 2 units, from **6** to **4**, would mean that the acidity is one hundred times greater, and so on. Normal rain has a pH of **5.6** slightly acidic because of the carbon dioxide picked up in the earth's atmosphere by the rain.
- **22. Aesthetic:** Attractive or appealing water or things in water that will not make you sick but may appear to change the water's color or taste.
- **23.** Culinary: Having to do with cooking food. Potable water is often called culinary water.
- **24. Potable:** Water that is free of objectionable pollution, contamination, or infective agents. Generally speaking, we serve only potable water and not palatable water. Palatable is pleasant tasting water.
- 25. What is hardness in water and what chemicals cause it?

Hardness: Water that contains high amounts of dissolved minerals, specifically calcium and magnesium. **Ion Exchange:** A method of water softening where hardness causing ions are exchanged with sodium ions; also effective in removing many inorganic contaminants such as nitrates, copper, and lead; and treating aesthetic water problems.

26. What is Escherichia Coliform and what does it indicate in relation to drinking water? *E. coli* is a sub-group of the fecal coliform group. Most *E. coli* bacteria are harmless and are found in great quantities in the intestines of people and warm-blooded animals. Some strains, however, can cause illness. The presence of *E. coli* in a drinking water sample almost always indicates recent fecal contamination meaning there is a greater risk that pathogens are present.

TOTAL COLIFORM, FECAL COLIFORM AND E. COLI



Total coliform, fecal coliform, and *E. coli* are all indicators of drinking water quality. The total coliform group is a large collection of different kinds of bacteria. Fecal coliforms are types of total coliform that mostly exist in feces. *E. coli* is a sub-group of fecal coliform. When a water sample is sent to a lab, it is tested for total coliform. If total coliform is present, the sample will also be tested for either fecal coliform or *E. coli*, depending on the lab testing method.

27. What problems are associated with Hydrogen Sulfide in the water?

Hydrogen sulfide is a gas which, when dissolved in water, gives it a "rotten egg" odor. Chlorination will remove this gas from the water but the effectiveness of the chlorine for disinfection is lessened.

- 28. When Hydrogen sulfide reacts with chlorine, it produces Sulfuric acid and elemental Sulfur: It is therefore recommended that aeration be applied prior to the addition of chlorine for the most effective disinfection.
- **29.** Why is it important to know what the turbidity of the water is when using chlorine? To be careful not to overdose with chlorine or properly dose with chlorine.

30. What is the log removal for Cryptosporidium?

The LT1ESWTR extends further this necessary protection from Cryptosporidium to communities of fewer than 10,000 persons. Today's rule for the first time establishes Cryptosporidium control requirements for systems serving less than 10,000 persons by requiring a minimum 2-log removal for Cryptosporidium. The rule also strengthens filter performance requirements to ensure 2-log Cryptosporidium removal, establishes individual filter monitoring to minimize poor performance in individual units, includes Cryptosporidium in the definition of GWUDI, and explicitly considers unfiltered system watershed control provisions. The rule also reflects a commitment to the importance of maintaining existing levels of microbial protection in public water systems as plants take steps to comply with newly applicable DBP standards.

31. What is the log removal?

This log-reduction terminology was developed by engineers as a way to express levels of decreased biological contamination in water by factors of 10 that could be easily converted to percent reduction. The most commonly used logarithmic base is 10 because it is compatible with our base-10 decimal system. The log of 10 in the base 10 logarithmic system is 1 and the log of 100 is 2, with the log of 1000 being 3, etc. A 1-log reduction is nine out of 10 and would be equivalent to a 90 percent reduction. A 2-log reduction would be 99 out of 100 or 99 percent reduction and a 3-log reduction would be 999 out of 1000 or 99.9 percent reduction. A 99.99 percent reduction would be called a 4-log reduction.

32. What are the turbidity requirements for Direct and Conventional filtration plants?

For conventional and direct filtration systems (including those systems utilizing in-line filtration), the turbidity level of representative samples of a system's filtered water (measured every four hours) must be less than or equal to *0.3 NTU* in at least 95 percent of the measurements taken each month. The turbidity level of representative samples of a system's filtered water must not exceed *1 NTU* at any time. Conventional filtration is defined as a series of processes including coagulation, flocculation, sedimentation, and filtration resulting in substantial particulate removal. Direct filtration is defined as a series of processes including coagulation and filtration but excluding sedimentation resulting in substantial particle removal.

33. What are chloramines, how are they formed, and do they have any beneficial use?

Chloramines: Ammonia and Chlorine are combined. Cl₂NH₃Yes, limited use and this chemical will create less THMS than chlorine alone. Chloramine is a disinfectant used to treat drinking water. It is formed by mixing chlorine with ammonia. Although it is a weaker disinfectant than chlorine, it is more stable and extends disinfectant benefits throughout a water utility's distribution system (a system of pipes water is delivered to homes through). Some water systems use chloramine as a secondary disinfectant to maintain a disinfectant residual throughout the distribution system so that drinking water remains safe as it travels from the treatment facility to the customer. Chloramine has been used by water systems for almost 90 years, and its use is closely regulated. Since chloramine is not as reactive as chlorine, it forms fewer disinfection byproducts. Some disinfection byproducts, such as the trihalomethanes (THMs) and haloacetic acids (HAAs), may have adverse health effects and are closely regulated. Because a chloramine residual is more stable and longer lasting than free chlorine, it provides better protection against bacterial regrowth in systems with large storage tanks and dead-end water mains. Chloramine, like chlorine, is effective in controlling biofilm, which is a coating in the pipe caused by bacteria. Controlling biofilm also tends to reduce coliform bacteria concentrations and biofilm-induced corrosion of pipes.

Glossary

ABANDONED WELL: Wells that have been or need to be sealed by an approved method.

ABSENCE OF OXYGEN: The complete absence of oxygen in water described as Anaerobic.

ACCURACY: How closely an instrument measures the true or actual value.

ACID AND BASE ARE MIXED: When an acid and a base are mixed, an explosive reaction occurs and decomposition products are created under certain conditions.

ACID: Slowly add the acid to water while stirring. An operator should not mix acid and water or acid to a strong base.

ACID RAIN: A result of airborne pollutants.

ACTIVATED CHARCOAL (GAC or PAC): Granular Activated Charcoal or Powered Activated Charcoal. Used for taste and odor removal. A treatment technique that is not included in the grading of a water facility.

ACTIVATED CARBON FILTRATION: Can remove organic chemicals that produce off-taste and odor. These compounds are not dangerous to health but can make the water unpleasant to drink. Carbon filtration comes in several forms, from small filters that attach to sink faucets to large tanks that contain removable cartridges. Activated carbon filters require regular maintenance or they can become a health hazard.

ADSORPTION: Not to be confused with absorption. Adsorption is a process that occurs when a gas or liquid solute accumulates on the surface of a solid or a liquid (adsorbent), forming a film of molecules or atoms (the adsorbate). It is different from absorption, in which a substance diffuses into a liquid or solid to form a solution. The term sorption encompasses both processes, while desorption is the reverse process. Adsorption is present in many natural physical, biological, and chemical systems, and is widely used in industrial applications such as activated charcoal, synthetic resins, and water purification.

ADSORPTION CLARIFIERS: The concept of the adsorption clarifier package plant was developed in the early 1980s. This technology uses an up-flow clarifier with low-density plastic bead media, usually held in place by a screen. This adsorption media is designed to enhance the sedimentation/clarification process by combining flocculation and sedimentation into one step. In this step, turbidity is reduced by adsorption of the coagulated and flocculated solids onto the adsorption media and onto the solids already adsorbed onto the media. Air scouring cleans adsorption clarifiers followed by water flushing. Cleaning of this type of clarifier is initiated more often than filter backwashing because the clarifier removes more solids. As with the tube-settler type of package plant, the sedimentation/ clarification process is followed by mixed-media filtration and disinfection to complete the water treatment.

AIR GAP SEPARATION: A physical separation space that is present between the discharge vessel and the receiving vessel; for an example, a kitchen faucet.

AIR HAMMER: A pneumatic cylindrical hammering device containing a piston used on air rotary rigs. The air hammer's heavy piston moves up and down by the introduction of compressed air creating a hammering action on the bit.

AIR HOOD: The most suitable protection when working with a chemical that produces dangerous fumes.

AIR ENTRAINMENT: The dissolution or inclusion of air bubbles into water.

AIRLIFT: The lifting of water and/or cuttings to the surface by the injection of high pressure bursts of air. Airlift occurs continuously when drilling with air rotary and can be used for well development with a surging technique.

AIR PUMPING: Continuous airlifting to remove water from the well.

AIR ROTARY: A method of rotary well drilling that utilizes compressed air as the primary drilling fluid.

AGGLOMERATION: A jumbled cluster or mass of varied parts. The act or process of agglomerating.

ALKALINITY: Alkalinity or AT is a measure of the ability of a solution to neutralize acids to the equivalence point of carbonate or bicarbonate. Alkalinity is closely related to the acid neutralizing capacity (ANC) of a solution and ANC is often incorrectly used to refer to alkalinity. However, the acid neutralizing capacity refers to the combination of the solution and solids present (e.g., suspended matter, or aquifer solids), and the contribution of solids can dominate the ANC (see carbonate minerals below).

ALTERNATIVE DISINFECTANTS: Disinfectants - other than chlorination (halogens) - used to treat water, e.g. ozone, ultraviolet radiation, chlorine dioxide, and chloramine. There is limited experience and scientific knowledge about the by-products and risks associated with the use of alternatives.

ALGAE: Microscopic plants that are free-living and usually live in water. They occur as single cells floating in water, or as multicellular plants like seaweed or strands of algae that attach to rocks.

ALPHA AND BETA RADIOACTIVITY: Represent two common forms of radioactive decay. Radioactive elements have atomic nuclei so heavy that the nucleus will break apart, or disintegrate spontaneously. When decay occurs, high-energy particles are released. These high-energy particles are called radioactivity. Although radioactivity from refined radioactive elements can be dangerous, it is rare to find dangerous levels of radioactivity in natural waters. An alpha particle is a doubly-charged helium nucleus comprised of two protons, two neutrons, and no electrons. A beta particle is a high-speed electron. Alpha particles do not penetrate matter easily, and are stopped by a piece of paper. Beta particles are much more penetrating and can pass through a millimeter of lead.

ALUMINUM SULFATE: The chemical name for Alum. The molecular formula of Alum is $Al_2(SO_4)3\sim14H_2O$. It is a cationic polymer.

AMOEBA: Amoeba (sometimes amoeba or ameba, plural amoebae) is a genus of protozoa that moves by means of pseudopods, and is well-known as a representative unicellular organism. The word amoeba or ameba is variously used to refer to it and its close relatives, now grouped as the Amoebozoa, or to all protozoa that move using pseudopods, otherwise termed amoeboids.

AMMONIA: NH₃ A chemical made with Nitrogen and Hydrogen and used with chlorine to disinfect water. Most ammonia in water is present as the ammonium ion rather than as ammonia.

AMMONIATOR: A control device which meters gaseous ammonia directly into water under positive pressure.

ANAEROBIC: An abnormal condition in which color and odor problems are most likely to occur.

ANAEROBIC CONDITIONS: When anaerobic conditions exist in either the metalimnion or hypolimnion of a stratified lake or reservoir, water quality problems may make the water unappealing for domestic use without costly water treatment procedures. Most of these problems are associated with Reduction in the stratified waters.

ANEROID: Using no fluid, as in aneroid barometer.

ASEPTIC: Free from the living germs of disease, fermentation, or putrefaction.

ANNULAR SPACE: The space between the borehole wall and either drill piping or casing within a well.

ANNULUS: See Annular Space.

AMMONIA: A chemical made with Nitrogen and Hydrogen and used with chlorine to disinfect water.

AQUICLUDE: A layer or layers of soils or formations which water cannot pass through (ex - solid bedrock or very stiff clay). The opposite of aguifer.

AQUIFER: A saturated layer or layers of soils or formations which water can pass through and be provided in usable quantities to supply wells or springs (ex – saturated semi consolidated sediment or saturated fractured bedrock.) An underground geologic formation capable of storing significant amounts of water.

AQUIFER PARAMETERS: Referring to such attributes as specific capacity, aquifer storage, transmissivity, hydraulic conductivity, gradient, and water levels. Refers to all of the components of Darcy's Law and related parameters.

ARTESIAN AQUIFER: A confined aquifer in which the pressure head results in a water elevation higher than the land surface.

ARTESIAN WELL: A well constructed within an artesian aquifer. When an artesian well is opened it will flow naturally.

As: The chemical symbol of Arsenic.

AS NITROGEN: An expression that tells how the concentration of a chemical is expressed mathematically. The chemical formula for the nitrate ion is NO_3 , with a mass of 62. The concentration of nitrate can be expressed either in terms of the nitrate ion or in terms of the principal element, nitrogen. The mass of the nitrogen atom is 14. The ratio of the nitrate ion mass to the nitrogen atom mass is 4.43. Thus a concentration of 10 mg/L nitrate expressed as nitrogen would be equivalent to a concentration of 44.3 mg/L nitrate expressed as nitrate ion. When dealing with nitrate numbers it is very important to know how numeric values are expressed.

ASYNCHRONOUS: Not occurring at the same time.

AUGER RIG: A drilling rig, which drives a rotating spiral flange to drill into the earth.

ATOM: The general definition of an ion is an atom with a positive or negative charge. Electron is the name of a negatively charged atomic particle.

BACKFLOW PREVENTION: To stop or prevent the occurrence of, the unnatural act of reversing the normal direction of the flow of liquid, gases, or solid substances back in to the public potable (drinking) water supply. See Cross-connection control.

BACKFLOW: To reverse the natural and normal directional flow of a liquid, gases, or solid substances back in to the public potable (drinking) water supply. This is normally an undesirable effect.

BACKSIPHONAGE: A liquid substance that is carried over a higher point. It is the method by which the liquid substance may be forced by excess pressure over or into a higher point.

BACTERIA: Small, one-celled animals too small to be seen by the naked eye. Bacteria are found everywhere, including on and in the human body. Humans would be unable to live without the bacteria that inhabit the intestines and assist in digesting food. Only a small percentage of bacteria cause disease in normal, healthy humans. Other bacteria can cause infections if they get into a cut or wound. Bacteria are the principal concern in evaluating the microbiological quality of drinking water, because some of the bacteria-caused diseases that can be transmitted by drinking water are potentially life-threatening.

BACTERIOPHAGE: Any of a group of viruses that infect specific bacteria, usually causing their disintegration or dissolution. A bacteriophage (from 'bacteria' and Greek phagein, 'to eat') is any one of a number of viruses that infect bacteria. The term is commonly used in its shortened form, phage. Typically, bacteriophages consist of an outer protein hull enclosing genetic material. The genetic material can be ssRNA (single stranded RNA), dsRNA, ssDNA, or dsDNA between 5 and 500 kilo base pairs long with either circular or linear arrangement. Bacteriophages are much smaller than the bacteria they destroy - usually between 20 and 200 nm in size.

BAILER: A device used to withdrawal water or sediment from a well utilizing a check valve type mechanism.

BARITE: Processed barium sulfate, often used to increase drilling fluid densities in mud rotary.

BATTERY: A source of direct current (**DC**) may be used for standby lighting in a water treatment facility. The electrical current used in a DC system may come from a battery.

BENTONITE: High quality clay composed primarily of montmorillonite. Used to thicken drilling mud in mud rotary drilling and used to form seals in well construction or abandonment.

BEST AVAILABLE TECHNOLOGY ECONOMICALLY ACHIEVABLE (BAT): A level of technology based on the best existing control and treatment measures that are economically achievable within the given industrial category or subcategory.

BEST MANAGEMENT PRACTICES (BMPs): Schedules of activities, prohibitions of practices, maintenance procedures, and other management practices to prevent or reduce the pollution of waters of the U.S. BMPs also include treatment requirements, operating procedures and practices to control plant site runoff, spillage or leaks, sludge or waste disposal, or drainage from raw material storage.

BEST PRACTICABLE CONTROL TECHNOLOGY CURRENTLY AVAILABLE (BPT): A level of technology represented by the average of the best existing wastewater treatment performance levels within an industrial category or subcategory.

BEST PROFESSIONAL JUDGMENT (BPJ): The method used by a permit writer to develop technology-based limitations on a case-by-case basis using all reasonably available and relevant data.

BIT: The primary cutting edge of a drill string.

BLANK CASING: A section of well casing that is solid.

BLOWDOWN: The discharge of water with high concentrations of accumulated solids from boilers to prevent plugging of the boiler tubes and/or steam lines. In cooling towers, blowdown is discharged to reduce the concentration of dissolved salts in the recirculating cooling water.

BOREHOLE DEVIATION: A boreholes' orientation deviates from vertical while drilling.

BOREHOLE GEOPHYSICS: A surveying technique of utilizing specialized tools to measure various physical parameters of the aquifer, formation, and well.

BOREHOLE: The hole that is formed when drilling into the earth.

BOULDER: An individual rock or solid mass of rock larger than 10 inches in diameter.

BREAK POINT CHLORINATION: The process of chlorinating the water with significant quantities of chlorine to oxidize all contaminants and organic wastes and leave all remaining chlorine as free chlorine.

BRIDGING: The tendency of sediment, filter, or seal media to create an obstruction if installed in too small an annulus or to rapidly. Also can occur within filter packs requiring development.

BROMINE: Chemical disinfectant (HALOGEN) that kills bacteria and algae. This chemical disinfectant has been used only on a very limited scale for water treatment because of its handling difficulties. This chemical causes skin burns on contact, and a residual is difficult to obtain.

BUCKET AUGER: A single cylindrical type of auger flight consisting of offset cutting blades at the bottom. A bucket auger rig rotates the bucket and its blades cut into the earth and fill the bucket with cuttings, which are dumped on the surface as needed.

BUFFER: Chemical that resists pH change, e.g. sodium bicarbonate

BUTTON BIT: A bit that is constructed with raised (typically carbide) buttons that strengthen the bit and aid in crushing and grinding efficiency. A button bit may be of a roller, hammer, or percussion type.

CABLE TOOL: (Also called Percussion Drilling) A method of drilling which utilizes the consecutive lifting and dropping of a heavy drill string via a system of cables.

CALCIUM HARDNESS: A measure of the calcium salts dissolved in water.

Ca: The chemical symbol for calcium.

CADMIUM: A contaminant that is usually not found naturally in water or in very small amounts.

CALCIUM HARDNESS: A measure of the calcium salts dissolved in water.

CALCIUM ION: Is divalent because it has a valence of +2.

CALCIUM, MAGNESIUM AND IRON: The three elements that cause hardness in water.

CaOCl₂.4H₂O: The molecular formula of Calcium hypochlorite.

CAPILLARY ACTION: The occurrence of an upward movement of fluid into previously unsaturated soil due to adhesion and surface tension which develops between the fluid and soil particles.

CAPILLARY FRINGE: The uppermost portion of an aquifer where the vadose zone ends. The capillary action of soils permits moisture to extend upwards into the vadose zone within the capillary fringe.

CARBON DIOXIDE GAS: The pH will decrease and alkalinity will change as measured by the Langelier index after pumping carbon dioxide gas into water.

CARBONATE HARDNESS: Carbonate hardness is the measure of Calcium and Magnesium and other hard ions associated with carbonate (CO₃2') and bicarbonate (HCO₃-) ions contained in a solution, usually water. It is usually expressed either as parts per million (ppm or mg/L), or in degrees (KH - from the German "Karbonathärte"). One German degree of carbonate hardness is equivalent to about 17.8575 mg/L. Both measurements (mg/L or KH) are usually expressed "as CaCO₃" – meaning the amount of hardness expressed as if calcium carbonate was the sole source of hardness. Every bicarbonate ion only counts for half as much carbonate hardness as a carbonate ion does. If a solution contained 1 liter of water and 50 mg NaHCO₃ (baking soda), it would have a carbonate hardness of about 18 mg/L as CaCO₃. If you had a liter of water containing 50 mg of Na₂CO₃, it would have a carbonate hardness of about 29 mg/L as CaCO₃.

CARBONATE, BICARBONATE AND HYDROXIDE: Chemicals that are responsible for the alkalinity of water.

CARBONATE ROCK: Rock that is composed primarily of calcium carbonate.

CASING DRIVER: A percussion or hammering device used to force casing into the subsurface.

CASING: A column of specially designed pipe of metal or plastic material installed in wells in order to keep a borehole open to permit serviceability of and/or construction and completion of a well within it.

CATHEAD: A specially designed auxiliary reel that normally utilizes heavy rope rather than steel cable. Often used on cable tool or percussion drilling rigs for the operation of drive blocks.

CATHODIC PROTECTION: An operator should protect against corrosion of the anode and/or the cathode by painting the copper cathode. Cathodic protection interrupts corrosion by supplying an electrical current to overcome the corrosion-producing mechanism. Guards against stray current corrosion.

CAUSTIC: NaOH (also called Sodium Hydroxide) is a strong chemical used in the treatment process to neutralize acidity, increase alkalinity or raise the pH value.

CAUSTIC SODA: Also known as sodium hydroxide and is used to raise pH.

CAVERN: Large open spaces (>5ft.) encountered while drilling. More often associated with limestone formations in a karst environment.

CEILING AREA: The specific gravity of ammonia gas is 0.60. If released, this gas will accumulate first at the ceiling area. Cl₂ gas will settle on the floor.

CEMENT GROUT: Cement of fine consistency, capable of being pumped. Used to seal in and around wells.

CENTRALIZER: Stand offs attached to well casing and screen to maintain annular space. In drilling, it has the same meaning as stabilizer or drill collar.

CENTRIFUGAL FORCE: That force when a ball is whirled on a string that pulls the ball outward. On a centrifugal pump, it is that force which throws water from a spinning impeller.

CENTRIFUGAL PUMP: A pump consisting of an impeller fixed on a rotating shaft and enclosed in a casing, having an inlet and a discharge connection. The rotating impeller creates pressure in the liquid by the velocity derived from centrifugal force.

CESIUM (also Caesium): Symbol Cs- A soft, silvery-white ductile metal, liquid at room temperature, the most electropositive and alkaline of the elements, used in photoelectric cells and to catalyze hydrogenation of some organic compounds.

CHAIN OF CUSTODY (COC): A record of each person involved in the possession of a sample from the person who collects the sample to the person who analyzes the sample in the laboratory.

CHAIN OF CUSTODY (COC): A record of each person involved in the possession of a sample from the person who collects the sample to the person who analyzes the sample in the laboratory.

CHECK VALVE: Allows water to flow in only one direction.

CHELATION: A chemical process used to control scale formation in which a chelating agent "captures" scale-causing ions and holds them in solution.

CHEMICAL FEED RATE: Chemicals are added to the water in order to improve the subsequent treatment processes. These may include pH adjusters and coagulants. Coagulants are chemicals, such as alum, that neutralize positive or negative charges on small particles, allowing them to stick together and form larger particles that are more easily removed by sedimentation (settling) or filtration. A variety of devices, such as baffles, static mixers, impellers and in-line sprays, can be used to mix the water and distribute the chemicals evenly.

CHEMICAL OXIDIZER: KMnO4 or Potassium Permanganate is used for taste and odor control because it is a strong oxidizer which eliminates many organic compounds.

CHEMICAL REATION RATE: In general, when the temperature decreases, the chemical reaction rate also decreases. The opposite is true for when the temperature increases.

CHEMISORPTION: (or chemical adsorption) Is adsorption in which the forces involved are valence forces of the same kind as those operating in the formation of chemical compounds.

CHLORAMINATION: Treating drinking water by applying chlorine before or after ammonia. This creates a persistent disinfectant residual called chloramines.

CHLORAMINES: A group of chlorine ammonia compounds formed when chlorine combines with organic wastes in the water. Chloramines are not effective as disinfectants and are responsible for eye and skin irritation as well as strong chlorine odors.

CHLORINATION: The process in water treatment of adding chlorine (gas or solid hypochlorite) for purposes of disinfection.

CHLORINE: A chemical used to disinfect water. Chlorine is extremely reactive, and when it comes in contact with microorganisms in water it kills them. Chlorine is added to swimming pools to keep the water safe for swimming. Chlorine is available as solid tablets for swimming pools. Some public water system's drinking water treatment plants use chlorine in a gas form because of the large volumes required. Chlorine is very effective against algae, bacteria and viruses. Protozoa are resistant to chlorine because they have thick coats; protozoa are removed from drinking water by filtration.

CHLORINE DEMAND: Amount of chlorine required to react on various water impurities before a residual is obtained. Also, means the amount of chlorine required to produce a free chlorine residual of 0.1 mg/l after a contact time of fifteen minutes as measured by iodmetic method of a sample at a temperature of twenty degrees in conformance with Standard methods.

CHLORINE FEED: Chlorine may be delivered by vacuum-controlled solution feed chlorinators. The chlorine gas is controlled, metered, introduced into a stream of injector water and then conducted as a solution to the point of application.

CHLORINE, **FREE**: Chlorine available to kill bacteria or algae. The amount of chlorine available for sanitization after the chlorine demand has been met. Also known as chlorine residual.

CIRCULATION: The continual flow of drilling fluid from injection to recovery and recirculation at the surface.

CLEAR WELL: A large underground storage facility sometimes made of concrete. A clear well or a plant storage reservoir is usually filled when demand is low. The final step in the conventional filtration process, the clearwell provides temporary storage for the treated water. The two main purposes for this storage are to have filtered water available for backwashing the filter and to provide detention time (or contact time) for the chlorine (or other disinfectant) to kill any microorganisms that may remain in the water.

CIO₂: The molecular formula of Chlorine dioxide.

COAGULATION: The best pH range for coagulation is between 5 and 7. Mixing is an important part of the coagulation process you want to complete the coagulation process as quickly as possible.

COBBLES: A rock smaller than a boulder but larger than a pebble. A cobble is greater than 2.5 inches in diameter and smaller than 10 inches in diameter.

COLIFORM: Bacteria normally found in the intestines of warm-blooded animals. Coliform bacteria are present in high numbers in animal feces. They are an indicator of potential contamination of water. Adequate and appropriate disinfection effectively destroys coliform bacteria. Public water systems are required to deliver safe and reliable drinking water to their customers 24 hours a day, 365 days a year. If the water supply becomes contaminated, consumers can become seriously ill. Fortunately, public water systems take many steps to ensure that the public has safe, reliable drinking water. One of the most important steps is to regularly test the water for coliform bacteria. Coliform bacteria are organisms that are present in the environment and in the feces of all warm-blooded animals and humans. Coliform bacteria will not likely cause illness. However, their presence in drinking water indicates that disease-causing organisms (pathogens) could be in the water system. Most pathogens that can contaminate water supplies come from the feces of humans or animals. Testing drinking water for all possible pathogens is complex, time-consuming, and expensive. It is relatively easy and inexpensive to test for coliform bacteria. If coliform bacteria are found in a water sample, water system operators work to find the source of contamination and restore safe drinking water. There are three different groups of coliform bacteria; each has a different level of risk.

COLIFORM TESTING: The effectiveness of disinfection is usually determined by Coliform bacteria testing. A positive sample is a bad thing and indicates that you have bacteria contamination.

COLLOIDAL SUSPENSIONS: Because both iron and manganese react with dissolved oxygen to form insoluble compounds, they are not found in high concentrations in waters containing dissolved oxygen except as colloidal suspensions of the oxide.

COLORIMETRIC MEASUREMENT: A means of measuring an unknown chemical concentration in water by measuring a sample's color intensity.

COMMUTATOR: A device for reversing the direction of a current. (in a DC motor or generator) a cylindrical ring or disk assembly of conducting members, individually insulated in a supporting structure with an exposed surface for contact with current-collecting brushes and mounted on the armature shaft, for changing the frequency or direction of the current in the armature windings.

CHRONIC: A stimulus that lingers or continues for a relatively long period of time, often one-tenth of the life span or more. Chronic should be considered a relative term depending on the life span of an organism. The measurement of chronic effect can be reduced growth, reduced reproduction, etc., in addition to lethality.

COMBINED CHLORINE: The reaction product of chlorine with ammonia or other pollutants, also known as chloramines.

COMMUNITY WATER SYSTEM: A water system which supplies drinking water to 25 or more of the same people year-round in their residences.

COMPLIANCE CYCLE: A 9-calendar year time-frame during which a public water system is required to monitor. Each compliance cycle consists of 3 compliance periods.

COMPLAINCE PERIOD: A 3-calendar year time-frame within a compliance cycle.

COMPLETION (WELL COMPLETION): Refers to the final construction of the well including the installation of pumping equipment.

COMPOSITE SAMPLE: A water sample that is a combination of a group of samples collected at various intervals during the day.

CONDENSATION: The process that changes water vapor to tiny droplets or ice crystals.

CONE OF DEPRESSION: That portion of the water table or potentiometric surface that experiences drawdown from a pumped well.

CONFINED AQUIFER: An aquifer that is isolated by confining layers on both its top and bottom. Pressures within a confined aquifer are normally greater than atmospheric pressure resulting in a potentiometric head.

CONFINING LAYER: An extensive layer of soil or formation that resists the movement of water from an aquifer below or above it. Confining layers isolate aquifers thereby confining them. May or may not be an aquiclude. (ex – Clay or silt rich layer)

CONSOLIDATED: Soil, sediment, or formation that is solidified or cemented together as a unit.

CONTACT TIME, pH and LOW TURBIDITY: Factors which are important in providing good disinfection using chlorine.

CONTACT TIME: If the water temperature decreases from 70°F (21°C) to 40°F (4°C). The operator needs to increase the detention time to maintain good disinfection of the water.

CONTAINS THE ELEMENT CARBON: A simple definition of an organic compound.

CONTAMINANT: Any natural or man-made physical, chemical, biological, or radiological substance or matter in water, which is at a level that may have an adverse effect on public health, and which is known or anticipated to occur in public water systems.

CONTAMINATE: tr.v. con·tam·i·nated, con·tam·i·nat·ing, con·tam·i·nates

- 1. To make impure or unclean by contact or mixture.
- 2. To expose to or permeate with radioactivity.

CONTAMINATION: A degradation in the quality of groundwater in result of the it's becoming polluted with unnatural or previously non-existent constituents.

CONTINUOUS SLOT SCREEN: A wire wrapped or plastic slotted screen in which the slot openings completely encircle the inner ribs of the screen.

CONTROL TASTE AND ODOR PROBLEMS: KMnO₄ Potassium permanganate is a strong oxidizer commonly used to control taste and odor problems.

CONVENTIONAL: A standard or common procedure to a group of more complex methods. (ex – Direct Rotary *conventional* vs. Reverse *non-conventional*)

COPPER: The chemical name for the symbol Cu.

CORROSION: The removal of metal from copper, other metal surfaces and concrete surfaces in a destructive manner. Corrosion is caused by improperly balanced water or excessive water velocity through piping or heat exchangers.

CORROSIVITY: The Langelier Index measures corrosivity.

COUPON: A coupon placed to measure corrosion damage in the water mains.

CROSS-CONNECTION: A physical connection between a public water system and any source of water or other substance that may lead to contamination of the water provided by the public water system through backflow. Might be the source of an organic substance causing taste and odor problems in a water distribution system.

CROSS-CONTAMINATION: The mixing of two unlike qualities of water. For example, the mixing of good water with a polluting substance like a chemical.

CUTTING HEAD (CUTTER HEAD): The bit portion of auger flighting that serves as the primary cutting edge of the auger.

CUTTING SHOE: A hardened steel sleeve with a wedged or armored cutting edge that is installed on well casing that is to be driven into the earth.

CUTTINGS: Crushed rock, soil, or formation material generated by the drilling action of a bit.

CRYPTOSPORIDIUM: A disease-causing parasite, resistant to chlorine disinfection. It may be found in fecal matter or contaminated drinking water. Cryptosporidium is a protozoan pathogen of the Phylum Apicomplexa and causes a diarrheal illness called cryptosporidiosis. Other apicomplexan pathogens include the malaria parasite Plasmodium, and Toxoplasma, the causative agent of toxoplasmosis. Unlike Plasmodium, which transmits via a mosquito vector, Cryptosporidium does not utilize an insect vector and is capable of completing its life cycle within a single host, resulting in cyst stages which are excreted in feces and are capable of transmission to a new host.

CYANURIC ACID: White, crystalline, water-soluble solid, C₃H₃O₃N₃·2H₂O, used chiefly in organic synthesis. Chemical used to prevent the decomposition of chlorine by ultraviolet (UV) light.

CYANOBACTERIA: Cyanobacteria, also known as blue-green algae, blue-green bacteria or Cyanophyta, is a phylum of bacteria that obtain their energy through photosynthesis. The name "cyanobacteria" comes from the color of the bacteria (Greek: kyanós = blue). They are a significant component of the marine nitrogen cycle and an important primary producer in many areas of the ocean, but are also found on land.

DAILY MAXIMUM LIMITATIONS: The maximum allowable discharge of pollutants during a 24 hour period. Where daily maximum limitations are expressed in units of mass, the daily discharge is the total mass discharged over the course of the day. Where daily maximum limitations are expressed in terms of a concentration, the daily discharge is the arithmetic average measurement of the pollutant concentration derived from all measurements taken that day.

DANGEROUS CHEMICALS: The most suitable protection when working with a chemical that produces dangerous fumes is to work under an air hood or fume hood.

DARCY'S LAW: (Q=KIA) A fundamental equation used in the groundwater sciences to determine aquifer characteristics, where Q=Flux, K=Hydraulic Conductivity (Permeability), I = Hydraulic Gradient (change in head), and A = Cross Sectional Area of flow.

DECIBELS: The unit of measurement for sound.

DECOMPOSE: To decay or rot.

DECOMPOSTION OF ORGANIC MATERIAL: The decomposition of organic material in water produces taste and odors.

DEMINERALIZATION PROCESS: Mineral concentration of the feed water is the most important consideration in the selection of a demineralization process. Acid feed is the most common method of scale control in a membrane demineralization treatment system.

DENTAL CARIES PREVENTION IN CHILDREN: The main reason that fluoride is added to a water supply.

DEPOLARIZATION: The removal of hydrogen from a cathode.

DESICCANT: When shutting down equipment which may be damaged by moisture, the unit may be protected by sealing it in a tight container. This container should contain a desiccant.

DESORPTION: Desorption is a phenomenon whereby a substance is released from or through a surface. The process is the opposite of sorption (that is, adsorption and absorption). This occurs in a system being in the state of sorption equilibrium between bulk phase (fluid, i.e. gas or liquid solution) and an adsorbing surface (solid or boundary separating two fluids). When the concentration (or pressure) of substance in the bulk phase is lowered, some of the sorbed substance changes to the bulk state. In chemistry, especially chromatography, desorption is the ability for a chemical to move with the mobile phase. The more a chemical desorbs, the less likely it will adsorb, thus instead of sticking to the stationary phase, the chemical moves up with the solvent front. In chemical

separation processes, stripping is also referred to as desorption as one component of a liquid stream moves by mass transfer into a vapor phase through the liquid-vapor interface.

DEVELOPMENT: The cleaning of the well and bore once construction is complete.

DETENTION LAG: Is the period of time between the moment of change in a chlorinator control system and the moment when the change is sensed by the chlorine residual indicator.

DETENTION LAG TIME: The minimum detention time range recommended for flocculation is 5-20 minutes for direct filtration and up to 30 minutes for conventional filtration.

DIATOMACEOUS EARTH: A fine silica material containing the skeletal remains of algae.

DIRECT CURRENT: A source of direct current (**DC**) may be used for standby lighting in a water treatment facility. The electrical current used in a DC system may come from a battery.

DIRECT ROTARY: The conventional method of rotary drilling involving the rotation of a drill string and standard use of drilling fluid to penetrate the earth.

DISCHARGE HEAD: See Total Dynamic Head.

DISINFECT: The application of a chemical to kill most, but not all, microorganisms that may be present. Chlorine is added to public water drinking systems drinking water for disinfection. Depending on your state rule, drinking water must contain a minimum of 0.2 mg/L free chlorine. Disinfection makes drinking water safe to consume from the standpoint of killing pathogenic microorganisms including bacteria and viruses. Disinfection does not remove all bacteria from drinking water, but the bacteria that can survive disinfection with chlorine are not pathogenic bacteria that can cause disease in normal healthy humans.

DISINFECTION: The treatment of water to inactivate, destroy, and/or remove pathogenic bacteria, viruses, protozoa, and other parasites.

DISINFECTION BY-PRODUCTS (DBPs): The products created due to the reaction of chlorine with organic materials (e.g. leaves, soil) present in raw water during the water treatment process. The EPA has determined that these DBPs can cause cancer. Chlorine is added to drinking water to kill or inactivate harmful organisms that cause various diseases. This process is called disinfection. However, chlorine is a very active substance and it reacts with naturally occurring substances to form compounds known as disinfection byproducts (DBPs). The most common DBPs formed when chlorine is used are trihalomethanes (THMs), and haloacetic acids (HAAs).

DISSOLVED OXYGEN: Can be added to zones within a lake or reservoir that would normally become anaerobic during periods of thermal stratification.

DISSOLUTION: The chemical and physical process of dissolving rock. Typically, limestone or carbonate rocks can be dissolved via the percolation or movement of groundwater that, in its infancy, is slightly acidic. As time goes on, the rock may also be physically worn away by the rapid movement of groundwater through the interconnected open spaces created by the initial chemical dissolving process.

DISTILLATION, REVERSE OSMOSIS AND FREEZING: Processes that can be used to remove minerals from the water.

DRAG BIT: A style of drill bit used in rotary drilling when soil or formation conditions are loosely consolidated and are comprised of fine-grained sediments.

DRAWDOWN: The change in water level from static to pumping level.

DRILL COLLAR: A section of the drill string that provides sufficient mass and diameter to maintain vertical borehole alignment and consistent borehole diameter.

DRILL FOAM: Surfactant used in air rotary drilling and well development.

DRILL PIPE: Sections of the drill string that are connected one to another in order to achieve a desired length while also providing a pathway for the circulation of drilling fluid.

DRILL STEM: The complete drill string or, in cable drilling, the equivalent of a drill collar.

DRILL STRING: The complete drilling assembly in rotary drilling including drill pipe, subs, collars, and bit.

DRILLER: A specially trained individual that operates the drilling rig.

DRILLING FLUID: Fluid circulated through the borehole in rotary drilling methods used to lift cuttings to the surface, provide borehole stability, and cool the bit. Drilling Fluid may consist of mud, water, air, foam, or other additives.

DRILLING PERMIT: A certificate of approval to drill and construct a well often required by the state or local regulating authority.

DRILLING PRESSURE: The pressure exerted within the borehole during drilling. The pressure required to circulate drilling fluid to the surface.

DRIVE BLOCK: A heavy collar that attaches over the drill pipe and is dropped successively to advance casing into the earth. Used primarily in cable tool or percussion drilling methods.

DRIVE CLAMP: A fitting that is attached to the top of a drill string or stem serving as a striking surface for driving casing into the earth.

DRIVE UNIT: The portion of a rotary rig that provides the rotation to the drill string. (ex – top drive or table drive unit). Also may be called the drive head.

DRIVING: The installation of a well or casing via forcing of it into the earth by repeated striking.

DRY ACID: A granular chemical used to lower pH and or total alkalinity.

E. COLI, Escherichia coli: A bacterium commonly found in the human intestine. For water quality analyses purposes, it is considered an indicator organism. These are considered evidence of water contamination. Indicator organisms may be accompanied by pathogens, but do not necessarily cause disease themselves.

EFFECTIVENESS OF CHLORINE: The factors which influence the effectiveness of chlorination the most are pH, turbidity and temperature. Effectiveness of Chlorine decreases occurs during disinfection in source water with excessive turbidity.

ELECTRON: The name of a negatively charged atomic particle.

ELEMENTARY BUSINESS PLAN: Technical Capacity, Managerial Capacity, and Financial Capacity make up the elementary business plan. To become a new public water system, an owner shall file an elementary business plan for review and approval by state environmental agency.

EMERGENCY RESPONSE TEAM: A local team that is thoroughly trained and equipped to deal with emergencies, e.g. chlorine gas leak. In case of a chlorine gas leak, get out of the area and notify your local emergency response team in case of a large uncontrolled chlorine leak.

ENHANCED COAGULATION: The process of joining together particles in water to help remove organic matter.

ENTAMOEBA HISTOLYTICA: Entamoeba histolytica, another water-borne pathogen, can cause diarrhea or a more serious invasive liver abscess. When in contact with human cells, these amoebae are cytotoxic. There is a rapid influx of calcium into the contacted cell, it quickly stops all membrane movement save for some surface blebbing. Internal organization is disrupted, organelles lyse, and the cell dies. The ameba may eat the dead cell or just absorb nutrients released from the cell.

ENTEROVIRUS: A virus whose presence may indicate contaminated water; a virus that may infect the gastrointestinal tract of humans.

EUGLENA: Euglena are common protists, of the class Euglenoidea of the phylum Euglenophyta. Currently, over 1000 species of Euglena have been described. Marin et al. (2003) revised the genus so and including several species without chloroplasts, formerly classified as Astasia and Khawkinea. Euglena sometimes can be considered to have both plant and animal features. Euglena gracilis has a long hair-like thing that stretches from its body. You need a very powerful microscope to see it. This is called a flagellum, and the euglena uses it to swim. It also has a red eyespot. Euglena gracilis uses its eyespot to locate light. Without light, it cannot use its chloroplasts to make itself food.

EVOLUTION: Any process of formation or growth; development: the evolution of a language; the evolution of the airplane. A product of such development; something evolved: The exploration of space is the evolution of decades of research.

Biology. Change in the gene pool of a population from generation to generation by such processes as mutation, natural selection, and genetic drift. A process of gradual, peaceful, progressive change or development, as in social or economic structure or institutions, a motion incomplete in itself, but combining with coordinated motions to produce a single action, as in a machine. A pattern formed by or as if by a series of movements: the evolutions of a figure skater.

An evolving or giving off of gas, heat, etc. **evolutional**, adjective ev·o·lu·tion·al·ly, adverb Synonyms 1. unfolding, change, progression, metamorphosis. Antonyms 1. stasis, inactivity, changelessness.

F: The chemical symbol of Fluorine.

FAUCET WITH AN AERATOR: When collecting a water sample from a distribution system, a faucet with an aerator should not be used as a sample location.

FAULT: A break in the earth's crust where movement has occurred.

FAULTING: A geological process involving the breaking and displacement of rock or formation through movements within the earth's crust along a fault.

FECAL COLIFORM: A group of bacteria that may indicate the presence of human or animal fecal matter in water. Total coliform, fecal coliform, and E. coli are all indicators of drinking water quality. The total coliform group is a large collection of different kinds of bacteria. Fecal coliforms are types of total coliform that mostly exist in feces. E. coli is a sub-group of fecal coliform. When a water sample is sent to a lab, it is tested for total coliform. If total coliform is present, the sample will also be tested for either fecal coliform or E. coli, depending on the lab testing method.

FILTRATION: The process of passing water through materials with very small holes to strain out particles. Most conventional water treatment plants used filters composed of gravel, sand, and anthracite. These materials settle into a compact mass that forms very small holes. Particles are filtered out as treated water passes through these holes. These holes are small enough to remove microorganisms including algae, bacteria, and protozoans, but not viruses. Viruses are eliminated from drinking water through the process of disinfection using chlorine. A series of processes that physically removes particles from water. A water treatment step used to remove turbidity, dissolved organics, odor, taste and color.

FILTER CLOGGING: An inability to meet demand may occur when filters are clogging.

FILTRATION METHODS: The conventional type of water treatment filtration method includes coagulation, flocculation, sedimentation, and filtration. Direct filtration method is similar to conventional except that the sedimentation step is omitted. Slow sand filtration process does not require pretreatment, has a flow of 0.1 gallons per minute per square foot of filter surface area, and is simple to operate and maintain. The Diatomaceous earth method uses a thin layer of fine siliceous material on a porous plate. This type of filtration medium is only used for water with low turbidity. Sedimentation, adsorption, and biological action treatment methods are filtration processes that involve a number of interrelated removal mechanisms. Demineralization is primarily used to remove total dissolved solids from industrial wastewater, municipal water, and seawater.

FINISHED WATER: Treated drinking water that meets minimum state and federal drinking water regulations.

FLIGHTING: The spiral flanged drill pipe used in auger drilling.

FLOATING SUB: A collapsible section of drill pipe shorter than primary drill pipe. Used to provide a cushion between the drive unit and the drill string.

FLOCCULATION: The process of bringing together destabilized or coagulated particles to form larger masses that can be settled and/or filtered out of the water being treated. Conventional coagulation–flocculation-sedimentation practices are essential pretreatments for many water purification systems—especially filtration treatments. These processes agglomerate suspended solids together into larger bodies so that physical filtration processes can more easily remove them. Particulate removal by these methods makes later filtering processes far more effective. The process is often followed by gravity separation (sedimentation or flotation) and is always followed by filtration. A chemical coagulant, such as iron salts, aluminum salts, or polymers, is added to source water to facilitate bonding among particulates. Coagulants work by creating a chemical reaction and eliminating the negative charges that cause particles to repel each other. The coagulant-source water mixture is then slowly stirred in a process known as flocculation. This water churning induces particles to collide and clump together into larger and more easily removable clots, or "flocs." The process requires chemical knowledge of source water characteristics to ensure that an effective coagulant mix is employed. Improper coagulants make these treatment methods ineffective. The ultimate effectiveness of coagulation/flocculation is also determined by the efficiency of the filtering process with which it is paired.

FLOCCULANTS: Flocculants, or flocculating agents, are chemicals that promote flocculation by causing colloids and other suspended particles in liquids to aggregate, forming a floc. Flocculants are used in water treatment processes to improve the sedimentation or filterability of small particles. For example, a flocculant may be used in swimming pool or drinking water filtration to aid removal of microscopic particles which would otherwise cause the water to be cloudy and which would be difficult or impossible to remove by filtration alone. Many flocculants are multivalent cations such as aluminum, iron, calcium or magnesium. These positively charged molecules interact with negatively charged particles and molecules to reduce the barriers to aggregation. In addition, many of these chemicals, under appropriate pH and other conditions such as temperature and salinity, react with water to form insoluble hydroxides which, upon precipitating, link together to form long chains or meshes, physically trapping small particles into the larger floc.

Long-chain polymer flocculants, such as modified polyacrylamides, are manufactured and sold by the flocculant producing business. These can be supplied in dry or liquid form for use in the flocculation process. The most common liquid polyacrylamide is supplied as an emulsion with 10-40 % actives and the rest is a carrier fluid, surfactants and latex. Emulsion polymers require activation to invert the emulsion and allow the electrolyte groups to be exposed.

FLOC SHEARING: Likely to happen to large floc particles when they reach the flocculation process.

FLOCCULATION BASIN: A compartmentalized basin with a reduction of speed in each compartment. This setup or basin will give the best overall results.

FLOOD RIM: The point of an object where the water would run over the edge of something and begin to cause a flood.

FLOW MUST BE MEASURED: A recorder that measures flow is most likely to be located in a central location.

FLUORIDE: High levels of fluoride may stain the teeth of humans. This is called Mottling. This chemical must not be overfed due to a possible exposure to a high concentration of the chemical. The most important safety considerations to know about fluoride chemicals are that all fluoride chemicals are extremely corrosive. These are the substances most commonly used to furnish fluoride ions to water: Sodium fluoride, Sodium silicofluoride and Hydrofluosilicic acid.

FLUORIDE FEEDING: Always review fluoride feeding system designs and specifications to determine whether locations for monitoring readouts and dosage controls are convenient to the operation center and easy to read and correct.

FLUX: The term flux describes the rate of water flow through a semipermeable membrane. When the water flux decreases through a semipermeable membrane, it means that the mineral concentration of the water is increasing.

FORMATION: A series of layers, deposits, or bodies of rock, which are geologically similar and related in depositional environment or origin. A formation can be clearly distinguished relative to bounding deposits or formations due to its particular characteristics and composition.

FORMATION OF TUBERCLES: This condition is of the most concern regarding corrosive water effects on a water system. It is the creation of mounds of rust inside the water lines.

FRACTURE: A discrete break in a rock or formation.

FRACTURED AQUIFER: An aquifer within and otherwise massive block that has been made permeable due to the concentrated presence of fractures typically resultant of faulting or concentrated joints.

FREE CHLORINE: In disinfection, chlorine is used in the form of free chlorine or as hypochlorite ion.

FREE CHLORINE RESIDUAL: Regardless of whether pre-chloration is practiced or not, a free chlorine residual of at least 10 mg/L should be maintained in the clear well or distribution reservoir immediately downstream from the point of post-chlorination. The reason for chlorinating past the breakpoint is to provide protection in case of backflow.

GATE VALVE: The most common type of valve used in isolating a small or medium sized section of a distribution system and is the only linear valve used in water distribution. All the other valves are in the rotary classification.

GIARDIA LAMLIA: Giardia lamblia (synonymous with Lamblia intestinalis and Giardia duodenalis) is a flagellated protozoan parasite that colonizes and reproduces in the small intestine, causing giardiasis. The giardia parasite attaches to the epithelium by a ventral adhesive disc, and reproduces via binary fission. Giardiasis does not spread via the bloodstream, nor does it spread to other parts of the gastro-intestinal tract, but remains confined to the lumen of the small intestine. Giardia trophozoites absorb their nutrients from the lumen of the small intestine, and are anaerobes.

GIARDIASAS, **HEPATITIS OR TYHOID**: Diseases that may be transmitted through the contamination of a water supply but not AIDS.

GIS – GRAPHIC INFORMATION SYSTEM: Detailed information about the physical locations of structures such as pipes, valves, and manholes within geographic areas with the use of satellites.

GEOTECHNICAL: Characteristics of soil, rock, or formation such as grain size, shear strength, porosity, and compressibility, etc. Of particular concern to a geologist or engineer relative to soil or aquifer characteristics.

GLOBE VAVLVE: The main difference between a globe valve and a gate valve is that a globe valve is designed as a controlling device.

GOOD CONTACT TIME, pH and LOW TURBIDITY: These are factors that are important in providing good disinfection when using chlorine.

GPM: Gallons per minute.

GRAB SAMPLE: A sample which is taken from a water or wastestream on a one-time basis with no regard to the flow of the water or wastestream and without consideration of time. A single grab sample should be taken over a period of time not to exceed 15 minutes.

GRAINSIZE: The dimension of particle classifications such as gravel, sand, silt, and clay. Often based on the unified soil classification system.

GROUNDWATER: Water that percolates through and exists within saturated portions of the earth's crust and is replenished by the hydrologic cycle.

GROUT: A type of cement that is normally fine grained and used to effectively construct well seals and used in well abandonment. Grout may also be used to stabilize otherwise unstable boreholes, permitting continued drilling.

GT: Represents (Detention time) x (mixing intensity) in flocculation.

H₂SO₄: The molecular formula of Sulfuric acid.

HALIDES: A halide is a binary compound, of which one part is a halogen atom and the other part is an element or radical that is less electronegative than the halogen, to make a fluoride, chloride, bromide, iodide, or astatide compound. Many salts are halides. All Group 1 metals form halides with the halogens and they are white solids. A halide ion is a halogen atom bearing a negative charge. The halide anions are fluoride (F), chloride (Cl), bromide (Br), iodide (I) and astatide (At). Such ions are present in all ionic halide salts.

HALL EFFECT: Refers to the potential difference (Hall voltage) on the opposite sides of an electrical conductor through which an electric current is flowing, created by a magnetic field applied perpendicular to the current. Edwin Hall discovered this effect in 1879.

HALOACETIC ACIDS: Haloacetic acids are carboxylic acids in which a halogen atom takes the place of a hydrogen atom in acetic acid. Thus, in a monohaloacetic acid, a single halogen would replace a hydrogen atom. For example, chloroacetic acid would have the structural formula CH₂CICO₂H. In the same manner, in dichloroacetic acid two chlorine atoms would take the place of two hydrogen atoms (CHCl₂CO₂H).

HAMMER BIT: The bit driven by the hammer to cut into rock or formation.

HAMMER: See Air Hammer

HARD ROCK: Consolidated formation or solid rock.

HARD WATER: Hard water causes a buildup of scale in household hot water heaters. Hard water is a type of water that has high mineral content (in contrast with soft water). Hard water primarily consists of calcium (Ca2+), and magnesium (Mg2+) metal cations, and sometimes other dissolved compounds such as bicarbonates and sulfates. Calcium usually enters the water as either calcium carbonate (CaCO₃), in the form of limestone and chalk, or calcium sulfate (CaSO₄), in the form of other mineral deposits. The predominant source of magnesium is dolomite (CaMg(CO₃)2). Hard water is generally not harmful. The simplest way to determine the hardness of water is the lather/froth test: soap or toothpaste, when agitated, lathers easily in soft water but not in hard water. More exact measurements of hardness can be obtained through a wet titration. The total water 'hardness' (including both Ca2+ and Mg2+ ions) is read as parts per million or weight/volume (mg/L) of calcium carbonate (CaCO₃) in the water. Although water hardness usually only measures the total concentrations of calcium and magnesium (the two most prevalent, divalent metal ions), iron, aluminum, and manganese may also be present at elevated levels in some geographical locations.

HARDNESS: A measure of the amount of calcium and magnesium salts in water. More calcium and magnesium lead to greater hardness. The term "hardness" comes from the fact that it is hard to get soap suds from soap or detergents in hard water. This happens because calcium and magnesium react strongly with negatively-charged chemicals like soap to form insoluble compounds.

HARTSHORN: The antler of a hart, formerly used as a source of ammonia. Ammonium carbonate.

HAZARDS OF POLYMERS: Slippery and difficult to clean-up are the most common hazards associated with the use of polymers in a water treatment plant.

HEAD: The measure of the pressure of water expressed in feet of height of water. 1 PSI = 2.31 feet of water or 1 foot of head equals about a half a pound of pressure or .433 PSI. There are various types of heads of water depending upon what is being measured. Static (water at rest) and Residual (water at flow conditions).

HEADWORKS: The facility at the "head" of the water source where water is first treated and routed into the distribution system.

HEALTH ADVISORY: An EPA document that provides guidance and information on contaminants that can affect human health and that may occur in drinking water, but which the EPA does not currently regulate in drinking water.

HERTZ: The term used to describe the frequency of cycles in an alternating current (AC) circuit.

HETEROTROPHIC PLATE COUNT: A test performed on drinking water to determine the total number of all types of bacteria in the water.

HF: The molecular formula of Hydrofluoric acid.

HIGH TURBIDITY CAUSING INCREASED CHLORINE DEMAND: May occur or be caused by the inadequate disinfection of water.

HOLLOW STEM (AUGER): An auger form of drilling in which the flighting is hollow.

HOLLOW STEM FLIGHT: The hollow spiral flanged drill pipe used on hollow stem auger rigs.

HOMOPOLAR: Of uniform polarity; not separated or changed into ions; not polar in activity. Electricity. unipolar.

HYDRAULIC CONDUCTIVITY: A primary factor in Darcy's Law, the measure of a soil or formations ability to transmit water, measured in gallons per day (gpd) See also Permeability and Darcy's Law.

HYDRIDES: Hydride is the name given to the negative ion of hydrogen, H. Although this ion does not exist except in extraordinary conditions, the term hydride is widely applied to describe compounds of hydrogen with other elements, particularly those of groups 1–16. The variety of compounds formed by hydrogen is vast, arguably greater than that of any other element. Various metal hydrides are currently being studied for use as a means of hydrogen storage in fuel cell-powered electric cars and batteries. They also have important uses in organic chemistry as powerful reducing agents, and many promising uses in hydrogen economy.

HYDROCHLORIC AND HYPOCHLOROUS ACIDS: HCL and HOCL The compounds that are formed in water when chlorine gas is introduced.

HYDROFLUOSILIC ACID: (H_2SiF_6) a clear, fuming corrosive liquid with a pH ranging from 1 to 1.5. Used in water treatment to fluoridate drinking water.

HYDROGEN SULFIDE OR CHLORINE GAS: These chemicals can cause olfactory fatigue.

HYDROLOGIC CYCLE: (Water Cycle) The continual process of precipitation (rain and snowfall), evaporation (primarily from the oceans), peculation (recharge to groundwater), runoff (surface water), and transpiration (plants) constituting the renew ability and recycling of each component.

HYDROPHOBIC: Does not mix readily with water.

HYGROSCOPIC: Absorbing or attracting moisture from the air.

HYPOCHLORITE (OCL-) AND ORGANIC MATERIALS: Heat and possibly fire may occur when hypochlorite is brought into contact with an organic material.

HYPOLIMNION: The layer of water in a thermally stratified lake that lies below the thermocline, is noncirculating, and remains perpetually cold.

IMPELLERS: The semi-open or closed props or blades of a turbine pump that when rotated generate the pumping force.

IMPERVIOUS: Not allowing, or allowing only with great difficulty, the movement of water.

IN SERIES: Several components being connected one to the other without a bypass, requiring each component to work dependent on the one before it.

INFILTRATION: The percolation of fluid into soil or formation. See also percolation.

INFECTIOUS PATHOGENS/MICROBES/GERMS: Are considered disease-producing bacteria, viruses and other microorganisms.

INFLATABLE PACKER: A rubber or fiber bladder device that is inflated to seal against either casing or borehole walls.

INFORMATION COLLECTION RULE: ICR EPA collected data required by the Information Collection Rule (May 14, 1996) to support future regulation of microbial contaminants, disinfectants, and disinfection byproducts. The rule was intended to provide EPA with information on chemical byproducts that form when disinfectants used for microbial control react with chemicals already present in source water (disinfection byproducts (DBPs)); disease-causing microorganisms (pathogens), including Cryptosporidium; and engineering data to control these contaminants.

INITIAL MONITORING YEAR: An initial monitoring year is the calendar year designated by the Department within a compliance period in which a public water system conducts initial monitoring at a point of entry.

INORGANIC CONTAMINANTS: Mineral-based compounds such as metals, nitrates, and asbestos. These contaminants are naturally-occurring in some water, but can also get into water through farming, chemical manufacturing, and other human activities. EPA has set legal limits on 15 inorganic contaminants.

INORGANIC IONS: Present in all waters. Inorganic ions are essential for human health in small quantities, but in larger quantities they can cause unpleasant taste and odor or even illness. Most community water systems will commonly test for the concentrations of seven inorganic ions: nitrate, nitrite, fluoride, phosphate, sulfate, chloride, and bromide. Nitrate and nitrite can cause an illness in infants called methemoglobinemia. Fluoride is actually added to the drinking water in some public water systems to promote dental health. Phosphate, sulfate, chloride, and bromide have little direct effect on health, but high concentrations of inorganic ions can give water a salty or briny taste.

INSOLUBLE COMPOUNDS: Are types of compounds cannot be dissolved. When iron or manganese reacts with dissolved oxygen (DO) insoluble compound are formed.

INTAKE FACILITIES: One of the more important considerations in the construction of intake facilities is the ease of operation and maintenance over the expected lifetime of the facility. Every intake structure must be constructed with consideration for operator safety and for cathodic protection.

ION EXCHANGE: An effective treatment process used to remove iron and manganese in a water supply. The hardness of the source water affects the amount of water an ion exchange softener may treat before the bed requires regeneration.

IRON: Fe The elements iron and manganese are undesirable in water because they cause stains and promote the growth of iron bacteria.

IRON AND MANGANESE: Fe and Mn In water they can usually be detected by observing the color of the inside walls of filters and the filter media. If the raw water is pre-chlorinated, there will be black stains on the walls below the water level and a black coating over the top portion of the sand filter bed. When significant levels of dissolved oxygen are present, iron and manganese exist in an oxidized state and normally precipitate into the reservoir bottom sediments. The presence of iron and manganese in water promote the growth of Iron bacteria. Only when a water sample has been acidified then you can perform the analysis beyond the 48 hour holding time. Iron and Manganese in water may be detected by observing the color of the of the filter media. Maintaining a free chlorine residual and regular flushing of water mains may control the growth of iron bacteria in a water distribution system.

IRON BACTERIA: Perhaps the most troublesome consequence of iron and manganese in the water is they promote the growth of a group of microorganism known as Iron Bacteria.

IRON FOULING: You should look for an orange color on the resin and backwash water when checking an ion exchange unit for iron fouling

JARS (DRILLING JARS): Metal sections of a drill string that when released provide a jarring force or action to aid in removing drill string. Used primarily in cable tool or percussion drilling methods.

JETTING: The process of injecting high velocity streams of water and/or air through a system of nozzles or jets into the well screen and filter pack for well development.

KARST TOPOGRAPHY: The visual presence of karst on the surface.

KARST: The presence of caverns, voids, sink holes as characteristic features of a weathered limestone or other carbonate formation on or beneath the surface.

KELLY: A multi-faceted section of drill pipe driven by a kelly drive (table or top drive).

KILL = C X T: Where other factors are constant, the disinfecting action may be represented by: Kill=C x T. C= Chlorine T= Contact time.

KINETIC ENERGY: The ability of an object to do work by virtue of its motion. The energy terms that are used to describe the operation of a pump are pressure and head.

LACRIMATION: The secretion of tears, esp. in abnormal abundance Also, lachrymation, lachrimation.

LANGELIER INDEX: A measurement of Corrosivity. The water is becoming corrosive in the distribution system causing rusty water if the Langelier index indicates that the pH has decreased from the equilibrium point. Mathematically derived factor obtained from the values of calcium hardness, total alkalinity, and pH at a given temperature. A Langelier index of zero indicates perfect water balance (i.e., neither corroding nor scaling). The Langelier Saturation Index (sometimes Langelier Stability Index) is a calculated number used to predict the calcium carbonate stability of water. It indicates whether the water will precipitate, dissolve, or be in equilibrium with calcium carbonate. Langelier developed a method for predicting the pH at which water is saturated in calcium carbonate (called pHs). The LSI is expressed as the difference between the actual system pH and the saturation pH.

LSI = pH - pHs

LEACHING: A chemical reaction between water and metals that allows for removal of soluble materials.

LEAD AND COPPER: Initial tap water monitoring for lead and copper must be conducted during 2 consecutive 6-month periods.

LIME: Is a chemical that may be added to water to reduce the corrosivity. When an operator adds lime to water, Calcium and magnesium become less soluble.

LIME SODA SOFTENING: In a lime soda softening process, to the pH of the water is raised to 11.0. In a lime softening process, excess lime is frequently added to remove Calcium and Magnesium Bicarbonate. The minimum hardness which can be achieved by the lime-soda ash process is 30 to 40 mg/L as calcium carbonate. The hardness due to noncarbonate hardness is most likely to determine the choice between lime softening and ion exchange to remove hardness.

LIME SOFTENING: Lime softening is primarily used to "soften" water—that is to remove calcium and magnesium mineral salts. But it also removes harmful toxins like radon and arsenic. Though there is no consensus, some studies have even suggested that lime softening is effective at removal of Giardia. Hard water is a common condition responsible for numerous problems. Users often recognize hard water because it prevents their soap from lathering properly. However, it can also cause buildup ("scale") in hot water heaters, boilers, and hot water pipes. Because of these inconveniences, many treatment facilities use lime softening to soften hard water for consumer use. Before lime softening can be used, managers must determine the softening chemistry required. This is a relatively easy task for groundwater sources, which remain more constant in their composition. Surface waters, however, fluctuate widely in quality and may require frequent changes to the softening chemical mix. In lime softening, lime and sometimes sodium carbonate are added to the water as it enters a combination solids contact clarifier. This raises the pH (i.e., increases alkalinity) and leads to the precipitation of calcium carbonate. Later, the pH of the effluent from the clarifier is reduced again, and the water is then filtered through a granular media filter. The water chemistry requirements of these systems require knowledgeable operators, which may make lime softening an economic challenge for some very small systems.

LINE SHAFT TURBINE: See vertical turbine.

LOGGED (LOGGING): The assessment and documentation of geological and water production data obtained while drilling progresses or following drilling through the use of borehole geophysical logging tools.

L.O.T.O.: Lock Out, Tag Out. If a piece of equipment is locked out, the key to the lock-out device the key should be held by the person who is working on the equipment. The tag is an identification device and the lock is a physical restraint.

M-ENDO BROTH: The coliform group is used as indicators of fecal pollution in water, for assessing the effectiveness of water treatment and disinfection, and for monitoring water quality. m-Endo Broth is used for selectively isolating coliform bacteria from water and other specimens using the membrane filtration technique. m-Endo Broth is prepared according to the formula of Fifield and Schaufus.1 It is recommended by the American Public Health Association in standard total coliform membrane filtration procedure for testing water, wastewater, and foods.2,3 The US EPA specifies using m-Endo Broth in the total coliform methods for testing water using single-step, two-step, and delayed incubation membrane filtration methods.

MAGNESIUM HARDNESS: Measure of the magnesium salts dissolved in water – it is not a factor in water balance.

MAGNETIC STARTER: Is a type of motor starter should be used in an integrated circuit to control flow automatically.

MARBLE AND LANGELIER TESTS: Are used to measure or determine the corrosiveness of a water source.

MAXIMUM CONTAMINANT LEVEL (MCLs): The maximum allowable level of a contaminant that federal or state regulations allow in a public water system. If the MCL is exceeded, the water system must treat the water so that it meets the MCL.

MAXIMUM CONTAMINANT LEVEL GOAL (MCLG): The level of a contaminant at which there would be no risk to human health. This goal is not always economically or technologically feasible, and the goal is not legally enforceable.

MCL for **TURBIDITY**: Turbidity is undesirable because it causes health hazards. An MCL for turbidity was established by the EPA because turbidity does not allow for proper disinfection.

MEASURE CORROSION DAMAGE: A coupon such as a strip of metal and is placed to measure corrosion damage in the distribution system in a water main.

MECHANICAL SEAL: A mechanical device used to control leakage from the stuffing box of a pump. Usually made of two flat surfaces, one of which rotates on the shaft. The two flat surfaces are of such tolerances as to prevent the passage of water between them. Held in place with spring pressure.

MEDIUM WATER SYSTEM: More than 3,300 persons and 50,000 or fewer persons.

MEGGER: Is a portable instrument used to measure insulation resistance. The megger consists of a hand-driven DC generator and a direct reading ohm meter. Used to test the insulation resistance on a motor.

M-ENDO BROTH: The media shall be brought to the boiling point when preparing M-Endo broth to be used in the membrane filter test for total coliform.

METALIMNION: Thermocline, middle layer of a thermally stratified lake which is characterized by a rapid decrease in temperature in proportion to depth.

METALLOID: Metalloid is a term used in chemistry when classifying the chemical elements. On the basis of their general physical and chemical properties, nearly every element in the periodic table can be termed either a metal or a nonmetal. A few elements with intermediate properties are, however, referred to as metalloids. (In Greek metallon = metal and eidos = sort)

METHANE: Methane is a chemical compound with the molecular formula CH₄. It is the simplest alkane, and the principal component of natural gas. Methane's bond angles are 109.5 degrees. Burning methane in the presence of oxygen produces carbon dioxide and water. The relative abundance of methane and its clean burning process makes it a very attractive fuel. However, because it is a gas at normal temperature and pressure, methane is difficult to transport from its source. In its natural gas form, it is generally transported in bulk by pipeline or LNG carriers; few countries still transport it by truck.

MILLILITER: One one-thousandth of a liter; A liter is a little more than a quart. A milliliter is about two drops from an eye dropper.

Mg/L: Stands for "milligrams per liter." A common unit of chemical concentration. It expresses the mass of a chemical that is present in a given volume of water. A milligram (one one-thousandth of a gram) is equivalent to about 18 grains of table salt. A liter is equivalent to about one quart.

MICROBIOLOGICAL: Is a type of analysis in which a composite sample unacceptable.

MICROBE OR MICROBIAL: Any minute, simple, single-celled form of life, especially one that causes disease.

MICROBIAL CONTAMINANTS: Microscopic organisms present in untreated water that can cause waterborne diseases.

MICROORGANISMS: Very small animals and plants that are too small to be seen by the naked eye and must be observed using a microscope. Microorganisms in water include algae, bacteria, viruses, and protozoa. Algae growing in surface waters can cause off-taste and odor by producing the chemicals MIB and geosmin. Certain types of bacteria, viruses, and protozoa can cause disease in humans. Bacteria are the most common microorganisms found in treated drinking water. The great majority of bacteria are not harmful. In fact, humans would not be able to live without the bacteria that inhabit the intestines. However, certain types of bacteria called coliform bacteria can signal the presence of possible drinking water contamination.

MILLILITER: One one-thousandth of a liter. A liter is a little more than a quart. A milliliter is about two drops from an eye dropper.

MOISTURE: If a material is hygroscopic, it must it be protected from water.

MOISTURE AND POTASSIUM PERMANGANATE: The combination of moisture and potassium permanganate produces heat.

MOLECULAR WEIGHT: The molecular mass (abbreviated Mr) of a substance, formerly also called molecular weight and abbreviated as MW, is the mass of one molecule of that substance, relative to the unified atomic mass unit u (equal to 1/12 the mass of one atom of carbon-12). This is distinct from the relative molecular mass of a molecule, which is the ratio of the mass of that molecule to 1/12 of the mass of carbon 12 and is a dimensionless number. Relative molecular mass is abbreviated to Mr.

MOTTLING: High levels of fluoride may stain the teeth of humans.

M.S.D.S.: Material Safety Data Sheet. A safety document must an employer provide to an operator upon request.

MUD BALLS IN FILTER MEDIA: Is a possible result of an ineffective or inadequate filter backwash.

MUD CAKE: A film of mud drilling fluid that builds up on borehole walls adding to borehole stability and limits the groundwater's ability to enter the borehole while drilling.

MUD CAKING: The process of building up the mud cake.

MUD ENGINEER: A specially trained individual who's responsible for maintaining proper drilling fluid densities and viscosity.

MUD PIT: Single or multiple subsurface or surface containment system used for settling cuttings out of drilling fluid and for recirculation of drilling fluid.

MUD PUMP: A specially designed pump that can pass particles of mud and cuttings (drilling fluid) at variable pressures, serving as the primary component in a mud rotary drilling system (similar to a grout or cement pump).

MUD ROTARY: The method of rotary drilling with mud circulation as the drilling fluid.

MURIATIC ACID: An acid used to reduce pH and alkalinity. Also used to remove stain and scale.

MYCOTOXIN: A toxin produced by a fungus.

NaOCI: Is the molecular formula of Sodium hypochlorite.

NaOH: Is the molecular formula of Sodium hydroxide.

NASCENT: Coming into existence; emerging.

NATURAL GRAVEL PACK (NATURALLY PACKED): Refers to a well that has no gravel pack installed but is simply allowed to develop a filter pack composed of the aquifer particles itself. Usually coarse grained and hard rock aquifers are naturally packed.

NH₃: The molecular formula of Ammonia.

NH₄+: The molecular formula of the Ammonium ion.

NITRATES: A dissolved form of nitrogen found in fertilizers and sewage by-products that may leach into groundwater and other water sources. Nitrates may also occur naturally in some waters. Over time, nitrates can accumulate in aquifers and contaminate groundwater.

NITROGEN: Nitrogen is a nonmetal, with an electronegativity of 3.0. It has five electrons in its outer shell and is therefore trivalent in most compounds. The triple bond in molecular nitrogen (N_2) is one of the strongest in nature. The resulting difficulty of converting (N_2) into other compounds, and the ease (and associated high energy release) of converting nitrogen compounds into elemental N_2 , have dominated the role of nitrogen in both nature and human economic activities.

NITROGEN AND PHOSPHORUS: Pairs of elements and major plant nutrients that cause algae to grow.

NO₃: The molecular formula of the Nitrate ion.

NON-CARBONATE HARDNESS: The portion of the total hardness in excess of the alkalinity.

NON-CARBONATE IONS: Water contains non-carbonate ions if it cannot be softened to a desired level through the use of lime only.

NON-POINT SOURCE POLLUTION: Air pollution may leave contaminants on highway surfaces. This non-point source pollution adversely impacts reservoir water and groundwater quality.

NON-TRANSIENT, NON-COMMUNITY WATER SYSTEM: A water system which supplies water to 25 or more of the same people at least six months per year in places other than their residences. Some examples are schools, factories, office buildings, and hospitals which have their own water systems.

NORMALITY: It is the number of equivalent weights of solute per liter of solution. Normality highlights the chemical nature of salts: in solution, salts dissociate into distinct reactive species (ions such as H^{+} , Fe_{3}^{+} , or $C\Gamma$). Normality accounts for any discrepancy between the concentrations of the various ionic species in a solution. For example, in a salt such as $MgCl_2$, there are two moles of $C\Gamma$ for every mole of Mg_2^{+} , so the concentration of Cl-as well as of Mg_2^{+} is said to be 2 N (read: "two normal"). Further examples are given below. A normal is one gram equivalent of a solute per liter of solution. The definition of a gram equivalent varies depending on the type of chemical reaction that is discussed - it can refer to acids, bases, redox species, and ions that will precipitate. It is critical to note that normality measures a single ion which takes part in an overall solute. For example, one could determine the normality of hydroxide or sodium in an aqueous solution of sodium hydroxide, but the normality of sodium hydroxide itself has no meaning. Nevertheless it is often used to describe solutions of acids or bases, in those cases it is implied that the normality refers to the H+ or OH- ion. For example, 2 Normal sulfuric acid (H_2SO_4), means that the normality of H+ ions is 2, or that the molarity of the sulfuric acid is 1. Similarly for 1 Molar H_3PO_4 the normality is 3 as it contains three H+ ions.

NTNCWS: Non-transient non-community water system.

NTU (Nephelometric turbidity unit): A measure of the clarity or cloudiness of water.

O₃: The molecular formula of ozone.

OIL TUBE: A tubular enclosure that houses the line shaft and bearings of a vertical turbine pump. Oil is allowed to pass through the oil tube in order to lubricate the pumps drive shaft and bearings.

OLIGOTROPHIC: A reservoir that is nutrient-poor and contains little plant or animal life. An oligotrophic ecosystem or environment is one that offers little to sustain life. The term is commonly utilized to describe bodies of water or soils with very low nutrient levels. It derives etymologically from the Greek oligo (small, little, few) and trophe (nutrients, food). Oligotrophic environments are of special interest for the alternative energy sources and survival strategies upon which life could rely.

ORGANIC PRESURSORS: Natural or man-made compounds with chemical structures based upon carbon that, upon combination with chlorine, leading to trihalomethane formation.

OSMOSIS: Osmosis is the process by which water moves across a semi permeable membrane from a low concentration solute to a high concentration solute to satisfy the pressure differences caused by the solute.

OVERBURDEN: Normally a thin loosely consolidated or unconsolidated sediment overlying competent formation.

OVER-RANGE PROTECTION DEVICES: Mechanical dampers, snubbers and an air cushion chamber are examples of surging and overrange protection devices.

OXIDE: An oxide is a chemical compound containing at least one oxygen atom as well as at least one other element. Most of the Earth's crust consists of oxides. Oxides result when elements are oxidized by oxygen in air. Combustion of hydrocarbons affords the two principal oxides of carbon, carbon monoxide and carbon dioxide. Even materials that are considered to be pure elements often contain a coating of oxides. For example, aluminum foil has a thin skin of Al_2O_3 that protects the foil from further corrosion.

OXIDIZED:

- 1. to convert (an element) into an oxide; combine with oxygen.
- 2. to cover with a coating of oxide or rust.
- 3. to take away hydrogen, as by the action of oxygen; add oxygen or any nonmetal.
- 4. to remove electrons from (an atom or molecule), thereby increasing the valence. Compare REDUCE (def. 12). –verb (used without object)
- 5. to become oxidized.

OXIDIZING: The process of breaking down organic wastes into simpler elemental forms or by products. Also used to separate combined chlorine and convert it into free chlorine.

OXYGEN DEFICIENT ENVIRONMENT: One of the most dangerous threats to an operator upon entering a manhole.

OZONE: Ozone or trioxygen (O_3) is a triatomic molecule, consisting of three oxygen atoms. It is an allotrope of oxygen that is much less stable than the diatomic O_2 . Ground-level ozone is an air pollutant with harmful effects on the respiratory systems of animals. Ozone in the upper atmosphere filters potentially damaging ultraviolet light from reaching the Earth's surface. It is present in low concentrations throughout the Earth's atmosphere. It has many industrial and consumer applications. Ozone, the first allotrope of a chemical element to be recognized by science, was proposed as a distinct chemical compound by Christian Friedrich Schönbein in 1840, who named it after the Greek word for smell (ozein), from the peculiar odor in lightning storms. The formula for ozone, O_3 , was not determined until 1865 by Jacques-Louis Soret and confirmed by Schönbein in 1867. Ozone is a powerful oxidizing agent, far better than dioxygen. It is also unstable at high concentrations, decaying to ordinary diatomic oxygen (in about half an hour in atmospheric conditions): $O_3 = O_3 = O_3$

This reaction proceeds more rapidly with increasing temperature and decreasing pressure. Deflagration of ozone can be triggered by a spark, and can occur in ozone concentrations of 10 wt% or higher.

OZONE DOES NOT PROVIDE A RESIDUAL: One of the major drawbacks to using ozone as a disinfectant.

OZONE, CHLORINE DIOXIDE, UV, CHLORAMINES: These chemicals may be used as alternative disinfectants.

PAC: A disadvantage of using PAC is it is very abrasive and requires careful maintenance of equipment. One precaution that should be taken in storing PAC is that bags of carbon should not be stored near bags of HTH. Removes tastes and odors by adsorption only. Powered activated carbon frequently used for taste and odor control because PAC is non-specific and removes a broad range of compounds. Jar tests and threshold odor number testing determines the application rate for powdered activated carbon. Powdered activated carbon, or PAC, commonly used for in a water treatment plant for taste and odor control. Powdered activated carbon may be used with some success in removing the precursors of THMs

PACKING: Material, usually of woven fiber, placed in rings around the shaft of a pump and used to control the leakage from the stuffing box.

PARAMECIUM: Paramecia are a group of unicellular ciliate protozoa formerly known as slipper animalcules from their slipper shape. They are commonly studied as a representative of the ciliate group. Simple cilia cover the body which allows the cell to move with a synchronous motion (like a caterpilla). There is also a deep oral groove containing inconspicuous compound oral cilia (as found in other peniculids) that is used to draw food inside. They generally feed upon bacteria and other small cells. Osmoregulation is carried out by a pair of contractile vacuoles, which actively expel water absorbed by osmosis from their surroundings. Paramecia are widespread in freshwater environments, and are especially common in scums. Paramecia are attracted by acidic conditions. Certain single-celled eukaryotes, such as Paramecium, are examples for exceptions to the universality of the genetic code (translation systems where a few codons differ from the standard ones).

PATHOGENS: Disease-causing pathogens; waterborne pathogens A pathogen may contaminate water and cause waterborne disease.

Pb: The chemical symbol of Lead.

PCE: Perchloroethylene. Known also as perc or tetrachloroethylene, perchloroethylene is a clear, colorless liquid with a distinctive, somewhat ether-like odor. It is non-flammable, having no measurable flashpoint or flammable limits in air. Effective over a wide range of applications, perchloroethylene is supported by closed loop transfer systems, stabilizers and employee exposure monitoring.

PEAK DEMAND: The maximum momentary load placed on a water treatment plant, pumping station or distribution system.

PERCOLATION: The process of fluid penetrating or slowly flowing through soil, rock, or formation. See also infiltration.

PERCUSSION RIG: See Cable Tool.

PERFORATED SCREEN: Well screen that has openings mechanically cut into it.

PERFORMANCE CURVE: A graphical representation of a pumps efficiency relative to gpm and feet of head.

PEPTIDOGLYCAN: A polymer found in the cell walls of prokaryotes that consists of polysaccharide and peptide chains in a strong molecular network. Also called *mucopeptide*, *murein*.

PERMEATE: The term for water which has passed through the membrane of a reverse osmosis unit.

PERMEABILITY: A measure of a soil or formation's capacity to transmit water, typically in volume per time units. Equivalent to Darcy's hydraulic conductivity.

PERMEABLE: Soil or formation of which water can pass through.

pH: A unit of measure which describes the degree of acidity or alkalinity of a solution. The pH scale runs from 0 to 14 with 7 being the mid-point or neutral. A pH of less than 7 is on the acid side of the scale with 0 as the point of greatest acid activity. A pH of more than 7 is on the basic (alkaline) side of the scale with 14 as the point of greatest basic activity. The term pH is derived from "p", the mathematical symbol of the negative logarithm, and "H", the chemical symbol of Hydrogen. The definition of pH is the negative logarithm of the Hydrogen ion activity. $pH=-log[H^{+}]$.

pH OF SATURATION: The ideal pH for perfect water balance in relation to a particular total alkalinity level and a particular calcium hardness level, at a particular temperature. The pH where the Langelier Index equals zero.

PHENOLPHTHALEIN/TOTAL ALKALINITY: The relationship between the alkalinity constituent's bicarbonate, carbonate, and hydroxide can be based on the P and T alkalinity measurement.

PHENOL RED: Chemical reagent used for testing pH in the range of 6.8 - 8.4.

PHOSPHATE, NITRATE AND ORGANIC NITROGEN: Nutrients in a domestic water supply reservoir may cause water quality problems if they occur in moderate or large quantities.

PHYSISORPTION: (Or physical adsorption) Is adsorption in which the forces involved are intermolecular forces (van der Waals forces) of the same kind as those responsible for the imperfection of real gases and the condensation of vapors, and which do not involve a significant change in the electronic orbital patterns of the species involved. The term van der Waals adsorption is synonymous with physical adsorption, but its use is not recommended.

PICOCURIE: A unit of radioactivity. "Pico" is a metric prefix that means one one-millionth of one one-millionth. A picocurie is one one-millionth of one one-millionth of a Curie. A Curie is that quantity of any radioactive substance that undergoes 37 billion nuclear disintegrations per second. Thus a picocurie is that quantity of any radioactive substance that undergoes 0.037 nuclear disintegrations per second.

pCi/L: Picocuries per liter A curie is the amount of radiation released by a set amount of a certain compound. A picocurie is one quadrillionth of a curie.

PICOCURIE: A unit of radioactivity. "Pico" is a metric prefix that means one one-millionth of one one-millionth. A picocurie is one one-millionth of one one-millionth of a Curie. A Curie is that quantity of any radioactive substance that undergoes 37 billion nuclear disintegrations per second. Thus a picocurie is that quantity of any radioactive substance that undergoes 0.037 nuclear disintegrations per second.

PIEZOMETRIC SURFACE: See potentiometric surface.

PILOT BIT: A bit used on auger rigs to cut a pilot hole ahead of the cutter head when drilling into more resistant formations.

PIPELINE APPURTENANCE: Pressure reducers, bends, valves, regulators (which are a type of valve), etc.

PITLESS ADAPTER: A fitting installed on a section of column pipe and well casing permitting piping from the well to be installed below grade. (Often requires a special permit for construction)

PLANKTON: The aggregate of passively floating, drifting, or somewhat motile organisms occurring in a body of water, primarily comprising microscopic algae and protozoa.

PLATFORM: The portion of the drilling rig where a driller and crew operate the drill rig.

PLUG: A removable cap installed behind the pilot and cutter bits on hollow stem auger flighting.

PLUNGER: See Surge-block.

POINT OF ENTRY: POE.

POLLUTION: To make something unclean or impure. See Contaminated.

POLYPHOSPHATES: Chemicals that may be added to remove low levels of iron and manganese.

POLYMER: A type of chemical when combined with other types of coagulants aid in binding small suspended particles to larger particles to help in the settling and filtering processes.

PORE SPACE: The interstitial space between sediments and fractures that is capable of storing and transmitting water.

POROSITY: A factor representing a rock, soil, or formations percentage of open space available for the percolation and storage of groundwater.

POST-CHLORINE: Where the water is chlorinated to make sure it holds a residual in the distribution system.

POTABLE: Good water which is safe for drinking or cooking purposes. Non-Potable: A liquid or water that is not approved for drinking.

POTENTIAL ENERGY: The energy that a body has by virtue of its position or state enabling it to do work.

POTENTIOMETRIC SURFACE: An imaginary surface representing the height a column of water will reach at any location within a confined aquifer. The measured surface of a confined aquifer related to the aquifer's pressure head.

PPM: Abbreviation for parts per million.

PRE-CHLORINE: Where the raw water is dosed with a large concentration of chlorine.

PRE-CHLORINATION: The addition of chlorine before the filtration process will help:

- > Control algae and slime growth
- > Control mud ball formation
- > Improve coagulation
- > Precipate iron

The addition of chlorine to the water prior to any other plant treatment processes.

PERKINESIS: The aggregation resulting from random thermal motion of fluid molecules.

PRESSURE: Pressure is defined as force per unit area. It is usually more convenient to use pressure rather than force to describe the influences upon fluid behavior. The standard unit for pressure is the Pascal, which is a Newton per square meter. For an object sitting on a surface, the force pressing on the surface is the weight of the object, but in different orientations it might have a different area in contact with the surface and therefore exert a different pressure.

PRESSURE HEAD: The height of a column of water capable of being maintained by pressure. See also Total Head, Total Dynamic Head.

PRESSURE MEASUREMENT: Bourdon tube, Bellows gauge and Diaphragm are commonly used to measure pressure in waterworks systems. A Bellows-type sensor reacts to a change in pressure.

PREVENTION: To take action; stop something before it happens.

PROTON, NEUTRON AND ELECTRON: Are the 3 fundamental particles of an atom.

PRODUCING ZONE: A specific productive interval.

PRODUCTIVE INTERVAL: The portion or portions of an aquifer in which significant water production is obtained within the well.

PROTIST: Any of a group of eukaryotic organisms belonging to the kingdom Protista according to some widely used modern taxonomic systems. The protists include a variety of unicellular, coenocytic, colonial, and multicellular organisms, such as the protozoans, slime molds, brown algae, and red algae. A unicellular protoctist in taxonomic systems in which the protoctists are considered to form a kingdom.

PROTOCTIST: Any of various unicellular eukaryotic organisms and their multicellular, coenocytic, or colonial descendants that belong to the kingdom Protoctista according to some taxonomic systems. The protoctists include the protozoans, slime molds, various algae, and other groups. In many new classification systems, all protoctists are considered to be protists.

PROTOZOA: Microscopic animals that occur as single cells. Some protozoa can cause disease in humans. Protozoa form cysts, which are specialized cells like eggs that are very resistant to chlorine. Cysts can survive the disinfection process, then "hatch" into normal cells that can cause disease. Protozoa must be removed from drinking water by filtration, because they cannot be effectively killed by chlorine.

PUBLIC NOTIFICATION: An advisory that EPA requires a water system to distribute to affected consumers when the system has violated MCLs or other regulations. The notice advises consumers what precautions, if any, they should take to protect their health.

PUBLIC WATER SYSTEM (PWS): Any water system which provides water to at least 25 people for at least 60 days annually. There are more than 170,000 PWSs providing water from wells, rivers and other sources to about 250 million Americans. The others drink water from private wells. There are differing standards for PWSs of different sizes and types.

PUMP SURGING: A process of well development whereby water is pumped nearly to the surface and then is allowed to fall back into the well. The process creates a backwashing action that cleans the well and nearby formation.

PUMPING LIFT: The height to which water must be pumped or lifted to, feet of head.

PWS: 3 types of public water systems. Community water system, non-transient non-community water system, transient non-community water system.

RADIOCHEMICALS: (Or radioactive chemicals) Occur in natural waters. Naturally radioactive ores are particularly common in the Southwestern United States, and some streams and wells can have dangerously high levels of radioactivity. Total alpha and beta radioactivity and isotopes of radium and strontium are the major tests performed for radiochemicals. The federal drinking water standard for gross alpha radioactivity is set at 5 picocuries per liter.

RADIUS OF INFLUENCE: The distance away from a pumping well that water levels are affected by a wells cone of depression.

RAWHIDING: See Pump Surging.

RAW TURBIDITY: The turbidity of the water coming to the treatment plant from the raw water source.

RAW WATER: Water that has not been treated in any way; it is generally considered to be unsafe to drink.

REAGENT: A substance used in a chemical reaction to measure, detect, examine, or produce other substances.

REAM: The process of enlarging a borehole.

REAMER BIT: A special bit designed to ream existing boreholes.

RECHARGE: The infiltration component of the hydrologic cycle. Often used in the context of referring to: The infiltration of water back into an aquifer, resulting in the restoration of lost storage and water levels which had been decreased due to pumping and/or natural discharges from the aquifer.

RECIRCULATING SYSTEM: A system of constructed or surface mud pits that settle out cuttings from drilling fluid to be circulated back down the borehole.

RECORDER, FLOW: A flow recorder that measures flow is most likely to be located anywhere in the plant where a flow must be measured and in a central location.

RED WATER AND SLIME: Iron bacteria are undesirable in a water distribution system because of red water and slime complaints.

REDOX POTENTIAL: Reduction potential (also known as redox potential, oxidation / reduction potential or ORP) is the tendency of a chemical species to acquire electrons and thereby be reduced. Each species has its own intrinsic reduction potential; the more positive the potential, the greater the species' affinity for electrons and tendency to be reduced. In aqueous solutions, the reduction potential is the tendency of the solution to either gain or lose electrons when it is subject to change by introduction of a new species. A solution with a higher (more positive) reduction potential than the new species will have a tendency to gain electrons from the new species (i.e. to be reduced by oxidizing the new species) and a solution with a lower (more negative) reduction potential will have a tendency to lose electrons to the new species (i.e. to be oxidized by reducing the new species).

RELAY LOGIC: The name of a popular method of automatically controlling a pump, valve, chemical feeder, and other devices

RESERVOIR: An impoundment used to store water.

RESIDUAL DISINFECTION PROTECTION: A required level of disinfectant that remains in treated water to ensure disinfection protection and prevent recontamination throughout the distribution system (i.e., pipes).

REVERSE MUD ROTARY: A non-conventional drilling method in which drilling fluid is injected through the borehole annulus downward through the bit and circulated back to the surface through the drill string.

REVERSE OSMOSIS: Forces water through membranes that contain holes so small that even salts cannot pass through. Reverse osmosis removes microorganisms, organic chemicals, and inorganic chemicals, producing very pure water. For some people, drinking highly purified water exclusively can upset the natural balance of salts in the body. Reverse osmosis units require regular maintenance or they can become a health hazard.

RIBBED STABILIZER: A stabilizer or drill collar that has cutting ribs attached to its side. Ribs are normally installed in vertical or spiral arrangements.

ROLLER BIT: A rotary drill bit having rotating cutting heads.

ROTAMETER: The name of transparent tube with a tapered bore containing a ball is often used to measure the rate of flow of a gas or liquid.

ROTARY RIG: A conventional rotary drill rig. Can be either an air or mud rotary rig.

ROTIFER: Rotifers get their name (derived from Greek and meaning "wheel-bearer"; they have also been called wheel animalcules) from the corona, which is composed of several ciliated tufts around the mouth that in motion resemble a wheel. These create a current that sweeps food into the mouth, where it is chewed up by a characteristic pharynx (called the mastax) containing a tiny, calcified, jaw-like structure called the trophi. The cilia also pull the animal, when unattached, through the water. Most free-living forms have pairs of posterior toes to anchor themselves while feeding. Rotifers have bilateral symmetry and a variety of different shapes. There is a well-developed cuticle which may be thick and rigid, giving the animal a box-like shape, or flexible, giving the animal a worm-like shape; such rotifers are respectively called loricate and illoricate.

RUNOFF: Surface water sources such as a river or lake are primarily the result of natural processes of runoff.

SAFE YIELD: A possible consequence when the "safe yield" of a well is exceeded and water continues to be pumped from a well, is land subsidence around the well will occur. Safe yield refers to a long-term balance between the water that is naturally and artificially recharged to an aquifer and the groundwater that is pumped out. When more water is removed than is recharged, the aquifer is described as being out of safe yield. When the water level in the aquifer then drops, we are said to be mining groundwater.

SALTS ARE ABSENT: Is a strange characteristic that is unique to water vapor in the atmosphere.

SAMPLE: The water that is analyzed for the presence of EPA-regulated drinking water contaminants. Depending on the regulation, EPA requires water systems and states to take samples from source water, from water leaving the treatment facility, or from the taps of selected consumers.

SAMPLING LOCATION: A location where soil or cuttings samples may be readily and accurately collected.

SAND, ANTHRACITE AND GARNET: Mixed media filters are composed of these three materials.

SANITARY SURVEY: Persons trained in public health engineering and the epidemiology of waterborne diseases should conduct the sanitary survey. The importance of a detailed sanitary survey of a new water source cannot be overemphasized. An on-site review of the water sources, facilities, equipment, operation, and maintenance of a public water systems for the purpose of evaluating the adequacy of the facilities for producing and distributing safe drinking water. The purpose of a non-regulatory sanitary survey is to identify possible biological and chemical pollutants which might affect a water supply.

SANITIZER: A disinfectant or chemical which disinfects (kills bacteria), kills algae and oxidizes organic matter.

SATURATION INDEX: See Langelier's Index.

SATURATOR: A device which produces a fluoride solution for the fluoride process. Crystal-grade types of sodium fluoride should be fed with a saturator. Overfeeding must be prevented to protect public health when using a fluoridation system.

SATURATED ZONE: Where an unconfined aguifer becomes saturated beneath the capillary fringe.

SCADA: A remote method of monitoring pumps and equipment. 130 degrees F is the maximum temperature that transmitting equipment is able to with stand. If the level controller may be set with too close a tolerance 45 could be the cause of a control system that is frequently turning a pump on and off.

SCALE: Crust of calcium carbonate, the result of unbalanced water. Hard insoluble minerals deposited (usually calcium bicarbonate) which forms on pool and spa surfaces and clog filters, heaters and pumps. Scale is caused by high calcium hardness and/or high pH. The regular use of stain prevention chemicals can prevent scale.

SCHMUTZDECKE: German, "grime or filth cover", sometimes spelt schmutzedecke) is a complex biological layer formed on the surface of a slow sand filter. The schmutzdecke is the layer that provides the effective purification in potable water treatment, the underlying sand providing the support medium for this biological treatment layer. The composition of any particular schmutzdecke varies, but will typically consist of a gelatinous biofilm matrix of bacteria, fungi, protozoa, rotifera and a range of aquatic insect larvae. As a schmutzdecke ages, more algae tend to develop, and larger aquatic organisms may be present including some bryozoa, snails and annelid worms.

SCROLL AND BASKET: The two basic types of centrifuges used in water treatment.

SEAL: For wells: to abandon a well by filling up the well with approved seal material including cementing with grout from a required depth to the land surface.

SECONDARY DRINKING WATER STANDARDS: Non-enforceable federal guidelines regarding cosmetic effects (such as tooth or skin discoloration) or aesthetic effects (such as taste, odor, or color) of drinking water.

SECTIONAL MAP: The name of a map that provides detailed drawings of the distribution system's zones. Sometimes we call these quarter-sections.

SEDIMENTATION BASIN: Where the thickest and greatest concentration of sludge will be found. Twice a year sedimentation tanks should be drained and cleaned if the sludge buildup interferes with the treatment process.

SEDIMENTATION: The process of suspended solid particles settling out (going to the bottom of the vessel) in water.

SEDIMENT: Grains of soil, sand, gravel, or rock deposited by and generated by water movement.

SENSOR: A float and cable system are commonly found instruments that may be used as a sensor to control the level of liquid in a tank or basin.

SESSILE: Botany. attached by the base, or without any distinct projecting support, as a leaf issuing directly from the stem. Zoology. permanently attached; not freely moving.

SETTLED SOLIDS: Solids that have been removed from the raw water by the coagulation and settling processes.

SHAKER: A device used in mud containment systems that vibrates various sized screens as drilling fluid passes through it, thereby separating cuttings from drilling fluid and providing a good sampling location.

SHOCK: Also known as superchlorination or break point chlorination. Ridding a water of organic waste through oxidization by the addition of significant quantities of a halogen.

SHORT-CIRCUITING: Short Circuiting is a condition that occurs in tanks or basins when some of the water travels faster than the rest of the flowing water. This is usually undesirable since it may result in shorter contact, reaction or settling times in comparison with the presumed detention times.

SHROUD: A baffle or piece of pipe installed over a pump to force water to pass the pumps motor.

SIEVE ANALYSIS: The process of sifting soil or formation samples through a series of screens to determine percentages of particle sizes.

SINGLE PHASE POWER: The type of power used for lighting systems, small motors, appliances, portable power tools and in homes.

SINUSOID: A curve described by the equation $y = a \sin x$, the ordinate being proportional to the sine of the abscissa.

SINUSOIDAL: Mathematics. Of or pertaining to a sinusoid. Having a magnitude that varies as the sine of an independent variable: a sinusoidal current.

SLUDGE BASINS: After cleaning sludge basins and before returning the tanks into service the tanks should be inspected, repaired if necessary, and disinfected.

SLUDGE REDUCTION: Organic polymers are used to reduce the quantity of sludge. If a plant produces a large volume of sludge, the sludge could be dewatered, thickened, or conditioned to decrease the volume of sludge. Turbidity of source water, dosage, and type of coagulant used are the most important factors which determine the amount of sludge produced in a treatment of water.

SLURRY: A mixture of crushed rock and water.

SMALL WATER SYSTEM: 3,300 or fewer persons.

SOC: Synthetic organic chemical. A common way for a synthetic organic chemical such as dioxin to be introduced to a surface water supply is from an industrial discharge, agricultural drainage, or a spill.

SODA ASH: Chemical used to raise pH and total alkalinity (sodium carbonate)

SODIUM BICARBONATE: Commonly used to increase alkalinity of water and stabilize pH.

SODIUM BISULFATE: Chemical used to lower pH and total alkalinity (dry acid).

SODIUM HYDROXIDE: Also known as caustic soda, a by-product chlorine generation and often used to raise pH.

SOIL MOISTURE: A relative consideration of the degree to which a soil is saturated.

SOFTENING WATER: When the water has a low alkalinity it is advantageous to use soda ash instead of caustic soda for softening water.

SOFTENING: The process that removes the ions which cause hardness in water.

SOLAR DRYING BEDS OR LAGOONS: Are shallow, small-volume storage pond where sludge is concentrated and stored for an extended periods.

SOLAR DRYING BEDS, CENTRIFUGES AND FILTER PRESSES: Are procedures used in the dewatering of sludge.

SOLID, LIQUID AND VAPOR: 3 forms of matter.

SOLDER: A fusible alloy used to join metallic parts.

SOLID STEM (AUGER): An auger that is constructed of solid stem drill flights.

SPADNS: The lab reagent called SPADNS solution is used in performing the Fluoride test.

SPECIFIC CAPACITY (Sc): A measure of a well's pumping performance in gallons per minute per foot of drawdown.

SPIDER: A bearing or flange used in vertical turbine pumps to stabilize the drive shaft or shaft tube and seal column joints.

SPIRAL FLANGE: A continuous blade that wraps spirally around auger flighting.

SPIRIT OF HARTSHORN: A colorless, pungent, suffocating, aqueous solution of about 28.5 percent ammonia gas: used chiefly as a detergent, for removing stains and extracting certain vegetable coloring agents, and in the manufacture of ammonium salts.

SPLIT SPOON: A sampling device that is driven into the earth and operated by a wire line for the retrieval of soil or formation samples.

SPLIT FLOW CONTROL SYSTEM: This type of control system is to control the flow to each filter influent which is divided by a weir.

SPRAY BOTTLE OF AMMONIA: An operator should use ammonia to test for a chlorine leak around a valve or pipe. You will see white smoke if there is a leak.

SPRING PRESSURE: Is what maintains contact between the two surfaces of a mechanical seal.

STABILE: Reference to formation, soil, or sediments of sufficient strength to remain in place under its own weight and existing pressures.

STABILIZE: Actions taken to enhance borehole stability or vertical rotational when drilling.

STABILIZER: The portion of a drill string used to stabilize rotation.

STANDPIPE: A water tank that is taller than it is wide. Should not be found in low point.

STERILIZED GLASSWARE: The only type of glassware that should be used in testing for coliform bacteria.

STORAGE TANKS: Three types of water usage that determine the volume of a storage tank are fire suppression storage, equalization storage, and emergency storage. Equalization storage is the volume of water needed to supply the system for periods when demand exceeds supply. Generally, a water storage tank's interior coating (paint) protects the interior about 3-5 years.

S.T.P.: Standard temperature and pressure standard temperature and pressure the temperature of 0°C and pressure of 1 atmosphere, usually taken as the conditions when stating properties of gases.

STRATIFIED: Layered.

STUFFING BOX: That portion of the pump that houses the packing or mechanical seal.

SUB: A small section of drill pipe used to connect larger sections.

SUBMERSIBLE PUMP: A turbine pump that has the motor attached directly to it and therefore is operated while submerged.

SULFATE: Will readily dissolve in water to form an anion. Sulfate is a substance that occurs naturally in drinking water. Health concerns regarding sulfate in drinking water have been raised because of reports that diarrhea may be associated with the ingestion of water containing high levels of sulfate. Of particular concern are groups within the general population that may be at greater risk from the laxative effects of sulfate when they experience an abrupt change from drinking water with low sulfate concentrations to drinking water with high sulfate concentrations.

Sulfate in drinking water currently has a secondary maximum contaminant level (SMCL) of 250 milligrams per liter (mg/L), based on aesthetic effects (i.e., taste and odor). This regulation is not a federally enforceable standard, but is provided as a guideline for States and public water systems. EPA estimates that about 3% of the public drinking water systems in the country may have sulfate levels of 250 mg/L or greater. The Safe Drinking Water Act (SDWA), as amended in 1996, directs the U.S. Environmental Protection Agency (EPA) and the Centers for Disease Control and Prevention (CDC) to jointly conduct a study to establish a reliable dose-response relationship for the adverse human health effects from exposure to sulfate in drinking water, including the health effects that may be experienced by sensitive subpopulations (infants and travelers). SDWA specifies that the study be based on the best available peer-reviewed science and supporting studies, conducted in consultation with interested States, and completed in February 1999.

SULFIDE: The term sulfide refers to several types of chemical compounds containing sulfur in its lowest oxidation number of -2. Formally, "sulfide" is the dianion, S_2 , which exists in strongly alkaline aqueous solutions formed from H_2S or alkali metal salts such as Li_2S , Na_2S , and K_2S . Sulfide is exceptionally basic and, with a pKa > 14, it does not exist in appreciable concentrations even in highly alkaline water, being undetectable at pH < ~15 (8 M NaOH). Instead, sulfide combines with electrons in hydrogen to form HS, which is variously called hydrogen sulfide ion, hydrosulfide ion, sulfhydryl ion, or bisulfide ion. At still lower pH's (<7), HS- converts to H_2S , hydrogen sulfide. Thus, the exact sulfur species obtained upon dissolving sulfide salts depends on the pH of the final solution. Aqueous solutions of transition metals cations react with sulfide sources (H_2S , NaSH, Na_2S) to precipitate solid sulfides. Such inorganic sulfides typically have very low solubility in water and many are related to minerals. One famous example is the bright yellow species CdS or "cadmium yellow". The black tarnish formed on sterling silver is Ag_2S . Such species are sometimes referred to as salts. In fact, the bonding in transition metal sulfides is highly covalent, which gives rise to their semiconductor properties, which in turn is related to the practical applications of many sulfide materials.

SUPERNATANT: The liquid layer which forms above the sludge in a settling basin.

SURFACE SEAL: The upper portion of a wells construction where surface contaminants are adequately prevented from entering the well, normally consisting of surface casing and neat cement grout.

SURFACE WATER SOURCES: Surface water sources such as a river or lake are primarily the result of Runoff.

SURFACE WATER: Water that is open to the atmosphere and subject to surface runoff; generally, lakes, streams, rivers.

SURFACTANT: Surfactants reduce the surface tension of water by adsorbing at the liquid-gas interface. They also reduce the interfacial tension between oil and water by adsorbing at the liquid-liquid interface. Many surfactants can also assemble in the bulk solution into aggregates. Examples of such aggregates are vesicles and micelles. The concentration at which surfactants begin to form micelles is known as the critical micelle concentration or CMC. When micelles form in water, their tails form a core that can encapsulate an oil droplet, and their (ionic/polar) heads form an outer shell that maintains favorable contact with water. When surfactants assemble in oil, the aggregate is referred to as a reverse micelle. In a reverse micelle, the heads are in the core and the tails maintain favorable contact with oil. Surfactants are also often classified into four primary groups; anionic, cationic, non-ionic, and zwitterionic (dual charge).

SUSCEPTIBILITY WAIVER: A waiver that is granted based upon the results of a vulnerability assessment.

SURGE-BLOCK: A disc shaped device that fits tightly into a well and is moved up and down to agitate the water column in order to develop a well.

SURGING: The process of purging a well rapidly for well development.

SWAB: See Surge-block.

SWING ARM: A large moveable arm on a bucket auger rig that pulls the bucket auger out away from the drilling rig for dumping.

SYNCHRONY: Simultaneous occurrence; synchronism.

TABLE DRIVE: A drilling rig that uses a rotating table within the platform to turn a kelly driven drill string.

TABLE: The back portion of a drill rig where the drill pipe is inserted (or driven if a table drive), adjacent to or within the driller's platform.

TAPPING VALVE: The name of the valve that is specifically designed for connecting a new water main to an existing main that is under pressure.

TARGET DEPTH: The proposed construction depth of a well prior to drilling.

TASTE AND ODORS: The primary purpose to use potassium permanganate in water treatment is to control taste and odors. Anaerobic water undesirable for drinking water purposes because of color and odor problems are more likely to occur under these conditions. Taste and odor problems in the water may happen if sludge and other debris are allowed to accumulate in a water treatment plant.

TCE, *trichloroethylene*: A solvent and degreaser used for many purposes; for example dry cleaning, it is a common groundwater contaminant. Trichloroethylene is a colorless liquid which is used as a solvent for cleaning metal parts. Drinking or breathing high levels of trichloroethylene may cause nervous system effects, liver and lung damage, abnormal heartbeat, coma, and possibly death. Trichloroethylene has been found in at least 852 of the 1,430 National Priorities List sites identified by the Environmental Protection Agency (EPA).

TDS-TOTAL DISSOLVED SOLIDS: An expression for the combined content of all inorganic and organic substances contained in a liquid which are present in a molecular, ionized or micro-granular (colloidal sol) suspended form. Generally, the operational definition is that the solids (often abbreviated TDS) must be small enough to survive filtration through a sieve size of two micrometers. Total dissolved solids are normally only discussed for freshwater systems, since salinity comprises some of the ions constituting the definition of TDS. The principal application of TDS is in the study of water quality for streams, rivers and lakes, although TDS is generally considered not as a primary pollutant (e.g. it is not deemed to be associated with health effects), but it is rather used as an indication of aesthetic characteristics of drinking water and as an aggregate indicator of presence of a broad array of chemical contaminants. Ion exchange is an effective treatment process used to remove iron and manganese in a water supply. This process is ideal as long as the water does not contain a large amount of TDS. When determining the total dissolved solids, a sample should be filtered before being poured into an evaporating dish and dried. Demineralization may be necessary in a treatment process if the water has a very high value Total Dissolved Solids.

TELEMETERING: The use of a transmission line with remote signaling to monitor a pumping station or motors. Can be used to accomplish accurate and reliable remote monitoring and control over a long distribution system.

TEMPERATURE SAMPLE: This test should be performed immediately in the field, this is a grab sample.

TELESCOPING KELLY: A kelly with successively smaller sized pipe within itself that drops out as a borehole is drilled. This permits that drilling may proceed without adding drill pipe. Normally found on bucket auger rigs.

TELESCOPING: The successive decrease in borehole size with depth.

THE RATE DECREASES: In general, when the temperature decreases, the chemical reaction rate decreases also.

THICKENING, CONDITIONING AND DEWATERING: Common processes that are utilized to reduce the volume of sludge.

TIME FOR TURBIDITY BREAKTHROUGH AND MAXIMUM HEADLOSS: Are the two factors which determine whether or not a change in filter media size should be made.

TITRATION: A method of testing by adding a reagent of known strength to a water sample until a specific color change indicates the completion of the reaction.

TITRIMETRIC: Chemistry. Using or obtained by titration. Titrimetrically, adverb.

TOP DRIVE: A rotary type drill head that moves freely up and down the rigs mast while driving the drill string.

TOROID: A surface generated by the revolution of any closed plane curve or contour about an axis lying in its plane. The solid enclosed by such a surface.

TOTAL ALKALINITY: A measure of the acid-neutralizing capacity of water which indicates its buffering ability, i.e. measure of its resistance to a change in pH. Generally, the higher the total alkalinity, the greater the resistance to pH change.

TOTAL COLIFORM: Total coliform, fecal coliform, and E. coli are all indicators of drinking water quality. The total coliform group is a large collection of different kinds of bacteria. Fecal coliforms are types of total coliform that mostly exist in feces. E. coli is a sub-group of fecal coliform. When a water sample is sent to a lab, it is tested for total coliform. If total coliform is present, the sample will also be tested for either fecal coliform or E. coli, depending on the lab testing method.

TOTAL DISSOLVED SOLIDS (TDS): The accumulated total of all solids that might be dissolved in water.

TOTAL DYNAMIC HEAD: The pressure (psi) or equivalent feet of water, required for a pump to lift water to its point of storage overcoming elevation head, friction loss, line pressure, drawdown and pumping lift.

TRANSIENT, NON-COMMUNITY WATER SYSTEM: TNCWS A water system which provides water in a place such as a gas station or campground where people do not remain for long periods of time. These systems do not have to test or treat their water for contaminants which pose long-term health risks because fewer than 25 people drink the water over a long period. They still must test their water for microbes and several chemicals. A Transient Non-community Water System: Is not required to sample for VOC's.

TREATED WATER: Disinfected and/or filtered water served to water system customers. It must meet or surpass all drinking water standards to be considered safe to drink.

TRIHALOMETHANES (THM): Four separate compounds including chloroform, dichlorobromomethane, dibromochloromethane, and bromoform. The most common class of disinfection by-products created when chemical disinfectants react with organic matter in water during the disinfection process. See Disinfectant Byproducts.

TRICONE BIT: A roller bit with three independent rolling bits with teeth or buttons that intermesh for efficient rock crushing and cutting.

TUBE SETTLERS: This modification of the conventional process contains many metal tubes that are placed in the sedimentation basin, or clarifier. These tubes are approximately 1 inch deep and 36 inches long, splithexagonal shape and installed at an angle of 60 degrees or less. These tubes provide for a very large surface area upon which particles may settle as the water flows upward. The slope of the tubes facilitates gravity settling of the solids to the bottom of the basin, where they can be collected and removed. The large surface settling area also means that adequate clarification can be obtained with detention times of 15 minutes or less. As with conventional treatment, this sedimentation step is followed by filtration through mixed media.

TUBERCLES: The creation of this condition is of the most concern regarding corrosive water effects on a water system. Tubercles are formed due to joining dissimilar metals, causing electro-chemical reactions. Like iron to copper pipe. We have all seen these little rust mounds inside cast iron pipe.

TURBIDIMETER: Monitoring the filter effluent turbidity on a continuous basis with an in-line instrument is a recommended practice. Turbidimeter is best suited to perform this measurement.

TURBIDITY: A measure of the cloudiness of water caused by suspended particles.

TURBINE PUMP: A pump that utilizes rotating impellers on a shaft that generate centrifugal force for pumping water.

UNCONFINED AQUIFER: An aquifer that exists under atmospheric pressure and is not confined.

UNCONSOLIDATED: Sediment that is not cemented or is loosely arranged.

UNDER-REAM: The process of reaming, from within the borehole, a section of an existing smaller borehole area.

UNSATURATED ZONE: That portion of the subsurface, including the capillary fringe that is not saturated but may contain water in both vapor and liquid form. See also Vadose Zone.

UNSTABLE: Sediment or other material that cannot exit without rapidly decomposing or collapsing in on itself. (ex. unconsolidated sediment)

U.S. ENVIRONMENTAL PROTECTION AGENCY: In the United States, this agency responsible for setting drinking water standards and for ensuring their enforcement. This agency sets federal regulations which all state and local agencies must enforce.

UNDER PRESSURE IN STEEL CONTAINERS: After chlorine gas is manufactured, it is primarily transported in steel containers.

UNIT FILTER RUN VOLUME (UFRV): One of the most popular ways to compare filter runs. This technique is the best way to compare water treatment filter runs.

VADOSE ZONE: A portion of the subsurface above the water table that is not saturated but contains water in both vapor and liquid form. The portion of the subsurface where water percolates through to the saturated zone. See also Unsaturated Zone.

VANE: That portion of an impeller that throws the water toward the volute.

VARIABLE DISPLACEMENT PUMP: A pump that will produce different volumes of water dependent on the pressure head against it.

VELOCITY HEAD: The vertical distance a liquid must fall to acquire the velocity with which it flows through the piping system. For a given quantity of flow, the velocity head will vary indirectly as the pipe diameter varies.

VENTURI: If water flows through a pipeline at a high velocity, the pressure in the pipeline is reduced. Velocities can be increased to a point that a partial vacuum is created.

VERTICAL TURBINE: A type of variable displacement pump in which the motor or drive head is mounted on the wellhead and rotates a drive shaft connected to the pump impellers.

VIRION: A complete viral particle, consisting of RNA or DNA surrounded by a protein shell and constituting the infective form of a virus.

VIRUSES: Very small disease-causing microorganisms that are too small to be seen even with microscopes. Viruses cannot multiply or produce disease outside of a living cell.

VITRIFICATION: Vitrification is a process of converting a material into a glass-like amorphous solid that is free from any crystalline structure, either by the quick removal or addition of heat, or by mixing with an additive. Solidification of a vitreous solid occurs at the glass transition temperature (which is lower than melting temperature, Tm, due to supercooling). When the starting material is solid, vitrification usually involves heating the substances to very high temperatures. Many ceramics are produced in such a manner. Vitrification may also occur naturally when lightning strikes sand, where the extreme and immediate heat can create hollow, branching rootlike structures of glass, called fulgurite. When applied to whiteware ceramics, vitreous means the material has an extremely low permeability to liquids, often but not always water, when determined by a specified test regime. The microstructure of whiteware ceramics frequently contain both amorphous and crystalline phases.

VOC WAIVER: The longest term VOC waiver that a public water system using groundwater could receive is 9 years.

VOLATILE ORGANIC COMPOUNDS: (VOCs) Solvents used as degreasers or cleaning agents. Improper disposal of VOCs can lead to contamination of natural waters. VOCs tend to evaporate very easily. This characteristic gives VOCs very distinct chemical odors like gasoline, kerosene, lighter fluid, or dry cleaning fluid. Some VOCs are suspected cancer-causing agents. Volatile organic compounds (VOCs) are organic chemical compounds that have high enough vapor pressures under normal conditions to significantly vaporize and enter the atmosphere. A wide range of carbon-based molecules, such as aldehydes, ketones, and other light hydrocarbons are VOCs. The term often is used in a legal or regulatory context and in such cases the precise definition is a matter of law. These definitions can be contradictory and may contain "loopholes"; e.g. exceptions, exemptions, and exclusions. The United States Environmental Protection Agency defines a VOC as any organic compound that participates in a photoreaction; others believe this definition is very broad and vague as organics that are not volatile in the sense that they vaporize under normal conditions can be considered volatile by this EPA definition. The term may refer both to well characterized organic compounds and to mixtures of variable composition.

VOID: An opening, gap, or space within rock or sedimentary formations formed at the time of origin or deposition.

VOLTAGE: Voltage (sometimes also called electric or electrical tension) is the difference of electrical potential between two points of an electrical or electronic circuit, expressed in volts. It measures the potential energy of an electric field to cause an electric current in an electrical conductor. Depending on the difference of electrical potential it is called extra low voltage, low voltage, high voltage or extra high voltage. Specifically Voltage is equal to energy per unit charge.

VOLUTE: The spiral-shaped casing surrounding a pump impeller that collects the liquid discharge by the impeller.

VORTEX: The helical swirling of water moving towards a pump.

VIRUSES: Are very small disease-causing microorganisms that are too small to be seen even with microscopes. Viruses cannot multiply or produce disease outside of a living cell.

VOLATILE ORGANIC COMPOUNDS: (**VOCs**) Solvents used as degreasers or cleaning agents. Improper disposal of VOCs can lead to contamination of natural waters. VOCs tend to evaporate very easily. This characteristic gives VOCs very distinct chemical odors like gasoline, kerosene, lighter fluid, or dry cleaning fluid. Some VOCs are suspected cancer-causing agents.

VULNERABILITY ASSESSMENT: An evaluation of drinking water source quality and its vulnerability to contamination by pathogens and toxic chemicals.

WAIVERS: Monitoring waivers for nitrate and nitrite are prohibited.

WASHOUT: The rapid erosion of aquifer material from the borehole walls while a well is being drilled, which often results in a loss of circulation.

WATER COURSE: An opening within a cable tool drill string that allows fluid to flow in and out of the drill string thereby minimizing friction loss to the slurry.

WATER HAMMER: A surge in a pipeline resulting from the rapid increase or decrease in water flow. Water hammer exerts tremendous force on a system and can be highly destructive.

WATER PURVEYOR: The individuals or organization responsible to help provide, supply, and furnish quality water to a community.

WATER QUALITY: The 4 broad categories of water quality are: Physical, chemical, biological, radiological. Pathogens are disease causing organisms such as bacteria and viruses. A positive bacteriological sample indicates the presence of bacteriological contamination. Source water monitoring for lead and copper be performed when a public water system exceeds an action level for lead of copper.

WATER QUALITY CRITERIA: Comprised of both numeric and narrative criteria. Numeric criteria are scientifically derived ambient concentrations developed by EPA or States for various pollutants of concern to protect human health and aquatic life. Narrative criteria are statements that describe the desired water quality goal.

WATER QUALITY STANDARD: A statute or regulation that consists of the beneficial designated use or uses of a waterbody, the numeric and narrative water quality criteria that are necessary to protect the use or uses of that particular waterbody, and an antidegradation statement.

WATER TABLE: The measured water level surface of an unconfined aguifer.

WATER VAPOR: A characteristic that is unique to water vapor in the atmosphere is that water does not contain any salts.

WATERBORNE DISEASE: A disease, caused by a virus, bacterium, protozoan, or other microorganism, capable of being transmitted by water (e.g., typhoid fever, cholera, amoebic dysentery, gastroenteritis).

WATERSHED: An area that drains all of its water to a particular water course or body of water. The land area from which water drains into a stream, river, or reservoir.

WEATHERED: The existence of rock or formation in a chemically or physically broken down or decomposed state. Weathered material is in an unstable state.

WELL ABANDONMENT: The process of sealing a well by approved means. The filling of a well to the surface with cement grout.

WELL HEAD: The upper portion of the well that is constructed on the land surface, including the well manifold. Also a term used to refer to the area near the well that is subject to wellhead protection.

WELL HEAD PROTECTION: Programs designed to maintain the quality of groundwater used as public drinking water sources, by managing the land uses around the well field. A government program that encourages the limitation and elimination of activities, near and within a wells recharge area, which present a potential risk to the wells water supply.

WELL MANIFOLD: The piping, valves, and metering equipment used to connect the well to the distribution system, installed on the wellhead.

WELL SCREEN: A section of well casing that contains openings which permit water to enter the well but limit or prevent sediment from entering the well while pumping.

WELL SEAL: The watertight cap or seal installed within and between the well casing and pumping equipment. The metal or plastic plug or seal, which the pumping column rests on the top of casing.

WHOLE EFFLUENT TOXICITY: The total toxic effect of an effluent measured directly with a toxicity test.

YIELD: The volume of water measured in flow rates that are produced from the well.

ZONE OF AERATION: See Saturated Zone or Vadose Zone.

ZONE OF SATURATION: See Saturated Zone.

REFERENCES

Benenson, Abram S., editor. 1990. *Control of Communicable Diseases in Man.* 15th ed. Baltimore: Victor Graphics, Inc.

Bick, H. 1972. Ciliated protozoa. An illustrated guide to the species used as biological indicators in freshwater biology. World Health Organization, Geneva. 198 pp.

Born, Stephen M., Douglas A. Yanggen, and Alexander Zaporozec. *A Guide to Groundwater Quality Planning and Management for Local Governments*. Wisconsin Geological and Natural History Survey, Madison, WI, 1987.

Cairns, J., and J.A. Ruthven. 1972. A test of the cosmopolitan distribution of fresh-water protozoans. Hydrobiologia 39:405-427.

Cairns, J., and W.H. Yongue. 1977. Factors affecting the number of species of freshwater protozoan communities. Pages 257-303 in J. Cairns, ed. Aquatic microbial communities. Garland, New York.

Cairns, J., G.R. Lanza, and B.C. Parker. 1972. Pollution related structural and functional changes in aquatic communities with emphasis on freshwater algae and protozoa. Proceedings of the National Academy of Sciences 124:79-127.

Concern, Inc. *Groundwater: A Community Action Guide*. Washington, D.C., 1989. Cross, Brad L and Jack Schulze. *City of Hurst (A Public Water Supply Protection Strategy)*. Texas Water Commission, Austin, TX, 1989.

Curds, C.R. 1992. Protozoa and the water industry. Cambridge University Press, MA. 122 pp. Curtis, Christopher and Teri Anderson. *A Guidebook for Organizing a Community Collection Event: Household Hazardous Waste*. Pioneer Valley Planning Commission and Western Massachusetts Coalition for Safe Waste Management, West Springfield, MA, 1984. Curtis, Christopher, Christopher Walsh, and Michael Przybyla. *The Road Salt Management Handbook: Introducing a Reliable Strategy to Safeguard People & Water Resources*. Pioneer

Valley Planning Commission, West Springfield, MA, 1986. Fenchel, T. 1974. Intrinsic rate increase: the relationship with body size. Oecologia 14:317-326. Fenchel, T., T. Perry, and A. Thane. 1977. Anaerobiosis and symbiosis with bacteria in free-living ciliates. Journal of Protozoology 24:154-163.

Foissner, W. 1987. Soil protozoa: fundamental problems, ecological significance, adaptations in ciliates and testaceans, bioindicators, and guide to the literature. Progress in Protistology 2:69-212.

Foissner, W. 1988. Taxonomic and nomenclatural revision of Stádecek's list of ciliates (Protozoa: Ciliophora) as indicators of water quality. Hydrobiologia 166:1-64.

Foster, Laurence, M.D. 1985. "Waterborne Disease - It's Our Job to Prevent It". PIPELINE newsletter, Oregon Health Division, Drinking Water Program, Portland, Oregon 1(4): 1-3. Foster, Laurence, M.D. 1990. "Waterborne Disease," Methods for the Investigation and Prevention of Waterborne Disease Outbreaks. Ed. Gunther F. Craun. Cincinnati: U.S. Environmental Protection Agency.

Giese, A.C. 1973. Blepharisma. Stanford University Press, CA. 366 pp.

Gordon, Wendy. *A Citizen's Handbook on Groundwater Protection*. Natural Resources Defense Council, New York, NY 1984.

Harrison, Ellen Z. and Mary Ann Dickinson. *Protecting Connecticut's Groundwater: A Guide to Groundwater Protection for Local Officials*. Connecticut Department of Environmental Protection. Hartford. CT, 1984.

Hrezo, Margaret and Pat Nickinson. *Protecting Virginia's Groundwater A Handbook for Local Government Officials*. Virginia Polytechnic Institute and State University, Blacksburg, VA, 1986.

Jaffe, Martin and Frank Dinovo. *Local Groundwater Protection*. American Planning Association, Chicago, IL, 1987.

Kreier, J.P., and J.R. Baker. 1987. Parasitic protozoa. Allen and Unwin, Boston, MA. 241 pp. Laybourn, J., and B.J. Finlay. 1976. Respiratory energy losses related to cell weight and temperature in ciliated protozoa. Oecologia 44:165-174.

Lee, C.C., and T. Fenchel. 1972. Studies on ciliates associated with sea ice from Antarctica. II. Temperature responses and tolerances in ciliates from Antarctica, temperate and tropical habitats. Archive für Protistenkunde 114:237-244.

Loomis, George and Yael Calhoon. "Natural Resource Facts: Maintaining Your Septic System." University of Rhode Island, Providence, RI, 1988.

Macozzi, Maureen. *Groundwater- Protecting Wisconsin's Buried Treasure*. Wisconsin Department of Natural Resources, Madison, WI, 1989.

Maine Association of Conservation Commissions. *Ground Water... Maine's Hidden Resource*. Hallowell, ME, 1985.

Massachusetts Audubon Society "Local Authority for Groundwater Protection." Groundwater Information Flyer #4. Lincoln, MA, 1984.

Massachusetts Audubon Society. "Groundwater and Contamination: From the Watershed into the Well." Groundwater Information Flyer # 2. Lincoln, MA, 1984.

Massachusetts Audubon Society. "Mapping Aquifers and Recharge Areas." Groundwater Information Flyer # 3. Lincoln, MA, 1984.

Massachusetts Audubon Society. "Road Salt and Groundwater Protection." Groundwater Information Flyer # 9. Lincoln, MA, 1987.

McCann, Alyson and Thomas P Husband. "Natural Resources Facts: Household Hazardous Waste." University of Rhode Island, Providence, RI; 1988.

Miller, David W. *Groundwater Contamination: A Special Report*. Geraghty & Miller, Inc., Syosset, NY 1982.

Montagnes, D.J.S., D.H. Lynn, J.C. Roff, and W.D. Taylor. 1988. The annual cycle of heterotrophic planktonic ciliates in the waters surrounding the Isles of Shoals, Gulf of Maine: an assessment of their trophic role. Marine Biology 99:21-30.

Mullikin, Elizabeth B. *An Ounce of Prevention: A Ground Water Protection Handbook for Local Officials*. Vermont Departments of Water Resources and Environmental Engineering, Health, and Agriculture, Montpelier, VT, 1984.

Murphy, Jim. "Groundwater and Your Town: What Your Town Can Do Right Now." Connecticut Department of Environmental Protection, Hartford, CT.

National Research Council. *Ground Water Quality Protection: State and Local Strategies.* National Academy Press, Washington, D.C., 1986.

New England Interstate Water Pollution Control Commission. "Groundwater: Out of Sight Not Out of Danger." Boston, MA, 1989.

Niederlehner, B.R., K.W. Pontasch, J.R. Pratt, and J. Cairns. 1990. Field evaluation of predictions of environmental effects from multispecies microcosm toxicity test. Archives of Environmental Contamination and Toxicology 19:62-71.

Noake, Kimberly D. Guide to *Contamination Sources for Wellhead Protection*. Draft. Massachusetts Department of Environmental Quality Engineering, Boston, MA, 1988. Office of Drinking Water. *A Local Planning Process for Groundwater Protection*. U.S. EPA, Washington, D.C., 1989.

Office of Ground-Water Protection. *Guidelines for Delineation of Wellhead Protection Areas*. U.S. EPA, Washington, D.C., 1987.

Office of Ground-Water Protection. Survey of State Ground Water Quality Protection Legislation Enacted From 1985 Through 1987. U.S. EPA, Washington, D.C., 1988.

Office of Ground-Water Protection. *Wellhead Protection Programs. - Tools for Local Governments.* U.S. EPA, Washington, D.C., 1989.

Office of Ground-Water Protection. *Wellhead Protection: A Decision-Makers' Guide.* U.S. EPA, Washington, D.C., 1987

Office of Pesticides and Toxic Substances. *Citizen's Guide to Pesticides.* U.S. EPA, Washington, D.C., 1989.

Office of Underground Storage Tanks. *Musts for USGS. - A Summary of the New Regulations for Underground Storage Tank Systems.* U.S. EPA, Washington, D.C., 1988.

Ohio Environmental Protection Agency. Ground Water. Columbus, OH.

Redlich, Susan. Summary of Municipal Actions for Groundwater Protection in the New England/New York Region. New England Interstate Water Pollution Control Commission, Boston, MA, 1988.

Southern Arizona Water Resources Association. "Water Warnings: Our Drinking Water.... It Takes Everyone to Keep It Clean." Tucson, AZ.

Sponenberg, Torsten D. and Jacob H. Kahn. *A Groundwater Primer for Virginians*. Virginia Polytechnic Institute and State University, Blacksburg, VA, 1984.


Taylor, W., and R. Sanders. 1991. Protozoa. Pages 37-93 in J.H. Thorp and A.P. Covich, eds. Ecology and classification of North American freshwater invertebrates. Academic Press, New York.

Texas Water Commission. "On Dangerous Ground: The Problem of Abandoned Wells in Texas." Austin, TX, 1989.

Texas Water Commission. *The Underground Subject: An Introduction to Ground Water Issues in Texas*. Austin, TX, 1989.

U.S. Environmental Protection Agency. *Seminar Publication: Protection of Public Water Supplies from Ground-Water Contaminants.* Center for Environmental Research Information, Cincinnati, OH, 1985.

Waller, Roger M. *Ground Water and the Rural Homeowner*. U.S. Geological Survey, Reston, VA, 1988.



We welcome you to complete the assignment in Microsoft Word. You can easily find the assignment at www.abctlc.com. Once complete, just simply fax or e-mail the answer key along with the registration page to us and allow two weeks for grading. Once we grade it, we will mail a certificate of completion to you. Call us if you need any help. If you need your certificate back within 48 hours, you may be asked to pay a rush service fee.

You can download the assignment in Microsoft Word from TLC's website under the Assignment Page. www.abctlc.com You will have 90 days in order to successfully complete this assignment with a score of 70% or better. If you need any assistance, please contact TLC's Student Services. Once you are finished, please mail, e-mail or fax your answer sheet along with your registration form to us. If you want your paper graded within 48 hours, please put RUSH on the registration form, and pay extra \$50 dollars for this service. Thank you!