




SOFTSTARTER HANDBOOK



About Motors

Modern electrical motors are available in many different forms, such as single phase motors, three-phase motors, brake motors, synchronous motors, asynchronous motors, special customised motors, two speed motors, three speed motors, and so on, all with their own performance and characteristics.


For each type of motor there are many different mounting arrangements, for example foot mounting, flange mounting or combined foot and flange mounting. The cooling method can also differ very much, from the simplest motor with free self-circulation of air to a more complex motor with totally enclosed air-water cooling with an interchangeable cassette type of cooler.

To ensure a long lifetime for the motor it is important to keep it with the correct degree of protection when under heavy-duty conditions in a server environment. The two letters IP (International Protection) state the degree of protection followed by two digits, the first of which indicates the degree of protection against contact and penetration of solid objects, whereas the second states the motor's degree of protection against water.

The end of the motor is defined in the IEC-standard as follows:

- The D-end is normally the drive end of the motor.
- The N-end is normally the non-drive end of the motor.

Note that in this handbook we will focus on asynchronous motors only.




Squirrel cage motors


In this book the focus has been placed on the squirrel cage motor, the most common type of motor on the market. It is relatively cheap and the maintenance cost is normally low. There are many different manufacturers represented on the market, selling at various prices. Not all motors have the same performance and quality as for example motors from ABB. High efficiency enables significant savings in energy costs during the motor's normal endurance. The low level of noise is something else that is of interest today, as is the ability to withstand severe environments.

There are also other parameters that differ.

The design of the rotor affects the starting current and torque and the variation can be really large between different manufacturers for the same power rating. When using a softstarter it is good if the motor has a high starting torque at Direct-on-line (D.O.L) start. When these motors are used together with a softstarter it is possible to reduce the starting current further when compared to motors with low starting torque. The number of poles also affects the technical data. A motor with two poles often has a lower starting torque than motors with four or more poles.



Current diagram for typical squirrel cage motor






Torque diagram for a typical squirrel cage motor


Voltage

Three-phase single speed motors can normally be connected for two different voltage levels. The three stator windings are connected in star (Y) or delta (D).

The windings can also be connected in series or parallel, Y or YY for instance. If the rating plate on a squirrel cage motor indicates voltages for both the star and delta connection, it is possible to use the motor for both 230 V, and 400 V as an example.



△ – Connection
230 V
(400 V)



Y – Connection
400 V
(690 V)

The winding is delta connected at 230 V and if the main voltage is 400 V, the Y-connection is used.

When changing the main voltage it is important to remember that for the same power rating the rated motor current will change depending on the voltage level.

The method for connecting the motor to the terminal blocks for star or delta connection is shown in the picture below.

Power factor

A motor always consumes active power, which it converts into mechanical action. Reactive power is also required for the magnetisation of the motor but it doesn't perform any action. In the diagram below the active and reactive power is represented by P and Q , which together give the power S .




Diagram indicating P , Q , S and $\cos \phi$

The ratio between the active power (kW) and the reactive power (kVA) is known as the power factor, and is often designated as the $\cos \phi$. A normal value is between 0.7 and 0.9, when running where the lower value is for small motors and the higher for large ones.

Speed

The speed of an AC motor depends on two things: the number of poles of the stator winding and the main frequency. At 50 Hz, a motor will run at a speed related to a constant of 6000 divided by the number of poles and for a 60 Hz motor the constant is 7200 rpm.

To calculate the speed of a motor, the following formula can be used:

$$n = \frac{2 \times f \times 60}{p}$$

n = speed

f = net frequency

p = number of poles

Example:

4-pole motor running at 50 Hz

$$n = \frac{2 \times 50 \times 60}{4} = 1500 \text{ rpm}$$

This speed is the synchronous speed and a squirrel-cage or a slip-ring motor can never reach it. At unloaded condition the speed will be very close to synchronous speed and will then drop when the motor is loaded.

The difference between the synchronous and asynchronous speed also named rated speed is "the slip" and it is possible to calculate this by using the following formula:

$$s = \frac{n_1 - n}{n_1}$$

s = slip (a normal value is between 1 and 3 %)

n₁ = synchronous speed

n = asynchronous speed (rated speed)

Table for synchronous speed at different number of poles and frequency:

No. of poles	50 Hz	60 Hz
2	3000	3600
4	1500	1800
6	1000	1200
8	750	900
10	600	720
12	500	600
16	375	450
20	300	360




Diagram showing synchronous speed vs.rated speed

Torque

The starting torque for a motor differs significantly depending on the size of the motor. A small motor, e.g. ≤ 30 kW, normally has a value of between 2.5 and 3 times the rated torque, and for a medium size motor, say up to 250 kW, a typical value is between 2 to 2.5 times the rated torque. Really big motors have a tendency to have a very low starting torque, sometimes even lower than the rated torque. It is not possible to start such a motor fully loaded not even at D.O.L start.


The rated torque of a motor can be calculated using the following formula:

$$M_r = \frac{9550 \times P_r}{n_r}$$

M_r = Rated torque (Nm)

P_r = Rated motor power (kW)

n_r = Rated motor speed (rpm)




Torque diagram for a typical squirrel cage motor

Slip-ring motors


In some cases when a D.O.L start is not permitted due to the high starting current, or when starting with a star-delta starter will give too low starting torque, a slip-ring motor is used. The motor is started by changing the rotor resistance and when speeding up the resistance is gradually removed until the rated speed is achieved and the motor is working at the equivalent rate of a standard squirrel-cage motor.

The advantage of a slip-ring motor is that the starting current will be lower and it is possible to adjust the starting torque up to the maximum torque.

In general, if a softstarter is going to be used for this application you also need to replace the motor.



Torque diagram for a slip-ring motor




Current diagram for a slip-ring motor

Different starting methods

The following is a short description of the most common starting methods for squirrel cage motors.

An overview of common problems when starting and stopping a motor with different starting methods, see page 14


Direct-on-line start (D.O.L)



Frequency converter



Start-delta start




Softstarter



Direct-on-line start (D.O.L)

This is by far the most common starting method available on the market. The starting equipment consists of only a main contactor and thermal or electronic overload relay. The disadvantage with this method is that it gives the highest possible starting current. A normal value is between 6 to 7 times the rated motor current but values of up to 9 or 10 times the rated current exist. Besides the starting current there also exists a current peak that can rise up to 14 times the rated current since the motor is not energised from the the first moment when starting.




D.O.L. starter with contactor and O/L relay

Single line diagram for a D.O.L.


KM 1 Main contactor
FR 1 Overload relay

The values are dependent on the design and size of the motor, but in general, a smaller motor gives higher values than a larger one.

During a direct-on-line start, the starting torque is also very high, and is higher than necessary for most applications. The torque is the same as the force, and an unnecessary high force gives unnecessary high stresses on couplings and the driven application. Naturally, there are cases where this starting method works perfectly and in some cases also the only starting method that works.



Torque/speed curve att D.O.L start



Current curve at D.O.L start


Star-delta start

This is a starting method that reduces the starting current and starting torque. The device normally consists of three contactors, an overload relay and a timer for setting the time in the star-position (starting position). The motor must be delta connected during a normal run, in order to be able to use this starting method.


The received starting current is about 30 % of the starting current during direct on line start and the starting torque is reduced to about 25 % of the torque available at a D.O.L start. This starting method only works when the application is light loaded during the start. If the motor is too heavily loaded, there will not be enough torque to

accelerate the motor up to speed before switching over to the delta position.

When starting up pumps and fans for example, the load torque is low at the beginning of the start and increases with the square of the speed. When reaching approx. 80-85 % of the motor rated speed the load torque is equal to the motor torque and the acceleration ceases. To reach the rated speed, a switch over to delta position is necessary, and this will very often result in high transmission and current peaks. In some cases the current peak can reach a value that is even bigger than for a D.O.L start. Applications with a load torque higher than 50 % of the motor rated torque will not be able to start using the start-delta starter.




Star-delta starter with contactors and O/L relay




Single line diagram for a Star-delta starter

- KM 1 Main contactor
- KM 2 Delta contactor
- KM 3 Star contactor
- FR 1 Overload relay



Torque/speed curve at Star-Delta start



Current curve at Star-Delta start

Frequency converter

The frequency converter is sometimes also called VSD (Variable Speed Drive), VFD (Variable Frequency Drive) or simply Drives, which is probably the most common name.

The drive consists primarily of two parts, one which converts AC (50 or 60 Hz) to DC and the second part which converts the DC back to AC, but now with a variable frequency of 0-250 Hz. As the speed of the motor depends on the frequency this makes it possible to control the speed of the motor by changing the output frequency from the drive and this is a big advantage if there is a need for speed regulation during a continuous run.

In many applications a drive is still only used for starting and stopping the motor, despite the

fact that there is no need for speed regulation during a normal run. Of course this will create a need for much more expensive starting equipment than necessary.


By controlling the frequency, the rated motor torque is available at a low speed and the starting current is low, between 0.5 and 1.0 times the rated motor current, maximum $1.5 \times I_n$.

Another available feature is softstop, which is very useful, for example when stopping pumps where the problem is water hammering in the pipe systems at direct stop. The softstop function is also useful when stopping conveyor belts from transporting fragile material that can be damaged when the belts stop too quickly.

It is very common to install a filter together with the drive in order to reduce the levels of emission and harmonics generated.



Frequency converter



Single line diagram for a frequency converter

Softstarter

A softstarter has different characteristics to the other starting methods. It has thyristors in the main circuit, and the motor voltage is regulated with a printed circuit board. The softstarter makes use of the fact that when the motor voltage is low during start, the starting current and starting torque is also low.

During the first part of the start the voltage to the motor is so low that it is only able to adjust the play between the gear wheels or stretching driving belts or chains etc. In other words, eliminating unnecessary jerks during the start.

Gradually, the voltage and the torque increase so that the machinery starts to accelerate.




Softstarter

One of the benefits with this starting method is the possibility to adjust the torque to the exact need, whether the application is loaded or not. In principle the full starting torque is available, but with the big difference that the starting procedure is much more forgiving to the driven machinery, with lower maintenance costs as a result.

Another feature of the softstarter is the softstop function, which is very useful when stopping pumps where the problem is water hammering in the pipe system at direct stop as for star-delta starter and direct-on-line starter.

The softstop function can also be used when stopping conveyor belts to prevent material from damage when the belts stop too quickly.



Single line diagram for a softstarter

Common problems when starting and stopping motors with different starting methods

Type of problem	Type of starting method			
	Direct-on-line	Star-delta start	Drives	Softstarter
Slipping belts and heavy wear on bearings	Yes	Medium	No	No
High inrush current	Yes	No	No	No
Heavy wear and tear on gear boxes	Yes	Yes (loaded start)	No	No
Damaged goods / products during stop	Yes	Yes	No	No
Water hammering in pipe system when stopping	Yes	Yes	Best solution	Reduced
Transmission peaks	Yes	Yes	No	No

Auto transformer start and start of a part winding motor have similar problems to the star-delta start.


Different applications

All motors are used for starting and running different applications. This chapter covers the most common ones. The different applications will also result in different load conditions for the motor. There are two factors to consider:

1. Braking load torque, a direct braking force on the motor shaft. To be able to accelerate, the motor has to be stronger than the load. The accelerating torque is the difference between the available motor torque and the load torque.

$$\text{Accelerating torque} = \text{Available motor torque} - \text{load torque}$$

2. Involved moment of inertia or flywheel mass will also affect the start. The bigger inertia the longer starting time for the same motor.



Centrifugal fan



Centrifugal pump



Compressor



Conveyor belt

Centrifugal fan




For some applications the motor is started with reduced load torque, i.e. unloaded start. Big centrifugal fans are often started with a closed damper and this will make the start easier (shorter) but since the moment of inertia is still present the starting time might be quite long anyway.


Direct-on-line start

Centrifugal fans are very often driven by one or more drive belts. During a D.O.L start these belts have a tendency to slip. The reason is that these types of fans always have a more or less high moment of inertia (big flywheel). So even if the fan is started unloaded, the flywheel is still there.

The belts slip depending on whether the starting torque from the motor is too high during the start sequence and the belts are not able to transfer these forces. This typical problem gives high maintenance costs but also production losses when you need to stop production to change belts and bearings.



Torque/speed curve at D.O.L start




Current curve at D.O.L start



Star-delta starter (Y-D)

The star-delta starter gives lower starting torque but depending on the fact that the load torque increases with the square of the speed, the motor torque will not be high enough in the star position to accelerate the fan to the rated speed.


When switching over to delta position it will be both a high transmission and current peak, often equal to values when making a D.O.L start or even higher, with a slipping belt as a result. It is possible to reduce the slip by stretching the belts very hard. This gives high mechanical stresses on bearings both in the motor and the fan with high maintenance costs as result.




Torque/speed curve at Star-Delta start

Softstarter


The key to solve these problems is to reduce the starting torque from the motor during start. By using an ABB softstarter the voltage is decreased to a low value at the beginning of the start, low enough to avoid slip but high enough to start up the fan. The softstarter provides the ability to adjust to fit any starting condition, both unloaded and fully loaded starts.



Torque/speed curve when using a softstarter



Current curve at Star-Delta start



Current curve when using a softstarter



Selection of a suitable softstarter

Normal start

For fans with small or medium large flywheels, select a softstarter according to the rated motor power.

The above is valid if the time for D.O.L start is less than 5 seconds.

Heavy duty start

For fans with large flywheels, select a softstarter designed for heavy duty start according to the rated motor power. It is also possible to select a softstarter for normal start, select a unit with one size bigger power rating than the motor and use an overload relay class 30.

The above is valid if the time for D.O.L start is more than 5 seconds.


Recommended basic settings:

Start ramp: 10 sec.

Stop ramp: 0 sec.

Initial voltage: 30 %

Current limit is recommended for use.



Application with a centrifugal fan


Centrifugal pump




There are a lot of different types of pumps; like piston pumps, centrifugal pumps, screw pumps etc. But the most common version is the centrifugal pump and we have selected this one to describe.

Direct-on-line start

Starting up a pump is normally not a problem for a squirrel cage motor. The problem is the wear and tear depending on pressure waves in the pipe system created when the motor starts and stops too quickly. During a D.O.L start the motor gives much too high starting torque with the result that the motor accelerates and reaches nominal speed too quickly. The reason is that the braking load torque is low for a pump during start. This starting method also gives maximum possible starting current.



Torque/speed curve at D.O.L start




Current curve at D.O.L start



Star-delta starter (Y-D)

By using a star-delta starter it is possible to reduce the starting torque. The motor torque in the star position is too weak to be able to complete the start and reach the rated speed.


The quadratic load torque will become too high for the motor when reaching approx. 80-85 % of the rated speed and the switch over to the delta position will give both high transmission and current peaks with pressure waves as a result. The current peaks can be equally high as at a D.O.L start or even higher.



Torque/speed curve at Star-Delta start

When stopping a pump

During stop it is also normal to have problems. When making a direct stop by disconnecting the main supply the motor stops too quickly. Depending on high mass flow in the pipe system the water will continue with the same speed for a short period and then come back again, backwards in the pipe system. This creates high pressure shocks on valves and gives high mechanical stresses on the pipe system.



Current curve at Star-Delta start




Softstarter


By using an ABB softstarter the voltage is reduced during the start sequence with the result that the motor torque is reduced. During the start sequence the softstarter increases the voltage so that the motor will be strong enough to accelerate the pump to the nominal speed without any torque or current peaks. A normal starting current with a softstarter when starting a fully loaded centrifugal pump is approx. 4 times rated motor current.

Also during the stop sequence the softstarter is the solution. The softstarter reduces the voltage during stop via a voltage ramp and the motor becomes weaker and weaker. Because of this the water speed slows down very smoothly without creating any pressure waves.

A special function on the softstarter is sometimes available, called "step-down voltage", which ensures an optimum setting to the actual need for any pipe system.



Torque/speed curve when using a softstarter



Current curve when using a softstarter



Selection of a suitable softstarter

Normal start

Starting a pump is a typical normal start condition.

Select a softstarter according to the rated motor power.

Heavy duty start


Not applicable for this application.

Recommended basic settings:

Start ramp: 10 sec.

Stop ramp: 20 sec.

Initial voltage: 30 %



Application with a pump.




Smaller compressors are often of piston type and the load torque increases linearly with the speed. Screw compressors are often used when there is a bigger need for air flow and this type has a load torque increasing with the square of the speed.

Drive belts are often used between motor and compressor but direct connections via some type of toothed couplings are also common. Some compressors are started with reduced load.


Direct-on-line start (D.O.L)

Compressors started direct-on-line are exposed to high mechanical stresses on the compressor itself, but also on drive belts and couplings. The result is shortened endurance. In cases where the

drive belts are used the belts very often slip during start. The high starting torque received during starting with this method is the source of the problems. The starting current is always high at D.O.L start. A normal value can be approx. 7 times rated motor current.



Torque/speed curve at D.O.L start




Current curve at D.O.L start




Star-delta starter (Y-D)

Star-delta start gives a lower starting torque and starting current but the motor is too weak during the start up to be able to accelerate the motor up to nominal speed. When switching to the delta position both current and torque peaks

will occur with high mechanical stresses as a result. Compressors are very often running at no load condition for longer periods when the pressure in the system is high. A motor running under these circumstances always has a poor power factor and low efficiency. Some times the value is so low that it must be compensated.



Torque/speed curve at Star-delta start




Current curve at Star-delta start




Softstarter

By using an ABB softstarter it is possible to limit the starting torque to a level suitable for all different applications. The result is less stress on couplings, bearings and no slipping belts during start. The maintenance cost will be reduced to a minimum. When using a softstarter the starting current received is approx. 3 to 4 times the rated motor current.



Torque/speed curve when using a softstarter



Current curve when using a softstarter



Selection of a suitable softstarter

Normal start

For compressors with D.O.L starting time less than 5 seconds, select a softstarter according to the rated motor power.

Heavy duty start

For compressors with D.O.L starting time more than 5 seconds, select a softstarter designed for heavy duty start according to the rated motor power.

It is also possible to select a softstarter for normal start, select a unit with one size bigger power rating than the motor and use an overload relay class 30.

Recommended basic settings:

Start ramp: 10 sec.


Stop ramp: 0 sec.

Initial voltage: 30 % (piston compressor)
40 % (screw compressor)



Application with a compressor

Conveyor belt



Conveyor belts can have a lot of different looks and directions of use. It is a typical constant torque load with low to high braking torque depending on how heavy it is loaded.


Direct-on-line start (D.O.L)

Conveyor belts often need a starting torque very near or just above the rated torque of the motor. A direct-on-line start with a normal squirrel cage motor gives approx. 1.5 to 2.5 times rated torque of the motor depending on motor size, type etc. When making a direct-on-line start there is a very high risk of slipping between the belt and


the driving role depending on this high starting torque.

Gearboxes and couplings are also exposed to high mechanical stresses. This result is considerable wear and tear and often high maintenance costs. Sometimes fluid couplings are used to reduce the transferred torque. This method is expensive and requires a lot of maintenance.

Low braking torque




Torque/speed curve at D.O.L start




Current curve at D.O.L start


High braking torque



Torque/speed curve at D.O.L start




Current curve at D.O.L start



Star-delta start


It is not possible to use this starting method when the load torque is close to the rated motor torque during start (see figure below, High braking torque).

Low braking torque




Torque/speed curve at Star-delta start


High braking torque



Torque/speed curve at Star-delta start



Current curve at Star-delta start




Current curve at Star-delta start

Softstarter

By using an ABB softstarter the starting torque can be reduced to a minimum value still able to start up the conveyor belt. The setting possibility of the softstarter makes it possible to adjust the torque to exactly the level that is necessary for the start. The result is the least possible stress on


gearboxes and couplings and no slipping belts during start. This will reduce the maintenance cost to a minimum. When using a softstarter you will receive approx. 3 to 4 times rated motor current during start.

Low braking torque




Torque/speed curve when using a softstarter


High braking torque



Torque/speed curve when using a softstarter



Current curve when using a softstarter



Current curve when using a softstarter

Selection of a suitable softstarter

Normal start

A start of short and light loaded conveyor belt is a typical normal start.

For conveyors with D.O.L starting time less than 5 seconds, select a softstarter according to the rated motor power.

Heavy duty start

Conveyor belts can in some cases be very long and if the belt is fully loaded during start the starting time can be very long. For such applications select a softstarter designed for heavy duty start. It is also possible to select a softstarter for normal start if the softstarter is chosen one size larger than the rated motor power and use an overload relay class 30.

Recommended basic settings:

Start ramp: 10 sec.

Stop ramp: 0 sec.

(If fragile material use 10 seconds)

Initial voltage: 40 %



Application with a conveyor belt

How to select a softstarter for different applications

It is normally possible to select a softstarter according to the rated motor power. In some cases it is necessary to select a larger softstarter than the rated motor power depending on the starting conditions (heavy duty start, many starts/h etc.) The starting capacity of a softstarter is very much depending on the thyristor capacity and the heat sink.

The table below can be used as a guide to select a softstarter if you need a quick answer and you want to be sure that the size is large enough to suit the application. This selection will not give the most optimized solution.

If an optimised solution is required, the software selection program "ProSoft" for selection of softstarters can be used, available on www.abb.com/lowvoltage.

Quick guide

Normal start

Typical applications

- »Bow thruster
- »Compressor
- »Elevator
- »Centrifugal pump
- »Conveyor belt (short)
- »Escalator

Selection

Select the softstarter according to the rated motor power.

For units with built-in overload, select trip class 10.

Heavy duty start

Typical applications

- »Centrifugal fan
- »Crusher
- »Mixer
- »Conveyor belt (long)
- »Mill
- »Stirrer

Selection

For softstarters designed for normal start, select one size larger than the rated motor power.

For softstarters designed for heavy duty start, select according to the rated motor power.

For units with built-in overload, select trip class 30.

If more than 6 starts /h

Select one size larger than the selection above.

Description of the softstarters


- Design, settings and signals

A softstarter in general is built up with a few main components such as a printed circuit board (PCB), heat sink, thyristors, fans and housing (plastic or metal). The controlling circuits can be of digital type, analogue type or a combination of these. The output signal relays can be of a type with fixed function or as a free programmable type where the user can decide upon the output function.

The softstarter is sometimes equipped with a built-in electronic overload relay (EOL) replacing the conventional bi-metal relay which is normally used. A built in EOL has much better accuracy than a conventional relay, since the values are calculated electronically and this is especially useful when on intermittent duty.

The need for communication between different devices in a plant and from the devices to a control board is increasing all the time. Many of today's softstarters are equipped with a port for such communication, which normally consists of a few fibre optic cables instead of former solutions, which often required hundreds of thousands of wires. Many different communication protocols exist today and some of them are more common than others, for example Modbus, Profibus, DeviceNet, Interbus-S, LON Works and so on.

Description of different components:




Printed circuit board is used to control the firing of the thyristors based on the current and voltage references, and also for the calculation of different values, for example the power factor, active power, etc. It can also be used for storing historical data, the event log, indicating trends and much more.

Heat sink is used to get rid of the heat in the softstarter generated by the current during the start and the continuous run. The capacity of the heat sink very much reflects the starting capacity and the operational current of the softstarter.

Fans are used to increase the cooling capacity of the heat sink. One, two or several fans can be used depending on size and design. Some smaller softstarters don't have fans at all and the number of starts may be limited.

Housing can be made of plastic material, metal or a combination of these, and its function is to protect the inside components from mechanical and electrical damage. It is also used to protect the components from dust and dirt. For total outside protection from dust and dirt a separate enclosure is often required since the degree of protection (IP class) of the unit itself is too low.

Thyristors are semi-conducting components connected in an anti-parallel fashion and placed in two or three phases of the main circuit. They regulate (by increasing or decreasing) the level of voltage during start and the stop ramp, as described in the picture below. During a continuous run the thyristors are conducting fully.



Start: The thyristors let part of the voltage through at the beginning and then increase it, according to the set ramp time for the start.

Stop: The thyristors are fully conducting and when soft stopping, they decrease the voltage according to the set ramp time for stop.

☐ Off : Thyristor is non-conducting

☒ On : Thyristor is conducting

Common settings

This section includes a short description of some common setting parameters available on most of the softstarters. Other settings may be available depending on the type of softstarter and manufacturer. The setting can be done either by adjusting potentiometers, changing dip switches, using a key pad, a computer or similar.

Start ramp is the time from where the softstarter start its ramp (initial voltage) until full voltage is reached. The ramp time should not be too long, as this will only result in unnecessary heating of the motor and a risk of the overload relay to trip. If the motor is unloaded the start time for the motor will probably become shorter than the set ramp time, and if the motor is heavily loaded, the start time will probably become longer.

Stop ramp is used when a soft stopping of the motor is required, for example a pump or a conveyor belt. The stop ramp is the time from full voltage until stop voltage (initial voltage) is reached. If the ramp time is set to zero the stop will be like a direct stop.

Initial voltage. Sometimes named pedestrian voltage or torque, this is the point from where the softstarter starts or stops its ramps. The torque of the motor will drop with the square of the voltage and if the voltage is set too low, for example 20 %, the starting torque will become $0.2^2 = 0.04 = 4\%$ only, and the motor will not start from the very beginning. Therefore it is very important to find a level that is just high enough to make the motor take off directly to avoid unnecessary heating.






Diagram showing start ramp, stop ramp and initial voltage

Current limit can be used in applications where a limited starting current is required, or at a heavy-duty start when it is difficult to achieve a perfect start with the setting of the initial voltage and the start ramp only. When the current limit is reached, the softstarter will temporarily stop increasing the voltage until the current drops below the set limit, and then continues ramping up to full voltage.

Note that this feature is not available on all softstarters.




Current limit function in softstarter use

Step down voltage gives a special type of stop ramp. It is possible to adjust the voltage to drop to a level where the speed of the motor starts to reduce immediately at the stop command. For low loaded motors the speed will not reduce until a very low voltage is reached, but using the step down voltage function can eliminate this phenomenon and is especially useful for stopping pumps.

Adjustable rated motor current

current makes it possible to set the motor rated current on the softstarter for the used motor. This setting may affect other values as well, such as the trip level of the electronic overload relay, the level of the current limit function and so on.



Curve showing the step down voltage function

Different indications

The indications on a softstarter differ very much from one type to another and also between manufacturers. Some of the most common indications are described below.

On normally indicates that the power supply is connected to the softstarter and that the unit is ready to start the motor.

Top of Ramp indicates that the start ramp is completed and full voltage is reached. If a by-pass contactor is used it will be activated at this point.

Fault indication can be of many different types. One is if there is an internal fault on the softstarter itself, a fault on the feeding side (phase loss, blown fuse or similar) or on the motor side (motor not connected, phase missing etc.)

Overload indicates that the overload protection has tripped. The reason for a tripping overload can be too high motor current, too long starting time, too many starts after each other, wrong set overload, wrong trip class of overload or a combination of these.

Overtemperature indicates that the softstarter unit is over-heated, due to the number of starts exceeded, too high-rated current, too long starting time or similar.

Different voltages

Different named voltages are used for the softstarters. The name and use of these different voltages is stated in the IEC-standard as below.

Main Voltage (U_e),


which is the voltage feeding the motor and also the voltage exposed to the main circuit (thyristors) in the softstarter. 200 - 690 V are normal values.

Supply voltage (U_s),


which is the voltage feeding the electronic components inside the softstarter, for example the printed circuit board. Common values are 110 - 120 V or 220 - 240 V.

Control Voltage (U_c),

which is the voltage for controlling the start and stop command of the softstarter. Values between 24 - 480 V exist.



Main voltage and supply voltage to a softstarter



Main voltage and control voltage to a softstarter

Ambient temperature

The ambient temperature is the average surrounding temperature of the softstarter over a period of 24 hours. For most types of softstarter the temperature may not exceed 40 °C without derating the operational current for the unit.

The maximum ambient temperature during operation differs from one type of softstarter to another and must be checked individually according to the manufacturer's specification.

When using an ABB softstarter with an ambient temperature of above 40 °C, the following formula can be used to calculate the operational current:

$$I_e \text{ derated} = I_e - (\Delta T \times I_e \times 0.008)$$

$I_e \text{ derated}$ = maximum operational current after derating

I_e = rated current of the softstarter

ΔT = temperature difference

0.008 = derating factor

Example 1

Rated current: 105 A

Ambient temperature: 48 °C

Derating with 0.8 % per °C above 40 °C
(PS S 18...300)

$$\Delta T = 48 - 40 \text{ °C} = 8 \text{ °C}$$

$$\text{New current} = I_e - (\Delta T \times I_e \times 0.008) = 105 - (8 \times 105 \times 0.008) = 98,2 \text{ A}$$

Example 2

Rated current: 300 A

Ambient temperature: 46 °C

Derating with 0.8 % per °C above 40 °C
(PS S 18...300)

$$\Delta T = 46 - 40 \text{ °C} = 6 \text{ °C}$$

$$\text{New current} = I_e - (\Delta T \times I_e \times 0.008) = 300 - (6 \times 300 \times 0.008) = 285,6 \text{ A}$$

Derating when used at high altitudes

When a softstarter is used at high altitudes the rated current for the unit has to be derated, due to less cooling. For most manufacturers the catalogue values are valid up to 1000 m above sea level before derating is necessary.

In some cases a larger softstarter is required to be able to cope with the motor current when used at high altitudes.

For ABB softstarters the following formula can be used for calculating the derating:

$$\% \text{ of } I_e = 100 - \frac{x - 1000}{150}$$

x = actual altitude for the softstarter


Example:

Softstarter with rated current 300 A used at 2500 meter above sea level.

$$\begin{aligned} \% \text{ of } I_e &= 100 - \frac{2500 - 1000}{150} = \\ &= 100 - \frac{1500}{150} = 90 \end{aligned}$$

$$I_e = 300 \times 0.9 = 270 \text{ A}$$

The diagram below can also be used for defining the derating of the softstarter.



Derating of motor current at high altitudes

Start of several motors

In some applications, more than one motor will be started with one softstarter, in parallel with each other or in a sequence. This is often possible to do but some data has to be taken into consideration.

Parallel start of motors

If a softstarter is going to be used for starting several motors at the same time (parallel start), there are two important parameters to check:

1. The softstarter must be able to cope with the rated current for all motors together.
2. The softstarter must be able to cope with the starting current for all motors together until rated speed is achieved.

Note! If a by-pass contactor is used for the softstarter, only point 2 above has to be taken into consideration.


Example:

Start of two motors with $I_e = 100$ A and relative starting current $4 \times I_e$.

Starting time is 10 seconds.

Total starting current is $100 \times 4 \times 2 = 800$ A over 10 seconds.

Check the softstarter starting capacity graph to verify the selected size.



Parallel start of motors using a softstarter

Sequential start of motors

If a softstarter is going to be used for starting several motors one by one (sequential start), it is important to check that the softstarter is able to cope with the starting current for each motor during the whole starting sequence.

Example:

Start of three motors with $I_e = 100$ A and relative starting current $4 \times I_e$.

Starting time for the motors is:

Motor 1 = 5 seconds


Motor 2 = 10 seconds

Motor 3 = 8 seconds

The starting current for the motors is $100 \times 4 = 400$ A and the total starting time is $5 + 10 + 8 = 23$ seconds.

Check the softstarter starting capacity graph to verify the selected size.


Note! It is not possible to add the starting time for each motor if the rated current is different from one motor to another. A separate calculation has to be made for those applications.




Sequential start of motors using a softstarter

Different ways of connecting the softstarter

There are two different ways of connecting the softstarter - In line, which is the most common method, and Inside Delta. Note that only a few types of softstarters can actually be connected Inside Delta for example the ABB softstarter range PS S 18/30...300/515.



In line



Inside Delta


In-line connection

This is easily the most common way to connect the softstarter.

All three phases are connected in a series with the overload relay, the main contactor and other devices used just like the diagram below.

The selected devices for Inline connection must be chosen to cope with the rated motor current.

Example: 100 A motor requires a 100 A softstarter, 100 A main contactor etc.



Softstarter connected In-line with the motor


Inside Delta connection

The Inside Delta connection makes it possible to place the softstarter in the delta circuit and in that way it can easily replace an existing Y/D-starter.

When the softstarter is Inside Delta it will only be exposed to 58 % ($1/\sqrt{3}$) of the In-line current. Therefore it is possible to downsize the devices in order to achieve a more cost-effective solution.

Example: A 100 A motor requires a 58 A softstarter, a 58 A main contactor if placed in the delta circuit, etc.

A motor used for an Inside Delta connection must be able to delta-connect during a continuous run. In the USA and some other countries a special six-wire motor has to be ordered for this type of connection.




Softstarter connected Inside Delta


Location of the main contactor

When using the softstarter Inside Delta there are two options for the main contactor: in the delta circuit or outside. Both locations will stop the motor but in alternative A, the motor is still considered to be under tension.

In alternative B the main contactor must be chosen according to the rated current of the motor, while the contactor in alternative A can be chosen according to 58 % ($1/\sqrt{3}$) of the rated current.



Alternative A
Main contactor located in the delta circuit



Alternative B
Main contactor located outside the delta circuit

Basic settings for different applications

The required settings for the softstarter will differ from one application to another depending on the type of load, motor characteristics, how much the motor is loaded, etc.

For a more in depth description of each setting, please see chapter "Description of the softstarters".

Note ! All settings on next page are only proposals and may change from one application to another and therefore need to be checked individually.

Settings when using a softstarter without current limit function

Type of load	Ramp time for start (sec.)	Ramp time for stop (sec.)	Initial voltage U_{ini}
Bow thruster	10	0	30 %
Centrifugal fan	10	0	30 %
Centrifugal pump	10	20	30 %
Centrifuge	10	0	40 %
Conveyor belt	10	0 ¹⁾	40 %
Crusher	10	0	60 %
Escalator	10	0	30 %
Heat pump	10	20	30 %
Hydraulic pump	10	0	30 %
Lifting equipment	10	10	60 %
Mill	10	0	60 %
Piston compressor	10	0	30 %
Rotary converter	10	0	30 %
Scraper	10	10	40 %
Screw compressor	10	0	40 %
Screw conveyor	10	10	40 %
Stirrer, Mixer	10	0	60 %
Unloaded motor	10	0	30 %

1) If fragile material, use 10 seconds.

Settings when using a softstarter with current limit function

Type of load	Ramp time for start (sec.)	Ramp time for stop (sec.)	Initial voltage U_{ini}	Current limit ($\times I_e$)
Bow thruster	10	0	30 %	3
Centrifugal fan	10	0	30 %	4
Centrifugal pump	10	20	30 %	3.5
Centrifuge	10	0	40 %	4.5
Conveyor belt	10	0 ¹⁾	40 %	4
Crusher	10	0	60 %	5
Escalator	10	0	30 %	3.5
Heat pump	10	20	30 %	3.5
Hydraulic pump	10	0	30 %	3.5
Lifting equipment	10	10	60 %	4
Mill	10	0	60 %	5
Piston compressor	10	0	30 %	4
Rotary converter	10	0	30 %	3
Scraper	10	10	40 %	4.5
Screw compressor	10	0	40 %	4
Screw conveyor	10	10	40 %	4
Stirrer, Mixer	10	0	60 %	5
Unloaded motor	10	0	30 %	2.5

1) If fragile material, use 10 seconds.

Starting capacity and overload protection

Starting capacity for soft-starters


When starting a squirrel cage motor there will always be a starting current (I_{st}) which is higher than the rated motor current.

The starting current depends on what type of starting method is used and in some cases also the size of the motor, particular at D.O.L.-start. For a softstarter a normal value is 3-4 times the rated motor current.

Heavy duty applications normally require a starting current between 4 and 5 times the rated motor current.

The maximum permitted starting current for a softstarter depends on the starting time. The ratio between the current and time is displayed in the graph below.

A higher starting current will give a shorter possible starting time, for example a crusher application. A lower current will allow a longer starting time, for example a pump application.



Typical starting capacity graph for a softstarter

Starting capacity when using by-pass contactor


When using a softstarter with a by-pass contactor it is sometimes possible to select a softstarter with a lower rated power than the motor rated power since the softstarter will be working during start and stop only, not continuously.

The softstarter can not withstand the rated motor current and therefore a check of the starting capacity must be carried out for the selected size.

Starting capacity when using overload protection

The overload protection for the motor (thermal or electronic) will very often set the limit of the starting capacity. A class 10 relay is used for normal starts in general while a class 30 relay is used for heavy-duty starts where a longer starting time must be used.

In some applications where the overload protection is by-passed (other protection active) during a start to achieve a longer available starting time, it is particularly important to check the softstarter starting capacity since this will be the limitation.



a) Tripping curve for overload protection

b) Max starting capacity for a softstarter (This will limit the starting time / current if the overload is by-passed during start)

Number of starts/hour

The maximum number of starts/hour for a softstarter depends on several different factors such as the starting current, ambient temperature, starting time and the intermittens factor.

Intermittens factor

The intermittens factor is a figure indicating how long the softstarter has been running for (starting time and running time) compared with the total cycle time.


It is important to define the intermittens factor when talking about the number of starts/hour since the OFF time is the cooling time for the softstarter.

A high starting current and a long starting time require a longer OFF time than a low starting current and short time to maintain the same number of starts/hour.

Examples:

If a softstarter has been running for 5 minutes of a total duty cycle of 10 minutes then the intermittens factor is 50 % ON time and 50 % OFF time.

If a softstarter has been running for 45 minutes of a duty cycle of 60 minutes then the intermittens factor is 75 % ON time and 25 % OFF time.



Harmonics

Harmonics are unwanted voltages and currents existing in almost every electrical system today and are always a multiple of the rated frequency.

Typical harmonics are 3rd, 5th, 7th, 9th etc. The harmonics contribute to the unnecessary heating of motors, cables and other equipment and may shorten the lifetime of these devices if exposed for a long period of time.

It can sometimes also disturb functions on electronics and systems. The harmonic contents and the level naturally depends on the source but also on several other parameters such as the impedance in the feeding network, the motor, capacitors and other devices used in the system altogether - in other words a quite complex phenomenon.

Harmonic content and softstarters

The question of harmonic content for softstarter applications is actually in general not relevant at all. These reflections usually come from drive applications where harmonics are generated continuously and a filter is always required in public networks and very often used also in industrial networks. With our softstarters we fulfil the EMC directive concerning emission and immunity and there is no need for any particular actions regarding this matter at all.