Membrane Technology for Wastewater Treatment & Recycling

A Paradigm Shift from End-of-Pipe-Engineering to Zero Emissions

Prof. Ir. Dr. ZAINI UJANG

Ph.D., P.Eng. (M), C.Eng. (UK), C.Sci. (UK), C.W.E.M. (UK), MIEM, DNS, PPT

Institute of Environmental & Water Resource Management (IPASA)

UNIVERSITI TEKNOLOGI MALAYSIA

Email: zaini@utm.my Homepage: http://web.utm.my/ipasa



Presentation Menu

Part 1: Membrane for WW Management

Part 2: Why Low-Pressure Membrane?

Part 3: Why Immersed Membrane?

Part 4: End-of-Pipe vs Zero Emissions

Part 5: For Developing Countries?

Part 6: Case Studies

Part 7: Conclusion & Future Directions



Part 1: Membrane for Wastewater Management





Part 1:

Chronology of Membrane Applications

- Treatment of industrial wastewater
- Biomass retention in treatment of municipal wastewater
- Treatment and recycling Bellagio 2003
- Zero emissions / cleaner production



Chronology of Membrane Applications

Treatment of industrial wastewater

- Since 1970s
- Electronics, pharmaceutical, nuclear, weapons
- Using organic membranes e.g. acetate-based
- Problems: Fouling and membrane life span
- Solution:
 - Progress in membrane materials
 - Low pressure systems



Chronology of Membrane Applications **Biomass retention in MWW treatment**

- Since 1980s
- For activated sludge system
- Using organic membranes
- Problems: Fouling and membrane life span
- Solution:
 - Progress in membrane materials
 - Low pressure systems



Bellagio Team Residency, Rockefeller Foundation 2003





Meeting Sustainability Criteria for Wastewater Systems by MBR Technology

Criteria	Indicators	Improvement Needed	Good Now
Economic	Cost & Affordability	X	
Environmental	Effluent Water Quality		
	Microbes		X
	Suspended Solid		X
	Biodegradable Organics		X
	Nutrient Removal		X
	Chemical Usage	X	
	Energy	X	
	Land Usage		X
Technical	Reliability		X
	Ease of Use	X	
	Flexible & adaptable		X
	Small – scale systems		Χ
Social-Cultural	Instituitional Requirements	X	
	Acceptance	X	
	Expertise	X	

Why MBR is becoming more acceptance?

- Improvements in membrane materials
- Innovation in application methods
- Increased competition between vendors is resulting in dramatic reductions in membrane costs
- Cost effective in much wider range of applications
- Sludge production, and process control




Operational Problems Associated of Activated Sludge System

- Maintaining young sludge / biomass
- Separation between sludge-supernatant
- Foaming
- Bulking
- Large foot print for clarifiers



Foaming Phenomena in Activated Sludge Secondary Clarifier






11


Microorganisms in Activated Sludge Flocs

Adsorption and enmeshment



Microorganisms and their activities

Adsorption and enmeshment






FIGURE 7-28

Typical examples of filamentous organisms that can develop in the activated-sludge process and affect the settleability of the MLSS.

Why Use MBRs Instead of Conventional Activated Sludge?

- Retain essentially all particulate matter and associated pollutants
- Remove bacteria without chemical disinfection
- Retain slow growing organisms
- Operate at high MLSS concentrations (5 to 15 g/L)
- Reduce plant footprint
- Increased automation and simpler operation
- Increased opportunities for reliable decentralized treatment



Water Sustainability

- To deliver in a sustainable way the basic human rights of safe water supply and sanitation
- A key to holistic water management is more effective use of water resources
- The sustainability of wastewater treatment systems can be assessed in terms of economic, environmental, technical and socio-cultural indicators




Sustainability of Membrane Technology

- Scaleable
- Excellent purification ability
- Automatic and less operating problems
- Good competition industry
- Compactness, simplicity (Newater requires only 2 operators – control room, security)




Why MBR for Wastewater Treatment?





Biomass Retention using Membrane for Wastewater Treatment





Chronology of Membrane Applications

Treatment and recycling

- Since 1990s
- Electronics, pharmaceutical, nuclear, weapons, MWW
- Using organic and inorganic membranes
- Problems: TDS build-up,
- Solution:
 - Progress in membrane materials
 - Low pressure systems



Part 2: Why Low-Pressure Membrane?






Part 2:

Why Low-Pressure?

- Low fouling problems
- Low compaction on membrane surface
- Less energy consumption
- Relatively easier cleaning procedure
- Relatively cheaper
- Relatively easier maintenance
- Overall: Low OPEX




Typical permeate flow decline in membrane operation






Backwash on Low-Pressure Membrane





MBR for leachate treatment (Fitrah & Ujang, 2004)





24

Part3: Why Immersed Membrane?





25


Part 3:

Why Immersed System?

- Low pressure system
- Hybrid with biochemical processes
- Hybrid with chemical processes
- Less fouling problems
- Relatively easier cleaning procedure
- Less sludge or by-products production




Immersed Membrane






Immersed Membrane




Zenon's MF Hollow-Fibre Module






Kubota's MF Tubular (Ceramic)





Part 3a: Membrane Bioreactor





31

MBR by Mitsubishi Rayon Engineering






Mitsubishi Rayon Engineering MBR

Items	Plant Conditions	
Treatment Capacity (m³/d)	32-48	
Type of filtration	Continuous flow	
Flux (m ³ /m ² .d)	Operating flux 0.5-0.7	
	Daily average 0.4-0.6	
Intermittent operation (min)	Operating: 8-12; Stop: 2	
MLSS (g/L)	10	
Air diffusion (m ³ /m ² .s)	0.06	
Retention time (h)	5.5 - 8.0	
Recirculation ratio	3	



Effluent of MBR from Mitsubishi Pilot Plant





Financial Comparison

MBR with Conventional Activated Sludge

Items	MBR	CAS
Sludge (m³/day)	0.069	0.963
Operating cost* (\$/day)	8.37	11.25
Sludge treatment* (\$/day0	34.65	48.3
Running cost	72%	100%
Space	30%	100%

^{*} Price for electricity at US\$0.075

Source: MRC, 1997 (in Visvanathan et al., 2000)



Terminology:

MBR confusion?

- Activated sludge membrane reactor (Yamamoto et al.)
- Membrane process for biomass retention (Anderson et al., 1984)
- Membrane separation bioreactor (Yamamoto et al.)
- Integrated type membrane separation activated sludge (Takeuchi et al., 1990)
- Membrane bioreactors (most authors since 2000)




Why MBR for Industrial Wastewater Treatment?


- Small foot print
- Concentrate sludge, less excess sludge
- Reduce sludge disposal (scheduled wastes)
- Better solid-liquid separation
- Option for water recycling
- Compactness, modular, clean plant
- Simplicity in operation
- Less operating cost












Activated Sludge Membrane System




Features of Membrane Application in Biological Wastewater Treatment

✓ Solid/liquid separation



External or side stream membrane




Immersed membrane


- To remove organic matter
- To remove nitrogen compounds (nitrification & denitrification)
- To remove phosphorus compounds




First Generation MBR




Second Generation MBR




Third Generation MBR



Fourth Generation MBR




Fifth Generation MBR





Sixth Generation MBR




Improvement on energy saving & cleaning methods using strong bubble aeration & hollow fiber

Membrane System Without Clarifiers




Seventh Generation MBR






Eighth Generation MBR





Ninth Generation MBR






Problems of Membrane Bioreactor

- Overflow of mixed liquor
- Irregular condition of sludge
- Biofouling during anaerobic stage
- Low water level during influent low flowrate
- Old sludge, less productivity




Part 4: End-of-Pipe vs Zero Discharge





Zero Discharge Engineering





UNIVERSITI TEKNOLOGI MALAYSIA

Principles and Priority in Waste Management Within Zero Discharge Society

Pollution should be prevented or reduced whenever possible

PRINCIPLE 1

Source Reduction

Recycle / Reuse

Treatment

Disposal/ Discharge




Disposal or discharge to the Environment should be employed only as a last resort

PRINCIPLE 2






Typical water uses in a chemical process industries





Regeneration, Flowrate Changes & Multiple Contaminants




Wastewater minimization through reuse



56

Regeneration, Flowrate Changes & Multiple Contaminants




Wastewater minimization through regeneration & reuse

Note: ReGen=Regeneration



57

Regeneration, Flowrate Changes & Multiple Contaminants



Wastewater minimization through regeneration & reuse

Note: ReGen=Regeneration




58

Strategies for Industrial Water Reuse & Wastewater Minimization

- Reduce freshwater consumption
- Minimize effluent discharges by reducing wastewater flowrates
- Zero liquid discharges



Low-Pressure Reverse Osmosis Membrane for Electroplating Waste Minimization





Specification of LRPOM Unit

Materials Sulphonated polysulphone

Configuration Spiral wound

Thickness 150 - 175 μm (<1 μm active layer)

Surface area 0.465 m²

pH range 2-11 for continuous operation

Temperature 2-45°C

Pressure Maximum of 125 psig


Charge Negative

Characteristics Low pressure & chlorine resistance



Wastewater Minimization in Textile Plant

ORIGINAL DESIGN




Old textile plant (installed 1957), with 200 employees and using 1000 te/day freshwater, and produce around 900 te/day wastewater



Wastewater Minimization in Textile Plant


Proposed Modification 1



Using Water Pinch Analysis (WPA) to design the minimize wastewater generation and freshwater consumption



Wastewater Minimization in Textile Plant



Using Water Pinch Analysis (WPA) to design the minimize wastewater generation and freshwater consumption plus immersed membrane-PAC



Part 7 Conclusion

- Membrane technology is growing fast and very instrumental for implementation of zero discharge concept
- Zero discharge can absorb the cost by waste reuse and recycling
- Zero discharge is much cheaper than allowing pollution to take place

